

NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special i	unction p	<u>lease re</u> :	<u>fer to the special fu</u>	inction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 11/2005	A-Class	169	Drive	ESM-Electronic selector module	EWM203	•	•	•	•	•	0	•	0003
Up to 11/2005	A-Class	169	Drive	FCVT-Continuously variable automatic transmission	FCVT	•	•	•	•	•	•	0	0043 0044
Up to 11/2005	A-Class	169	Drive	ME-SFI-Motor electronics	SIM266	•	•	•	•	•	•	*	0013
Up to 11/2005	A-Class	169	Drive	CDI-Common Rail Diesel Injection	CRA	•	•	•	•	•	•		
Up to 11/2005	A-Class	169	Chassis	ES-Electrical power steering	EPS169	•	•	•	•	•	0	0	0012
Up to 11/2005	A-Class	169	Chassis	ESP-Electronic stability program	ESP169	•	•	•	•	•	•		0015
Up to 11/2005	A-Class	169	Body	CGW-Central gateway	ZGW169	•	•	•	•	0	0	0	0003
Up to 11/2005	A-Class	169	Body	EZS-Electronic ignition switch	EZS169	•	•	•	•	•	0	0	0034
Up to 11/2005	A-Class	169	Body	AB-Airbag	DCCAM	•	•	•	•	•	•		0041
Up to 11/2005	A-Class	169	Body	OCP-Overhead control panel	DBE169	•	•	•	•	•	0	•	
Up to 11/2005	A-Class	169	Body	ATA-Anti-theft alarm system	EDW169	•	•	•	•	•	0	•	
Up to 11/2005	A-Class	169	Body	SAM-Signal acquisition and actuation module	SAM169	•	•	•	•	•	0	*	
Up to 11/2005	A-Class	169	Body	AHE-Trailer recognition	AAG169	•	•	•	•	•	0	•	
Up to 11/2005	A-Class	169	Body	MSS-Special vehicle multifunction control module	MSS169	•	•	•	•	•	0	•	0003
Up to 11/2005	A-Class	169	Body	MSS-Special vehicle multifunction control module	MSS_EF169	•	•	•	•	•	0	•	
Up to 11/2005	A-Class	169	Body	HRA-FR-Front right headlamp range control	ALWRM203_230	•	•	•	•	•	0	•	
Up to 11/2005	A-Class	169	Body	HRA-FL-Front left headlamp range control	ALWRS203_230	•	•	•	•	•	0	0	
Up to 11/2005	A-Class	169	Body	System diagnosis(CAN)	SD211	•	•	•	•	•	•		
Up to 11/2005	A-Class	169	Information and communication	SCM [MRM]-Steering column module	MRM169	•	•	•	•	•	•	•	0005
Up to 11/2005	A-Class	169	Information and communication	PTS-Parktronic system	PTS169	•	•	•	•	•	•		
Up to 11/2005	A-Class	169	Information and communication	IC-Instrument cluster	KI169	•	•	•	•	•	0	•	0002
Up to 11/2005	A-Class	169	Information and communication	ASSYST-Active Service System	WIA169	•	•	0	•	•	0	0	0001
Up to 11/2005	A-Class	169	Information and communication	ASSYST PLUS-PLUS Active Service System	WR169	•	•	0	•	•	•	0	0002
Up to 11/2005	A-Class	169	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
Up to 11/2005	A-Class	169	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003



NOTES:

This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

As for special	function p		fer to the special f	function table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 11/2005	A-Class	169	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	XCDR	•	•	•	•	•	•		0003
Up to 11/2005	A-Class	169	Information and communication	AUDIO	XHU	•	•	•	•	•	•		0003
Up to 11/2005	A-Class	169	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•		
Up to 11/2005	A-Class	169	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
Up to 11/2005	A-Class	169	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
Up to 11/2005	A-Class	169	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
Up to 11/2005	A-Class	169	Information and communication	SOUND- Sound system	XSNDHB	•	•	0	•	•	•		
Up to 11/2005	A-Class	169	Information and communication	CTEL-Cellular telephone	XTELJP	•	•	•	•	•	•	0	
Up to 11/2005	A-Class	169	Seats and doors	DCM-FL-Door control module front left	TSGVL169	•	•	•	•	•	0	•	
Up to 11/2005	A-Class	169	Seats and doors	DCM-FR-Door control module front right	TSGVR169	•	•	•	•	•	0	•	
Up to 11/2005	A-Class	169	Seats and doors	DCM-RL-Door control module rear left	TSGHL169	•	•	•	•	•	0	•	
Up to 11/2005	A-Class	169	Seats and doors	DCM-RR-Door control module rear right	TSGHR169	•	•	•	•	•	0	•	
Up to 11/2005	A-Class	169	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	KLA169	•	•	•	•	•	0	•	
As of 12/2005	A-Class	169	Drive	ESM-Electronic selector module	EWM203	•	•	•	•	•	0	•	0003
As of 12/2005	A-Class	169	Drive	FCVT-Continuously variable automatic transmission	FCVT	•	•	•	•	•	•	0	0043 0044
As of 12/2005	A-Class	169	Drive	ME-SFI-Motor electronics	SIM266	•	•	•	•	•	•	*	0013
As of 12/2005	A-Class	169	Drive	CDI-Common Rail Diesel Injection	CRA	•	•	•	•	•	•		
As of 12/2005	A-Class	169	Chassis	ES-Electrical power steering	EPS169	•	•	•	•	•	0	0	0012
As of 12/2005	A-Class	169	Chassis	ESP-Electronic stability program	ESP169	•	•	•	•	•	•		0015
As of 12/2005	A-Class	169	Body	CGW-Central gateway	ZGW169	•	•	•	•	0	0	0	0003
As of 12/2005	A-Class	169	Body	EZS-Electronic ignition switch	EZS169	•	•	•	•	•	0	0	0034
As of 12/2005	A-Class	169	Body	AB-Airbag	DCCAM	•	•	•	•	•	•		0041
As of 12/2005	A-Class	169	Body	OCP-Overhead control panel	DBE169	•	•	•	•	•	0	•	
As of 12/2005	A-Class	169	Body	ATA-Anti-theft alarm system	EDW169	•	•	•	•	•	0	•	
As of 12/2005	A-Class	169	Body	SAM-Signal acquisition and actuation module	SAM169	•	•	•	•	•	0	*	
As of 12/2005	A-Class	169	Body	AHE-Trailer recognition	AAG169	•	•	•	•	•	0	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special:	function p	<u>lease rei</u>	<u>fer to the special fu</u>	inction table.									
Model year	Mode1		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory			Freeze Frame	Active Test	Special Function
As of 12/2005	A-Class	169	Body	MSS-Special vehicle multifunction control module	MSS169	•	•	•	•	•	0	•	0003
As of 12/2005	A-Class	169	Body	MSS-Special vehicle multifunction control module	MSS_EF169	•	•	•	•	•	0	•	
As of 12/2005	A-Class	169	Body	HRA-FR-Front right headlamp range control	ALWRM203_230	•	•	•	•	•	0	•	
As of 12/2005	A-Class	169	Body	HRA-FL-Front left headlamp range control	ALWRS203_230	•	•	•	•	•	0	0	
As of 12/2005	A-Class	169	Body	System diagnosis(CAN)	SD211	•	•	•	•	•	•		
As of 12/2005	A-Class	169	Information and communication	SCM [MRM]-Steering column module	MRM169	•	•	•	•	•	•	•	0005
As of 12/2005	A-Class	169	Information and communication	PTS-Parktronic system	PTS169	•	•	•	•	•	•		
As of 12/2005	A-Class	169	Information and communication	IC-Instrument cluster	KI169	•	•	•	•	•	0	•	0002
As of 12/2005	A-Class	169	Information and communication	ASSYST-Active Service System	WIA169	•	•	0	•	•	0	0	0001
As of 12/2005	A-Class	169	Information and communication	ASSYST PLUS-PLUS Active Service System	WR169	•	•	0	•	•	•	0	0002
As of 12/2005	A-Class	169	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
As of 12/2005	A-Class	169	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
As of 12/2005	A-Class	169	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	XCDR	•	•	•	•	•	•		
As of 12/2005	A-Class	169	Information and communication	AUDIO	XHU	•	•	•	•	•	•		0003
As of 12/2005	A-Class	169	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•		
As of 12/2005	A-Class	169	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
As of 12/2005	A-Class	169	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
As of 12/2005	A-Class	169	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
As of 12/2005	A-Class	169	Information and communication	SOUND- Sound system	XSNDHB	•	•	0	•	•	•		
As of 12/2005	A-Class	169	Information and communication	CTEL-Cellular telephone	XTELJP	•	•	•	•	•	•	0	
As of 12/2005	A-Class	169	Information and communication	PTS-Parktronic system	APC169	•	•	•	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special i	tunction p	lease re	fer to the special fi	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memorv	Erase Codes	Live Data		Active Test	Special Function
As of 12/2005	A-Class	169	Information and communication	COMAND or AUDIO	HU25	•	•	•	•	•	•		
As of 12/2005	A-Class	169	Information and communication	SOUND- Sound system	SOUND25	•	•	•	•	•	•		
As of 12/2005	A-Class	169	Information and communication	UCI	UCI25	•	•	•	•	•	•	0	
As of 12/2005	A-Class	169	Information and communication	DAB-Digital radio	DAB25	•	•	•	•	•	0		
As of 12/2005	A-Class	169	Information and communication	SDAR-Satellite radio(Valid for USA)	SDARS25	•	•	•	•	•	•		
As of 12/2005	A-Class	169	Information and communication	CTEL-Cellular telephone(JAPAN)	CBJ25	•	•	•	•	•	0		
As of 12/2005	A-Class	169	Seats and doors	DCM-FL-Door control module front left	TSGVL169	•	•	•	•	•	0	•	
As of 12/2005	A-Class	169	Seats and doors	DCM-FR-Door control module front right	TSGVR169	•	•	•	•	•	0	•	
As of 12/2005	A-Class	169	Seats and doors	DCM-RL-Door control module rear left	TSGHL169	•	•	•	•	•	0	•	
As of 12/2005	A-Class	169	Seats and doors	DCM-RR-Door control module rear right	TSGHR169	•	•	•	•	•	0	•	
As of 12/2005	A-Class	169	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	KLA169	•	•	•	•	•	0	•	
A11	A-Class	168	Drive	ECM-Engine control monolith	MSM1_H	•	•	0	•	•	*		
A11	A-Class	168	Drive	ECM-Engine control monolith	MSM2	•	•	•	•	•	*		
A11	A-Class	168	Drive	ACS-Automatic clutch system	AKS414	•	•	•	•	•	*		
A11	A-Class	168	Drive	FTC-Front transmission control	FAG414	•	•	•	•	•	*		
A11	A-Class	168	Drive	FTC2 -Front transmission control2	VGS2FAG	•	•	•	•	•	•		
A11	A-Class	168	Drive	GRM-Gear recognition module	EWM414	•	•	•	•	•	*	•	
A11	A-Class	168	Drive	CDI-Common Rail Diesel Injection	CR1	•	•	•	•	•	*	•	0003
A11	A-Class	168	Chassis	ESP-Electronic stability program	ESP34_H	•	•	0	•	•	*		
A11	A-Class	168	Chassis	ESP-Electronic stability program	ESP30_H	•	•	0	•	•	*		0040
A11	A-Class	168	Body	AB-Airbag	ARMIN	•	•	0	•	•	*	0	
A11	A-Class	168	Body	AB-Airbag	ZAE_H	•	•	0	•		*		
A11	A-Class	168	Body	RFL-Radio frequency locking/electric central locking	FFZ_H	•	•	0	•	•	*		
A11	A-Class	168	Body	LCP-Lower control panel	UBF2_H	•	•	0	•	•	*		
A11	A-Class	168	Body	ATA-Anti-theft alarm system	EDW2_H	•	•	0	•	•	*		
A11	A-Class	168	Body	APS-Auto pilot system	APS_H	•	•	0	•	•	*		
A11	A-Class	168	Body	HB-Heater booster	ZUH_H	•	•	0	•		*		
A11	A-Class	168	Information and communication	ICM-Instrument cluster with maintenance interval display	KIW_H	•	•	0	•	•	*	•	0002



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	<u>lease re</u>	<u>fer to the special f</u>	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
A11	A-Class	168	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
A11	A-Class	168	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	0	
A11	A-Class	168	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
A11	A-Class	168	Information and communication	PTS-Parktronic system	PTS163	•	•	•	•	•	*	•	
A11	A-Class	168	Seats and doors	DCM-FL-Door control module front left	TSG2VL_H	•	•	0	•	•	*		
A11	A-Class	168	Seats and doors	DCM-FR-Door control module front right	TSG2VR_H	•	•	0	•	•	*		
A11	A-Class	168	Seats and doors	DCM-RL-Door control module rear left	TSG2HL_H	•	•	0	•	•	*		
A11	A-Class	168	Seats and doors	DCM-RR-Door control module rear right	TSG2HR_H	•	•	0	•	•	*		
A11	A-Class	168	Air conditioning	STH-Stationary heater	STH_H	•	•	0	•	•	*		
A11	A-Class	168	Air conditioning	TAC-Automatic temperature control	KLA414	•	•	•	•	•	*	•	
Up to 11/2005	B-Class	245	Drive	ESM-Electronic selector module	EWM203	•	•	•	•	•	0	•	0003
Up to 11/2005	B-Class	245	Drive	FCVT-Continuously variable automatic transmission	FCVT	•	•	•	•	•	•	0	0043 0044
Up to 11/2005	B-Class	245	Drive	ME-SFI-Motor electronics	SIM266	•	•	•	•	•	•	*	0013
Up to 11/2005	B-Class	245	Drive	CDI-Common Rail Diesel Injection	CRA	•	•	•	•	•	•		
Up to 11/2005	B-Class	245	Chassis	ES-Electrical power steering	EPS169	•	•	•	•	•	0	0	0012
Up to 11/2005	B-Class	245	Chassis	ESP-Electronic stability program	ESP169	•	•	•	•	•	•		0015
Up to 11/2005	B-Class	245	Body	CGW-Central gateway	ZGW169	•	•	•	•	0	0	0	0003
Up to 11/2005	B-Class	245	Body	EZS-Electronic ignition switch	EZS169	•	•	•	•	•	0	0	0034
Up to 11/2005	B-Class	245	Body	AB-Airbag	DCCAM	•	•	•	•	•	•		0041
Up to 11/2005	B-Class	245	Body	OCP-Overhead control panel	DBE169	•	•	•	•	•	0	•	
Up to 11/2005	B-Class	245	Body	ATA-Anti-theft alarm system	EDW169	•	•	•	•	•	0	•	
Up to 11/2005	B-Class	245	Body	SAM-Signal acquisition and actuation module	SAM169	•	•	•	•	•	0	*	
Up to 11/2005	B-Class	245	Body	AHE-Trailer recognition	AAG169	•	•	•	•	•	0	•	
Up to 11/2005	B-Class	245	Body	MSS-Special vehicle multifunction control module	MSS169	•	•	•	•	•	0	•	0003
Up to 11/2005	B-Class	245	Body	MSS-Special vehicle multifunction control module	MSS_EF169	•	•	•	•	•	0	•	
Up to 11/2005	B-Class	245	Body	XALWA-L-Xenon headlamp, left	XALWA221_M	•	•	•	•	•	0	•	
Up to 11/2005	B-Class	245	Body	XALWA-R-Xenon headlamp, right	XALWA221_S	•	•	•	•	•	0	•	
Up to 11/2005	B-Class	245	Body	System diagnosis(CAN)	SD211	•	•	•	•	•	•		
Up to 11/2005	B-Class	245	Information and communication	SCM [MRM]-Steering column module	MRM169	•	•	•	•	•	•	•	0005



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	<u>function p</u>	<u>lease re</u> :	<u>fer to the special fu</u>	<u>inction table.</u>									
Model year	Mode1	Model Series	Control Unit	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 11/2005	B-Class	245	Information and communication	CM-Compass module	CM164	•	•	•	•	•	•	0	
Up to 11/2005	B-Class	245	Information and communication	PTS-Parktronic system	PTS169	•	•	•	•	•	•		
Up to 11/2005	B-Class	245	Information and communication	IC-Instrument cluster	KI169	•	•	•	•	•	0	•	0002
Up to 11/2005	B-Class	245	Information and communication	ASSYST-Active Service System	WIA169	•	•	0	•	•	0	0	0001
Up to 11/2005	B-Class	245	Information and communication	ASSYST PLUS-PLUS Active Service System	WR169	•	•	0	•	•	•	0	0002
Up to 11/2005	B-Class	245	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
Up to 11/2005	B-Class	245	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
Up to 11/2005	B-Class	245	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	XCDR	•	•	•	•	•	•		
Up to 11/2005	B-Class	245	Information and communication	AUDIO	XHU	•	•	•	•	•	•		0003
Up to 11/2005	B-Class	245	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•		
Up to 11/2005	B-Class	245	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
Up to 11/2005	B-Class	245	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
Up to 11/2005	B-Class	245	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
Up to 11/2005	B-Class	245	Information and communication	SOUND- Sound system	XSNDHB	•	•	0	•	•	•		
Up to 11/2005	B-Class	245	Information and communication	NAVI-Navigation system	XMCSNAV	•	•	•	•	•	•	•	
Up to 11/2005	B-Class	245	Information and communication	CTEL-Cellular telephone	XTELJP	•	•	•	•	•	•	0	
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Telematic servicesMB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	tunction p.	lease rei	<u>fer to the special f</u>	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes				Freeze Frame	Active Test	Special Function
Up to 11/2005	B-Class	245	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
Up to 11/2005	B-Class	245	Seats and doors	DCM-FL-Door control module front left	TSGVL169	•	•	•	•	•	0	•	
Up to 11/2005	B-Class	245	Seats and doors	DCM-FR-Door control module front right	TSGVR169	•	•	•	•	•	0	•	
Up to 11/2005	B-Class	245	Seats and doors	DCM-RL-Door control module rear left	TSGHL169	•	•	•	•	•	0	•	
Up to 11/2005	B-Class	245	Seats and doors	DCM-RR-Door control module rear right	TSGHR169	•	•	•	•	•	0	•	
Up to 11/2005	B-Class	245	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	KLA169	•	•	•	•	•	0	•	
As of 12/2005	B-Class	245	Drive	ESM-Electronic selector module	EWM203	•	•	•	•	•	0	•	0003
As of 12/2005	B-Class	245	Drive	FCVT-Continuously variable automatic transmission	FCVT	•	•	•	•	•	•	0	0043 0044
As of 12/2005	B-Class	245	Drive	ME-SFI-Motor electronics	SIM266	•	•	•	•	•	•	*	0013
As of 12/2005	B-Class	245	Drive	ME-SFI-Motor electronics	SIM266CNG	•	•	•	•	•	•	*	0013
As of 12/2005	B-Class	245	Drive	CDI-Common Rail Diesel Injection	CRA	•	•	•	•	•	•		
As of 12/2005	B-Class	245	Chassis	ES-Electrical power steering	EPS169	•	•	•	•	•	0	0	0012
As of 12/2005	B-Class	245	Chassis	ESP-Electronic stability program	ESP169	•	•	•	•	•	•		0015
As of 12/2005	B-Class	245	Body	CGW-Central gateway	ZGW169	•	•	•	•	0	0	0	0003
As of 12/2005	B-Class	245	Body	EZS-Electronic ignition switch	EZS169	•	•	•	•	•	0	0	0034
As of 12/2005	B-Class	245	Body	AB-Airbag	DCCAM	•	•	•	•	•	•		0041
As of 12/2005	B-Class	245	Body	OCP-Overhead control panel	DBE169	•	•	•	•	•	0	•	
As of 12/2005	B-Class	245	Body	ATA-Anti-theft alarm system	EDW169	•	•	•	•	•	0	•	
As of 12/2005	B-Class	245	Body	SAM-Signal acquisition and actuation module	SAM169	•	•	•	•	•	0	*	
As of 12/2005	B-Class	245	Body	AHE-Trailer recognition	AAG169	•	•	•	•	•	0	•	
As of 12/2005	B-Class	245	Body	MSS-Special vehicle multifunction control module	MSS169	•	•	•	•	•	0	•	0003
As of 12/2005	B-Class	245	Body	MSS-Special vehicle multifunction control module	MSS_EF169	•	•	•	•	•	0	•	
As of 12/2005	B-Class	245	Body	XALWA-L-Xenon headlamp, left	XALWA221_M	•	•	•	•	•	0	•	
As of 12/2005	B-Class	245	Body	XALWA-R-Xenon headlamp, right	XALWA221_S	•	•	•	•	•	0	•	
As of 12/2005	B-Class	245	Body	System diagnosis(CAN)	SD211	•	•	•	•	•	•		
As of 12/2005	B-Class	245	Information and communication	SCM [MRM]-Steering column module	MRM169	•	•	•	•	•	•	•	0005
As of 12/2005	B-Class	245	Information and communication	CM-Compass module	CM164	•	•	•	•	•	•	0	
As of 12/2005	B-Class	245	Information and communication	PTS-Parktronic system	PTS169	•	•	•	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease re	fer to the special f	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 12/2005	B-Class	245	Information and communication	PTS-Parktronic system	APC169	•	•	•	•	•	•		
As of 12/2005	B-Class	245	Information and communication	IC-Instrument cluster	KI169	•	•	•	•	•	0	•	0002
As of 12/2005	B-Class	245	Information and communication	ASSYST-Active Service System	WIA169	•	•	0	•	•	0	0	0001
As of 12/2005	B-Class	245	Information and communication	ASSYST PLUS-PLUS Active Service System	WR169	•	•	0	•	•	•	0	0002
As of 12/2005	B-Class	245	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
As of 12/2005	B-Class	245	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
As of 12/2005	B-Class	245	Information and communication	AGW-Audio gateway or Audio 20 with CD drive	XCDR	•	•	•	•	•	•		
As of 12/2005	B-Class	245	Information and communication	AUDIO	XHU	•	•	•	•	•	•		0003
As of 12/2005	B-Class	245	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•		
As of 12/2005	B-Class	245	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
As of 12/2005	B-Class	245	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
As of 12/2005	B-Class	245	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
As of 12/2005	B-Class	245	Information and communication	SOUND- Sound system	XSNDHB	•	•	0	•	•	•		
As of 12/2005	B-Class	245	Information and communication	NAVI-Navigation system	XMCSNAV	•	•	•	•	•	•	•	
As of 12/2005	B-Class	245	Information and communication	CTEL-Cellular telephone	XTELJP	•	•	•	•	•	•	0	
As of 12/2005	B-Class	245	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
As of 12/2005	B-Class	245	Information and communication	ů ,	XLCTECL	•	•	•	•		•	0	
As of 12/2005	B-Class	245	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
As of 12/2005	B-Class	245	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
As of 12/2005	B-Class	245	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

All C-Class 204 Drive FSCU-Fuel pump FSCM221	Special
As of 12/2005 B-Class 245 Communication COMAND or AUDIO Hi25	Special Function
As of 12/2005 B-Class 245 Information and communication B-Class 245 B-Class 246 B-Class 247 B-Covenience automatic air conditioning,/HEAT-Automatic heater C-AAC-Convenience automatic heater C-AAC-Convenience automatic heater C-AAC-Convenience automatic heater All C-Class 245 B-Class 246 B-Class 247 B-Class B-C	
As of 12/2005 B-Class 245 Communication DAB Digital radio DAB25 DA	
As of 12/2005 B-Class 245 Information and communication SDAR-Satellite radio(Valid for USA) SDARS25 As of 12/2005 B-Class 245 Information and communication As of 12/2005 B-Class 245 Seats and doors DCM-FL-Door control module front left TSGVL169 As of 12/2005 B-Class 245 Seats and doors DCM-FL-Door control module front right As of 12/2005 B-Class 245 Seats and doors DCM-FL-Door control module rear left TSGVL169 As of 12/2005 B-Class 245 Seats and doors DCM-FR-Door control module rear right TSGR169 As of 12/2005 B-Class 245 Seats and doors DCM-RR-Door control module rear right TSGR169 As of 12/2005 B-Class 245 Seats and doors DCM-RR-Door control module rear right TSGR169 As of 12/2005 B-Class 245 Seats and doors DCM-RR-Door control module rear right TSGR169 As of 12/2005 B-Class 245 Seats and doors DCM-RR-Door control module rear right TSGR169 C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/AAC-Automatic air conditioning/AAC-Automatic air conditioning/AAC-Automatic heater All C-Class 240 Drive ETC-Electronic transmission control EGS53 All C-Class 204 Drive ETC-Electronic transmission control VSNAG2 All C-Class 204 Drive ME-SFI-Motor electronics SIM271KE20 All C-Class 204 Drive PSCU-Fuel pump FSCW212 All C-Class 204 Drive ME-9.7-Motor electronics 9.7 (AMC) ME-97 All C-Class 204 Drive ME-9.7-Motor electronics 9.7 (AMC) ME-97 All C-Class 204 Drive ME-9.7-Motor electronics 9.7 (AMC) ME-97 All C-Class 204 Drive ME-9.7-Motor electronics 9.7 (AMC) ME-97 All C-Class 204 Drive ME-9.7-Motor electronics 9.7 (AMC) ME-97 All C-Class 204 Drive ME-9.7-Motor electronics 9.7 (AMC) ME-97 All C-Class 204 Drive ME-9.7-Motor electronics 9.7 (AMC) ME-97 All C-Class 204 Drive ME-9.7-Motor electronics 9.7 (AMC) ME-97 All C-Class C-Class DAL Drive ME-9.7-Motor electronics 9.7 (AMC) ME-97 All C-Class DAL DRIVE ME-97 All C-Class DAL DRIVE DAL DAL DAL DAL DAL D	
As of 12/2005 B-Class 245 Information and communication CTEL-Cellular telephone (JAPAN) B-Class	
As of 12/2005 B-Class 245 Seats and doors DCM-FR-Door control module front left TSGVL169 B-Class 245 Seats and doors DCM-FR-Door control module front right TSGVL169 B-Class 245 Seats and doors DCM-RR-Door control module rear left TSGVL169 B-Class 245 Seats and doors DCM-RR-Door control module rear left TSGHL169 B-Class 245 Seats and doors DCM-RR-Door control module rear right TSGHL169 B-Class 245 Seats and doors DCM-RR-Door control module rear right TSGHL169 C-AAC-Convenience automatic air conditioning conditioning and conditioni	
As of 12/2005 B-Class 245 Seats and doors DCM-FR-Door control module front right TSGVR169	
As of 12/2005 B-Class 245 Seats and doors DCM-RL-Door control module rear left TSGHL169	
As of 12/2005 B-Class 245 Seats and doors DCM-RR-Door control module rear right C-AAC-Convenience automatic air conditioning/HaC-Automatic air conditi	
As of 12/2005 B-Class 245 Air conditioning C-AAC-Convenience automatic air conditioning /ACC-Automatic air conditioning/ACC-Automatic air conditioning/AEC-Automatic heater All C-Class 204 Drive ETC-Electronic transmission control EGS53 All C-Class 204 Drive ETC-Electronic transmission control VGSNAG2 All C-Class 204 Drive ME-SFI-Motor electronics SIM271KE20 All C-Class 204 Drive FSCU-Fuel pump FSCM221 All C-Class 204 Drive FSCU-Fuel pump FSCM211 All C-Class 204 Drive ESM-Electronic selector module TSLM_204 All C-Class 204 Drive ME 9.7 -Motor electronics 9.7 All C-Class 204 Drive FSCU Left-Control unit 'Right fuel pump' All C-Class 204 Drive FSCM_AMG_PT A All C-Class 204 Drive FSCU Right-Control unit 'Right fuel pump' FSCM_AMG_PT A All C-Class 204 Drive FSCU Right-Control unit 'Right fuel pump' FSCM_AMG_PT B FSCM_AMG_PT A FSCM_AMG_PT A FSCM_AMG_PT A FSCM_AMG_PT A FSCM_AMG_PT A FSCM_AMG_PT A A FSCM_AMG_PT A FSCM_AMG_PT A FSCM_AMG_PT A FSCM_AMG_PT A FSCM_AMG_PT A FSCM_AMG_PT B FSCM_AMG_PT A FSCM_AMG_PT A FSCM_AMG_PT B FSCM_AMG_PT A FSCM_AMG_PT A FSCM_AMG_PT A FSCM_AMG_PT A FSCM_AMG_PT A FSCM_AMG_PT A FSCM_AMG_PT B FSCM_AMG_PT B FSCM_AMG_PT A FSCM_AMG_PT A FSCM_AMG_PT B FSCM_AMG_PT A FSCM_AMG_PT B FSCM_AMG_PT B FSCM_AMG_PT A FSCM_AMG_PT A FSCM_AMG_PT B FSCM_AMG_PT A FSCM_AMG_PT B FSCM_AMG_PT A FSCM_AMG_PT B F	
As of 12/2005 B-Class 245 Air conditioning conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater ETC-Electronic transmission control EGS53 All C-Class 204 Drive ETC-Electronic transmission control VGSNAG2 VGSNAG2 All C-Class 204 Drive ME-SFI-Motor electronics SIM271KE20 All C-Class 204 Drive FSCU-Fuel pump FSCM221 All C-Class 204 Drive FSCU-Fuel pump FSCM21 All C-Class 204 Drive ESM-Electronic selector module TSLM_204 All C-Class 204 Drive ME 9.7-Motor electronics 9.7 All C-Class 204 Drive ME 9.7 (AMG)-Motor electronics 9.7 (AMG) ME97AMG All C-Class 204 Drive FSCU Left-Control unit 'Right fuel pump' FSCM_AMG_PT_ A FSCM_AMG_PT_ B FSCM_AMG_PT_ A FSCM_AMG_PT_ A FSCM_AMG_PT_ B FSCM_AMG_PT_ B FSCM_AMG_PT_ A FSCM_AMG_PT_ A FSCM_AMG_PT_ A FSCM_AMG_PT_ B FSCM_AMG_PT_ A FSCM_AMG_PT_ A FSCM_AMG_PT_ A FSCM_AMG_PT_ A FSCM_AMG_PT_ B FSCM_AMG_PT_ B FSCM_AMG_PT_ A FSCM_AMG_PT_ A FSCM_AMG_PT_ B FSCM_AMG_PT_ A FSCM_AMG_PT_ A FSCM_AMG_PT_ A FSCM_AMG_PT_ B FSCM_AMG_PT_ B FSCM_AMG_PT_ A FSCM_AMG_PT_ B FSCM_AMG_PT_	
All C-Class 204 Drive ETC-Electronic transmission control VGSNAG2	
All C-Class 204 Drive ME-SFI-Motor electronics SIM271KE20	
All C-Class 204 Drive FSCU-Fuel pump FSCM221	
All C-Class 204 Drive FSCU-Fuel pump FSCM212	0013
All C-Class 204 Drive ESM-Electronic selector module TSLM_204 • • • • • • • • • • • • • • • • • • •	
All C-Class 204 Drive ME 9.7-Motor electronics 9.7 ME97 All C-Class 204 Drive ME 9.7 (AMG) -Motor electronics 9.7 (AMG) ME97AMG All C-Class 204 Drive FSCU Left-Control unit 'left fuel pump' All C-Class 204 Drive FSCU Right-Control unit 'Right fuel pump' FSCM_AMG_PT_ A O O O O O O O O O O O O	
All C-Class 204 Drive ME 9.7 (AMG)-Motor electronics 9.7 (AMG) ME97AMG • • • • • • • • • • • • • • • • • • •	
All C-Class 204 Drive FSCU Left-Control unit 'left fuel pump' FSCM_AMG_PT_A C-Class 204 Drive FSCU Right-Control unit 'Right fuel pump' FSCM_AMG_PT_B O	0004 0013
All C-Class 204 Drive FSCU Right-Control unit 'Right fuel pump' FSCM_AMG_PT_ B	0004 0013
All C-Class 204 Drive FSCU Right-Control unit Right fuel pump B	
All $I(=0)$ acc $I(1)$ $I(1)$ $I(1)$ $I(1)$ $I(1)$ $I(1)$ $I(1)$ $I(2)$ $I(3)$ $I(3)$ $I(3)$ $I(3)$ $I(3)$ $I(3)$	0013 0019 0020 0021
	0013 0023 0024 0025 0026
All C-Class 204 Chassis ABR-Adaptive Brake ESP_E1	0047, 0015
All C-Class 204 Chassis TPC-Tire pressure monitor TPM_204 • • • • • • • •	0005
	0048, 0049, 0051



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	<u>lease re</u>	fer to the special f	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
A11	C-Class	204	Body	CGW-Central gateway	CGW_204	•	•	•	•	•	•	0	
A11	C-Class	204	Body	EZS-Electronic ignition switch	EIS_204	•	•	•	•	•	•	0	
A11	C-Class	204	Body	KG-Keyless Go	KG_204	•	•	•	•	•	•	•	
A11	C-Class	204	Body	AB-Airbag	ORC_204	•	•	•	•	•	•		
A11	C-Class	204	Body	WSS-Weight sensing system	OCM_204	•	•	•	•	•	•	0	0005
A11	C-Class	204	Body	OCP-Overhead control panel	R00F_204	•	•	•	•	•	•	•	
A11	C-Class	204	Body	OCP-Control module 'Panoramic sliding sunroof'	TSSR_204	•	•	•	•	•	•		
A11	C-Class	204	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMF_204	•	•	•	•	•	•	•	
A11	C-Class	204	Body	REAR SAM-Rear signal acquisition and actuation module	SAMR_204	•	•	•	•	•	•	•	
A11	C-Class	204	Body	AHE-Trailer recognition	AAG221	•	•	•	•	•	•	•	
A11	C-Class	204	Body	MSS-Special vehicle multifunction control module	MPM_204	•	•	•	•	•	•	•	
A11	C-Class	204	Body	RevETR-LF-Left front reversible emergency tensioning retractor	RBTMFL_204	•	•	•	•	•	•	•	
A11	C-Class	204	Body	RevETR-RF-Right front reversible emergency tensioning retractor	KB1MFK_2U4	•	•	•	•	•	•		
A11	C-Class	204	Body	XALWA-L-Xenon headlamp, left	HLMLT_204	•	•	•	•	•	•	•	
A11	C-Class	204	Body	XALWA-L-Xenon headlamp, left	HLMLT_X204	•	•	•	•	•	•		
A11	C-Class	204	Body	XALWA-R-Xenon headlamp, right	HLMRT_204	•	•	•	•	•	•		
A11	C-Class	204	Body	XALWA-R-Xenon headlamp, right	HLMRT_X204	•	•	•	•	•	•		
A11	C-Class	204	Information and communication	ICM-Instrument cluster with maintenance interval display	IC_204	•	•	•	•	•	•	•	0002
A11	C-Class	204	Information and communication	PTS-Parktronic	PTS_204	•	•	•	•	•	•	•	
A11	C-Class	204	Information and communication	RFK-Backup camera	DRVM221	•	•	•	•	•	•	0	
A11	C-Class	204	Information and communication	SCM [MRM]-Steering column module	SCCM_204	•	•	•	•	•	•	•	
A11	C-Class	204	Information and communication	COMAND or AUDIO	HU_204	•	•	•	•	•	•		
A11	C-Class	204	Information and communication	COU [ZBE]-Central operating unit	CTRLC_204	•	•	•	•	•	•	•	
A11	C-Class	204	Information and communication	ZAN-Central display	DISPC_204	•	•	•	•	•	•		
A11	C-Class	204	Information and communication	TV-TV tuner	TVJP_204	•	•	•	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p		fer to the special f	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
A11	C-Class	204	Information and communication	CTEL-Cellular telephone(JAPAN)	TELJP_204	•	•	•	•	•	•		
A11	C-Class	204	Information and communication	DAB-Digital radio	DAB_204	•	•	•	•	•	•		
A11	C-Class	204	Information and communication	SOUND- Sound system	SOUND_204	•	•	•	•	•	•		
A11	C-Class	204	Information and communication	SDAR-Satellite radio(Valid for USA)	SDAR221	•	•	•	•	•	•		
A11	C-Class	204	Information and communication	UCI	UCI_204	•	•	•	•	•	•	0	
A11	C-Class	204	Information and communication	AVE-H-Rear audio video unit	FU	•	•	•	•	•	•		
A11	C-Class	204	Information and communication	Left rear screen	DISP_RL	•	•	•	•	•	•		
A11	C-Class	204	Information and communication	Right rear screen	DISP_RR	•	•	•	•	•	•		
A11	C-Class	204	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
A11	C-Class	204	Information and communication	ŭ ,	XLCTECL	•	•	•	•		•	0	
A11	C-Class	204	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
A11	C-Class	204	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
A11	C-Class	204	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
A11	C-Class	204	Seats and doors	DCM-FL-Door control module front left	DMFL_204	•	•	•	•	•	•	•	
A11	C-Class	204	Seats and doors	DCM-FR-Door control module front right	DMFR_204	•	•	•	•	•	•	•	
A11	C-Class	204	Seats and doors	DCM-RL-Door control module rear left	DMRL_204	•	•	•	•	•	•	•	
A11	C-Class	204	Seats and doors	DCM-RR-Door control module rear right	DMRR_204	•	•	•	•	•	•	•	
A11	C-Class	204	Seats and doors	HKS-Tailgate control	PTCM	•	•	•	•	•	•	•	
A11	C-Class	204	Seats and doors	ESA driver	SEATD_204	•	•	•	•	•	•	•	
A11	C-Class	204	Seats and doors	ESA passenger	SEATP_204	•	•	•	•	•	•	•	
A11 Up to 08/2003	C-Class	204 203	Air conditioning Drive	AAC-Air conditioning ETC-Electronic transmission control	HVAC_204 EGS		•	0	•	•	*	•	
Up to 08/2003	C-Class	203	Drive	ETC-Electronic transmission control	EGS EGS52			•	•		*		
Up to 08/2003	C-Class	203	Drive	SEQ-Sequentronic automated manual transmission	KSG	•	•	•	•	•	•		
Up to 08/2003	C-Class	203	Drive	ESM-Electronic selector module	EWM203	•	•	•	•	•	0	•	0003



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease re	<u>fer to the special f</u>	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes		Erase Codes		Freeze Frame	Active Test	Special Function
Up to 08/2003	C-Class	203	Drive	ME-SFI-Motor electronics	SIM4	•	•	•	•	•	•	•	0013
Up to 08/2003	C-Class	203	Drive	DTR-Distronic	ART220	•	•	•	•	•	*	0	0005
Up to 08/2003	C-Class	203	Drive	ME-SFI-Motor electronics	SIM4LSE	•	•	•	•	•	•	•	0013
Up to 08/2003	C-Class	203	Drive	ME-SFI-Motor electronics	SIM4LDE	•	•	•	•	•	•	•	0013
Up to 08/2003	C-Class	203	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
Up to 08/2003	C-Class	203	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
Up to 08/2003	C-Class	203	Drive	CDI 2-Common Rail Diesel Injection	CR2	•	•	•	•	•	•	*	
As of 09/2003	C-Class	203	Drive	CDI 4-Common Rail Diesel Injection	CR3_UP_2	•	•	•	•	•	•	•	0019
Up to 08/2003	C-Class	203	Drive	CDI 4-Common Rail Diesel Injection	CR3_UP_2	•	•	•	•	•	•	•	0019
As of 09/2002	S-Class	220	Drive	CDI 3-Common Rail Diesel Injection3	CR3_UP_1	•	•	•	•	•	•	•	0019
Ab 06/2005 bis 05/2006	E-Class	211	Drive	CDI 3-Common Rail Diesel Injection3	CR3_UP_1	•	•	•	•	•	•	•	0019
Up to 05/2005	E-Class	211	Drive	CDI 3-Common Rail Diesel Injection3	CR3_UP_1	•	•	•	•	•	•	•	0019
As of 09/2003	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3	CR3_UP_1	•	•	•	•	•	•	•	0019
Up to 08/2003	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3	CR3_UP_1	•	•	•	•	•	•	•	0019
Up to 08/2003	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3	CR3_UP	•	•	•	•	•	•	•	0019
Up to 08/2003	C-Class	203	Drive	CDI 2-Common Rail Diesel Injection	CR2_AMG	•	•	•	•	•	•	*	
Up to 08/2003	C-Class	203	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
Up to 08/2003	C-Class	203	Chassis	ESP-Electronic stability program	ESP203_1	•	•	•	•	•	•		0047
Up to 08/2003	C-Class	203	Chassis	ESP-Electronic stability program	ESPMK25	•	•	•	•	•	•		0047, 0015
Up to 08/2003	C-Class	203	Chassis	BAS-Brake assist	BAS203	•	•	0	•	•	•	0	
Up to 08/2003	C-Class	203	Chassis	VP-Vacuum pump brake booster	UP28	•	•	•	•	•	•	•	
Up to 08/2003	C-Class	203	Chassis	ESP-Electronic stability program	ESP203	•	•	•	•	•	•	0	0047
Up to 08/2003	C-Class	203	Body	EZS-Electronic ignition switch	EZS203	•	•	•	•	•	0	0	0034
Up to 08/2003	C-Class	203	Body	EZS-Electronic ignition switch	EZS209	•	•	•	•	•	0	0	0034
Up to 08/2003	C-Class	203	Body	AB-Airbag	ARMINCA	•	•	•	•	•	•	0	
Up to 08/2003	C-Class	203	Body	OCP-Overhead control panel	DBE203	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Body	LCP-Lower control panel	UBF203	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Body	UCP-Upper control panel	0BF203	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Body	SAM-F-Signal acquisition and actuation module front	SAMV203	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH203	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Body	AHE-Trailer recognition	AAG203	•	•	•	•	•	0	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

As for specia	1 function p		fer to the special f	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
Up to 08/2003	C-Class	203	Body	MSS-Special vehicle multifunction control module	MSS203	•	•	•	•	•	0	•	0003
Up to 08/2003	C-Class	203	Body	HRA-FR-Front right headlamp range control	ALWRM203_230	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Body	HRA-FL-Front left headlamp range control	ALWRS203_230	•	•	•	•	•	0	0	
Up to 08/2003	C-Class	203	Body	CGW-Central gateway	ZGW203	•	•	•	•	•	•	0	0018
Up to 08/2003	C-Class	203	Body	AB-Airbag	ARMADA	•	•	•	•	•	•	0	0003 0010 0041
Up to 08/2003	C-Class	203	Body	WSS-Weight sensing system	WSS	•	•	•	•	•	•	0	0005
Up to 08/2003	C-Class	203	Body	AHE-Trailer recognition	AAG169	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Body	System diagnosis(CAN)	SD211	•	•	•	•	•	•		
Up to 08/2003	C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	KI203	•	•	•	•	•	0	*	0002
Up to 08/2003	C-Class	203	Information and communication	PTS-Parktronic system	PTS203	•	•	•	•	•	•	•	
Up to 08/2003	C-Class	203	Information and communication	SCM [MRM]-Steering column module	MRM209	•	•	•	•	•	•		0005
Up to 08/2003	C-Class	203	Information and communication	TV-TV tuner	TV	•	•	•	•		•	•	
Up to 08/2003	C-Class	203	Information and communication	E-call [Japan]-Telematic system	TAIDJAP2	•	•	•	•	•	•		
Up to 08/2003	C-Class	203	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
Up to 08/2003	C-Class	203	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
Up to 08/2003	C-Class	203	Information and communication	D2B-COMAND, MCS or AUDIO	AVN	•	•	•	•	•	•		
Up to 08/2003	C-Class	203	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
Up to 08/2003	C-Class	203	Information and communication	COMAND	COMAND	•	•	0	•	•	•	•	
Up to 08/2003	C-Class	203	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
Up to 08/2003	C-Class	203	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
Up to 08/2003	C-Class	203	Information and communication	SOUND- Sound system	SOUND	•	•	0	•	•	•	0	
Up to 08/2003	C-Class	203	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	TELE	•	•	•	•	0	0	0	
Up to 08/2003	C-Class	203	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

As for special	function p		fer to the special fu	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 08/2003	C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	KI203M	•	•	•	•	•	0	•	0002
Up to 08/2003	C-Class	203	Information and communication	SCM [MRM]-Steering column module	MRM169	•	•	•	•	•	•	•	0005
Up to 08/2003	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
Up to 08/2003	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
Up to 08/2003	C-Class	203	Information and communication	AUDIO	XHU	•	•	•	•	•	•		0003
Up to 08/2003	C-Class	203	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•		
Up to 08/2003	C-Class	203	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
Up to 08/2003	C-Class	203	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
Up to 08/2003	C-Class	203	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
Up to 08/2003	C-Class	203	Information and communication	SOUND- Sound system	XSNDHB	•	•	0	•	•	•		
Up to 08/2003	C-Class	203	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•		
Up to 08/2003	C-Class	203	Information and communication	NAVI-Navigation system	XMCSNAV	•	•	•	•	•	•	•	
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
Up to 08/2003	C-Class	203	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
Up to 08/2003	C-Class	203	Information and communication	CTEL-Cellular telephone	XTELJP	•	•	•	•	•	•	0	
Up to 08/2003	C-Class	203	Seats and doors	DCM-FL-Door control module front left	TSGVL203	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Seats and doors	DCM-FR-Door control module front right	TSGVR203	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Seats and doors	DCM-RL-Door control module rear left	TSGHL203	•	•	•	•	•	0	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special i	tunction p.	lease rei	<u>fer to the special f</u>	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory			Freeze Frame	Active Test	Special Function
Up to 08/2003	C-Class	203	Seats and doors	DCM-RR-Door control module rear right	TSGHR203	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB203	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB211	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver	SSGF203	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver	SSGF211	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164	•	•	•	•	•	0	•	
Up to 08/2003	C-Class	203	Air conditioning	AAC-Automatic air conditioning	KLA203	•	•	•	•	•	•	•	
Up to 08/2003	C-Class	203	Air conditioning	STH-Stationary heater	STH203	•	•	•	•	•	•		
Up to 08/2003	C-Class	203	Air conditioning	STH-Stationary heater	STH211	•	•	•	•	•	•	•	
From 09/2003 to 12/2007	C-Class	203	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
From 09/2003 to 12/2007	C-Class	203	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
From 09/2003 to 12/2007	C-Class	203	Drive	SEQ-Sequentronic automated manual transmission	KSG	•	•	•	•	•	•		
From 09/2003 to 12/2007	C-Class	203	Drive	ESM-Electronic selector module	EWM203	•	•	•	•	•	0	•	0003
From 09/2003 to 12/2007	C-Class	203	Drive	ME-SFI-Motor electronics	SIM4LSE	•	•	•	•	•	•	•	0013
From 09/2003 to 12/2007	C-Class	203	Drive	ME-SFI-Motor electronics	SIM4LDE	•	•	•	•	•	•	•	0013
From 09/2003 to 12/2007	C-Class	203	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
From 09/2003 to 12/2007	C-Class	203	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
From 09/2003 to 12/2007	C-Class	203	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3	CR3_UP	•	•	•	•	•	•	•	0019
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 2-Common Rail Diesel Injection	CR2	•	•	•	•	•	•	*	
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 2-Common Rail Diesel Injection	CR2_AMG	•	•	•	•	•	•	*	
From 09/2003 to 12/2007	C-Class	203	Drive	CDI 4-Common Rail Diesel Injection	CR4	•	•	•	•	•	•	*	0013



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	<u>lease rei</u>	fer to the special fu	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
From 09/2003 to 12/2007	C-Class	203	Chassis	ESP-Electronic stability program	ESPMK25	•	•	•	•	•	•		0047, 0015
From 09/2003 to 12/2007	C-Class	203	Body	CGW-Central gateway	ZGW203	•	•	•	•	•	•	0	0018
From 09/2003 to 12/2007	C-Class	203	Body	EZS-Electronic ignition switch	EZS209	•	•	•	•	•	0	0	0034
From 09/2003 to 12/2007	C-Class	203	Body	AB-Airbag	ARMADA	•	•	•	•	•	•	0	0003 0010 0041
From 09/2003 to 12/2007	C-Class	203	Body	OCP-Overhead control panel	DBE203	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Body	WSS-Weight sensing system	WSS	•	•	•	•	•	•	0	0005
From 09/2003 to 12/2007	C-Class	203	Body	LCP-Lower control panel	UBF203	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Body	UCP-Upper control panel	0BF203	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Body	SAM-F-Signal acquisition and actuation module front	SAMV203	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH203	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Body	AHE-Trailer recognition	AAG203	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Body	AHE-Trailer recognition	AAG169	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Body	MSS-Special vehicle multifunction control module	MSS203	•	•	•	•	•	0	•	0003
From 09/2003 to 12/2007	C-Class	203	Body	HRA-FR-Front right headlamp range control	ALWRM203_230	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Body	HRA-FL-Front left headlamp range control	ALWRS203_230	•	•	•	•	•	0	0	
From 09/2003 to 12/2007	C-Class	203	Body	System diagnosis(CAN)	SD211	•	•	•	•	•	•		
From 09/2003 to 12/2007	C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	KI203M	•	•	•	•	•	0	•	0002
From 09/2003 to 12/2007	C-Class	203	Information and communication	PTS-Parktronic system	PTS203	•	•	•	•	•	•	•	
From 09/2003 to 12/2007	C-Class	203	Information and communication	SCM [MRM]-Steering column module	MRM169	•	•	•	•	•	•	•	0005
From 09/2003 to 12/2007	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

unction p.	i <u>ease rel</u>	ter to the special fu	nction table.									
Mode1		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
C-Class	203	Information and communication	AUDIO	XHU	•	•	•	•	•	•		0003
C-Class	203	Information and communication	COMAND or AUDIO	ХНИЈР	•	•	0	•	•	•		
C-Class	203	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
C-Class	203	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
C-Class	203	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
C-Class	203	Information and communication	SOUND- Sound system	XSNDHB	•	•	0	•	•	•		
C-Class	203	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•		
C-Class	203	Information and communication	NAVI-Navigation system	XMCSNAV	•	•	•	•	•	•	•	
C-Class	203	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
C-Class	203	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
C-Class	203	Information and	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
C-Class	203	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
C-Class	203	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
C-Class	203	Information and communication	CTEL-Cellular telephone	XTELJP	•	•	•	•	•	•	0	
C-Class	203	Seats and doors	DCM-FL-Door control module front left	TSGVL203	•	•	•	•	•	0	•	
C-Class	203	Seats and doors	DCM-FR-Door control module front right	TSGVR203	•	•	•	•	•	0	•	
C-Class	203	Seats and doors	DCM-RL-Door control module rear left	TSGHL203	•	•	•	•	•	0	•	
C-Class	203	Seats and doors	DCM-RR-Door control module rear right	TSGHR203	•	•	•	•	•	0	•	
C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB203	•	•	•	•	•	0	•	
	Model C-Class	Mode1 Mode1 Series C-Class 203 C-Class 203	Model Series Groups C-Class 203 Information and communication C-Class 203 Seats and doors C-Class 203 Seats and doors	C-Class 203 Information and communication AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	Model Series Groups C-Class 203 Information and communication C-Class 203 Information and C-Class 203 Information and C-Class 203 Information and C-Class 20	Model Series Control Unit Series Coups Compus Coups Coups Coups Compus Comp	Model Series Groups C-Class 203 Information and communication C-Class 203 Seats and doors DCM-FL-Door control module front left TSGVL203 • • • • • • • • • • • • • • • • • • •	Model Series Groups System Name DiagName Ecu Info. Read Groups Coclass 203 Information and communication MUIU MUI	Model Series Groups C-Class 203 Information and communication C-Class 203 Information and CDC-CD changer C-Class 203 Information and communication C-Class 203 Information and CDC-CD CDC-CDC-CDC-CDC-CDC-CDC-CDC-CDC-	Model Series Groups Groups Groups AGW Audic gateway (MOST notwork management, diagnosis gateway, radio towards communication towards management, diagnosis gateway, radio MHLAGW Groups Groups Groups AGW Audic gateway (MOST notwork management, diagnosis gateway, radio MHLAGW Groups Groups Groups Groups Information and communication Groups Groups Groups Groups AGW Audic gateway (MOST notwork management, diagnosis gateway, radio MHLAGW Groups Groups Groups Groups Information and communication Groups Groups Groups Groups Groups Groups Groups Information and communication Groups Gr	Model Control Unit System Name DiagName Ecu Read Event Erase Live Proeze GroUps GroUps	Model



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special f	unction p	<u> rease re</u>	<u>fer to the special fu</u>	inction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB211	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver	SSGF203	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver	SSGF211	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164	•	•	•	•	•	0	•	
From 09/2003 to 12/2007	C-Class	203	Air conditioning	AAC-Automatic air conditioning	KLA203	•	•	•	•	•	•	•	
From 09/2003 to 12/2007	C-Class	203	Air conditioning	STH-Stationary heater	STH211	•	•	•	•	•	•	•	
As of 01/2008	C-Class	203	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
As of 01/2008	C-Class	203	Drive	ETC-Electronic transmission control	EGS53	•	•	•	•	•	•	•	
As of 01/2008	C-Class	203	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
As of 01/2008	C-Class	203	Drive	ESM-Electronic selector module	EWM203	•	•	•	•	•	0	•	0003
As of 01/2008	C-Class	203	Drive	ME-SFI-Motor electronics	SIM4LSE	•	•	•	•	•	•	•	0013
As of 01/2008	C-Class	203	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
As of 01/2008	C-Class	203	Drive	CDI 3-Common Rail Diesel Injection3	CR3_UP	•	•	•	•	•	•	•	0019
As of 01/2008	C-Class	203	Chassis	ESP-Electronic stability program	ESPMK25	•	•	•	•	•	•		0047, 0015
As of 01/2008	C-Class	203	Body	EZS-Electronic ignition switch	EZS209	•	•	•	•	•	0	0	0034
As of 01/2008	C-Class	203	Body	AB-Airbag	ARMADA	•	•	•	•	•	•	0	0003 0010 0041
As of 01/2008	C-Class	203	Body	OCP-Overhead control panel	DBE203	•	•	•	•	•	0	•	
As of 01/2008	C-Class	203	Body	LCP-Lower control panel	UBF203	•	•	•	•	•	0	•	
As of 01/2008	C-Class	203	Body	UCP-Upper control panel	0BF203	•	•	•	•	•	0	•	
As of 01/2008	C-Class	203	Body	SAM-F-Signal acquisition and actuation module front	SAMV203	•	•	•	•	•	0	•	
As of 01/2008	C-Class	203	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH203	•	•	•	•	•	0	•	
As of 01/2008	C-Class	203	Body	MSS-Special vehicle multifunction control module	MSS203	•	•	•	•	•	0	•	0003
As of 01/2008	C-Class	203	Body	XALWA-L-Xenon headlamp, left	ALWRL203CL	•	•	•	•	•	•	*	
As of 01/2008	C-Class	203	Body	XALWA-R-Xenon headlamp, right	ALWRR203CL	•	•	•	•	•	•	•	
As of 01/2008	C-Class	203	Information and communication	ICM-Instrument cluster with maintenance interval display	KI203M	•	•	•	•	•	0	•	0002
As of 01/2008	C-Class	203	Information and communication	PTS-Parktronic system	PTS211MOPF	•	•	•	•	•	0	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for spec	ial function p	<u>lease re</u>	fer to the special f	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 01/2008	C-Class	203	Information and communication	SCM [MRM]-Steering column module	MRM169	•	•	•	•	•	•	•	0005
As of 01/2008	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
As of 01/2008	C-Class	203	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
As of 01/2008	C-Class	203	Information and communication	AUDIO	XHU	•	•	•	•	•	•		0003
As of 01/2008	C-Class	203	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•		
As of 01/2008	C-Class	203	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
As of 01/2008	C-Class	203	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
As of 01/2008	C-Class	203	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
As of 01/2008	C-Class	203	Information and communication	SOUND- Sound system	XSNDHB	•	•	0	•	•	•		
As of 01/2008	C-Class	203	Information and communication	NAVI-Navigation system	XNAVIH	•	•	0	•	•	•		
As of 01/2008	C-Class	203	Information and communication	COMAND or AUDIO	HU25	•	•	•	•	•	•		
As of 01/2008	C-Class	203	Information and communication	SOUND- Sound system	SOUND25	•	•	•	•	•	•		
As of 01/2008	C-Class	203	Information and communication	UCI	UCI25	•	•	•	•	•	•	0	
As of 01/2008	C-Class	203	Information and communication	DAB-Digital radio	DAB25	•	•	•	•	•	0		
As of 01/2008	C-Class	203	Information and communication	SDAR-Satellite radio(Valid for USA)	SDARS25	•	•	•	•	•	•		
As of 01/2008	C-Class	203	Information and communication	CTEL-Cellular telephone(JAPAN)	CBJ25	•	•	•	•	•	0		
As of 01/2008	C-Class	203	Seats and doors	DCM-FL-Door control module front left	TSGVL203	•	•	•	•	•	0	•	
As of 01/2008	C-Class	203	Seats and doors	DCM-FR-Door control module front right	TSGVR203	•	•	•	•	•	0	•	
As of 01/2008	C-Class	203	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164	•	•	•	•	•	0	•	
As of 01/2008	C-Class	203	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164	•	•	•	•	•	0	•	
As of 01/2008	C-Class	203	Air conditioning	AAC-Automatic air conditioning	KLA203	•	•	•	•	•	•	•	
As of 01/2008	C-Class	203	Air conditioning	STH-Stationary heater	STH211	•	•	•	•	•	•	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
As of 06/97	C-Class	202	Drive	ETC-Electronic transmission control	EGS_H	•	•	0	•		*		
As of 06/97	C-Class	202	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
As of 06/97	C-Class	202	Drive	ETC-Electronic transmission control	EGS	•	•	0	•	•	*	•	
As of 06/97	C-Class	202	Drive	ESM-Electronic selector module	EWM210	•	•	0	•	•	*	•	
As of 06/97	C-Class	202	Drive	HFM-SFI-Hot film engine management	HFM_H	•	•	0	•		*		
As of 06/97	C-Class	202	Drive	ME2-SFI-Motor electronics 2	ME2_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
As of 06/97	C-Class	202	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
As of 06/97	C-Class	202	Drive	DFI-Electronic distributor injection system diesel	EVE_H	•	•	0	•		*		
As of 06/97	C-Class	202	Drive	IFI-Electronic in-line injection system diesel	ERE_H	•	•	0	•		*		
As of 06/97	C-Class	202	Drive	CDI-Common Rail Diesel Injection	CR1_H	•	•	0	•		*		
As of 06/97	C-Class	202	Drive	ME-SFI-Motor electronics	SIM4	•	•	•	•	•	•	•	0013
As of 06/97	C-Class	202	Chassis	ABS-Antilock brake system	ABS30_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Chassis	ASR-Acceleration Slip Regulation	ASR34_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Chassis	ESP-Electronic stability program	ESP35_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Chassis	ESP-Electronic stability program	ESP203	•	•	•	•	•	•	0	0047
As of 06/97	C-Class	202	Chassis	ASR-Acceleration Slip Regulation	ASR30_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Chassis	ESP-Electronic stability program	ESP30_H	•	•	0	•	•	*		0040
As of 06/97	C-Class	202	Chassis	ETS-Electronic traction system	ETS30_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Chassis	ESP-Electronic stability program	ESP34_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Chassis	ETS-Electronic traction system	ETS34_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Chassis	BAS-Brake assist	BAS_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Chassis	BAS-Brake assist	BAS203	•	•	0	•	•	•	0	
As of 06/97	C-Class	202	Chassis	VP-Vacuum pump brake booster	UP28	•	•	•	•	•	•	•	
As of 06/97	C-Class	202	Body	AB-Airbag	ZAE_H	•	•	0	•		*		
As of 06/97	C-Class	202	Body	EZS-Electronic ignition switch	EZS1_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Body	OCP-Overhead control panel	DBE1_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Body	LCP-Lower control panel	UBF1_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Body	PSE-Pneumatic system equipment	PSE1_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Body	SAM-Signal acquisition and actuation module	SAM1_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Body	MSS-Special vehicle multifunction control module	MSS1_H	•	•	0	•	•	*		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for specia	<u>l function p</u>		fer to the special	function table.									
Model year	Mode1		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
As of 06/97	C-Class	202	Body	HRA-Headlamp range adjustment	LWR1_H	•	•	0	•		*		
As of 06/97	C-Class	202	Body	APS-Auto pilot system	APS_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Body	HB-Heater booster	ZUH_H	•	•	0	•		*		
As of 06/97	C-Class	202	Information and communication	ICM-Instrument cluster with maintenance interval display	KIW_H	•	•	0	•	•	*	•	0002
As of 06/97	C-Class	202	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
As of 06/97	C-Class	202	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	0	
As of 06/97	C-Class	202	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		
As of 06/97	C-Class	202	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
As of 06/97	C-Class	202	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
As of 06/97	C-Class	202	Information and communication	PTS-Parktronic system	PTS163	•	•	•	•	•	*	•	
As of 06/97	C-Class	202	Information and communication	TELE AID-Emergency call system	ECALLECE	•	•	•	•	•	•		
As of 06/97	C-Class	202	Information and communication	TELE AID-Telematic system	AID_H	•	•	0	•		•		
As of 06/97	C-Class	202	Information and communication	DN-Dynamic navigation by means of CTEL	TELEDZS	•	•	•	•	•	0	0	
As of 06/97	C-Class	202	Seats and doors	DCM1-Door control module front driver side	TSGVL_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Seats and doors	DCM2-Door control module front passenger side	TSGVR_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Seats and doors	DCM3-Door control module rear driver side	TSGHL_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Seats and doors	DCM4-Door control module rear passenger side	TSGHR_H	•	•	0	•	•	*		
As of 06/97	C-Class	202	Air conditioning	TAC-Automatic temperature control	TAU_H	•	•	0	•		*	•	
As of 06/97	C-Class	202	Air conditioning	AAC-Automatic air conditioning	KLA_H	•	•	0	•		*		
As of 06/97	C-Class	202	Air conditioning	STH-Stationary heater	STH_H	•	•	0	•	•	*		
Up to 03/2004	CLK	209	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
Up to 03/2004	CLK	209	Drive	SEQ-Sequentronic automated manual transmission	KSG	•	•	•	•	•	•		
Up to 03/2004	CLK	209	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
Up to 03/2004	CLK	209	Drive	ESM-Electronic selector module	EWM203	•	•	•	•	•	0	•	0003
Up to 03/2004	CLK	209	Drive	ME-SFI-Motor electronics	SIM4LSE	•	•	•	•	•	•	•	0013
Up to 03/2004	CLK	209	Drive	ME-SFI-Motor electronics	SIM4LDE	•	•	•	•	•	•	•	0013



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease re	<u>fer to the special f</u>	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 03/2004	CLK	209	Drive	DTR-Distronic	ART220	•	•	•	•	•	*	0	0005
Up to 03/2004	CLK	209	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
Up to 03/2004	CLK	209	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
Up to 03/2004	CLK	209	Drive	CDI 2-Common Rail Diesel Injection	CR2	•	•	•	•	•	•	*	
Up to 03/2004	CLK	209	Chassis	ESP-Electronic stability program	ESPMK25	•	•	•	•	•	•		0047, 0015
Up to 03/2004	CLK	209	Body	EZS-Electronic ignition switch	EZS209	•	•	•	•	•	0	0	0034
Up to 03/2004	CLK	209	Body	AB-Airbag	ARMINCA	•	•	•	•	•	•	0	
Up to 03/2004	CLK	209	Body	OCP-Overhead control panel	DBE203	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Body	LCP-Lower control panel	UBF203	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Body	UCP-Upper control panel	0BF203	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Body	SAM-F-Signal acquisition and actuation module front	SAMV203	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH203	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Body	AHE-Trailer recognition	AAG203	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Body	MSS-Special vehicle multifunction control module	MSS203	•	•	•	•	•	0	•	0003
Up to 03/2004	CLK	209	Body	RVC-Rollover bar soft top control module	UVS209	•	•	•	•	•	0		
Up to 03/2004	CLK	209	Body	HRA-FR-Front right headlamp range control	ALWRM203_230	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Body	HRA-FL-Front left headlamp range control	ALWRS203_230	•	•	•	•	•	0	0	
Up to 03/2004	CLK	209	Information and communication	ICM-Instrument cluster with maintenance interval display	KI209	•	•	•	•	•	0		0002
Up to 03/2004	CLK	209	Information and communication	PTS-Parktronic system	PTS203	•	•	•	•	•	•	•	
Up to 03/2004	CLK	209	Information and communication	SCM [MRM]-Steering column module	MRM209	•	•	•	•	•	•		0005
Up to 03/2004	CLK	209	Information and communication	TV-TV tuner	TV	•	•	•	•		•	•	
Up to 03/2004	CLK	209	Information and communication	E-call [Japan]-Telematic system	TAIDJAP2	•	•	•	•	•	•		
Up to 03/2004	CLK	209	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
Up to 03/2004	CLK	209	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
Up to 03/2004	CLK	209	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
Up to 03/2004	CLK	209	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	<u>function p</u>	lease rei	fer to the special fu	inction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes		Freeze Frame	Active Test	Special Function
Up to 03/2004	CLK	209	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
Up to 03/2004	CLK	209	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
Up to 03/2004	CLK	209	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
Up to 03/2004	CLK	209	Information and communication	D2B-COMAND, MCS or AUDIO	AVN	•	•	•	•	•	•		
Up to 03/2004	CLK	209	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
Up to 03/2004	CLK	209	Information and communication	COMAND	COMAND	•	•	0	•	•	•	•	
Up to 03/2004	CLK	209	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
Up to 03/2004	CLK	209	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
Up to 03/2004	CLK	209	Information and communication	SOUND- Sound system	SOUND	•	•	0	•	•	•	0	
Up to 03/2004	CLK	209	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	TELE	•	•	•	•	0	0	0	
Up to 03/2004	CLK	209	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		
Up to 03/2004	CLK	209	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB211	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Seats and doors	ESA driver-Electric seat adjustment driver	SSGF211	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Seats and doors	DCM-L-Door control module left	TSGVL209	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Seats and doors	DCM-R-Door control module right	TSGVR209	•	•	•	•	•	0	•	
Up to 03/2004	CLK	209	Seats and doors	TLC-Trunk lid control	HFS211	•	•	•	•		•	•	
Up to 03/2004	CLK	209	Seats and doors	RCM-Rear control module	FSG209	•	•	•	•	•	0		
Up to 03/2004	CLK	209	Air conditioning	AAC-Automatic air conditioning	KLA203	•	•	•	•	•	•	•	
Up to 03/2004	CLK	209	Air conditioning	STH-Stationary heater	STH203	•	•	•	•	•	•		
As of 04/2004	CLK	209	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
As of 04/2004	CLK	209	Drive	ETC-Electronic transmission control	EGS53	•	•	•	•	•	•	•	
As of 04/2004	CLK	209	Drive	SEQ-Sequentronic automated manual transmission	KSG	•	•	•	•	•	•		



NOTES:

This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

As for special	function p		fer to the special f	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 04/2004	CLK	209	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
As of 04/2004	CLK	209	Drive	ESM-Electronic selector module	EWM203	•	•	•	•	•	0	•	0003
As of 04/2004	CLK	209	Drive	DTR-Distronic	ARS200	•	•	•	•	•	•	0	0005
As of 04/2004	CLK	209	Drive	ME-SFI-Motor electronics	SIM4LSE	•	•	•	•	•	•	•	0013
As of 04/2004	CLK	209	Drive	ME-SFI-Motor electronics	SIM4LDE	•	•	•	•	•	•	•	0013
As of 04/2004	CLK	209	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
As of 04/2004	CLK	209	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
As of 04/2004	CLK	209	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
As of 04/2004	CLK	209	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	ME97AMG	•	•	•	•	•	•	•	0004 0013
As of 04/2004	CLK	209	Drive	FSCU Left-Control unit 'Left fuel pump'	FSCM_AMG_DB_ A_1	•	•	•	•	•	•		
As of 04/2004	CLK	209	Drive	FSCU Right-Control unit 'Right fuel pump'	FSCM_AMG_DB_ B_1	•	•	•	•	•	•		
As of 04/2004	CLK	209	Drive	CDI 4-Common Rail Diesel Injection	CR4	•	•	•	•	•	•	*	0013
As of 04/2004	CLK	209	Drive	CDI 3-Common Rail Diesel Injection3	CR3_UP	•	•	•	•	•	•	•	0019
As of 04/2004	CLK	209	Drive	CDI 3-Common Rail Diesel Injection3	CR3	•	•	•	•	•	•	*	
As of 04/2004	CLK	209	Drive	CDI 2-Common Rail Diesel Injection	CR2	•	•	•	•	•	•	*	
As of 04/2004	CLK	209	Chassis	ESP-Electronic stability program	ESPMK25	•	•	•	•	•	•		0047, 0015
As of 04/2004	CLK	209	Chassis	TPC-Tire pressure monitor	TPM_209	•	•	•	•	•	•	•	0005
As of 04/2004	CLK	209	Body	EZS-Electronic ignition switch	EZS209	•	•	•	•	•	0	0	0034
As of 04/2004	CLK	209	Body	AB-Airbag	ARMADA	•	•	•	•	•	•	0	0003 0010 0041
As of 04/2004	CLK	209	Body	OCP-Overhead control panel	DBE203	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Body	WSS-Weight sensing system	WSS	•	•	•	•	•	•	0	0005
As of 04/2004	CLK	209	Body	LCP-Lower control panel	UBF203	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Body	UCP-Upper control panel	0BF203	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Body	SAM-F-Signal acquisition and actuation module front	SAMV203	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH203	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Body	AHE-Trailer recognition	AAG203	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Body	AHE-Trailer recognition	AAG169	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Body	MSS-Special vehicle multifunction control module	MSS203	•	•	•	•	•	0	•	0003
As of 04/2004	CLK	209	Body	RVC-Rollover bar soft top control module	UVS209	•	•	•	•	•	0		
As of 04/2004	CLK	209	Body	HRA-Automatic headlamp range adjustment and headlamp control	ALWR211	•	•	•	•	•	0	•	0005 0009



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p		fer to the special f	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 04/2004	CLK	209	Body	HRA-FR-Front right headlamp range control	ALWRM203_230	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Body	HRA-FL-Front left headlamp range control	ALWRS203_230	•	•	•	•	•	0	0	
As of 04/2004	CLK	209	Body	On board electrical system(voltage supply)	BSG211_1	•	•	•	•	•	•		
As of 04/2004	CLK	209	Information and communication	ICM-Instrument cluster with maintenance interval display	KI209	•	•	•	•	•	0		0002
As of 04/2004	CLK	209	Information and communication	PTS-Parktronic system	PTS203	•	•	•	•	•	•	•	
As of 04/2004	CLK	209	Information and communication	SCM [MRM]-Steering column module	MRM169	•	•	•	•	•	•	•	0005
As of 04/2004	CLK	209	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
As of 04/2004	CLK	209	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
As of 04/2004	CLK	209	Information and communication	AUDIO	XHU	•	•	•	•	•	•		0003
As of 04/2004	CLK	209	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•		
As of 04/2004	CLK	209	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
As of 04/2004	CLK	209	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
As of 04/2004	CLK	209	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
As of 04/2004	CLK	209	Information and communication	SOUND- Sound system	XSNDHB	•	•	0	•	•	•		
As of 04/2004	CLK	209	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•		
As of 04/2004	CLK	209	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
As of 04/2004	CLK	209	Information and communication	NAVI-Navigation system	XMCSNAV	•	•	•	•	•	•	•	
As of 04/2004	CLK	209	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
As of 04/2004	CLK	209	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
As of 04/2004	CLK	209	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special:	function p	lease re	fer to the special fi	inction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
As of 04/2004	CLK	209	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	2 0.1.0 0.2 0.1.
As of 04/2004	CLK	209	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
As of 04/2004	CLK	209	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB211	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Seats and doors	ESA driver-Electric seat adjustment driver	SSGF211	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Seats and doors	DCM-L-Door control module left	TSGVL209	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Seats and doors	DCM-R-Door control module right	TSGVR209	•	•	•	•	•	0	•	
As of 04/2004	CLK	209	Seats and doors	TLC-Trunk lid control	HFS211	•	•	•	•	•	•	•	
As of 04/2004	CLK	209	Seats and doors	RCM-Rear control module	FSG209	•	•	•	•	•	0		
As of 04/2004	CLK	209	Air conditioning	AAC-Automatic air conditioning	KLA203	•	•	•	•	•	•	•	
As of 04/2004	CLK	209	Air conditioning	STH-Stationary heater	STH211	•	•	•	•	•	•	•	
A11	CLK	208	Drive	ETC-Electronic transmission control	EGS_H	•	•	0	•		*		
A11	CLK	208	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
A11	CLK	208	Drive	SEQ-Sequentronic automated manual transmission	KSG	•	•	•	•	•	•		
A11	CLK	208	Drive	ESM-Electronic selector module	EWM210	•	•	0	•	•	*	•	
A11	CLK	208	Drive	HFM-SFI-Hot film engine management	HFM_H	•	•	0	•		*		
A11	CLK	208	Drive	ME2-SFI-Motor electronics 2	ME2_H	•	•	0	•	•	*		
A11	CLK	208	Drive	ME-SFI-Motor electronics	SIM4	•	•	•	•	•	•	•	0013
A11	CLK	208	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
A11	CLK	208	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
A11	CLK	208	Chassis	ABS-Antilock brake system	ABS30_H	•	•	0	•	•	*		
A11	CLK	208	Chassis	ESP-Electronic stability program	ESP34_H	•	•	0	•	•	*		
A11	CLK	208	Chassis	ESP-Electronic stability program	ESP203	•	•	•	•	•	•	0	0047
A11	CLK	208	Chassis	ASR-Acceleration Slip Regulation	ASR30_H	•	•	0	•	•	*		
A11	CLK	208	Chassis	BAS-Brake assist	BAS_H	•	•	0	•	•	*		
A11	CLK	208	Chassis	BAS-Brake assist	BAS203	•	•	0	•	•	•	0	
A11	CLK	208	Chassis	VP-Vacuum pump brake booster	UP28	•	•	•	•	•	•	•	
A11	CLK	208	Body	AB-Airbag	ZAE_H	•	•	0	•		*		
A11	CLK	208	Body	EZS-Electronic ignition switch	EZS1 H	•	•	0	•	•	*		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p		fer to the special fu	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes		Erase Codes			Active Test	Special Function
A11	CLK	208	Body	OCP-Overhead control panel	DBE1_H	•	•	0	•	•	*		
A11	CLK	208	Body	LCP-Lower control panel	UBF1_H	•	•	0	•	•	*		
A11	CLK	208	Body	PSE-Pneumatic system equipment	PSE1_H	•	•	0	•	•	*		
A11	CLK	208	Body	SAM-Signal acquisition and actuation module	SAM1_H	•	•	0	•	•	*		
A11	CLK	208	Body	HRA-Headlamp range adjustment	LWR1_H	•	•	0	•		*		
A11	CLK	208	Body	HRA-Headlamp range adjustment	LWR2_H	•	•	0	•	•	0		
A11	CLK	208	Body	APS-Auto pilot system	APS_H	•	•	0	•	•	*		
A11	CLK	208	Body	RVC-Rollover bar soft top control module	UVS_H	•	•	0	•		*		
A11	CLK	208	Information and communication	ICM-Instrument cluster with maintenance interval display	KIW_H	•	•	0	•	•	*	•	0002
A11	CLK	208	Information and communication	ICM-Instrument cluster with maintenance interval display	KIL	•	•	•	•	•	•		0002
A11	CLK	208	Information and communication	COMAND	COMAND	•	•	0	•	•	•	•	
A11	CLK	208	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
A11	CLK	208	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	0	
A11	CLK	208	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		
A11	CLK	208	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
A11	CLK	208	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
A11	CLK	208	Information and communication	PTS-Parktronic system	PTS163	•	•	•	•	•	*	•	
A11	CLK	208	Information and communication	TV-TV tuner	TV	•	•	•	•		•	•	
A11	CLK	208	Information and communication	TELE AID-Emergency call system	ECALLECE	•	•	•	•	•	•		
A11	CLK	208	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
A11	CLK	208	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
A11	CLK	208	Information and communication	DN-Dynamic navigation by means of CTEL	TELEDZS	•	•	•	•	•	0	0	
A11	CLK	208	Seats and doors	DCM1-Door control module front driver side	TSGVL_H	•	•	0	•	•	*		
A11	CLK	208	Seats and doors	DCM2-Door control module front passenger side	TSGVR_H	•	•	0	•	•	*		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special :	<u>function p</u>	<u>lease re</u>	fer to the special f	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
A11	CLK	208	Seats and doors	ESA-FL-Electric seat adjustment front left	ESV1L_H	•	•	0	•	•	*		
A11	CLK	208	Seats and doors	ESA-FR-Electric seat adjustment front right	ESV1R_H	•	•	0	•	•	*		
A11	CLK	208	Air conditioning	TAC-Automatic temperature control	TAU_H	•	•	0	•		*	•	
A11	CLK	208	Air conditioning	AAC-Automatic air conditioning	KLA_H	•	•	0	•		*		
A11	CLK	208	Air conditioning	STH-Stationary heater	STH_H	•	•	0	•	•	*		
A11	C-Class	X 204	Drive	ETC-Electronic transmission control	EGS53	•	•	•	•	•	•	•	
A11	C-Class	X 204	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
A11	C-Class	X 204	Drive	FSCU-Fuel pump	FSCM221	•	•	•	•	0	•		
A11	C-Class	X 204	Drive	FSCU-Fuel pump	FSCM212	•	•	•	•	•	•		
A11	C-Class	X 204	Drive	ESM-Electronic selector module	TSLM_204	•	•	•	•	•	•	•	
A11	C-Class	X 204	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
A11	C-Class	X 204	Drive	CDI 6-Common Rail Diesel Injection	CR6	•	•	•	•	•	•		0013 0023 0024 0025 0026
A11	C-Class	X 204	Chassis	ABR-Adaptive Brake	ESP_E1	•	•	•	•	•	•	•	0047, 0015
A11	C-Class	X 204	Chassis	TPC-Tire pressure monitor	TPM_204	•	•	•	•	•	•	•	0005
A11	C-Class	X 204	Chassis	AIRMATIC-AIRMATIC	SPC_204_X	A	A	A	A	A	A	A	0048, 0049, 0051
A11	C-Class	X 204	Body	CGW-Central gateway	CGW_204	•	•	•	•	•	•	0	
A11	C-Class	X 204	Body	EZS-Electronic ignition switch	EIS_204	•	•	•	•	•	•	0	
A11	C-Class	X 204	Body	KG-Keyless Go	KG_204	•	•	•	•	•	•	•	
A11	C-Class	X 204	Body	AB-Airbag	ORC_204	•	•	•	•	•	•		
A11	C-Class	X 204	Body	WSS-Weight sensing system	OCM_204	•	•	•	•	•	•	0	0005
A11	C-Class	X 204	Body	OCP-Overhead control panel	R00F_204	•	•	•	•	•	•	•	
A11	C-Class	X 204	Body	OCP-Control module 'Panoramic sliding sunroof'	TSSR_204	•	•	•	•	•	•		
A11	C-Class	X 204	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMF_204	•	•	•	•	•	•	•	
A11	C-Class	X 204	Body	REAR SAM-Rear signal acquisition and actuation module	SAMR_204	•	•	•	•	•	•	•	
A11	C-Class	X 204	Body	AHE-Trailer recognition	AAG221	•	•	•	•	•	•	•	
A11	C-Class	X 204	Body	MSS-Special vehicle multifunction control module	MPM_204	•	•	•	•	•	•	•	
A11	C-Class	X 204	Body	RevETR-LF-Left front reversible emergency tensioning retractor	RBTMFL_204	•	•	•	•	•	•	•	
A11	C-Class	X 204	Body	RevETR-RF-Right front reversible emergency tensioning retractor	RBTMFR_204	•	•	•	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	<u>lease re</u>	fer to the special f	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
A11	C-Class	X 204	Body	XALWA-L-Xenon headlamp, left	HLMLT_204	•	•	•	•	•	•	•	
A11	C-Class	X 204	Body	XALWA-L-Xenon headlamp, left	HLMLT_X204	•	•	•	•	•	•		
A11	C-Class	X 204	Body	XALWA-R-Xenon headlamp, right	HLMRT_204	•	•	•	•	•	•		
A11	C-Class	X 204	Body	XALWA-R-Xenon headlamp, right	HLMRT_X204	•	•	•	•	•	•		
A11	C-Class	X 204	Information and communication	ICM-Instrument cluster with maintenance interval display	IC_204	•	•	•	•	•	•	•	0002
A11	C-Class	X 204	Information and communication	PTS-Parktronic	PTS_204	•	•	•	•	•	•	•	
A11	C-Class	X 204	Information and communication	RFK-Backup camera	DRVM221	•	•	•	•	•	•	0	
A11	C-Class	X 204	Information and communication	SCM [MRM]-Steering column module	SCCM_204	•	•	•	•	•	•	•	
A11	C-Class	X 204	Information and communication	COMAND or AUDIO	HU_204	•	•	•	•	•	•		
A11	C-Class	X 204	Information and communication	COU [ZBE]-Central operating unit	CTRLC_204	•	•	•	•	•	•	•	
A11	C-Class	X 204	Information and communication	ZAN-Central display	DISPC_204	•	•	•	•	•	•		
A11	C-Class	X 204	Information and communication	TV-TV tuner	TVJP_204	•	•	•	•	•	•		
A11	C-Class	X 204	Information and communication	CTEL-Cellular telephone(JAPAN)	TELJP_204	•	•	•	•	•	•		
A11	C-Class	X 204	Information and communication	DAB-Digital radio	DAB_204	•	•	•	•	•	•		
A11	C-Class	X 204	Information and communication	SOUND- Sound system	SOUND_204	•	•	•	•	•	•		
A11	C-Class	X 204	Information and communication	SDAR-Satellite radio(Valid for USA)	SDAR221	•	•	•	•	•	•		
A11	C-Class	X 204	Information and communication	UCI	UCI_204	•	•	•	•	•	•	0	
A11	C-Class	X 204	Information and communication	AVE-H-Rear audio video unit	FU	•	•	•	•	•	•		
A11	C-Class	X 204	Information and communication	Left rear screen	DISP_RL	•	•	•	•	•	•		
A11	C-Class	X 204	Information and communication	Right rear screen	DISP_RR	•	•	•	•	•	•		
A11	C-Class	X 204	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
A11	C-Class	X 204	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease re	<u>fer to the special fi</u>	inction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
A11	C-Class	X 204	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
A11	C-Class	X 204	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
A11	C-Class	X 204	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
A11	C-Class	X 204	Seats and doors	DCM-FL-Door control module front left	DMFL_204	•	•	•	•	•	•	•	
A11	C-Class	X 204	Seats and doors	DCM-FR-Door control module front right	DMFR_204	•	•	•	•	•	•	•	
A11	C-Class	X 204	Seats and doors	DCM-RL-Door control module rear left	DMRL_204	•	•	•	•	•	•	•	
A11	C-Class	X 204	Seats and doors	DCM-RR-Door control module rear right	DMRR_204	•	•	•	•	•	•	•	
A11	C-Class	X 204	Seats and doors	HKS-Tailgate control	PTCM	•	•	•	•	•	•	•	
A11	C-Class	X 204	Seats and doors	ESA driver	SEATD_204	•	•	•	•	•	•	•	
A11	C-Class	X 204	Seats and doors	ESA passenger	SEATP_204	•	•	•	•	•	•	•	
A11	C-Class	X 204	Air conditioning	AAC-Air conditioning	HVAC_204	•	•	•	•	•	•	•	
Up to 05/2005	E-Class	211	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	XCPTA	•	•	•	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
Up to 05/2005	E-Class	211	Information and communication	AUDIO	XHU	•	•	•	•	•	•		0003
Up to 05/2005	E-Class	211	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	NAVI-Navigation system	XNAVIH	•	•	0	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
Up to 05/2005	E-Class	211	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
Up to 05/2005	E-Class	211	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	GPS box	XGPSB0X	•	•	0	•	•	•	0	
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease re	<u>fer to the special fu</u>	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
Up to 05/2005	E-Class	211	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
Up to 05/2005	E-Class	211	Information and communication	PTS-Parktronic system	PTS211MOPF	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Information and communication	COMAND or AUDIO	HU25	•	•	•	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	SOUND- Sound system	SOUND25	•	•	•	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	UCI	UCI25	•	•	•	•	•	•	0	
Up to 05/2005	E-Class	211	Information and communication	DAB-Digital radio	DAB25	•	•	•	•	•	0		
Up to 05/2005	E-Class	211	Information and communication	SDAR-Satellite radio(Valid for USA)	SDARS25	•	•	•	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	TV-TV tuner	TV25	•	•	•	•	•	•		
Up to 05/2005	E-Class	211	Information and communication	CTEL-Cellular telephone(JAPAN)	CBJ25	•	•	•	•	•	0		
Up to 05/2005	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver	SSGF211	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB211	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Seats and doors	DS-LF-Left front dynamic seat	FDSVL211	•	•	•	•	•	•	•	
Up to 05/2005	E-Class	211	Seats and doors	DS-RF-Right front dynamic seat	FDSVR211	•	•	•	•	•	•	•	
Up to 05/2005	E-Class	211	Seats and doors	DSP-Pneumatic pump for dynamic seat	PFDS211	•	•	•	•	•	•	•	
Up to 05/2005	E-Class	211	Seats and doors	HS-Seat heater	SHZ211	•	•	•	•	0	0	0	
Up to 05/2005	E-Class	211	Seats and doors	HS-Seat heater	SHZ164	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Seats and doors	DCM-FL-Door control module front left	TSGVL211	•	•	•	•	•	0	•	0003
Up to 05/2005	E-Class	211	Seats and doors	DCM-FR-Door control module front right	TSGVR211	•	•	•	•	•	0	•	0003
Up to 05/2005	E-Class	211	Seats and doors	DCM-RL-Door control module rear left	TSGHL211	•	•	•	•	•	0	•	0003
Up to 05/2005	E-Class	211	Seats and doors	DCM-RR-Door control module rear right	TSGHR211	•	•	•	•	•	0	•	0003
Up to 05/2005	E-Class	211	Seats and doors	TLC-Trunk lid control	HFS211	•	•	•	•	•	•	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for specia	l function p	lease re	<u>fer to the special</u>	function table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes		Freeze Frame	Active Test	Special Function
Up to 05/2005	E-Class	211	Seats and doors	LAE [LAA]-Loading floor automatically extendable	ALB211	•	•	•	•	•	•	•	
Up to 05/2005	E-Class	211	Seats and doors	RWT-Rear-end door control module	RWT211	•	•	•	•	•	0	•	
Up to 05/2005	E-Class	211	Seats and doors	TLC-Trunk lid control	HFSS211	•	•	•	•	•	•	•	
Up to 05/2005	E-Class	211	Air conditioning	AAC-Automatic air conditioning	KLA211	•	•	•	•	•	•	•	0009
Up to 05/2005	E-Class	211	Air conditioning	HSW-Heated steering wheel	LRK_211	•	•	•	•	•	•	•	0003 0005
Up to 05/2005	E-Class	211	Air conditioning	HSW-Heated steering wheel	SHZ164_1	•	•	•	•	•	0	*	
Up to 05/2005	E-Class	211	Air conditioning	STH-Stationary heater	STH211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Drive	SEQ-Sequentronic automated manual transmission	KSG	•	•	•	•	•	•		
From 06/2005 to 05/2006	E-Class	211	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	E-Class	211	Drive	DTR-Distronic	ARS210	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	E-Class	211	Drive	ME-SFI-Motor electronics	SIM4LSE	•	•	•	•	•	•	•	0013
From 06/2005 to 05/2006	E-Class	211	Drive	ME-SFI-Motor electronics	SIM4LDE	•	•	•	•	•	•	•	0013
From 06/2005 to 05/2006	E-Class	211	Drive	ME-SFI-Motor electronics	SIM4CNG	•	•	•	•	•	•	•	0004 0013
From 06/2005 to 05/2006	E-Class	211	Drive	ESM-Electronic selector module	EWM203	•	•	•	•	•	0	•	0003
From 06/2005 to 05/2006	E-Class	211	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
From 06/2005 to 05/2006	E-Class	211	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
From 06/2005 to 05/2006	E-Class	211	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
From 06/2005 to 05/2006	E-Class	211	Drive	CDI 3-Common Rail Diesel Injection3	CR3_UP	•	•	•	•	•	•	•	0019
From 06/2005 to 05/2006	E-Class	211	Drive	CDI 3-Common Rail Diesel Injection3	CR3	•	•	•	•	•	•	*	
From 06/2005 to 05/2006	E-Class	211	Drive	ETC-Electronic transmission control	EGS53	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Drive	CDI 4-Common Rail Diesel Injection	CR4	•	•	•	•	•	•	*	0013
From 06/2005 to 05/2006	E-Class	211	Drive	CDI5-Common Rail Diesel Injection(USA)	CR5_US07	•	•	•	•	•	•	•	0013
From 06/2005 to 05/2006	E-Class	211	Drive	CDI 5-Common Rail Diesel Injection	CR5	•	•	•	•	•	•		0013 0019 0022



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2005 to 05/2006	E-Class	211	Chassis	SBC-Sensotronic Brake Control	EHB_ASG_2	•	•	•	•	•	•		0006 0007 0008 0038 0039
From 06/2005 to 05/2006	E-Class	211	Chassis	SBC-Sensotronic Brake Control	EHB_ASG_1	•	•	•	•	•	•		0006 0007 0008 0038 0039
From 06/2005 to 05/2006	E-Class	211	Chassis	ESP-Electronic stability program	EHB_FSG	•	•	•	•	•	•	•	0014
From 06/2005 to 05/2006	E-Class	211	Chassis	ESP-Electronic stability program	SBC121_F	•	•	•	•	•	•	•	0014
From 06/2005 to 05/2006	E-Class	211	Chassis	AIRmatic	SLF211	•	•	•	•	•	0	*	0048, 0049, 0056
From 06/2005 to 05/2006	E-Class	211	Chassis	Suspension	EHNR211	•	•	•	•	•	•	*	0042
From 06/2005 to 05/2006	E-Class	211	Chassis	TPC-Tire pressure monitor	TPMLS	•	•	•	•	•	•	•	0005
From 06/2005 to 05/2006	E-Class	211	Body	CGW-Central gateway	ZGW211	•	•	•	•	0	0	0	0016 0017 0018
From 06/2005 to 05/2006	E-Class	211	Body	EZS-Electronic ignition switch	EZS211	•	•	•	•	•	0	*	0027 0028 0029 0030 0031 0032 0033 0034 0035 0036 0037
From 06/2005 to 05/2006	E-Class	211	Body	AB-Airbag	ARMADA	•	•	•	•	•	•	0	0003 0010 0041
From 06/2005 to 05/2006	E-Class	211	Body	WSS-Weight sensing system	WSS	•	•	•	•	•	•	0	0005
From 06/2005 to 05/2006	E-Class	211	Body	BCM-Battery control module	BSG211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Body	On board electrical system(voltage supply)	BSG2FLASH	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	E-Class	211	Body	System diagnosis(CAN)	SD211	•	•	•	•	•	•		
From 06/2005 to 05/2006	E-Class	211	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMV211	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	SAMB211	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH211	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Body	AHE-Trailer recognition	AAG211	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Body	MSS-Special vehicle multifunction control module	MSS203	•	•	•	•	•	0	•	0003
From 06/2005 to 05/2006	E-Class	211	Body	LCP-Lower control panel	UBF211	•	•	•	•	•	0		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	1	fer to the special fu	inction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2005 to 05/2006	E-Class	211	Body	UCP-Upper control panel	OBF211	•	•	•	•	•	0	•	0005
From 06/2005 to 05/2006	E-Class	211	Body	OCP-Overhead control panel	DBE211	•	•	•	•	•	0	•	0003 0011
From 06/2005 to 05/2006	E-Class	211	Body	RevETR-LF-Left front reversible emergency tensioning retractor	RGSL211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Body	RevETR-RF-Right front reversible emergency tensioning retractor	RGSR211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Body	HRA-Automatic headlamp range adjustment and headlamp control	ALWR211	•	•	•	•	•	0	•	0005 0009
From 06/2005 to 05/2006	E-Class	211	Body	On board electrical system(voltage supply)	BSG211_1	•	•	•	•	•	•		
From 06/2005 to 05/2006	E-Class	211	Information and communication	PTS-Parktronic system	PTS211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Information and communication	SCM [MRM]-Steering column module	MRM211	•	•	•	•	•	•	•	0005
From 06/2005 to 05/2006	E-Class	211	Information and communication	SCM [MRM]-Steering column module	MRM171	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Information and communication	IC-Instrument cluster	KI211	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Information and communication	ASSYST-Active Service System	WIA211	•	•	0	•	•	0	0	0001
From 06/2005 to 05/2006	E-Class	211	Information and communication	ASSYST PLUS-PLUS Active Service System	WR211	•	•	•	•	•	•	0	0002
From 06/2005 to 05/2006	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
From 06/2005 to 05/2006	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
From 06/2005 to 05/2006	E-Class	211	Information and communication	CTEL-Telecommunication for telematics services	XCP	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	E-Class	211	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	XCPTA	•	•	•	•	•	•		
From 06/2005 to 05/2006	E-Class	211	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	E-Class	211	Information and communication	AUDIO	XHU	•	•	•	•	•	•		0003
From 06/2005 to 05/2006	E-Class	211	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•		
From 06/2005 to 05/2006	E-Class	211	Information and communication	NAVI-Navigation system	XNAVIH	•	•	0	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	<u>function p</u>	lease re	fer to the special fo	unction table.									
Model year	Model	Model Series		System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2005 to 05/2006	E-Class	211	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
From 06/2005 to 05/2006	E-Class	211	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
From 06/2005 to 05/2006	E-Class	211	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•		
From 06/2005 to 05/2006	E-Class	211	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
From 06/2005 to 05/2006	E-Class	211	Information and communication	GPS box	XGPSBOX	•	•	0	•	•	•	0	
From 06/2005 to 05/2006	E-Class	211	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	E-Class	211	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
From 06/2005 to 05/2006	E-Class	211	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
From 06/2005 to 05/2006	E-Class	211	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
From 06/2005 to 05/2006	E-Class	211	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver	SSGF211	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB211	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DS-LF-Left front dynamic seat	FDSVL211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DS-RF-Right front dynamic seat	FDSVR211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DSP-Pneumatic pump for dynamic seat	PFDS211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	HS-Seat heater	SHZ211	•	•	•	•	0	0	0	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	HS-Seat heater	SHZ164	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DCM-FL-Door control module front left	TSGVL211	•	•	•	•	•	0	•	0003
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DCM-FR-Door control module front right	TSGVR211	•	•	•	•	•	0	•	0003



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

As for special	function p		fer to the special f	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	_	Active Test	Special Function
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DCM-RL-Door control module rear left	TSGHL211	•	•	•	•	•	0	•	0003
From 06/2005 to 05/2006	E-Class	211	Seats and doors	DCM-RR-Door control module rear right	TSGHR211	•	•	•	•	•	0	•	0003
From 06/2005 to 05/2006	E-Class	211	Seats and doors	TLC-Trunk lid control	HFS211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	LAE [LAA]-Loading floor automatically extendable	ALB211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	RWT-Rear-end door control module	RWT211	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	TLC-Trunk lid control	HFSS211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	E-Class	211	Seats and doors	ARWT-Automatic rear-end door	ARWT211	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	E-Class	211	Air conditioning	AAC-Automatic air conditioning	KLA211	•	•	•	•	•	•	•	0009
From 06/2005 to 05/2006	E-Class	211	Air conditioning	HSW-Heated steering wheel	LRK_211	•	•	•	•	•	•	•	0003 0005
From 06/2005 to 05/2006	E-Class	211	Air conditioning	HSW-Heated steering wheel	SHZ164_1	•	•	•	•	•	0	*	
From 06/2005 to 05/2006	E-Class	211	Air conditioning	STH-Stationary heater	STH211	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Drive	ETC-Electronic transmission control	EGS53	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Drive	SEQ-Sequentronic automated manual transmission	KSG	•	•	•	•	•	•		
As of 06/2006	E-Class	211	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
As of 06/2006	E-Class	211	Drive	DTR-Distronic	ARS210	•	•	•	•	•	•	0	
As of 06/2006	E-Class	211	Drive	ME-SFI-Motor electronics	SIM4LSE	•	•	•	•	•	•	•	0013
As of 06/2006	E-Class	211	Drive	ME-SFI-Motor electronics	SIM4LDE	•	•	•	•	•	•	•	0013
As of 06/2006	E-Class	211	Drive	ME-SFI-Motor electronics	SIM4CNG	•	•	•	•	•	•	•	0004 0013
As of 06/2006	E-Class	211	Drive	ESM-Electronic selector module	EWM203	•	•	•	•	•	0	•	0003
As of 06/2006	E-Class	211	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
As of 06/2006	E-Class	211	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	ME97AMG	•	•	•	•	•	•	•	0004 0013
As of 06/2006	E-Class	211	Drive	FSCU Right-Control unit 'Right fuel pump'	FSCM_AMG_DB_ A_2	•	•	•	•	•	•		
As of 06/2006	E-Class	211	Drive	FSCU Left-Control unit 'Left fuel pump'	FSCM_AMG_DB_ B_2	•	•	•	•	•	•		
As of 06/2006	E-Class	211	Drive	CDID-Common Rail Diesel Injection	CRD	•	•	•	•	•	•		0013 0019 0020 0021



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	<u>l function p</u>	<u>lease re</u>	fer to the special f	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes		Freeze Frame	Active Test	Special Function
As of 06/2006	E-Class	211	Drive	CDI 4-Common Rail Diesel Injection	CR4	•	•	•	•	•	•	*	0013
As of 06/2006	E-Class	211	Drive	CDI5-Common Rail Diesel Injection(USA)	CR5_US07	•	•	•	•	•	•	•	0013
As of 06/2006	E-Class	211	Drive	CDI 5-Common Rail Diesel Injection	CR5	•	•	•	•	•	•		0013 0019 0022
As of 06/2006	E-Class	211	Chassis	ABR-Adaptive Brake	SBC211	•	•	•	•	•	•	•	0014 0015
As of 06/2006	E-Class	211	Chassis	AIRmatic	SLF211	•	•	•	•	•	0	*	0048, 0049, 0056
As of 06/2006	E-Class	211	Chassis	Suspension	EHNR211	•	•	•	•	•	•	*	0042
As of 06/2006	E-Class	211	Chassis	TPC-Tire pressure monitor	TPMLS	•	•	•	•	•	•	•	0005
As of 06/2006	E-Class	211	Body	CGW-Central gateway	ZGW211	•	•	•	•	0	0	0	0016 0017 0018
As of 06/2006	E-Class	211	Body	EZS-Electronic ignition switch	EZS211	•	•	•	•	•	0	*	0027 0028 0029 0030 0031 0032 0033 0034 0035 0036 0037
As of 06/2006	E-Class	211	Body	AB-Airbag	ARMADA	•	•	•	•	•	•	0	0003 0010 0041
As of 06/2006	E-Class	211	Drive	ME-SFI-Motor electronics	SIM4CNG_NCV3	•	•	•	•	•	•	•	0013
As of 06/2006	E-Class	211	Body	WSS-Weight sensing system	WSS	•	•	•	•	•	•	0	0005
As of 06/2006	E-Class	211	Body	System diagnosis(CAN)	SD211	•	•	•	•	•	•		
As of 06/2006	E-Class	211	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMV211	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	SAMB211	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH211	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Body	AHE-Trailer recognition	AAG211	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Body	MSS-Special vehicle multifunction control module	MSS203	•	•	•	•	•	0	•	0003
As of 06/2006	E-Class	211	Body	LCP-Lower control panel	UBF211	•	•	•	•	•	0		
As of 06/2006	E-Class	211	Body	UCP-Upper control panel	OBF211	•	•	•	•	•	0	•	0005
As of 06/2006	E-Class	211	Body	OCP-Overhead control panel	DBE211	•	•	•	•	•	0	•	0003 0011
As of 06/2006	E-Class	211	Body	RevETR-LF-Left front reversible emergency tensioning retractor	RGSL211	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Body	RevETR-RF-Right front reversible emergency tensioning retractor	RGSR211	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Body	XALWA-L-Xenon headlamp, left	XALWA211_L	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Body	XALWA-R-Xenon headlamp, right	XALWA211_R	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Information and communication	PTS-Parktronic system	PTS211MOPF	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Information and communication	SCM [MRM]-Steering column module	MRM211	•	•	•	•	•	•	•	0005



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	l function p	lease re	fer to the special f	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 06/2006	E-Class	211	Information and communication	SCM [MRM]-Steering column module	MRM171	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Information and communication	IC-Instrument cluster	KI211	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Information and communication	ASSYST-Active Service System	WIA211	•	•	0	•	•	0	0	0001
As of 06/2006	E-Class	211	Information and communication	ASSYST PLUS-PLUS Active Service System	WR211	•	•	•	•	•	•	0	0002
As of 06/2006	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
As of 06/2006	E-Class	211	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
As of 06/2006	E-Class	211	Information and communication	CTEL-Telecommunication for telematics services	XCP	•	•	•	•	•	•	0	
As of 06/2006	E-Class	211	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	XCPTA	•	•	•	•	•	•		0010
As of 06/2006	E-Class	211	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
As of 06/2006	E-Class	211	Information and communication	AUDIO	XHU	•	•	•	•	•	•		0003
As of 06/2006	E-Class	211	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•		
As of 06/2006	E-Class	211	Information and communication	NAVI-Navigation system	XNAVIH	•	•	0	•	•	•		
As of 06/2006	E-Class	211	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
As of 06/2006	E-Class	211	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
As of 06/2006	E-Class	211	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•		
As of 06/2006	E-Class	211	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
As of 06/2006	E-Class	211	Information and communication	GPS box	XGPSB0X	•	•	0	•	•	•	0	
As of 06/2006	E-Class	211	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
As of 06/2006	E-Class	211	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
As of 06/2006	E-Class	211	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	l function p	lease re	fer to the special f	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
As of 06/2006	E-Class	211	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
As of 06/2006	E-Class	211	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
As of 06/2006	E-Class	211	Information and communication	COMAND or AUDIO	HU25	•	•	•	•	•	•		
As of 06/2006	E-Class	211	Information and communication	SOUND- Sound system	SOUND25	•	•	•	•	•	•		
As of 06/2006	E-Class	211	Information and communication	UCI	UCI25	•	•	•	•	•	•	0	
As of 06/2006	E-Class	211	Information and communication	DAB-Digital radio	DAB25	•	•	•	•	•	0		
As of 06/2006	E-Class	211	Information and communication	SDAR-Satellite radio(Valid for USA)	SDARS25	•	•	•	•	•	•		
As of 06/2006	E-Class	211	Information and communication	TV-TV tuner	TV25	•	•	•	•	•	•		
As of 06/2006	E-Class	211	Information and communication	CTEL-Cellular telephone(JAPAN)	СВЈ25	•	•	•	•	•	0		
As of 06/2006	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver		•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB211	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Seats and doors	DS-LF-Left front dynamic seat	FDSVL211	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Seats and doors	DS-RF-Right front dynamic seat	FDSVR211	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Seats and doors	DSP-Pneumatic pump for dynamic seat	PFDS211	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Seats and doors	HS-Seat heater	SHZ211	•	•	•	•	0	0	0	
As of 06/2006	E-Class	211	Seats and doors	HS-Seat heater	SHZ164	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Seats and doors	DCM-FL-Door control module front left	TSGVL211	•	•	•	•	•	0	•	0003
As of 06/2006	E-Class	211	Seats and doors	DCM-FR-Door control module front right	TSGVR211	•	•	•	•	•	0	•	0003
As of 06/2006	E-Class	211	Seats and doors	DCM-RL-Door control module rear left	TSGHL211	•	•	•	•	•	0	•	0003
As of 06/2006	E-Class	211	Seats and doors	DCM-RR-Door control module rear right	TSGHR211	•	•	•	•	•	0	•	0003
As of 06/2006	E-Class	211	Seats and doors	TLC-Trunk lid control	HFS211	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Seats and doors	LAE [LAA]-Loading floor automatically extendable	ALB211	•	•	•	•	•	•	•	
As of 06/2006	E-Class	211	Seats and doors	RWT-Rear-end door control module	RWT211	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Seats and doors	TLC-Trunk lid control	HFSS211	•	•	•	•	•	•	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special i	unction p.	lease re	fer to the special fu	inction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	_	Active Test	Special Function
As of 06/2006	E-Class	211	Seats and doors	ARWT-Automatic rear-end door	ARWT211	•	•	•	•	•	0	•	
As of 06/2006	E-Class	211	Air conditioning	AAC-Automatic air conditioning	KLA211	•	•	•	•	•	•	•	0009
As of 06/2006	E-Class	211	Air conditioning	HSW-Heated steering wheel	LRK_211	•	•	•	•	•	•	•	0003 0005
As of 06/2006	E-Class	211	Air conditioning	HSW-Heated steering wheel	SHZ164_1	•	•	•	•	•	0	*	
As of 06/2006	E-Class	211	Air conditioning	STH-Stationary heater	STH211	•	•	•	•	•	•	•	
As of 03/97 DAS 3	E-Class	210	Drive	ETC-Electronic transmission control	EGS_H	•	•	0	•		*		
As of 03/97 DAS 3	E-Class	210	Drive	ETC-Electronic transmission control	EGS	•	•	0	•	•	*	•	
As of 03/97 DAS 3	E-Class	210	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
As of 03/97 DAS 3	E-Class	210	Drive	ESM-Electronic selector module	EWM210	•	•	0	•	•	*	•	
As of 03/97 DAS 3	E-Class	210	Drive	HFM-SFI-Hot film engine management	HFM_H	•	•	0	•		*		
As of 03/97 DAS 3	E-Class	210	Drive	ME2-SFI-Motor electronics 2	ME2_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Drive	ME-SFI-Motor electronics	SIM4	•	•	•	•	•	•	•	0013
As of 03/97 DAS 3	E-Class	210	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
As of 03/97 DAS 3	E-Class	210	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
As of 03/97 DAS 3	E-Class	210	Drive	DFI-Electronic distributor injection system diesel	EVE_H	•	•	0	•		*		
As of 03/97 DAS 3	E-Class	210	Drive	IFI-Electronic in-line injection system diesel	ERE_H	•	•	0	•		*		
As of 03/97 DAS 3	E-Class	210	Drive	CDI-Common Rail Diesel Injection	CR1_H	•	•	0	•		*		
As of 03/97 DAS 3	E-Class	210	Drive	CDI 2-Common Rail Diesel Injection	CR2	•	•	•	•	•	•	*	
As of 03/97 DAS 3	E-Class	210	Chassis	ABS-Antilock brake system	ABS30_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Chassis	ASR-Acceleration Slip Regulation	ASR34_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Chassis	ESP-Electronic stability program	ESP35_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Chassis	ESP-Electronic stability program	ESP203	•	•	•	•	•	•	0	0047
As of 03/97 DAS 3	E-Class	210	Chassis	ASR-Acceleration Slip Regulation	ASR30_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Chassis	ESP-Electronic stability program	ESP30_H	•	•	0	•	•	*		0040
As of 03/97 DAS 3	E-Class	210	Chassis	ETS-Electronic traction system	ETS30_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Chassis	ESP-Electronic stability program	ESP34_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Chassis	ETS-Electronic traction system	ETS34_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Chassis	BAS-Brake assist	BAS_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Chassis	BAS-Brake assist	BAS203	•	•	0	•	•	•	0	
As of 03/97 DAS 3	E-Class	210	Chassis	SPS-Speed-sensitive power steering	PL2_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Chassis	TPC-Tire pressure monitor	RDK210	•	•	•	•	•	*	•	0005 0009
As of 03/97 DAS 3	E-Class	210	Chassis	VP-Vacuum pump brake booster	UP28	•	•	•	•	•	•	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p.	lease rei	<u>fer to the special fu</u>	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 03/97 DAS 3	E-Class	210	Body	AB-Airbag	ARMIN	•	•	0	•	•	*	0	
As of 03/97 DAS 3	E-Class	210	Body	AB-Airbag	ZAE_H	•	•	0	•		*		
As of 03/97 DAS 3	E-Class	210	Body	EZS-Electronic ignition switch	EZS1_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Body	OCP-Overhead control panel	DBE1_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Body	LCP-Lower control panel	UBF1_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Body	PSE-Pneumatic system equipment	PSE1_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Body	SAM-Signal acquisition and actuation module	SAM1_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Body	MSS-Special vehicle multifunction control module	MSS1_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Body	HRA-Headlamp range adjustment	LWR1_H	•	•	0	•		*		
As of 03/97 DAS 3	E-Class	210	Body	HRA-Headlamp range adjustment	LWR2_H	•	•	0	•	•	0		
As of 03/97 DAS 3	E-Class	210	Body	APS-Auto pilot system	APS_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Body	HB-Heater booster	ZUH_H	•	•	0	•		*		
As of 03/97 DAS 3	E-Class	210	Information and communication	ICM-Instrument cluster with maintenance interval display	KIW_H	•	•	0	•	•	*	•	0002
As of 03/97 DAS 3	E-Class	210	Information and communication	ICM-Instrument cluster with maintenance interval display	KIL	•	•	•	•	•	•		0002
As of 03/97 DAS 3	E-Class	210	Information and communication	COMAND	COMAND	•	•	0	•	•	•	•	
As of 03/97 DAS 3	E-Class	210	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
As of 03/97 DAS 3	E-Class	210	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	0	
As of 03/97 DAS 3	E-Class	210	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		
As of 03/97 DAS 3	E-Class	210	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
As of 03/97 DAS 3	E-Class	210	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
As of 03/97 DAS 3	E-Class	210	Information and communication	ICS-Information and communication system	ICS_H	•	•	0	•		*		
As of 03/97 DAS 3	E-Class	210	Information and communication	PTS-Parktronic system	PTS163	•	•	•	•	•	*	•	
As of 03/97 DAS 3	E-Class	210	Information and communication	TV-TV tuner	TV	•	•	•	•		•	•	
As of 03/97 DAS 3	E-Class	210	Information and communication	TELE AID-Emergency call system	ECALLECE	•	•	•	•	•	•		
As of 03/97 DAS 3	E-Class	210	Information and communication	TELE AID-Telematic system	AID_H	•	•	0	•		•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

Model year	Model	Mode1	Control Unit	System Name	DiagName	Ecu	Read				Freeze		Special
·		Series	Groups Information and			Info.	Codes	Memory				Test	Function
As of 03/97 DAS 3	E-Class	210	communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
As of 03/97 DAS 3	E-Class	210	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
As of 03/97 DAS 3	E-Class	210	Information and communication	DN-Dynamic navigation by means of CTEL	TELEDZS	•	•	•	•	•	0	0	
As of 03/97 DAS 3	E-Class	210	Seats and doors	DCM1-Door control module front driver side	TSGVL_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Seats and doors	DCM2-Door control module front passenger side	TSGVR_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Seats and doors	DCM3-Door control module rear driver side	TSGHL_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Seats and doors	DCM4-Door control module rear passenger side	TSGHR_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Seats and doors	ESA-FL-Electric seat adjustment front left	ESV1L_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Seats and doors	ESA-FR-Electric seat adjustment front right	ESV1R_H	•	•	0	•	•	*		
As of 03/97 DAS 3	E-Class	210	Air conditioning	TAC-Automatic temperature control	TAU_H	•	•	0	•		*	•	
As of 03/97 DAS 3	E-Class	210	Air conditioning	AAC-Automatic air conditioning	KLA_H	•	•	0	•		*		
As of 03/97 DAS 3	E-Class	210	Air conditioning	STH-Stationary heater	STH_H	•	•	0	•	•	*		
Up to 05/2005	CLS	219	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Drive	SEQ-Sequentronic automated manual transmission	KSG	•	•	•	•	•	•		
Up to 05/2005	CLS	219	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
Up to 05/2005	CLS	219	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
Up to 05/2005	CLS	219	Drive	DTR-Distronic	ARS210	•	•	•	•	•	•	0	
Up to 05/2005	CLS	219	Drive	ESM-Electronic selector module	EWM203	•	•	•	•	•	0	•	0003
Up to 05/2005	CLS	219	Drive	MED 9.7-Motor electronics for direct injection 9.7	MED97	•	•	•	•	•	•	*	0013
Up to 05/2005	CLS	219	Drive	FSCU-Fuel pump	FSCM219	•	•	•	•	0	•		
Up to 05/2005	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
Up to 05/2005	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
Up to 05/2005	CLS	219	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	ME97AMG	•	•	•	•	•	•	•	0004 0013
Up to 05/2005	CLS	219	Drive	FSCU Right-Control unit 'Right fuel pump'	FSCM_AMG_DB_ A_2	•	•	•	•	•	•		
Up to 05/2005	CLS	219	Drive	FSCU Left-Control unit 'Left fuel pump'	FSCM_AMG_DB_ B_2	•	•	•	•	•	•		
Up to 05/2005	CLS	219	Drive	CDI 4-Common Rail Diesel Injection	CR4	•	•	•	•	•	•	*	0013



NOTES:

• This function is supported.

- ▲ This function is the new feature in this version.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p.	lease rei	<u>fer to the special f</u>	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes		Erase Codes		Freeze Frame	Active Test	Function
Up to 05/2005	CLS	219	Chassis	SBC-Sensotronic Brake Control	EHB_ASG_2	•	•	•	•	•	•		0006 0007 0008 0038 0039
Up to 05/2005	CLS	219	Chassis	ESP-Electronic stability program	SBC121_F	•	•	•	•	•	•	•	0014
Up to 05/2005	CLS	219	Chassis	AIRmatic	SLF211	•	•	•	•	•	0	*	0048, 0049, 0056
Up to 05/2005	CLS	219	Chassis	TPC-Tire pressure monitor	RDK211	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Chassis	TPC-Tire pressure monitor	TPMLS	•	•	•	•	•	•	•	0005
Up to 05/2005	CLS	219	Body	CGW-Central gateway	ZGW211	•	•	•	•	0	0	0	0016 0017 0018
Up to 05/2005	CLS	219	Body	EZS-Electronic ignition switch	EZS211	•	•	•	•	•	0	*	0027 0028 0029 0030 0031 0032 0033 0034 0035 0036 0037
Up to 05/2005	CLS	219	Body	AB-Airbag	ARMADA	•	•	•	•	•	•	0	0003 0010 0041
Up to 05/2005	CLS	219	Body	WSS-Weight sensing system	WSS	•	•	•	•	•	•	0	0005
Up to 05/2005	CLS	219	Body	BCM-Battery control module	BSG211	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Body	System diagnosis(CAN)	SD211	•	•	•	•	•	•		
Up to 05/2005	CLS	219	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMV211	•	•	•	•	•	0	•	
Up to 05/2005	CLS	219	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	SAMB211	•	•	•	•	•	0	•	
Up to 05/2005	CLS	219	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH211	•	•	•	•	•	0	•	
Up to 05/2005	CLS	219	Body	LCP-Lower control panel	UBF211	•	•	•	•	•	0		
Up to 05/2005	CLS	219	Body	UCP-Upper control panel	OBF211	•	•	•	•	•	0	•	0005
Up to 05/2005	CLS	219	Body	OCP-Overhead control panel	DBE211	•	•	•	•	•	0	•	0003 0011
Up to 05/2005	CLS	219	Body	RevETR-LF-Left front reversible emergency tensioning retractor	RGSL211	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Body	RevETR-RF-Right front reversible emergency tensioning retractor	RGSR211	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Body	HRA-Automatic headlamp range adjustment and headlamp control	ALWR211	•	•	•	•	•	0	•	0005 0009
Up to 05/2005	CLS	219	Body	On board electrical system(voltage supply)	BSG211_1	•	•	•	•	•	•		
Up to 05/2005	CLS	219	Information and communication	PTS-Parktronic system	PTS211	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Information and communication	SCM [MRM]-Steering column module	MRM171	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Information and communication	IC-Instrument cluster	KI211	•	•	•	•	•	0	•	
Up to 05/2005	CLS	219	Information and communication	ASSYST-Active Service System	WIA211	•	•	0	•	•	0	0	0001



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	<u>lease re</u>	fer to the special fo	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes		Freeze Frame	Active Test	Special Function
Up to 05/2005	CLS	219	Information and communication	ASSYST PLUS-PLUS Active Service System	WR211	•	•	•	•	•	•	0	0002
Up to 05/2005	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
Up to 05/2005	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
Up to 05/2005	CLS	219	Information and communication	AUDIO	XHU	•	•	•	•	•	•		0003
Up to 05/2005	CLS	219	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•		
Up to 05/2005	CLS	219	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
Up to 05/2005	CLS	219	Information and communication	NAVI-Navigation system	XNAVIH	•	•	0	•	•	•		
Up to 05/2005	CLS	219	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	0010
Up to 05/2005	CLS	219	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
Up to 05/2005	CLS	219	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•		
Up to 05/2005	CLS	219	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
Up to 05/2005	CLS	219	Information and communication	GPS box	XGPSB0X	•	•	0	•	•	•	0	
Up to 05/2005	CLS	219	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
Up to 05/2005	CLS	219	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
Up to 05/2005	CLS	219	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
Up to 05/2005	CLS	219	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
Up to 05/2005	CLS	219	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
Up to 05/2005	CLS	219	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164	•	•	•	•	•	0	•	
Up to 05/2005	CLS	219	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164	•	•	•	•	•	0	•	
Up to 05/2005	CLS	219	Seats and doors	DS-LF-Left front dynamic seat	FDSVL211	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Seats and doors	DS-RF-Right front dynamic seat	FDSVR211	•	•	•	•	•	•	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease re	<u>fer to the special f</u>	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 05/2005	CLS	219	Seats and doors	DSP-Pneumatic pump for dynamic seat	PFDS211	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Seats and doors	HS-Seat heater	SHZ164	•	•	•	•	•	0	•	
Up to 05/2005	CLS	219	Seats and doors	DCM-FL-Door control module front left	TSGVL211	•	•	•	•	•	0	•	0003
Up to 05/2005	CLS	219	Seats and doors	DCM-FR-Door control module front right	TSGVR211	•	•	•	•	•	0	•	0003
Up to 05/2005	CLS	219	Seats and doors	DCM-RL-Door control module rear left	TSGHL211	•	•	•	•	•	0	•	0003
Up to 05/2005	CLS	219	Seats and doors	DCM-RR-Door control module rear right	TSGHR211	•	•	•	•	•	0	•	0003
Up to 05/2005	CLS	219	Seats and doors	TLC-Trunk lid control	HFS211	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Seats and doors	LAE [LAA]-Loading floor automatically extendable	ALB211	•	•	•	•	•	•	•	
Up to 05/2005	CLS	219	Seats and doors	RWT-Rear-end door control module	RWT211	•	•	•	•	•	0	•	
Up to 05/2005	CLS	219	Air conditioning	AAC-Automatic air conditioning	KLA211	•	•	•	•	•	•	•	0009
Up to 05/2005	CLS	219	Air conditioning	HSW-Heated steering wheel	SHZ164_1	•	•	•	•	•	0	*	
Up to 05/2005	CLS	219	Air conditioning	STH-Stationary heater	STH211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219	Drive	SEQ-Sequentronic automated manual transmission	KSG	•	•	•	•	•	•		
From 06/2005 to 05/2006	CLS	219	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	CLS	219	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
From 06/2005 to 05/2006	CLS	219	Drive	DTR-Distronic	ARS210	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	CLS	219	Drive	ESM-Electronic selector module	EWM203	•	•	•	•	•	0	•	0003
From 06/2005 to 05/2006	CLS	219	Drive	MED 9.7-Motor electronics for direct injection 9.7	MED97	•	•	•	•	•	•	*	0013
From 06/2005 to 05/2006	CLS	219	Drive	FSCU-Fuel pump	FSCM219	•	•	•	•	0	•		
From 06/2005 to 05/2006	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
From 06/2005 to 05/2006	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
From 06/2005 to 05/2006	CLS	219	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	ME97AMG	•	•	•	•	•	•	•	0004 0013
From 06/2005 to 05/2006	CLS	219	Drive	FSCU Right-Control unit 'Right fuel pump'	FSCM_AMG_DB_ A_2	•	•	•	•	•	•		
From 06/2005 to 05/2006	CLS	219	Drive	FSCU Left-Control unit 'Left fuel pump'	FSCM_AMG_DB_ B_2	•	•	•	•	•	•		



NOTES:

This function is supported.

▲ This function is the new feature in this version.

As for special	function p		fer to the special f	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2005 to 05/2006	CLS	219	Drive	CDI 4-Common Rail Diesel Injection	CR4	•	•	•	•	•	•	*	0013
From 06/2005 to 05/2006	CLS	219	Chassis	SBC-Sensotronic Brake Control	EHB_ASG_2	•	•	•	•	•	•		0006 0007 0008 0038 0039
From 06/2005 to 05/2006	CLS	219	Chassis	ESP-Electronic stability program	SBC121_F	•	•	•	•	•	•	•	0014
From 06/2005 to 05/2006	CLS	219	Chassis	AIRmatic	SLF211	•	•	•	•	•	0	*	0048, 0049, 0056
From 06/2005 to 05/2006	CLS	219	Chassis	TPC-Tire pressure monitor	TPMLS	•	•	•	•	•	•	•	0005
From 06/2005 to 05/2006	CLS	219	Body	CGW-Central gateway	ZGW211	•	•	•	•	0	0	0	0016 0017 0018
From 06/2005 to 05/2006	CLS	219	Body	EZS-Electronic ignition switch	EZS211	•	•	•	•	•	0	*	0027 0028 0029 0030 0031 0032 0033 0034 0035 0036 0037
From 06/2005 to 05/2006	CLS	219	Body	AB-Airbag	ARMADA	•	•	•	•	•	•	0	0003 0010 0041
From 06/2005 to 05/2006	CLS	219	Body	WSS-Weight sensing system	WSS	•	•	•	•	•	•	0	0005
From 06/2005 to 05/2006	CLS	219	Body	BCM-Battery control module	BSG211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219	Body	System diagnosis(CAN)	SD211	•	•	•	•	•	•		
From 06/2005 to 05/2006	CLS	219	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMV211	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	CLS	219	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	SAMB211	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	CLS	219	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH211	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	CLS	219	Body	LCP-Lower control panel	UBF211	•	•	•	•	•	0		
From 06/2005 to 05/2006	CLS	219	Body	UCP-Upper control panel	0BF211	•	•	•	•	•	0	•	0005
From 06/2005 to 05/2006	CLS	219	Body	OCP-Overhead control panel	DBE211	•	•	•	•	•	0	•	0003 0011
From 06/2005 to 05/2006	CLS	219	Body	RevETR-LF-Left front reversible emergency tensioning retractor	RGSL211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219	Body	RevETR-RF-Right front reversible emergency tensioning retractor	RGSR211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219	Body	HRA-Automatic headlamp range adjustment and headlamp control	ALWR211	•	•	•	•	•	0	•	0005 0009



NOTES:

This function is supported.

▲ This function is the new feature in this version.

As for special	function p		fer to the special f	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2005 to 05/2006	CLS	219	Body	On board electrical system(voltage supply)	BSG211_1	•	•	•	•	•	•		
From 06/2005 to 05/2006	CLS	219	Information and communication	PTS-Parktronic system	PTS211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219	Information and communication	SCM [MRM]-Steering column module	MRM171	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219	Information and communication	IC-Instrument cluster	KI211	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	CLS	219	Information and communication	ASSYST-Active Service System	WIA211	•	•	0	•	•	0	0	0001
From 06/2005 to 05/2006	CLS	219	Information and communication	ASSYST PLUS-PLUS Active Service System	WR211	•	•	•	•	•	•	0	0002
From 06/2005 to 05/2006	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
From 06/2005 to 05/2006	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
From 06/2005 to 05/2006	CLS	219	Information and communication	AUDIO	XHU	•	•	•	•	•	•		0003
From 06/2005 to 05/2006	CLS	219	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•		
From 06/2005 to 05/2006	CLS	219	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	CLS	219	Information and communication	NAVI-Navigation system	XNAVIH	•	•	0	•	•	•		
From 06/2005 to 05/2006	CLS	219	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	0010
From 06/2005 to 05/2006	CLS	219	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
From 06/2005 to 05/2006	CLS	219	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•		
From 06/2005 to 05/2006	CLS	219	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
From 06/2005 to 05/2006	CLS	219	Information and communication	GPS box	XGPSBOX	•	•	0	•	•	•	0	
From 06/2005 to 05/2006	CLS	219	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
From 06/2005 to 05/2006	CLS	219	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
From 06/2005 to 05/2006	CLS	219	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

AS TOT Special I	tunetion p.	rease re.	ter to the special it	metron tabre.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2005 to 05/2006	CLS	219	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
From 06/2005 to 05/2006	CLS	219	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
From 06/2005 to 05/2006	CLS	219	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	CLS	219	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	CLS	219	Seats and doors	DS-LF-Left front dynamic seat	FDSVL211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219	Seats and doors	DS-RF-Right front dynamic seat	FDSVR211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219	Seats and doors	DSP-Pneumatic pump for dynamic seat	PFDS211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219	Seats and doors	HS-Seat heater	SHZ164	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	CLS	219	Seats and doors	DCM-FL-Door control module front left	TSGVL211	•	•	•	•	•	0	•	0003
From 06/2005 to 05/2006	CLS	219	Seats and doors	DCM-FR-Door control module front right	TSGVR211	•	•	•	•	•	0	•	0003
From 06/2005 to 05/2006	CLS	219	Seats and doors	DCM-RL-Door control module rear left	TSGHL211	•	•	•	•	•	0	•	0003
From 06/2005 to 05/2006	CLS	219	Seats and doors	DCM-RR-Door control module rear right	TSGHR211	•	•	•	•	•	0	•	0003
From 06/2005 to 05/2006	CLS	219	Seats and doors	TLC-Trunk lid control	HFS211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219	Seats and doors	LAE [LAA]-Loading floor automatically extendable	ALB211	•	•	•	•	•	•	•	
From 06/2005 to 05/2006	CLS	219	Seats and doors	RWT-Rear-end door control module	RWT211	•	•	•	•	•	0	•	
From 06/2005 to 05/2006	CLS	219	Air conditioning	AAC-Automatic air conditioning	KLA211	•	•	•	•	•	•	•	0009
From 06/2005 to 05/2006	CLS	219	Air conditioning	HSW-Heated steering wheel	SHZ164_1	•	•	•	•	•	0	*	
From 06/2005 to 05/2006	CLS	219	Air conditioning	STH-Stationary heater	STH211	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Drive	SEQ-Sequentronic automated manual transmission	KSG	•	•	•	•	•	•		
As of 06/2006	CLS	219	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
As of 06/2006	CLS	219	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
As of 06/2006	CLS	219	Drive	DTR-Distronic	ARS210	•	•	•	•	•	•	0	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	<u>function p</u>	<u>lease re</u>	<u>fer to the special f</u>	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 06/2006	CLS	219	Drive	ESM-Electronic selector module	EWM203	•	•	•	•	•	0	•	0003
As of 06/2006	CLS	219	Drive	MED 9.7-Motor electronics for direct injection 9.7	MED97	•	•	•	•	•	•	*	0013
As of 06/2006	CLS	219	Drive	FSCU-Fuel pump	FSCM219	•	•	•	•	0	•		
As of 06/2006	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
As of 06/2006	CLS	219	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
As of 06/2006	CLS	219	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	ME97AMG	•	•	•	•	•	•	•	0004 0013
As of 06/2006	CLS	219	Drive	FSCU Right-Control unit 'Right fuel pump'	FSCM_AMG_DB_ A_2	•	•	•	•	•	•		
As of 06/2006	CLS	219	Drive	FSCU Left-Control unit 'Left fuel pump'	FSCM_AMG_DB_ B_2	•	•	•	•	•	•		
As of 06/2006	CLS	219	Drive	CDI 4-Common Rail Diesel Injection	CR4	•	•	•	•	•	•	*	0013
As of 06/2006	CLS	219	Chassis	ABR-Adaptive Brake	SBC211	•	•	•	•	•	•	•	0014 0015
As of 06/2006	CLS	219	Chassis	AIRmatic	SLF211	•	•	•	•	•	0	*	0048, 0049, 0056
As of 06/2006	CLS	219	Chassis	TPC-Tire pressure monitor	TPMLS	•	•	•	•	•	•	•	0005
As of 06/2006	CLS	219	Body	CGW-Central gateway	ZGW211	•	•	•	•	0	0	0	0016 0017 0018
As of 06/2006	CLS	219	Body	EZS-Electronic ignition switch	EZS211	•	•	•	•	•	0	*	0027 0028 0029 0030 0031 0032 0033 0034 0035 0036 0037
As of 06/2006	CLS	219	Body	AB-Airbag	ARMADA	•	•	•	•	•	•	0	0003 0010 0041
As of 06/2006	CLS	219	Body	WSS-Weight sensing system	WSS	•	•	•	•	•	•	0	0005
As of 06/2006	CLS	219	Body	System diagnosis(CAN)	SD211	•	•	•	•	•	•		
As of 06/2006	CLS	219	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMV211	•	•	•	•	•	0	•	
As of 06/2006	CLS	219	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	SAMB211	•	•	•	•	•	0	•	
As of 06/2006	CLS	219	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH211	•	•	•	•	•	0	•	
As of 06/2006	CLS	219	Body	LCP-Lower control panel	UBF211	•	•	•	•	•	0		
As of 06/2006	CLS	219	Body	UCP-Upper control panel	OBF211	•	•	•	•	•	0	•	0005
As of 06/2006	CLS	219	Body	OCP-Overhead control panel	DBE211	•	•	•	•	•	0	•	0003 0011
As of 06/2006	CLS	219	Body	RevETR-LF-Left front reversible emergency tensioning retractor	RGSL211	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Body	RevETR-RF-Right front reversible emergency tensioning retractor	RGSR211	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Body	HRA-Automatic headlamp range adjustment and headlamp control	ALWR211	•	•	•	•	•	0	•	0005 0009



NOTES:

This function is supported.

▲ This function is the new feature in this version.

As for special	l function p	olease re	fer to the special f	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 06/2006	CLS	219	Information and communication	PTS-Parktronic system	PTS211	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Information and communication	PTS-Parktronic system	PTS211MOPF	•	•	•	•	•	0	•	
As of 06/2006	CLS	219	Information and communication	SCM [MRM]-Steering column module	MRM171	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Information and communication	IC-Instrument cluster	KI211	•	•	•	•	•	0	•	
As of 06/2006	CLS	219	Information and communication	ASSYST-Active Service System	WIA211	•	•	0	•	•	0	0	0001
As of 06/2006	CLS	219	Information and communication	ASSYST PLUS-PLUS Active Service System	WR211	•	•	•	•	•	•	0	0002
As of 06/2006	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
As of 06/2006	CLS	219	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
As of 06/2006	CLS	219	Information and communication	AUDIO	XHU	•	•	•	•	•	•		0003
As of 06/2006	CLS	219	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•		
As of 06/2006	CLS	219	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
As of 06/2006	CLS	219	Information and communication	NAVI-Navigation system	XNAVIH	•	•	0	•	•	•		
As of 06/2006	CLS	219	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
As of 06/2006	CLS	219	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
As of 06/2006	CLS	219	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•		
As of 06/2006	CLS	219	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
As of 06/2006	CLS	219	Information and communication	GPS box	XGPSB0X	•	•	0	•	•	•	0	
As of 06/2006	CLS	219	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
As of 06/2006	CLS	219	Information and communication	5 ,	XLCTECL	•	•	•	•		•	0	
As of 06/2006	CLS	219	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special f	unction p	lease re	<u>fer to the special fu</u>	inction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	_	Active Test	Special Function
As of 06/2006	CLS	219	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	1 0.110 0.1
As of 06/2006	CLS	219	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
As of 06/2006	CLS	219	Information and communication	COMAND or AUDIO	HU25	•	•	•	•	•	•		
As of 06/2006	CLS	219	Information and communication	SOUND- Sound system	SOUND25	•	•	•	•	•	•		
As of 06/2006	CLS	219	Information and communication	UCI	UCI25	•	•	•	•	•	•	0	
As of 06/2006	CLS	219	Information and communication	DAB-Digital radio	DAB25	•	•	•	•	•	0		
As of 06/2006	CLS	219	Information and communication	SDAR-Satellite radio(Valid for USA)	SDARS25	•	•	•	•	•	•		
As of 06/2006	CLS	219	Information and communication	TV-TV tuner	TV25	•	•	•	•	•	•		
As of 06/2006	CLS	219	Information and communication	CTEL-Cellular telephone (JAPAN)	CBJ25	•	•	•	•	•	0		
As of 06/2006	CLS	219	Seats and doors	ESA driver-Electric seat adjustment driver (with memory) ESA passenger-Electric seat adjustment	SSGF164	•	•	•	•	•	0	•	
As of 06/2006	CLS	219	Seats and doors	passenger	SSGB164	•	•	•	•	•	0	•	
As of 06/2006 As of 06/2006	CLS CLS	219 219	Seats and doors	DS-LF-Left front dynamic seat	FDSVL211	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Seats and doors Seats and doors	DS-RF-Right front dynamic seat DSP-Pneumatic pump for dynamic seat	FDSVR211 PFDS211	•	•	•					
As of 06/2006	CLS	219	Seats and doors	HS-Seat heater	SHZ164						0		
As of 06/2006	CLS	219	Seats and doors	DCM-FL-Door control module front left	TSGVL211	•	•	•	•	•	0	•	0003
As of 06/2006	CLS	219	Seats and doors	DCM-FR-Door control module front right	TSGVR211	•	•	•	•	•	0	•	0003
As of 06/2006	CLS	219	Seats and doors	DCM-RL-Door control module rear left	TSGHL211	•	•	•	•	•	0	•	0003
As of 06/2006	CLS	219	Seats and doors	DCM-RR-Door control module rear right	TSGHR211	•	•	•	•	•	0	•	0003
As of 06/2006	CLS	219	Seats and doors	TLC-Trunk lid control	HFS211	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Seats and doors	LAE [LAA]-Loading floor automatically extendable	ALB211	•	•	•	•	•	•	•	
As of 06/2006	CLS	219	Seats and doors	RWT-Rear-end door control module	RWT211	•	•	•	•	•	0	•	
As of 06/2006	CLS	219	Air conditioning	AAC-Automatic air conditioning	KLA211	•	•	•	•	•	•	•	0009
As of 06/2006	CLS	219	Air conditioning	HSW-Heated steering wheel	SHZ164_1	•	•	•	•	•	0	*	
As of 06/2006	CLS	219	Air conditioning	STH-Stationary heater	STH211	•	•	•	•	•	•	•	
A11	S-Class	221	Drive	ISM-Intelligent servo module	ISM	•	•	•	•	•	•	*	
A11	S-Class	221	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

As for special function places references

* This function may be supported, which depends on the actual condition of the vehicle.

As for specia	1 function p	lease re	fer to the special	function table.									
Model year	Mode1		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
A11	S-Class	221	Drive	ETC-Electronic transmission control	EGS53	•	•	•	•	•	•	•	
A11	S-Class	221	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
A11	S-Class	221	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
A11	S-Class	221	Drive	DTR-Distronic	ARS210_1	•	•	•	•	•	•	0	0058
A11	S-Class	221	Drive	FSCU-Fuel pump	FSCM221	•	•	•	•	0	•		
A11	S-Class	221	Drive	SGR-Radar sensors control unit	RDU221	•	•	•	•	•	0	•	
A11	S-Class	221	Drive	MED 9.7-Motor electronics for direct injection 9.7	MED97	•	•	•	•	•	•	*	0013
A11	S-Class	221	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	ME97AMG	•	•	•	•	•	•	•	0004 0013
A11	S-Class	221	Drive	FSCU-Fuel pump AMG	FPDM_AMG_PT	•	•	•	•	•	•		
A11	S-Class	221	Drive	CDI 5-Common Rail Diesel Injection	CR5	•	•	•	•	•	•		0013 0019 0022
A11	S-Class	221	Drive	ME 2.7.2-Motor electronics 2.7.2	ME272	•	•	•	•	•	•		0004
A11	S-Class	221	Drive	ME 2.7.2-Motor electronics 2.7.2	ME272AMG	•	•	•	•	•	•		0004
A11	S-Class	221	Chassis	ABR-Adaptive Brake	SBC221	•	•	•	•	•	•	•	0047, 0015
A11	S-Class	221	Chassis	AIRmatic	LF221	•	•	•	•	•	•	•	0048, 0049, 0051, 0 056, 0057, 0059
A11	S-Class	221	Chassis	ABC-ABC active body control	ABC221	•	•	•	•	•	•	•	0046, 0048, 0051, 0 052, 0060, 0045
A11	S-Class	221	Chassis	Electronic parking brake-Electric parking brake	EFB221	•	•	•	•	•	•	•	
A11	S-Class	221	Chassis	TPC-Tire pressure monitor	TPMHS	•	•	•	•	•	•	•	0005
A11	S-Class	221	Body	CGW-Central gateway	ZGW221	•	•	•	•	0	•	0	0016 0017 0018
A11	S-Class	221	Body	EZS-Electronic ignition switch	EZS221	•	•	•	•	•	•	0	
A11	S-Class	221	Body	KG-Keyless Go	KG221	•	•	•	•	•	•	*	
A11	S-Class	221	Body	MSS-Special vehicle multifunction control module	MPM221	•	•	•	•	•	•	•	0003
A11	S-Class	221	Body	AB-Airbag	ARCADE221	•	•	•	•	•	•		0041
A11	S-Class	221	Body	WSS-Weight sensing system	WSS221	•	•	•	•	•	0	0	0005
A11	S-Class	221	Body	OCP-Overhead control panel	DBE221	•	•	•	•	•	•	*	
A11	S-Class	221	Body	UCP-Upper control panel	0BF221	•	•	•	•	•	•	•	
A11	S-Class	221	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMF221	•	•	•	•	•	•	•	
A11	S-Class	221	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH221	•	•	•	•	•	•	•	
A11	S-Class	221	Body	BNS-Vehicle power supply control module	BSG221	•	•	•	•	•	0	•	
A11	S-Class	221	Body	AHE-Trailer recognition	AAG221	•	•	•	•	•	•	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	<u>function p</u>	<u>lease re</u> :	<u>fer to the special f</u>	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
A11	S-Class	221	Body	RevETR-LF-Left front reversible emergency tensioning retractor	RGSL221	•	•	•	•	•	•	•	
A11	S-Class	221	Body	RevETR-RF-Right front reversible emergency tensioning retractor	RGSR221	•	•	•	•	•	•	•	
A11	S-Class	221	Body	XALWA-L-Xenon headlamp, left	XALWA221_M_1	•	•	•	•	•	•	*	
A11	S-Class	221	Body	XALWA-R-Xenon headlamp, right	XALWA221_S_1	•	•	•	•	•	•	*	
A11	S-Class	221	Body	System diagnosis(CAN)	SD221	•	•	•	•	•	0		
A11	S-Class	221	Body	COU [ZBE]-Central operating unit	CTC221	•	•	•	•	•	•	•	
A11	S-Class	221	Body	HBF (Rear control panel)-Rear control field	CTCR221	•	•	•	•	•	•	•	
A11	S-Class	221	Information and communication	NSA-Night View Assist	NV221	•	•	•	•	•	0	•	
A11	S-Class	221	Information and communication	SCM [MRM]-Steering column module	MRM221	•	•	•	•	•	•	•	0005
A11	S-Class	221	Information and communication	IC-Instrument cluster	KI221	•	•	•	•	•	•	•	
A11	S-Class	221	Information and communication	ASSYST-Active Service System	WIA221	•	•	•	•	•	•	0	0001
A11	S-Class	221	Information and communication	ASSYST PLUS	WR221	•	•	•	•	•	•	0	0002
A11	S-Class	221	Information and communication	PTS-Parktronic	PTS221	•	•	•	•	•	•	•	
A11	S-Class	221	Information and communication	RFK-Backup camera	DRVM221	•	•	•	•	•	•	0	
A11	S-Class	221	Information and communication	COMAND	HU221	•	•	•	•	•	•	*	
A11	S-Class	221	Information and communication	Tuner-Standard tuner	TUA221	•	•	•	•	•	•	*	
A11	S-Class	221	Information and communication	Tuner-Tuner sound	TUS221	•	•	•	•	•	•	*	
A11	S-Class	221	Information and communication	VCS-Voice control	SDS221	•	•	•	•	•	•	•	
A11	S-Class	221	Information and communication	CTEL-Mobile phone adapter with universal interface	UHI221	•	•	•	•	•	•	*	
A11	S-Class	221	Information and communication	TV-TV tuner(AGW)	TV221	•	•	•	•	•	•		
A11	S-Class	221	Information and communication	SDAR-Satellite radio(Valid for USA)	SDAR221	•	•	•	•	•	•		
A11	S-Class	221	Information and communication	DAB-Digital radio	DAB_204	•	•	•	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	lunction p.		rer to the special i	unction table.				_	I	I	I_		G 1 1
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes				Freeze Frame	Active Test	Special Function
A11	S-Class	221	Information and communication	ZAN-Central display	DSPC221	•	•	•	•	•	•	*	
A11	S-Class	221	Information and communication	AVE-H-Rear audio video unit	XAVS221	•	•	•	•	•	•	*	
A11	S-Class	221	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
A11	S-Class	221	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
All	S-Class	221	Information and communication	TELE AID-Telematic servicesMB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
A11	S-Class	221	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
A11	S-Class	221	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
A11	S-Class	221	Seats and doors	DS-LF-Left front dynamic seat	FDSVL221	•	•	•	•	•	•	•	
A11	S-Class	221	Seats and doors	DS-RF-Right front dynamic seat	FDSVR221	•	•	•	•	•	•		
A11	S-Class	221	Seats and doors	MKL-HL-Rear left multicontour backrest	FDSHL221	•	•	•	•	•	•		
A11	S-Class	221	Seats and doors	MKL-HR-Rear right multicontour backrest	FDSHR221	•	•	•	•	•	•		
A11	S-Class	221	Seats and doors	DSP-Pneumatic pump for dynamic seat	PFDS221	•	•	•	•	•	•	•	
A11	S-Class	221	Seats and doors	DCM-FL-Door control module front left	TSGVL221	•	•	•	•	•	•	•	
A11	S-Class	221	Seats and doors	DCM-FR-Door control module front right	TSGVR221	•	•	•	•	•	•	•	
A11	S-Class	221	Seats and doors	DCM-RL-Door control module rear left	TSGHL221	•	•	•	•	•	•	•	
A11	S-Class	221	Seats and doors	DCM-RR-Door control module rear right	TSGHR221	•	•	•	•	•	•	•	
A11	S-Class	221	Seats and doors	ESA-FL-Electric seat adjustment front left	SSGVL221	•	•	•	•	•	•	•	
A11	S-Class	221	Seats and doors	ESA-FR-Electric seat adjustment front right	SSGVR221	•	•	•	•	•	•	•	
A11	S-Class	221	Seats and doors	ESA-R-Electric seat adjustment rear	SSGH221	•	•	•	•	•	•	•	
A11	S-Class	221	Seats and doors	TLC-Trunk lid control	HFS221	•	•	•	•	•	•	•	
A11	S-Class	221	Seats and doors	TLC-Trunk lid control	PTCM_1	•	•	•	•	•	•	•	
A11	S-Class	221	Air conditioning	AAC-Automatic air conditioning	KLA221	•	•	•	•	•	•	*	
A11	S-Class	221	Air conditioning	STH-Stationary heater with remote control	STH221	•	•	•	•	•	•	•	
A11	S-Class	221	Air conditioning	KBE-H-Rear A/C operating unit	HVCR221	•	•	•	•	•	•	•	
Up to 08/2002	S-Class	220	Drive	ETC-Electronic transmission control	EGS	•	•	0	•	•	*	•	
Up to 08/2002	S-Class	220	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
Up to 08/2002	S-Class	220	Drive	ESM-Electronic selector module	EWM220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Drive	DTR-Distronic	ART220	•	•	•	•	•	*	0	0005



NOTES:

This function is supported.

▲ This function is the new feature in this version.

As for specia	l function p	lease re	fer to the special	function table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes		Freeze Frame	Active Test	Special Function
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.0-Motor electronics 2.0	ME20	•	•	•	•	•	*	•	0003
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.0-Motor electronics 2.0	ME20AMG	•	•	•	•	•	*	•	0003
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
Up to 08/2002	S-Class	220	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
Up to 08/2002	S-Class	220	Drive	DTR-Distronic	ARS200	•	•	•	•	•	•	0	0005
Up to 08/2002	S-Class	220	Drive	ME-SFI 2.7-Motor electronics 2.7	ME27	•	•	•	•	•	•		
Up to 08/2002	S-Class	220	Drive	CDI 2-Common Rail Diesel Injection	CR2	•	•	•	•	•	•	*	
Up to 08/2002	S-Class	220	Drive	CDI-V-Common Rail Diesel Injection	CRV	•	•	•	•	•	•		
Up to 08/2002	S-Class	220	Chassis	ESP-Electronic stability program	ESP	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Chassis	AIRmatic	LUFE220	•	•	•	•	•	*		0049, 0051, 0056, 0 057
Up to 08/2002	S-Class	220	Chassis	ABC-ABC active body control	ABC	•	•	•	•	•	*	•	0046, 0048, 0051, 0 052
Up to 08/2002	S-Class	220	Chassis	TPC-Tire pressure monitor	RDK220	•	•	•	•	•	*	•	0005 0009
Up to 08/2002	S-Class	220	Body	AB-Airbag	ARMIN	•	•	0	•	•	*	0	
Up to 08/2002	S-Class	220	Body	EZS-Electronic ignition switch	EZS220	•	•	•	•	•	*	0	
Up to 08/2002	S-Class	220	Body	EZS-Electronic ignition switch	EZS230	•	•	•	•	•	*	0	
Up to 08/2002	S-Class	220	Body	SAM-FL-Front left signal acquisition and actuation module	SAMF220	•	•	•	•	•	*	*	0050
Up to 08/2002	S-Class	220	Body	SAM-FR-Front right signal acquisition and actuation module	SAMB220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Body	AHE-Trailer recognition	AAG220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Body	OCP-Overhead control panel	DBE220	•	•	•	•	•	*	*	
Up to 08/2002	S-Class	220	Body	PSE-Pneumatic system equipment	PSE220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Body	UCP-Upper control panel	0BF220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Body	KG-Keyless Go	KEYG0220	•	•	•	•	•	*		
Up to 08/2002	S-Class	220	Body	MSS-Special vehicle multifunction control module	MSS220	•	•	•	•	•	*	•	0003
Up to 08/2002	S-Class	220	Body	HRA-Headlamp range adjustment	LWR220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Body	EZS-Electronic ignition switch	EZS230_2	•	•	•	•	•	*	0	0034
Up to 08/2002	S-Class	220	Body	HRA-Headlamp range adjustment	LWR220_MOPF	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Body	HRA-FR-Front right headlamp range control	ALWRM203_230	•	•	•	•	•	0	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

As for special	function p	lease re	fer to the special f	unction table.									
Model year	Mode1		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
Up to 08/2002	S-Class	220	Body	HRA-FL-Front left headlamp range control	ALWRS203_230	•	•	•	•	•	0	0	
Up to 08/2002	S-Class	220	Body	CGW-Central gateway	ZGW220	•	•	•	•	0	0	0	0016 0017 0018
Up to 08/2002	S-Class	220	Body	AB-Airbag	ARMADA215_22 0_230	•	•	•	•	•	•	0	0041
Up to 08/2002	S-Class	220	Body	RevETR-LF-Left front reversible emergency tensioning retractor	REVASL	•	•	•	•	•	•	0	
Up to 08/2002	S-Class	220	Body	RevETR-RF-Right front reversible emergency tensioning retractor	REVASR	•	•	•	•	•	•	0	
Up to 08/2002	S-Class	220	Body	OCP-Overhead control panel	DBE220_MOPF	•	•	•	•	•	0	•	
Up to 08/2002	S-Class	220	Body	UCP-Upper control panel	OBF220_MOPF	•	•	•	•	•	0	•	
Up to 08/2002	S-Class	220	Body	System diagnosis(CAN)	SD240	•	•	•	•	•	•		
Up to 08/2002	S-Class	220	Information and communication	PTS-Parktronic system	PTS220	•	•	•	•	•	*		
Up to 08/2002	S-Class	220	Information and communication	SCM [MRM]-Steering column module	MRM220	•	•	•	•	•	*	•	0005
Up to 08/2002	S-Class	220	Information and communication	TSTH-Radio remote control of stationary heater	TSA220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Information and communication	ICM-Instrument cluster with maintenance interval display	KI220	•	•	•	•	•	*	•	0002
Up to 08/2002	S-Class	220	Information and communication	ICM-Instrument cluster with maintenance interval display	KI220K2	•	•	•	•	•	0	•	0002
Up to 08/2002	S-Class	220	Information and communication	COMAND	COMAND	•	•	0	•	•	•	•	
Up to 08/2002	S-Class	220	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
Up to 08/2002	S-Class	220	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
Up to 08/2002	S-Class	220	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	0	
Up to 08/2002	S-Class	220	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		
Up to 08/2002	S-Class	220	Information and communication	SOUND- Sound system	SOUND	•	•	0	•	•	•	0	
Up to 08/2002	S-Class	220	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
Up to 08/2002	S-Class	220	Information and communication	TV-TV tuner	TV	•	•	•	•		•	•	
Up to 08/2002	S-Class	220	Information and communication	E-call [Japan]-Telematic system	TAIDJAP2	•	•	•	•	•	•		
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Emergency call system	ECALLECE	•	•	•	•	•	•		



NOTES:

This function is supported.

▲ This function is the new feature in this version.

As for special	function p		fer to the special fu	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 08/2002	S-Class	220	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
Up to 08/2002	S-Class	220	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
Up to 08/2002	S-Class	220	Information and communication	DN-Dynamic navigation by means of CTEL	TELEDZS	•	•	•	•	•	0	0	
Up to 08/2002	S-Class	220	Information and communication	SCM [MRM]-Steering column module	MRM230	•	•	•	•	•	*		
Up to 08/2002	S-Class	220	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW220	•	•	•	•	•	•	0	
Up to 08/2002	S-Class	220	Information and communication	CTEL-Telecommunication for telematics services	XCP	•	•	•	•	•	•	0	
Up to 08/2002	S-Class	220	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	XCPTA	•	•	•	•	•	•		
Up to 08/2002	S-Class	220	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
Up to 08/2002	S-Class	220	Information and communication	AUDIO	XHU	•	•	•	•	•	•		0003
Up to 08/2002	S-Class	220	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•		
Up to 08/2002	S-Class	220	Information and communication	NAVI-Navigation system	XNAVIH	•	•	0	•	•	•		
Up to 08/2002	S-Class	220	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
Up to 08/2002	S-Class	220	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
Up to 08/2002	S-Class	220	Information and communication	SOUND-Bose sound system	XSND	•	•	0	•	•	•		
Up to 08/2002	S-Class	220	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•		
Up to 08/2002	S-Class	220	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
Up to 08/2002	S-Class	220	Information and communication	GPS box	XGPSB0X	•	•	0	•	•	•	0	
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	<u>function p</u>	<u>lease ref</u>	fer to the special f	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes		Erase Codes		Freeze Frame	Active Test	Special Function
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
Up to 08/2002	S-Class	220	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
Up to 08/2002	S-Class	220	Seats and doors	DCM-FL-Door control module front left	TSGVL220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Seats and doors	DCM-FR-Door control module front right	TSGVR220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Seats and doors	DCM-RL-Door control module rear left	TSGHL220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Seats and doors	DCM-RR-Door control module rear right	TSGHR220	•	•	•	•	•	*	*	
Up to 08/2002	S-Class	220	Seats and doors	ESA-R-Electric seat adjustment rear	SSGH220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Seats and doors	ESA-FL-Electric seat adjustment front left	SSGVL220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Seats and doors	ESA-FR-Electric seat adjustment front right	SSGVR220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Seats and doors	OSB-R-Multicontour backrest rear	MKLH220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Seats and doors	OSB-FL-Multicontour backrest front left	MKLVL220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Seats and doors	OSB-FR-Multicontour backrest front right	MKLVR220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Seats and doors	DS-LF-Left front dynamic seat	FDSVL220	•	•	•	•	•	•	•	
Up to 08/2002	S-Class	220	Seats and doors	DS-RF-Right front dynamic seat	FDSVR220	•	•	•	•	•	•	•	
Up to 08/2002	S-Class	220	Seats and doors	DSP-Pneumatic pump for dynamic seat	PFDS220	•	•	•	•	•	•	•	
Up to 08/2002	S-Class	220	Air conditioning	AAC-Automatic air conditioning	KLA220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Air conditioning	REAR AC- Rear air conditioning	FRA220	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Air conditioning	STH-Stationary heater	STH230	•	•	•	•	•	*		
Up to 08/2002	S-Class	220	Air conditioning	HSW-Heated steering wheel	LRK_215_220_ 230	•	•	•	•	•	*	•	
Up to 08/2002	S-Class	220	Air conditioning	STH-Stationary heater	SHEIZ220	•	•	•	•	•	*		
Up to 08/2002	S-Class	220	Air conditioning	STH-Stationary heater	STH220	•	•	•	•	•	•		
As of 09/2002	S-Class	220	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
As of 09/2002	S-Class	220	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
As of 09/2002	S-Class	220	Drive	ESM-Electronic selector module	EWM220	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Drive	DTR-Distronic	ART220	•	•	•	•	•	*	0	0005
As of 09/2002	S-Class	220	Drive	DTR-Distronic	ARS200	•	•	•	•	•	•	0	0005
As of 09/2002	S-Class	220	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
As of 09/2002	S-Class	220	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
As of 09/2002	S-Class	220	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	MME275	•	•	•	•	•	•	•	0004
As of 09/2002	S-Class	220	Drive	CDI 3-Common Rail Diesel Injection3	CR3_UP	•	•	•	•	•	•	•	0019
As of 09/2002	S-Class	220	Drive	CDI 3-Common Rail Diesel Injection3	CR3	•	•	•	•	•	•	*	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease re	fer to the special t	function table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes		Freeze Frame	Active Test	Special Function
As of 09/2002	S-Class	220	Drive	CDI-V-Common Rail Diesel Injection	CRV	•	•	•	•	•	•		
As of 09/2002	S-Class	220	Chassis	ESP-Electronic stability program	ESP	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Chassis	AIRmatic	LUFE220	•	•	•	•	•	*		0049, 0051, 0056, 0 057
As of 09/2002	S-Class	220	Chassis	ABC-ABC active body control	ABC	•	•	•	•	•	*	•	0046, 0048, 0051, 0 052
As of 09/2002	S-Class	220	Chassis	TPC-Tire pressure monitor	RDK220	•	•	•	•	•	*	•	0005 0009
As of 09/2002	S-Class	220	Body	EZS-Electronic ignition switch	EZS230_2	•	•	•	•	•	*	0	0034
As of 09/2002	S-Class	220	Body	SAM-FL-Front left signal acquisition and actuation module	SAMF220	•	•	•	•	•	*	*	0050
As of 09/2002	S-Class	220	Body	SAM-FR-Front right signal acquisition and actuation module	SAMB220	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH220	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Body	AHE-Trailer recognition	AAG220	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Body	PSE-Pneumatic system equipment	PSE220	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Body	KG-Keyless Go	KEYGO220	•	•	•	•	•	*		
As of 09/2002	S-Class	220	Body	MSS-Special vehicle multifunction control module	MSS220	•	•	•	•	•	*	•	0003
As of 09/2002	S-Class	220	Body	HRA-Headlamp range adjustment	LWR220_MOPF	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Body	HRA-FR-Front right headlamp range control	ALWRM203_230	•	•	•	•	•	0	•	
As of 09/2002	S-Class	220	Body	HRA-FL-Front left headlamp range control	ALWRS203_230	•	•	•	•	•	0	0	
As of 09/2002	S-Class	220	Body	CGW-Central gateway	ZGW220	•	•	•	•	0	0	0	0016 0017 0018
As of 09/2002	S-Class	220	Body	AB-Airbag	ARMADA215_22 0_230	•	•	•	•	•	•	0	0041
As of 09/2002	S-Class	220	Body	RevETR-LF-Left front reversible emergency tensioning retractor	REVASL	•	•	•	•	•	•	0	
As of 09/2002	S-Class	220	Body	RevETR-RF-Right front reversible emergency tensioning retractor	REVASR	•	•	•	•	•	•	0	
As of 09/2002	S-Class	220	Body	OCP-Overhead control panel	DBE220_MOPF	•	•	•	•	•	0	•	
As of 09/2002	S-Class	220	Body	UCP-Upper control panel	OBF220_MOPF	•	•	•	•	•	0	•	
As of 09/2002	S-Class	220	Body	System diagnosis(CAN)	SD240	•	•	•	•	•	•		
As of 09/2002	S-Class	220	Information and communication	PTS-Parktronic system	PTS220	•	•	•	•	•	*		
As of 09/2002	S-Class	220	Information and communication	SCM [MRM]-Steering column module	MRM230	•	•	•	•	•	*		
As of 09/2002	S-Class	220	Information and communication	ICM-Instrument cluster with maintenance interval display	KI220K2	•	•	•	•	•	0	•	0002



NOTES:

- This function is supported.
- ▲ This function is the new feature in this version.
- O This function is not supported. * This function may be supported, which depends on the actual condition of the vehicle. O This function is not supported.

 ** This function may be As for special function please refer to the special function table.

As for special	<u>function p</u>	lease re	fer to the special fu	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 09/2002	S-Class	220	Information and communication	COMAND	COMAND	•	•	0	•	•	•	•	
As of 09/2002	S-Class	220	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
As of 09/2002	S-Class	220	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
As of 09/2002	S-Class	220	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	0	
As of 09/2002	S-Class	220	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		
As of 09/2002	S-Class	220	Information and communication	SOUND- Sound system	SOUND	•	•	0	•	•	•	0	
As of 09/2002	S-Class	220	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
As of 09/2002	S-Class	220	Information and communication	TV-TV tuner	TV	•	•	•	•		•	•	
As of 09/2002	S-Class	220	Information and communication	E-call [Japan]-Telematic system	TAIDJAP2	•	•	•	•	•	•		
As of 09/2002	S-Class	220	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
As of 09/2002	S-Class	220	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
As of 09/2002	S-Class	220	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW220	•	•	•	•	•	•	0	
As of 09/2002	S-Class	220	Information and communication	CTEL-Telecommunication for telematics services	XCP	•	•	•	•	•	•	0	
As of 09/2002	S-Class	220	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	XCPTA	•	•	•	•	•	•		
As of 09/2002	S-Class	220	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
As of 09/2002	S-Class	220	Information and communication	AUDIO	XHU	•	•	•	•	•	•		0003
As of 09/2002	S-Class	220	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•		
As of 09/2002	S-Class	220	Information and communication	NAVI-Navigation system	XNAVIH	•	•	0	•	•	•		
As of 09/2002	S-Class	220	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
As of 09/2002	S-Class	220	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
As of 09/2002	S-Class	220	Information and communication	SOUND-Bose sound system	XSND	•	•	0	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	<u>function p</u>	<u>lease re</u>	fer to the special fu	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 09/2002	S-Class	220	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•		
As of 09/2002	S-Class	220	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
As of 09/2002	S-Class	220	Information and communication	GPS box	XGPSB0X	•	•	0	•	•	•	0	
As of 09/2002	S-Class	220	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
As of 09/2002	S-Class	220	Information and communication	ÿ ,	XLCTECL	•	•	•	•		•	0	
As of 09/2002	S-Class	220	Information and communication	TELE AID-Telematic servicesMB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
As of 09/2002	S-Class	220	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
As of 09 /2002	S-Class	220	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
As of 09/2002	S-Class	220	Seats and doors	DCM-FL-Door control module front left	TSGVL220	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Seats and doors	DCM-FR-Door control module front right	TSGVR220	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Seats and doors	DCM-RL-Door control module rear left	TSGHL220	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Seats and doors	DCM-RR-Door control module rear right	TSGHR220	•	•	•	•	•	*	*	
As of 09/2002	S-Class	220	Seats and doors	ESA-R-Electric seat adjustment rear	SSGH220	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Seats and doors	ESA-FL-Electric seat adjustment front left	SSGVL220	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Seats and doors	ESA-FR-Electric seat adjustment front right	SSGVR220	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Seats and doors	OSB-R-Multicontour backrest rear	MKLH220	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Seats and doors	OSB-FL-Multicontour backrest front left	MKLVL220	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Seats and doors	OSB-FR-Multicontour backrest front right	MKLVR220	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Seats and doors	DS-LF-Left front dynamic seat	FDSVL220	•	•	•	•	•	•	•	
As of 09/2002	S-Class	220	Seats and doors	DS-RF-Right front dynamic seat	FDSVR220	•	•	•	•	•	•	•	
As of 09/2002	S-Class	220	Seats and doors	DSP-Pneumatic pump for dynamic seat	PFDS220	•	•	•	•	•	•	•	
As of 09/2002	S-Class	220	Air conditioning	AAC-Automatic air conditioning	KLA220	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Air conditioning	REAR AC- Rear air conditioning	FRA220	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Air conditioning	HSW-Heated steering wheel	LRK_215_220_ 230	•	•	•	•	•	*	•	
As of 09/2002	S-Class	220	Air conditioning	STH-Stationary heater	STH220	•	•	•	•	•	•		
1991-1998	S-Class	140	Drive	HFM-SFI-Hot film engine management	HFM_H	•	•	0	•		*		
1991-1998	S-Class	140	Drive	ME2-SFI-Motor electronics 2	ME2_H	•	•	0	•	•	*		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease re	fer to the special f	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes		Freeze Frame	Active Test	Special Function
1991-1998	S-Class	140	Drive	ME1RE-Motor electronics 1 RE	ME1RE_ATL	•	•	0	•	0	*	0	
1991-1998	S-Class	140	Drive	EFP, TPM, ISC	EFP_ATL	•	•	0	•	0	*	0	
1991-1998	S-Class	140	Chassis	ESP-Electronic stability program	ESP35_H	•	•	0	•	•	*		
1991-1998	S-Class	140	Chassis	BAS-Brake assist	BAS_H	•	•	0	•	•	*		
1991-1998	S-Class	140	Chassis	SPS-Speed-sensitive power steering	PL2_H	•	•	0	•	•	*		
1991-1998	S-Class	140	Chassis	EGS, EAG	EGS_ATL	•	•	0	•	0	*	0	
1991-1998	S-Class	140	Body	RFL-Radio frequency locking/electric central locking	FFZ_H	•	•	0	•	•	*		
1991-1998	S-Class	140	Body	PTS-Parktronic system	PTS_ATL	•	•	0	•	0	*	0	
1991-1998	S-Class	140	Body	PSE-Pneumatic system equipment	PSE_ATL	•	•	0	•	0	*	0	
1991-1998	S-Class	140	Body	AirBag	AB_ATL	•	•	0	•	0	*	0	
1991-1998	S-Class	140	Body	KFB	KFB_ATL	•	•	0	•	0	*	0	
1991-1998	S-Class	140	Information and communication	ICM-Instrument cluster with maintenance interval display	KIW_H	•	•	0	•	•	*	•	0002
1991-1998	S-Class	140	Air conditioning	AAC-Automatic air conditioning	KLA_H	•	•	0	•		*		
A11	CL	216	Drive	ISM-Intelligent servo module	ISM	•	•	•	•	•	•	*	
A11	CL	216	Drive	ETC-Electronic transmission control	EGS53	•	•	•	•	•	•	•	
A11	CL	216	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
A11	CL	216	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
A11	CL	216	Drive	DTR-Distronic	ARS210_1	•	•	•	•	•	•	0	0058
A11	CL	216	Drive	FSCU-Fuel pump	FSCM221	•	•	•	•	0	•		
A11	CL	216	Drive	SGR-Radar sensors control unit	RDU221	•	•	•	•	•	0	•	
A11	CL	216	Drive	ME 2.7.2-Motor electronics 2.7.2	ME272	•	•	•	•	•	•		0004
A11	CL	216	Drive	ME 2.7.2-Motor electronics 2.7.2	ME272AMG	•	•	•	•	•	•		0004
A11	CL	216	Drive	FSCU-Fuel pump AMG	FPDM_AMG_PT	•	•	•	•	•	•		
A11	CL	216	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	ME97AMG	•	•	•	•	•	•	•	0004 0013
A11	CL	216	Chassis	ABR-Adaptive Brake	SBC221	•	•	•	•	•	•	•	0047, 0015
A11	CL	216	Chassis	AIRmatic	LF221	•	•	•	•	•	•	•	0048, 0049, 0051, 0 056, 0057, 0059
A11	CL	216	Chassis	ABC-ABC active body control	ABC221	•	•	•	•	•	•	•	0046, 0048, 0051, 0 052, 0060, 0045
A11	CL	216	Chassis	Electronic parking brake-Electric parking brake	EFB221	•	•	•	•	•	•	•	
A11	CL	216	Chassis	TPC-Tire pressure monitor	TPMHS	•	•	•	•	•	•	•	0005
A11	CL	216	Body	CGW-Central gateway	ZGW221	•	•	•	•	0	•	0	0016 0017 0018
A11	CL	216	Body	EZS-Electronic ignition switch	EZS221	•	•	•	•	•	•	0	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

			Control Unit		D:N	Ecu	Read	Event	Erase	Live	Freeze	Active	Special
Model year	Mode1	Series	Groups	System Name	DiagName	Info.	Codes	Memory	Codes	Data		Test	Function
A11	CL		Body	KG-Keyless Go	KG221	•	•	•	•	•	•	*	
A11	CL		Body	AB-Airbag	ARCADE221	•	•	•	•	•	•		0041
A11	CL		Body	WSS-Weight sensing system	OCM_204	•	•	•	•	•	•	0	0005
A11	CL	216	Body	OCP-Overhead control panel	DBE221	•	•	•	•	•	•	*	
A11	CL	216	Body	UCP-Upper control panel	0BF221	•	•	•	•	•	•	•	
A11	CL	216	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMF221	•	•	•	•	•	•	•	
A11	CL	216	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH221	•	•	•	•	•	•	•	
A11	CL	216	Body	BNS-Vehicle power supply control module	BSG221	•	•	•	•	•	0	•	
A11	CL	216	Body	AHE-Trailer recognition	AAG221	•	•	•	•	•	•	•	
A11	CL	216	Body	XALWA-L-Xenon headlamp, left	XALWA221_M_1	•	•	•	•	•	•	*	
A11	CL	216	Body	XALWA-R-Xenon headlamp, right	XALWA221_S_1	•	•	•	•	•	•	*	
A11	CL	216	Body	System diagnosis(CAN)	SD221	•	•	•	•	•	0		
A11	CL	216	Body	COU [ZBE]-Central operating unit	CTC221	•	•	•	•	•	•	•	
A11	CL	216	Information and communication	NSA-Night View Assist	NV221	•	•	•	•	•	0	•	
A11	CL	216	Information and communication	SCM [MRM]-Steering column module	MRM221	•	•	•	•	•	•	•	0005
A11	CL	216	Information and communication	IC-Instrument cluster	KI221	•	•	•	•	•	•	•	
A11	CL	216	Information and communication	ASSYST-Active Service System	WIA221	•	•	•	•	•	•	0	0001
A11	CL	216	Information and communication	ASSYST PLUS	WR221	•	•	•	•	•	•	0	0002
A11	CL	216	Information and communication	PTS-Parktronic	PTS221	•	•	•	•	•	•	•	
A11	CL	216	Information and communication	RFK-Backup camera	DRVM221	•	•	•	•	•	•	0	
A11	CL	216	Information and communication	COMAND	HU221	•	•	•	•	•	•	*	
A11	CL	216	Information and communication	Tuner-Standard tuner	TUA221	•	•	•	•	•	•	*	
A11	CL	216	Information and communication	Tuner-Tuner sound	TUS221	•	•	•	•	•	•	*	
A11	CL	216	Information and communication	VCS-Voice control	SDS221	•	•	•	•	•	•	•	
A11	CL	216	Information and communication	CTEL-Mobile phone adapter with universal interface	UHI221	•	•	•	•	•	•	*	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special :	function p.	lease rei	er to the special fi	inction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes				Freeze Frame	Active Test	Special Function
A11	CL	216	Information and communication	TV-TV tuner (AGW)	TV221	•	•	•	•	•	•		
A11	CL	216	Information and communication	DAB-Digital radio	DAB_204	•	•	•	•	•	•		
A11	CL	216	Information and communication	SDAR-Satellite radio(Valid for USA)	SDAR221	•	•	•	•	•	•		
A11	CL	216	Information and communication	ZAN-Central display	DSPC221	•	•	•	•	•	•	*	
A11	CL	216	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
A11	CL	216	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
A11	CL	216	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Telediagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
A11	CL	216	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
A11	CL	216	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
A11	CL	216	Seats and doors	DS-LF-Left front dynamic seat	FDSVL221	•	•	•	•	•	•	•	
A11	CL	216	Seats and doors	DS-RF-Right front dynamic seat	FDSVR221	•	•	•	•	•	•		
A11	CL	216	Seats and doors	DSP-Pneumatic pump for dynamic seat	PFDS221	•	•	•	•	•	•	•	
A11	CL	216	Seats and doors	DCM-FL-Door control module front left	TSGVL221	•	•	•	•	•	•	•	
A11	CL	216	Seats and doors	DCM-FR-Door control module front right	TSGVR221	•	•	•	•	•	•	•	
A11	CL	216	Seats and doors	RCM-Rear control module	FSG216	•	•	•	•	•	•		
A11	CL	216	Seats and doors	ESA-FL-Electric seat adjustment front left	SSGVL221	•	•	•	•	•	•	•	
A11	CL	216	Seats and doors	ESA-FR-Electric seat adjustment front right	SSGVR221	•	•	•	•	•	•	•	
A11	CL	216	Seats and doors	TLC-Trunk lid control	HFS221	•	•	•	•	•	•	•	
A11	CL	216	Seats and doors	TLC-Trunk lid control	PTCM_1	•	•	•	•	•	•	•	
A11	CL	216	Air conditioning	AAC-Automatic air conditioning	KLA221	•	•	•	•	•	•	*	
A11	CL	216	Air conditioning	STH-Stationary heater with remote control	STH221	•	•	•	•	•	•	•	
Up to 08/2002	CL	215	Drive	ETC-Electronic transmission control	EGS	•	•	0	•	•	*	•	
Up to 08/2002	CL	215	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
Up to 08/2002	CL	215	Drive	ESM-Electronic selector module	EWM220	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Drive	DTR-Distronic	ART220	•	•	•	•	•	*	0	0005
Up to 08/2002	CL	215	Drive	ME-SFI 2.0-Motor electronics 2.0	ME20	•	•	•	•	•	*	•	0003
Up to 08/2002	CL	215	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004



NOTES:

- This function is supported.
- lacktriangle This function is the new feature in this version.
- O This function is not supported.
 ** This function may be supported, which depends on the actual condition of the vehicle.

As for special:	function p.	lease rei	<u>fer to the special f</u>	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory			Freeze Frame	Active Test	Special Function
Up to 08/2002	CL	215	Drive	ME-SFI 2.0-Motor electronics 2.0	ME20AMG	•	•	•	•	•	*	•	0003
Up to 08/2002	CL	215	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
Up to 08/2002	CL	215	Drive	ME-SFI 2.7-Motor electronics 2.7	ME27	•	•	•	•	•	•		
Up to 08/2002	CL	215	Chassis	ESP-Electronic stability program	ESP	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Chassis	ABC-ABC active body control	ABC	•	•	•	•	•	*	•	0046, 0048, 0051, 0 052
Up to 08/2002	CL	215	Chassis	TPC-Tire pressure monitor	RDK220	•	•	•	•	•	*	•	0005 0009
Up to 08/2002	CL	215	Body	AB-Airbag	ARMIN	•	•	0	•	•	*	0	
Up to 08/2002	CL	215	Body	EZS-Electronic ignition switch	EZS220	•	•	•	•	•	*	0	
Up to 08/2002	CL	215	Body	EZS-Electronic ignition switch	EZS230	•	•	•	•	•	*	0	
Up to 08/2002	CL	215	Body	SAM-FL-Front left signal acquisition and actuation module	SAMF220	•	•	•	•	•	*	*	0050
Up to 08/2002	CL	215	Body	SAM-FR-Front right signal acquisition and actuation module	SAMB220	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH220	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Body	AHE-Trailer recognition	AAG220	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Body	OCP-Overhead control panel	DBE220	•	•	•	•	•	*	*	
Up to 08/2002	CL	215	Body	PSE-Pneumatic system equipment	PSE220	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Body	UCP-Upper control panel	0BF220	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Body	KG-Keyless Go	KEYG0220	•	•	•	•	•	*		
Up to 08/2002	CL	215	Body	MSS-Special vehicle multifunction control module	MSS220	•	•	•	•	•	*	•	0003
Up to 08/2002	CL	215	Body	HRA-Headlamp range adjustment	LWR220	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Information and communication	PTS-Parktronic system	PTS220	•	•	•	•	•	*		
Up to 08/2002	CL	215	Information and communication	SCM [MRM]-Steering column module	MRM220	•	•	•	•	•	*	•	0005
Up to 08/2002	CL	215	Information and communication	TSTH-Radio remote control of stationary heater	TSA220	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Information and communication	ICM-Instrument cluster with maintenance interval display	KI220	•	•	•	•	•	*	•	0002
Up to 08/2002	CL	215	Information and communication	ICM-Instrument cluster with maintenance interval display	KI220K2	•	•	•	•	•	0	•	0002
Up to 08/2002	CL	215	Information and communication	COMAND	COMAND	•	•	0	•	•	•	•	
Up to 08/2002	CL	215	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	



NOTES:

• This function is supported.

- ▲ This function is the new feature in this version.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

As for special f	tunction p	<u> rease re</u>	fer to the special fu	inction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 08/2002	CL	215	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	О	0	
Up to 08/2002	CL	215	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	0	
Up to 08/2002	CL	215	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		
Up to 08/2002	CL	215	Information and communication	SOUND- Sound system	SOUND	•	•	0	•	•	•	0	
Up to 08/2002	CL	215	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
Up to 08/2002	CL	215	Information and communication	TV-TV tuner	TV	•	•	•	•		•	•	
Up to 08/2002	CL	215	Information and communication	E-call [Japan]-Telematic system	TAIDJAP2	•	•	•	•	•	•		
Up to 08/2002	CL	215	Information and communication	TELE AID-Emergency call system	ECALLECE	•	•	•	•	•	•		
Up to 08/2002	CL	215	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
Up to 08/2002	CL	215	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
Up to 08/2002	CL	215	Information and communication	DN-Dynamic navigation by means of CTEL	TELEDZS	•	•	•	•	•	0	0	
Up to 08/2002	CL	215	Seats and doors	DCM-FL-Door control module front left	TSGVL220	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Seats and doors	DCM-FR-Door control module front right	TSGVR220	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Seats and doors	RCM-Rear control module	FSG215	•	•	•	•	•	*		
Up to 08/2002	CL	215	Seats and doors	ESA-FL-Electric seat adjustment front left	SSGVL215	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Seats and doors	ESA-FR-Electric seat adjustment front right	SSGVR215	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Seats and doors	OSB-FL-Multicontour backrest front left	MKLVL215_230	•	•	•	•	•	*		
Up to 08/2002	CL	215	Seats and doors	OSB-FR-Multicontour backrest front right	MKLVR215_230	•	•	•	•	•	*		
Up to 08/2002	CL	215	Air conditioning	AAC-Automatic air conditioning	KLA220	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Air conditioning	STH-Stationary heater	STH230	•	•	•	•	•	*		
Up to 08/2002	CL	215	Air conditioning	HSW-Heated steering wheel	LRK_215_220_ 230	•	•	•	•	•	*	•	
Up to 08/2002	CL	215	Air conditioning	STH-Stationary heater	SHEIZ220	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
As of 09/2002	CL	215	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
As of 09/2002	CL	215	Drive	ESM-Electronic selector module	EWM220	•	•	•	•	•	*	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special:	function p	<u>lease re</u>	<u>fer to the special fu</u>	inction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 09/2002	CL	215	Drive	DTR-Distronic	ART220	•	•	•	•	•	*	0	0005
As of 09/2002	CL	215	Drive	DTR-Distronic	ARS200	•	•	•	•	•	•	0	0005
As of 09/2002	CL	215	Drive	ME-SFI 2.0-Motor electronics 2.0	ME20	•	•	•	•	•	*	•	0003
As of 09/2002	CL	215	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
As of 09/2002	CL	215	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
As of 09/2002	CL	215	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	MME275	•	•	•	•	•	•	•	0004
As of 09/2002	CL	215	Chassis	ESP-Electronic stability program	ESP	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Chassis	ABC-ABC active body control	ABC	•	•	•	•	•	*	•	0046, 0048, 0051, 0 052
As of 09/2002	CL	215	Chassis	TPC-Tire pressure monitor	RDK220	•	•	•	•	•	*	•	0005 0009
As of 09/2002	CL	215	Body	EZS-Electronic ignition switch	EZS230_2	•	•	•	•	•	*	0	0034
As of 09/2002	CL	215	Body	PSE-Pneumatic system equipment	PSE220	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Body	SAM-FL-Front left signal acquisition and actuation module	SAMF220	•	•	•	•	•	*	*	0050
As of 09/2002	CL	215	Body	SAM-FR-Front right signal acquisition and actuation module	SAMB220	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH220	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Body	AHE-Trailer recognition	AAG220	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Body	KG-Keyless Go	KEYG0220	•	•	•	•	•	*		
As of 09/2002	CL	215	Body	MSS-Special vehicle multifunction control module	MSS220	•	•	•	•	•	*	•	0003
As of 09/2002	CL	215	Body	HRA-FR-Front right headlamp range control	ALWRM203_230	•	•	•	•	•	0	•	
As of 09/2002	CL	215	Body	HRA-FL-Front left headlamp range control	ALWRS203_230	•	•	•	•	•	0	0	
As of 09/2002	CL	215	Body	CGW-Central gateway	ZGW220	•	•	•	•	0	0	0	0016 0017 0018
As of 09/2002	CL	215	Body	AB-Airbag	ARMADA215_22 0_230	•	•	•	•	•	•	0	0041
As of 09/2002	CL	215	Body	OCP-Overhead control panel	DBE220_MOPF	•	•	•	•	•	0	•	
As of 09/2002	CL	215	Body	UCP-Upper control panel	OBF220_MOPF	•	•	•	•	•	0	•	
As of 09/2002	CL	215	Body	System diagnosis(CAN)	SD240	•	•	•	•	•	•		
As of 09/2002	CL	215	Information and communication	PTS-Parktronic system	PTS220	•	•	•	•	•	*		
As of 09/2002	CL	215	Information and communication	SCM [MRM]-Steering column module	MRM230	•	•	•	•	•	*		
As of 09/2002	CL	215	Information and communication	ICM-Instrument cluster with maintenance interval display	KI220K2	•	•	•	•	•	0	•	0002



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease re	fer to the special f	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 09/2002	CL	215	Information and communication	COMAND	COMAND	•	•	0	•	•	•	•	
As of 09/2002	CL	215	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
As of 09/2002	CL	215	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
As of 09/2002	CL	215	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	0	
As of 09/2002	CL	215	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		
As of 09/2002	CL	215	Information and communication	SOUND- Sound system	SOUND	•	•	0	•	•	•	0	
As of 09/2002	CL	215	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
As of 09/2002	CL	215	Information and communication	TV-TV tuner	TV	•	•	•	•		•	•	
As of 09/2002	CL	215	Information and communication	E-call [Japan]-Telematic system	TAIDJAP2	•	•	•	•	•	•		
As of 09/2002	CL	215	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
As of 09/2002	CL	215	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
As of 09/2002	CL	215	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW220	•	•	•	•	•	•	0	
As of 09/2002	CL	215	Information and communication	CTEL-Telecommunication for telematics services	XCP	•	•	•	•	•	•	0	
As of 09/2002	CL	215	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	XCPTA	•	•	•	•	•	•		
As of 09/2002	CL	215	Information and communication	AUDIO	XHU	•	•	•	•	•	•	•	0003
As of 09/2002	CL	215	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•	•	
As of 09/2002	CL	215	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
As of 09/2002	CL	215	Information and communication	NAVI-Navigation system	XNAVIH	•	•	0	•	•	•		
As of 09/2002	CL	215	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
As of 09/2002	CL	215	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
As of 09/2002	CL	215	Information and communication	SOUND-Bose sound system	XSND	•	•	0	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease re	<u>fer to the special f</u>	unction table.									
Model year	Mode1		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 09/2002	CL	215	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•	•	
As of 09/2002	CL	215	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
As of 09/2002	CL	215	Information and communication	GPS box	XGPSBOX	•	•	0	•	•	•	0	
As of 09/2002	CL	215	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
As of 09/2002	CL	215	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
As of 09/2002	CL	215	Information and communication	TELE AID-Telematic servicesMB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
As of 09/2002	CL	215	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
As of 09/2002	CL	215	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
As of 09/2002	CL	215	Seats and doors	DCM-FL-Door control module front left	TSGVL220	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Seats and doors	DCM-FR-Door control module front right	TSGVR220	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Seats and doors	RCM-Rear control module	FSG215	•	•	•	•	•	*		
As of 09/2002	CL	215	Seats and doors	ESA-FL-Electric seat adjustment front left	SSGVL215	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Seats and doors	ESA-FR-Electric seat adjustment front right	SSGVR215	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Seats and doors	OSB-FL-Multicontour backrest front left	MKLVL215_230	•	•	•	•	•	*		
As of 09/2002	CL	215	Seats and doors	OSB-FR-Multicontour backrest front right	MKLVR215_230	•	•	•	•	•	*		
As of 09/2002	CL	215	Air conditioning	AAC-Automatic air conditioning	KLA220	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Air conditioning	REAR AC- Rear air conditioning	FRA220	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Air conditioning	HSW-Heated steering wheel	LRK_215_220_ 230	•	•	•	•	•	*	•	
As of 09/2002	CL	215	Air conditioning	STH-Stationary heater	STH220	•	•	•	•	•	•	•	
Up to 08/2006	MayBach	240	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
Up to 08/2006	MayBach	240	Drive	ESM-Electronic selector module	EWM220	•	•	•	•	•	*	•	
Up to 08/2006	MayBach	240	Drive	SGR-Radar sensors control unit	RDU240	•	•	•	•	•	•	0	
Up to 08/2006	MayBach	240	Drive	DTR-Distronic	ART220	•	•	•	•	•	*	0	0005
Up to 08/2006	MayBach	240	Drive	DTR-Distronic	ARS200	•	•	•	•	•	•	0	0005
Up to 08/2006	MayBach	240	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	MME275	•	•	•	•	•	•	•	0004
Up to 08/2006	MayBach	240	Chassis	SBC-Sensotronic Brake Control	EHB_ASG	•	•	•	•	•	0	0	0006 0007 0008



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	<u>function p</u>	<u>lease re</u>	<u>fer to the special fu</u>	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
Up to 08/2006	MayBach	240	Chassis	SBC-Right Sensotronic Brake Control	EHB_ASG2	•	•	•	•	•	0		0006 0007 0008 0038 0039
Up to 08/2006	MayBach	240	Chassis	ESP-Electronic stability program	EHB_FSG	•	•	•	•	•	•	•	0014
Up to 08/2006	MayBach	240	Chassis	AIRmatic	SLF211	•	•	•	•	•	0	*	0048, 0049, 0056
Up to 08/2006	MayBach	240	Chassis	TPC-Tire pressure monitor	RDK211	•	•	•	•	•	•	•	
Up to 08/2006	MayBach	240	Body	CGW-Central gateway	ZGW240	•	•	•	•	•	0	0	0016 0017 0018
Up to 08/2006	MayBach	240	Body	EZS-Electronic ignition switch	EZS240	•	•	•	•	•	•		
Up to 08/2006	MayBach	240	Body	AB-Airbag	ARMADA	•	•	•	•	•	•	0	0003 0010 0041
Up to 08/2006	MayBach	240	Body	WSS-Weight sensing system	WSS171	•	•	•	•	•	0	0	0005
Up to 08/2006	MayBach	240	Body	BNS-Vehicle power supply control module	BNS240	•	•	•	•	•	0	0	
Up to 08/2006	MayBach	240	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMF240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	SAMB240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Body	Rear SAM 1-Rear signal acquisition and actuation module1	SAM_H1240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Body	Rear SAM 2-Rear signal acquisition and actuation module2	SAM_H2240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Body	MSS-Special vehicle multifunction control module	MSS240	•	•	•	•	•	0	•	0003
Up to 08/2006	MayBach	240	Body	VBF (Front control panel)-Front control panel	VBF240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Body	HBF (Rear control panel)-Rear control field	HBF240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Body	BCG-Remote control(Rear control field)	BCG240	•	•	•	•	•	0	•	0003
Up to 08/2006	MayBach	240	Body	OCP-Overhead control panel	DBE240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Body	CRN-Center roof node	DKM240	•	•	0	•	•	•	•	
Up to 08/2006	MayBach	240	Body	PSE-Pneumatic system equipment	PSE240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Body	HRA-Automatic headlamp range adjustment and headlamp control	ALWR211	•	•	•	•	•	0	•	0005 0009
Up to 08/2006	MayBach	240	Body	System diagnosis(CAN)	SD240	•	•	•	•	•	•		
Up to 08/2006	MayBach	240	Information and communication	PTS-Parktronic system	PTS211	•	•	•	•	•	•	•	
Up to 08/2006	MayBach	240	Information and communication	SCM [MRM]-Steering column module	MRM211	•	•	•	•	•	•	•	0005
Up to 08/2006	MayBach	240	Information and communication	ICM-Instrument cluster	KI240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	<u>lease re</u> :	<u>fer to the special f</u>	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
Up to 08/2006	MayBach	240	Information and communication	CTEL-Telecommunication for telematics services	XCP	•	•	•	•	•	•	0	
Up to 08/2006	MayBach	240	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	XCPTA	•	•	•	•	•	•		
Up to 08/2006	MayBach	240	Information and communication	AUDIO	XHU	•	•	•	•	•	•	•	0003
Up to 08/2006	MayBach	240	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•	•	
Up to 08/2006	MayBach	240	Information and communication	NAVI-Navigation system	XNAVIH	•	•	0	•	•	•		
Up to 08/2006	MayBach	240	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•	•	
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
Up to 08/2006	MayBach	240	Information and communication	SOUND-Bose sound system	XSND	•	•	0	•	•	•		
Up to 08/2006	MayBach	240	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
Up to 08/2006	MayBach	240	Information and communication	AVC-Audio video controller	XAVC	•	•	0	•	•	•	•	
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner(REAR)	XFTV	•	•	0	•	•	•		
Up to 08/2006	MayBach	240	Information and communication	TV-TV tuner (rear)	FTV_240	•	•	•	•	•	•		
Up to 08/2006	MayBach	240	Information and communication	CDC-CD changer(REAR)	XFCDC	•	•	0	•	•	•	0	
Up to 08/2006	MayBach	240	Information and communication	KTL-Left headphone transmitter	XRFTL	•	•	0	•	•	0		
Up to 08/2006	MayBach	240	Information and communication	KTR-Right headphone transmitter	XRFTR	•	•	0	•	•	0		
Up to 08/2006	MayBach	240	Information and communication	GPS box	XGPSB0X	•	•	0	•	•	•	0	
Up to 08/2006	MayBach	240	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
Up to 08/2006	MayBach	240	Seats and doors	ESA-FL-Electric seat adjustment front left	SSGVL240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Seats and doors	ESA-FR-Electric seat adjustment front right	SSGVR240	•	•	•	•	•	0	*	
Up to 08/2006	MayBach	240	Seats and doors	ESA-LR-Left rear electrical seat adjustment	SSGHL240	•	•	•	•	•	0	•	



NOTES:

• This function is supported.

- ▲ This function is the new feature in this version.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

AS for special	Tunction p		rer to the special r	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory			Freeze Frame	Active Test	Special Function
Up to 08/2006	MayBach	240	Seats and doors	ESA-RR-Right rear electrical seat adjustment	SSGHR240	•	•	0	•	•	•	•	
Up to 08/2006	MayBach	240	Seats and doors	OSB-FL-Multicontour backrest front left	MMKLVL240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Seats and doors	OSB-FR-Multicontour backrest front right	MMKLVR240	•	•	0	•	•	0	•	
Up to 08/2006	MayBach	240	Seats and doors	MKL-HL-Rear left multicontour backrest	MMKLHL240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Seats and doors	MKL-HR-Rear right multicontour backrest	MMKLHR240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Seats and doors	DCM-FL-Door control module front left	TSGVL240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Seats and doors	DCM-FR-Door control module front right	TSGVR240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Seats and doors	DCM-RL-Door control module rear left	TSGHL240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Seats and doors	DCM-RR-Door control module rear right	TSGHR240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Seats and doors	PWC-Partition wall control module	TWS240	•	•	•	•	•	0		
Up to 08/2006	MayBach	240	Seats and doors	LDCA-Electric left door closing assist	TZL240	•	•	•	•	•	•	0	
Up to 08/2006	MayBach	240	Seats and doors	RDCA-Electric right door closing assist	TZR240	•	•	•	•	•	•	0	
Up to 08/2006	MayBach	240	Seats and doors	TLC-Trunk lid control	HFS211	•	•	•	•	•	•	•	
Up to 08/2006	MayBach	240	Air conditioning	AAC-Automatic air conditioning	KLA240	•	•	•	•	•	0	•	0003
Up to 08/2006	MayBach	240	Air conditioning	REAR AC-Rear air conditioning	FKLA240	•	•	•	•	•	0	•	
Up to 08/2006	MayBach	240	Air conditioning	STH-Stationary heater	STH211	•	•	•	•	•	•	•	
Up to 08/2006	MayBach	240	Air conditioning	HSW-Heated steering wheel	LRK_211	•	•	•	•	•	•	•	0003 0005
As of 09/2006	MayBach	240	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
As of 09/2006	MayBach	240	Drive	ETC-Electronic transmission control	EGS53	•	•	•	•	•	•	•	
As of 09/2006	MayBach	240	Drive	ESM-Electronic selector module	EWM220	•	•	•	•	•	*	•	
As of 09/2006	MayBach	240	Drive	SGR-Radar sensors control unit	RDU240	•	•	•	•	•	•	0	
As of 09/2006	MayBach	240	Drive	DTR-Distronic	ARS200	•	•	•	•	•	•	0	0005
As of 09/2006	MayBach	240	Drive	ME 2.7.2-Motor electronics 2.7.2	ME272	•	•	•	•	•	•		0004
As of 09/2006	MayBach	240	Drive	ME 2.7.2-Motor electronics 2.7.2	ME272AMG	•	•	•	•	•	•		0004
As of 09/2006	MayBach	240	Drive	FSCU-Fuel pump	FSCM221	•	•	•	•	0	•		
As of 09/2006	MayBach	240	Chassis	SBC-Sensotronic Brake Control	EHB_ASG	•	•	•	•	•	0	0	0006 0007 0008
As of 09/2006	MayBach	240	Chassis	SBC-Right Sensotronic Brake Control	EHB_ASG2	•	•	•	•	•	0		0006 0007 0008 0038 0039
As of 09/2006	MayBach	240	Chassis	ESP-Electronic stability program	EHB_FSG	•	•	•	•	•	•	•	0014
As of 09/2006	MayBach	240	Chassis	AIRmatic	SLF211	•	•	•	•	•	0	*	0048, 0049, 0056
As of 09/2006	MayBach	240	Chassis	TPC-Tire pressure monitor	RDK211	•	•	•	•	•	•	•	
As of 09/2006	MayBach	240	Body	CGW-Central gateway	ZGW240	•	•	•	•	•	0	0	0016 0017 0018
As of 09/2006	MayBach	240	Body	EZS-Electronic ignition switch	EZS240	•	•	•	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

AS TOT SPECIAL	I unction p.		er to the special it	Inction table.		ъ	D 1	ъ .	Б	т •	Б		g · 1
Model year	Mode1		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory		Live Data	Freeze Frame	Active Test	Special Function
As of 09/2006	MayBach	240	Body	AB-Airbag	ARCADE164	•	•	•	•	•	•		0041
As of 09/2006	MayBach	240	Body	WSS-Weight sensing system	WSS171	•	•	•	•	•	0	0	0005
As of 09/2006	MayBach	240	Body	BNS-Vehicle power supply control module	BNS240	•	•	•	•	•	0	0	
As of 09/2006	MayBach	240	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMF240	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	SAMB240	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Body	Rear SAM 1-Rear signal acquisition and actuation module1	SAM_H1240	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Body	Rear SAM 2-Rear signal acquisition and actuation module2	SAM_H2240	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Body	MSS-Special vehicle multifunction control module	MSS240	•	•	•	•	•	0	•	0003
As of 09/2006	MayBach	240	Body	VBF (Front control panel)-Front control panel	VBF240	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Body	HBF (Rear control panel)-Rear control field	HBF240	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Body	BCG-Remote control(Rear control field)	BCG240	•	•	•	•	•	0	•	0003
As of 09/2006	MayBach	240	Body	OCP-Overhead control panel	DBE240	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Body	CRN-Center roof node	DKM240	•	•	0	•	•	•	•	
As of 09/2006	MayBach	240	Body	PSE-Pneumatic system equipment	PSE240	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Body	HRA-Automatic headlamp range adjustment and headlamp control	ALWR211	•	•	•	•	•	0	•	0005 0009
As of 09/2006	MayBach	240	Body	System diagnosis(CAN)	SD240	•	•	•	•	•	•		
As of 09/2006	MayBach	240	Information and communication	PTS-Parktronic system	PTS211	•	•	•	•	•	•	•	
As of 09/2006	MayBach	240	Information and communication	SCM [MRM]-Steering column module	MRM211	•	•	•	•	•	•	•	0005
As of 09/2006	MayBach	240	Information and communication	ICM-Instrument cluster	KI240	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
As of 09/2006	MayBach	240	Information and communication	CTEL-Telecommunication for telematics services	XCP	•	•	•	•	•	•	0	
As of 09/2006	MayBach	240	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	XCPTA	•	•	•	•	•	•		
As of 09/2006	MayBach	240	Information and communication	AUDIO	XHU	•	•	•	•	•	•	•	0003
As of 09/2006	MayBach	240	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special f	unction p	<u>lease re</u>	<u>fer to the special fu</u>	inction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 09/2006	MayBach	240	Information and communication	NAVI-Navigation system	XNAVIH	•	•	0	•	•	•	_ 1050	1 0110 0 1011
As of 09/2006	MayBach	240	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•	•	
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
As of 09/2006	MayBach	240	Information and communication	SOUND-Bose sound system	XSND	•	•	0	•	•	•		
As of 09/2006	MayBach	240	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
As of 09/2006	MayBach	240	Information and communication	AVC-Audio video controller	XAVC	•	•	0	•	•	•	•	
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner(REAR)	XFTV	•	•	0	•	•	•		
As of 09/2006	MayBach	240	Information and communication	TV-TV tuner (rear)	FTV_240	•	•	•	•	•	•		
As of 09/2006	MayBach	240	Information and communication	CDC-CD changer(REAR)	XFCDC	•	•	0	•	•	•	0	
As of 09/2006	MayBach	240	Information and communication	KTL-Left headphone transmitter	XRFTL	•	•	0	•	•	0		
As of 09/2006	MayBach	240	Information and communication	KTR-Right headphone transmitter	XRFTR	•	•	0	•	•	0		
As of 09/2006	MayBach	240	Information and communication	GPS box	XGPSBOX	•	•	0	•	•	•	0	
As of 09/2006	MayBach	240	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
As of 09/2006	MayBach	240	Seats and doors	ESA-FL-Electric seat adjustment front left	SSGVL240	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Seats and doors	ESA-FR-Electric seat adjustment front right	SSGVR240	•	•	•	•	•	0	*	
As of 09/2006	MayBach	240	Seats and doors	ESA-LR-Left rear electrical seat adjustment	SSGHL240	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Seats and doors	ESA-RR-Right rear electrical seat adjustment	SSGHR240	•	•	0	•	•	•	•	
As of 09/2006	MayBach	240	Seats and doors	OSB-FL-Multicontour backrest front left	MMKLVL240	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Seats and doors	OSB-FR-Multicontour backrest front right	MMKLVR240	•	•	0	•	•	0	•	
As of 09/2006	MayBach	240	Seats and doors	MKL-HL-Rear left multicontour backrest	MMKLHL240	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Seats and doors	MKL-HR-Rear right multicontour backrest	MMKLHR240	•	•	•	•		0	•	
As of 09/2006	MayBach	240	Seats and doors	DCM_FL-Door control module front left	TSGVL240	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Seats and doors	DCM-FR-Door control module front right	TSGVR240	•	•	•			0	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

As for special function places references

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	l function p	lease re	fer to the special	function table.									
Model year	Mode1		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes		Erase Codes		Freeze Frame	Active Test	Special Function
As of 09/2006	MayBach	240	Seats and doors	DCM-RL-Door control module rear left	TSGHL240	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Seats and doors	DCM-RR-Door control module rear right	TSGHR240	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Seats and doors	PWC-Partition wall control module	TWS240	•	•	•	•	•	0		
As of 09/2006	MayBach	240	Seats and doors	LDCA-Electric left door closing assist	TZL240	•	•	•	•	•	•	0	
As of 09/2006	MayBach	240	Seats and doors	RDCA-Electric right door closing assist	TZR240	•	•	•	•	•	•	0	
As of 09/2006	MayBach	240	Seats and doors	TLC-Trunk lid control	HFS211	•	•	•	•	•	•	•	
As of 09/2006	MayBach	240	Air conditioning	AAC-Automatic air conditioning	KLA240	•	•	•	•	•	0	•	0003
As of 09/2006	MayBach	240	Air conditioning	REAR AC-Rear air conditioning	FKLA240	•	•	•	•	•	0	•	
As of 09/2006	MayBach	240	Air conditioning	STH-Stationary heater	STH211	•	•	•	•	•	•	•	
As of 09/2006	MayBach	240	Air conditioning	HSW-Heated steering wheel	LRK_211	•	•	•	•	•	•	•	0003 0005
Up to 08/2003	SL	230	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
Up to 08/2003	SL	230	Drive	SEQ-Sequentronic automated manual transmission	KSG	•	•	•	•	•	•		
Up to 08/2003	SL	230	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
Up to 08/2003	SL	230	Drive	ESM-Electronic selector module	EWM220	•	•	•	•	•	*	•	
Up to 08/2003	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
Up to 08/2003	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
Up to 08/2003	SL	230	Drive	DTR-Distronic	ART220	•	•	•	•	•	*	0	0005
Up to 08/2003	SL	230	Chassis	SBC-Sensotronic Brake Control	EHB_ASG	•	•	•	•	•	0	0	0006 0007 0008
Up to 08/2003	SL	230	Chassis	ESP-Electronic stability program	EHB_FSG	•	•	•	•	•	•	•	0014
Up to 08/2003	SL	230	Chassis	ABC-ABC active body control	ABC	•	•	•	•	•	*	•	0046, 0048, 0051, 0 052
Up to 08/2003	SL	230	Chassis	TPC-Tire pressure monitor	RDK220	•	•	•	•	•	*	•	0005 0009
Up to 08/2003	SL	230	Body	System diagnosis(CAN)	SDS	•	•	•	•	0	•	0	
Up to 08/2003	SL	230	Body	AB-Airbag	ARMADA215_22 0_230	•	•	•	•	•	•	0	0041
Up to 08/2003	SL	230	Body	AB-Airbag	ARMIN	•	•	0	•	•	*	0	
Up to 08/2003	SL	230	Body	EZS-Electronic ignition switch	EZS230	•	•	•	•	•	*	0	
Up to 08/2003	SL	230	Body	OCP-Overhead control panel	DBE230	•	•	•	•	•	*	•	
Up to 08/2003	SL	230	Body	LCP-Lower control panel	UBF230	•	•	•	•	•	*	•	
Up to 08/2003	SL	230	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMF230	•	•	•	•	•	*	•	
Up to 08/2003	SL	230	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	SAMB230	•	•	•	•	•	*	•	
Up to 08/2003	SL	230	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH230	•	•	•	•	•	*	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special f	function p.	lease re	<u>fer to the special fu</u>	inction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 08/2003	SL	230	Body	BNS-Vehicle power supply control module	BNS230	•	•	•	•	•	*	0	
Up to 08/2003	SL	230	Body	RVC-Rollover bar/vario roof control module	UVS230	•	•	•	•	•	*		
Up to 08/2003	SL	230	Body	PSE-Pneumatic system equipment	PSE230	•	•	•	•	•	*	•	
Up to 08/2003	SL	230	Body	KG-Keyless Go	KEYG0220	•	•	•	•	•	*		
Up to 08/2003	SL	230	Body	HRA-FR-Front right headlamp range control	ALWRM203_230	•	•	•	•	•	0	•	
Up to 08/2003	SL	230	Body	HRA-FL-Front left headlamp range control	ALWRS203_230	•	•	•	•	•	0	0	
Up to 08/2003	SL	230	Information and communication	PTS-Parktronic system	PTS230	•	•	•	•	•	*		
Up to 08/2003	SL	230	Information and communication	SCM [MRM]-Steering column module	MRM230	•	•	•	•	•	*		
Up to 08/2003	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	KI230	•	•	•	•	•	0	•	0002
Up to 08/2003	SL	230	Information and communication	TV-TV tuner	TV	•	•	•	•		•	•	
Up to 08/2003	SL	230	Information and communication	E-call [Japan]-Telematic system	TAIDJAP2	•	•	•	•	•	•		
Up to 08/2003	SL	230	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
Up to 08/2003	SL	230	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
Up to 08/2003	SL	230	Information and communication	COMAND	COMAND	•	•	0	•	•	•	•	
Up to 08/2003	SL	230	Information and communication	D2B-COMAND, MCS or AUDIO	AVN	•	•	•	•	•	•		
Up to 08/2003	SL	230	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
Up to 08/2003	SL	230	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
Up to 08/2003	SL	230	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
Up to 08/2003	SL	230	Information and communication	SOUND- Sound system	SOUND	•	•	0	•	•	•	0	
Up to 08/2003	SL	230	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	0	
Up to 08/2003	SL	230	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		
Up to 08/2003	SL	230	Seats and doors	DCM-L-Door control module left	TSGVL230	•	•	•	•	•	*		
Up to 08/2003	SL	230	Seats and doors	DCM-R-Door control module right	TSGVR230	•	•	•	•	•	*		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special:	runction p	<u>lease</u> re:	<u>fer to the special fu</u>	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 08/2003	SL	230	Seats and doors	ESA-FL-Electric seat adjustment front left	SSGVL230	•	•	•	•	•	*	•	
Up to 08/2003	SL	230	Seats and doors	ESA-FR-Electric seat adjustment front right	SSGVR230	•	•	•	•	•	*	•	
Up to 08/2003	SL	230	Seats and doors	OSB-FL-Multicontour backrest front left	MKLVL215_230	•	•	•	•	•	*		
Up to 08/2003	SL	230	Seats and doors	OSB-FR-Multicontour backrest front right	MKLVR215_230	•	•	•	•	•	*		
Up to 08/2003	SL	230	Air conditioning	AAC-Automatic air conditioning	KLA230	•	•	•	•	•	*	•	
Up to 08/2003	SL	230	Air conditioning	STH-Stationary heater	STH230	•	•	•	•	•	*		
Up to 08/2003	SL	230	Air conditioning	HSW-Heated steering wheel	LRK_215_220_ 230	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
From 09/2003 to 05/2006	SL	230	Drive	ETC-Electronic transmission control	EGS53	•	•	•	•	•	•	•	
From 09/2003 to 05/2006	SL	230	Drive	SEQ-Sequentronic automated manual transmission	KSG	•	•	•	•	•	•		
From 09/2003 to 05/2006	SL	230	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
From 09/2003 to 05/2006	SL	230	Drive	ESM-Electronic selector module	EWM220	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Drive	DTR-Distronic	ARS210	•	•	•	•	•	•	0	
From 09/2003 to 05/2006	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
From 09/2003 to 05/2006	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
From 09/2003 to 05/2006	SL	230	Drive	DTR-Distronic	ART220	•	•	•	•	•	*	0	0005
From 09/2003 to 05/2006	SL	230	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
From 09/2003 to 05/2006	SL	230	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	MME275	•	•	•	•	•	•	•	0004
From 09/2003 to 05/2006	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	ME272	•	•	•	•	•	•		0004
From 09/2003 to 05/2006	SL	230	Chassis	SBC-Sensotronic Brake Control	EHB_ASG_2	•	•	•	•	•	•		0006 0007 0008 0038 0039
From 09/2003 to 05/2006	SL	230	Chassis	SBC-Sensotronic Brake Control	EHB_ASG_1	•	•	•	•	•	•		0006 0007 0008
From 09/2003 to 05/2006	SL	230	Chassis	ESP-Electronic stability program	EHB_FSG	•	•	•	•	•	•	•	0014



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p.	lease re	<u>fer to the special fu</u>	inction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 09/2003 to 05/2006	SL	230	Chassis	ESP-Electronic stability program	SBC121_F	•	•	•	•	•	•	•	0014
From 09/2003 to 05/2006	SL	230	Chassis	ABC-ABC active body control	ABC	•	•	•	•	•	*	•	0046, 0048, 0051, 0 052
From 09/2003 to 05/2006	SL	230	Chassis	ABC-ABC active body control	ABC230_MOPF	•	•	•	•	•	•	*	0045, 0048, 0060
From 09/2003 to 05/2006	SL	230	Chassis	TPC-Tire pressure monitor	RDK220	•	•	•	•	•	*	•	0005 0009
From 09/2003 to 05/2006	SL	230	Chassis	TPC-Tire pressure monitor	TPMLS	•	•	•	•	•	•	•	0005
From 09/2003 to 05/2006	SL	230	Body	CGW-Central gateway	ZGW220	•	•	•	•	0	0	0	0016 0017 0018
From 09/2003 to 05/2006	SL	230	Body	EZS-Electronic ignition switch	EZS230_2	•	•	•	•	•	*	0	0034
From 09/2003 to 05/2006	SL	230	Body	System diagnosis(CAN)	SDS	•	•	•	•	0	•	0	
From 09/2003 to 05/2006	SL	230	Body	AB-Airbag	ARMADA215_22 0_230	•	•	•	•	•	•	0	0041
From 09/2003 to 05/2006	SL	230	Body	WSS-Weight sensing system	WSS171	•	•	•	•	•	0	0	0005
From 09/2003 to 05/2006	SL	230	Body	OCP-Overhead control panel	DBE230	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Body	LCP-Lower control panel	UBF230	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMF230	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	SAMB230	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH230	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Body	BNS-Vehicle power supply control module	BNS230	•	•	•	•	•	*	0	
From 09/2003 to 05/2006	SL	230	Body	RVC-Rollover bar/vario roof control module	UVS230	•	•	•	•	•	*		
From 09/2003 to 05/2006	SL	230	Body	RVC-Rollover bar/vario roof control module	UVS230C	•	•	•	•	•	•		
From 09/2003 to 05/2006	SL	230	Body	PSE-Pneumatic system equipment	PSE230	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Body	KG-Keyless Go	KEYG0220	•	•	•	•	•	*		
From 09/2003 to 05/2006	SL	230	Body	KG-Keyless Go	KG230	•	•	•	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	<u>function p</u>	<u>lease re</u>	fer to the special fo	inction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
From 09/2003 to 05/2006	SL	230	Body	HRA-FR-Front right headlamp range control	ALWRM203_230	•	•	•	•	•	0	•	
From 09/2003 to 05/2006	SL	230	Body	HRA-FL-Front left headlamp range control	ALWRS203_230	•	•	•	•	•	0	0	
From 09/2003 to 05/2006	SL	230	Body	System diagnosis(CAN)	SD230	•	•	0	•	*	•		
From 09/2003 to 05/2006	SL	230	Information and communication	PTS-Parktronic system	PTS230	•	•	•	•	•	*		
From 09/2003 to 05/2006	SL	230	Information and communication	SCM [MRM]-Steering column module	MRM230	•	•	•	•	•	*		
From 09/2003 to 05/2006	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	KI230	•	•	•	•	•	0	•	0002
From 09/2003 to 05/2006	SL	230	Information and communication	TV-TV tuner	TV	•	•	•	•		•	•	
From 09/2003 to 05/2006	SL	230	Information and communication	E-call [Japan]-Telematic system	TAIDJAP2	•	•	•	•	•	•		
From 09/2003 to 05/2006	SL	230	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
From 09/2003 to 05/2006	SL	230	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
From 09/2003 to 05/2006	SL	230	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW220	•	•	•	•	•	•	0	
From 09/2003 to 05/2006	SL	230	Information and communication	CTEL-Telecommunication for telematics services	XCP	•	•	•	•	•	•	0	
From 09/2003 to 05/2006	SL	230	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	XCPTA	•	•	•	•	•	•		
From 09/2003 to 05/2006	SL	230	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
From 09/2003 to 05/2006	SL	230	Information and communication	AUDIO	XHU	•	•	•	•	•	•	•	0003
From 09/2003 to 05/2006	SL	230	Information and communication	NAVI-Navigation system	XNAVIH	•	•	0	•	•	•		
From 09/2003 to 05/2006	SL	230	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
From 09/2003 to 05/2006	SL	230	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
From 09/2003 to 05/2006	SL	230	Information and communication	SOUND-Bose sound system	XSND	•	•	0	•	•	•		
From 09/2003 to 05/2006	SL	230	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•	•	
From 09/2003 to 05/2006	SL	230	Information and communication	TV-TV tuner (AGW)	TV211	•	•	•	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease rei	<u>fer to the special f</u>	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
From 09/2003 to 05/2006	SL	230	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
From 09/2003 to 05/2006	SL	230	Information and communication	COMAND	COMAND	•	•	0	•	•	•	•	
From 09/2003 to 05/2006	SL	230	Information and communication	D2B-COMAND, MCS or AUDIO	AVN	•	•	•	•	•	•		
From 09/2003 to 05/2006	SL	230	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
From 09/2003 to 05/2006	SL	230	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
From 09/2003 to 05/2006	SL	230	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
From 09/2003 to 05/2006	SL	230	Information and communication	SOUND- Sound system	SOUND	•	•	0	•	•	•	0	
From 09/2003 to 05/2006	SL	230	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	TELE	•	•	•	•	0	0	0	
From 09/2003 to 05/2006	SL	230	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		
From 09/2003 to 05/2006	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	KI230_1	•	•	•	•	•	0	•	0002
From 09/2003 to 05/2006	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	KI230_2	•	•	•	•	•	0	•	0002
From 09/2003 to 05/2006	SL	230	Seats and doors	DCM-L-Door control module left	TSGVL230	•	•	•	•	•	*		
From 09/2003 to 05/2006	SL	230	Seats and doors	DCM-R-Door control module right	TSGVR230	•	•	•	•	•	*		
From 09/2003 to 05/2006	SL	230	Seats and doors	ESA-FL-Electric seat adjustment front left	SSGVL230	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Seats and doors	ESA-FR-Electric seat adjustment front right	SSGVR230	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Seats and doors	OSB-FL-Multicontour backrest front left	MKLVL215_230	•	•	•	•	•	*		
From 09/2003 to 05/2006	SL	230	Seats and doors	OSB-FR-Multicontour backrest front right	MKLVR215_230	•	•	•	•	•	*		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

AS for special	runction p	<u>rease re</u> :	fer to the special fi	inction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 09/2003 to 05/2006	SL	230	Air conditioning	AAC-Automatic air conditioning	KLA230	•	•	•	•	•	*	•	
From 09/2003 to 05/2006	SL	230	Air conditioning	STH-Stationary heater	STH230	•	•	•	•	•	*		
From 09/2003 to 05/2006	SL	230	Air conditioning	HSW-Heated steering wheel	LRK_215_220_ 230	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
From 06/2006 to 02/2008	SL	230	Drive	ETC-Electronic transmission control	EGS53	•	•	•	•	•	•	•	
From 06/2006 to 02/2008	SL	230	Drive	SEQ-Sequentronic automated manual transmission	KSG	•	•	•	•	•	•		
From 06/2006 to 02/2008	SL	230	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
From 06/2006 to 02/2008	SL	230	Drive	ESM-Electronic selector module	EWM220	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230	Drive	DTR-Distronic	ARS210	•	•	•	•	•	•	0	
From 06/2006 to 02/2008	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
From 06/2006 to 02/2008	SL	230	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
From 06/2006 to 02/2008	SL	230	Drive	DTR-Distronic	ART220	•	•	•	•	•	*	0	0005
From 06/2006 to 02/2008	SL	230	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
From 06/2006 to 02/2008	SL	230	Drive	ME-SFI 2.7.1-Motor electronics 2.7.1	MME275	•	•	•	•	•	•	•	0004
From 06/2006 to 02/2008	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	ME272	•	•	•	•	•	•		0004
From 06/2006 to 02/2008	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	ME272AMG	•	•	•	•	•	•		0004
From 06/2006 to 02/2008	SL	230	Chassis	SBC-Sensotronic Brake Control	EHB_ASG_2	•	•	•	•	•	•		0006 0007 0008 0038 0039
From 06/2006 to 02/2008	SL	230	Chassis	SBC-Sensotronic Brake Control	EHB_ASG_1	•	•	•	•	•	•		0006 0007 0008 0038 0039
From 06/2006 to 02/2008	SL	230	Chassis	ESP-Electronic stability program	EHB_FSG	•	•	•	•	•	•	•	0014
From 06/2006 to 02/2008	SL	230	Chassis	ESP-Electronic stability program	SBC121_F	•	•	•	•	•	•	•	0014
From 06/2006 to 02/2008	SL	230	Chassis	ABC-ABC active body control	ABC	•	•	•	•	•	*	•	0046, 0048, 0051, 0 052



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

AS TOT SPECIAL I	unction p.		fer to the special fu	miction table.			- 4	_	_				
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2006 to 02/2008	SL	230	Chassis	ABC-ABC active body control	ABC230_MOPF	•	•	•	•	•	•	*	0045, 0048, 0060
From 06/2006 to 02/2008	SL	230	Chassis	TPC-Tire pressure monitor	RDK220	•	•	•	•	•	*	•	0005 0009
From 06/2006 to 02/2008	SL	230	Chassis	TPC-Tire pressure monitor	TPMLS	•	•	•	•	•	•	•	0005
From 06/2006 to 02/2008	SL	230	Body	CGW-Central gateway	ZGW220	•	•	•	•	0	0	0	0016 0017 0018
From 06/2006 to 02/2008	SL	230	Body	EZS-Electronic ignition switch	EZS230_2	•	•	•	•	•	*	0	0034
From 06/2006 to 02/2008	SL	230	Body	System diagnosis(CAN)	SDS	•	•	•	•	0	•	0	
From 06/2006 to 02/2008	SL	230	Body	AB-Airbag	ARMADA215_22 0_230	•	•	•	•	•	•	0	0041
From 06/2006 to 02/2008	SL	230	Body	WSS-Weight sensing system	WSS171	•	•	•	•	•	0	0	0005
From 06/2006 to 02/2008	SL	230	Body	OCP-Overhead control panel	DBE230	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230	Body	LCP-Lower control panel	UBF230	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMF230	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	SAMB230	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH230	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230	Body	BNS-Vehicle power supply control module	BNS230	•	•	•	•	•	*	0	
From 06/2006 to 02/2008	SL	230	Body	RVC-Rollover bar/vario roof control module	UVS230	•	•	•	•	•	*		
From 06/2006 to 02/2008	SL	230	Body	RVC-Rollover bar/vario roof control module	UVS230C	•	•	•	•	•	•		
From 06/2006 to 02/2008	SL	230	Body	PSE-Pneumatic system equipment	PSE230	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230	Body	KG-Keyless Go	KEYG0220	•	•	•	•	•	*		
From 06/2006 to 02/2008	SL	230	Body	KG-Keyless Go	KG230	•	•	•	•	•	•		
From 06/2006 to 02/2008	SL	230	Body	HRA-FR-Front right headlamp range control	ALWRM203_230	•	•	•	•	•	0	•	
From 06/2006 to 02/2008	SL	230	Body	HRA-FL-Front left headlamp range control	ALWRS203_230	•	•	•	•	•	0	0	



NOTES:

This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

** This function may be supported, which depends on the actual condition of the vehicle.

** As for special function please refer to the special function table.

As for special	function p		fer to the special fu	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2006 to 02/2008	SL	230	Body	System diagnosis(CAN)	SD230	•	•	0	•	*	•		
From 06/2006 to 02/2008	SL	230	Information and communication	PTS-Parktronic system	PTS230	•	•	•	•	•	*		
From 06/2006 to 02/2008	SL	230	Information and communication	SCM [MRM]-Steering column module	MRM230	•	•	•	•	•	*		
From 06/2006 to 02/2008	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	KI230	•	•	•	•	•	0	•	0002
From 06/2006 to 02/2008	SL	230	Information and communication	TV-TV tuner	TV	•	•	•	•		•	•	
From 06/2006 to 02/2008	SL	230	Information and communication	E-call [Japan]-Telematic system	TAIDJAP2	•	•	•	•	•	•		
From 06/2006 to 02/2008	SL	230	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
From 06/2006 to 02/2008	SL	230	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW220	•	•	•	•	•	•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	CTEL-Telecommunication for telematics services	XCP	•	•	•	•	•	•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	XCPTA	•	•	•	•	•	•		
From 06/2006 to 02/2008	SL	230	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	AUDIO	XHU	•	•	•	•	•	•	•	0003
From 06/2006 to 02/2008	SL	230	Information and communication	NAVI-Navigation system	XNAVIH	•	•	0	•	•	•		
From 06/2006 to 02/2008	SL	230	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
From 06/2006 to 02/2008	SL	230	Information and communication	SOUND-Bose sound system	XSND	•	•	0	•	•	•		
From 06/2006 to 02/2008	SL	230	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•	•	
From 06/2006 to 02/2008	SL	230	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease re	fer to the special fu	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	COMAND	COMAND	•	•	0	•	•	•	•	
From 06/2006 to 02/2008	SL	230	Information and communication	D2B-COMAND, MCS or AUDIO	AVN	•	•	•	•	•	•		
From 06/2006 to 02/2008	SL	230	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
From 06/2006 to 02/2008	SL	230	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
From 06/2006 to 02/2008	SL	230	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
From 06/2006 to 02/2008	SL	230	Information and communication	SOUND- Sound system	SOUND	•	•	0	•	•	•	0	
From 06/2006 to 02/2008	SL	230	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	0	
From 06/2006 to 02/2008	SL	230	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		
From 06/2006 to 02/2008	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	KI230_1	•	•	•	•	•	0	•	0002
From 06/2006 to 02/2008	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	KI230_2	•	•	•	•	•	0	•	0002
From 06/2006 to 02/2008	SL	230	Seats and doors	DCM-L-Door control module left	TSGVL230	•	•	•	•	•	*		
From 06/2006 to 02/2008	SL	230	Seats and doors	DCM-R-Door control module right	TSGVR230	•	•	•	•	•	*		
From 06/2006 to 02/2008	SL	230	Seats and doors	ESA-FL-Electric seat adjustment front left	SSGVL230	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230	Seats and doors	ESA-FR-Electric seat adjustment front right	SSGVR230	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230	Seats and doors	OSB-FL-Multicontour backrest front left	MKLVL215_230	•	•	•	•	•	*		
From 06/2006 to 02/2008	SL	230	Seats and doors	OSB-FR-Multicontour backrest front right	MKLVR215_230	•	•	•	•	•	*		
From 06/2006 to 02/2008	SL	230	Air conditioning	AAC-Automatic air conditioning	KLA230	•	•	•	•	•	*	•	
From 06/2006 to 02/2008	SL	230	Air conditioning	STH-Stationary heater	STH230	•	•	•	•	•	*		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	<u>lease re</u>	fer to the special f	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
From 06/2006 to 02/2008	SL	230	Air conditioning	HSW-Heated steering wheel	LRK_215_220_ 230	•	•	•	•	•	*	•	
As of 03/2008	SL	230	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
As of 03/2008	SL	230	Drive	ETC-Electronic transmission control	EGS53	•	•	•	•	•	•	•	
As of 03/2008	SL	230	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
As of 03/2008	SL	230	Drive	ESM-Electronic selector module	EWM220	•	•	•	•	•	*	•	
As of 03/2008	SL	230	Drive	DTR-Distronic	ARS210	•	•	•	•	•	•	0	
As of 03/2008	SL	230	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
As of 03/2008	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	ME272	•	•	•	•	•	•		0004
As of 03/2008	SL	230	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	ME97AMG	•	•	•	•	•	•	•	0004 0013
As of 03/2008	SL	230	Drive	ME 2.7.2-Motor electronics 2.7.2	ME272AMG	•	•	•	•	•	•		0004
As of 03/2008	SL	230	Chassis	SBC-Sensotronic Brake Control	EHB_ASG_2	•	•	•	•	•	•		0006 0007 0008 0038 0039
As of 03/2008	SL	230	Chassis	ESP-Electronic stability program	SBC121_F	•	•	•	•	•	•	•	0014
As of 03/2008	SL	230	Chassis	ABC-ABC active body control	ABC230_MOPF	•	•	•	•	•	•	*	0045, 0048, 0060
As of 03/2008	SL	230	Chassis	TPC-Tire pressure monitor	TPMLS	•	•	•	•	•	•	•	0005
As of 03/2008	SL	230	Body	CGW-Central gateway	ZGW220	•	•	•	•	0	0	0	0016 0017 0018
As of 03/2008	SL	230	Body	EZS-Electronic ignition switch	EZS230_2	•	•	•	•	•	*	0	0034
As of 03/2008	SL	230	Body	System diagnosis(CAN)	SDS	•	•	•	•	0	•	0	
As of 03/2008	SL	230	Body	AB-Airbag	ARMADA215_22 0_230	•	•	•	•	•	•	0	0041
As of 03/2008	SL	230	Body	WSS-Weight sensing system	WSS171	•	•	•	•	•	0	0	0005
As of 03/2008	SL	230	Body	OCP-Overhead control panel	DBE230	•	•	•	•	•	*	•	
As of 03/2008	SL	230	Body	LCP-Lower control panel	UBF230	•	•	•	•	•	*	•	
As of 03/2008	SL	230	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMF230	•	•	•	•	•	*	•	
As of 03/2008	SL	230	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	SAMB230	•	•	•	•	•	*	•	
As of 03/2008	SL	230	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH230	•	•	•	•	•	*	•	
As of 03/2008	SL	230	Body	BNS-Vehicle power supply control module	BNS230	•	•	•	•	•	*	0	
As of 03/2008	SL	230	Body	RVC-Rollover bar/vario roof control module	UVS230C	•	•	•	•	•	•		
As of 03/2008	SL	230	Body	PSE-Pneumatic system equipment	PSE230	•	•	•	•	•	*	•	
As of 03/2008	SL	230	Body	KG-Keyless Go	KG230	•	•	•	•	•	•		
As of 03/2008	SL	230	Body	XALWA-L-Xenon headlamp, left	ALWRL230M2	•	•	•	•	•	•	*	
As of 03/2008	SL	230	Body	XALWA-R-Xenon headlamp, right	ALWRR230M2	•	•	•	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	<u>lease re</u>	fer to the special f	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory				Active Test	Special Function
As of 03/2008	SL	230	Body	System diagnosis(CAN)	SD230	•	•	0	•	*	•		
As of 03/2008	SL	230	Body	DRVU-Drive Unit	DRVU230	•	•	•	•	•	•		
As of 03/2008	SL	230	Information and communication	PTS-Parktronic system	PTS230MOPF	•	•	•	•	•	•		
As of 03/2008	SL	230	Information and communication	SCM [MRM]-Steering column module	MRM230	•	•	•	•	•	*		
As of 03/2008	SL	230	Information and communication	ICM-Instrument cluster with maintenance interval display	KI230	•	•	•	•	•	0	•	0002
As of 03/2008	SL	230	Information and communication	TV-TV tuner	TV	•	•	•	•		•	•	
As of 03/2008	SL	230	Information and communication	E-call [Japan]-Telematic system	TAIDJAP2	•	•	•	•	•	•		
As of 03/2008	SL	230	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
As of 03/2008	SL	230	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
As of 03/2008	SL	230	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW220	•	•	•	•	•	•	0	
As of 03/2008	SL	230	Information and communication	CTEL-Telecommunication for telematics services	XCP	•	•	•	•	•	•	0	
As of 03/2008	SL	230	Information and communication	Telephone adapter for portable CTEL- Telecommunication for telematics services	XCPTA	•	•	•	•	•	•		
As of 03/2008	SL	230	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
As of 03/2008	SL	230	Information and communication	AUDIO	XHU	•	•	•	•	•	•	•	0003
As of 03/2008	SL	230	Information and communication	NAVI-Navigation system	XNAVIH	•	•	0	•	•	•		
As of 03/2008	SL	230	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
As of 03/2008	SL	230	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
As of 03/2008	SL	230	Information and communication	SOUND-Bose sound system	XSND	•	•	0	•	•	•		
As of 03/2008	SL	230	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•	•	
As of 03/2008	SL	230	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
As of 03/2008	SL	230	Information and communication	COMAND or AUDIO	HU25	•	•	•	•	•	•		
As of 03/2008	SL	230	Information and communication	SOUND- Sound system	SOUND25	•	•	•	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease re	fer to the special fu	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	_	Active Test	Special Function
As of 03/2008	SL	230	Information and communication	UCI	UCI25	•	•	•	•	•	•	0	
As of 03/2008	SL	230	Information and communication	DAB-Digital radio	DAB25	•	•	•	•	•	0		
As of 03/2008	SL	230	Information and communication	SDAR-Satellite radio(Valid for USA)	SDARS25	•	•	•	•	•	•		
As of 03/2008	SL	230	Information and communication	TV-TV tuner	TV25	•	•	•	•	•	•		
As of 03/2008	SL	230	Information and communication	CTEL-Cellular telephone(JAPAN)	CBJ25	•	•	•	•	•	0		
As of 03/2008	SL	230	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
As of 03/2008	SL	230	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
As of 03/2008	SL	230	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
As of 03/2008	SL	230	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
As of 03/2008	SL	230	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
As of 03/2008	SL	230	Seats and doors	DCM-L-Door control module left	TSGVL230	•	•	•	•	•	*		
As of 03/2008	SL	230	Seats and doors	DCM-R-Door control module right	TSGVR230	•	•	•	•	•	*		
As of 03/2008	SL	230	Seats and doors	ESA-FL-Electric seat adjustment front left	SSGVL230	•	•	•	•	•	*	•	
As of 03/2008	SL	230	Seats and doors	ESA-FR-Electric seat adjustment front right	SSGVR230	•	•	•	•	•	*	•	
As of 03/2008	SL	230	Seats and doors	OSB-FL-Multicontour backrest front left	MKLVL215_230	•	•	•	•	•	*		
As of 03/2008	SL	230	Seats and doors	OSB-FR-Multicontour backrest front right	MKLVR215_230	•	•	•	•	•	*		
As of 03/2008	SL	230	Seats and doors	AIRSCARF	AS_230	•	•	•	•	•	•		
As of 03/2008	SL	230	Air conditioning	AAC-Automatic air conditioning	KLA230	•	•	•	•	•	*	•	
As of 03/2008	SL	230	Air conditioning	STH-Stationary heater	STH230	•	•	•	•	•	*		
As of 03/2008	SL	230	Air conditioning	HSW-Heated steering wheel	LRK_215_220_ 230	•	•	•	•	•	*	•	
As of 09/99	SL	129	Drive	ETC-Electronic transmission control	EGS_H	•	•	0	•		*		
As of 09/99	SL	129	Drive	ME2-SFI-Motor electronics 2	ME2_H	•	•	0	•	•	*		
As of 09/99	SL	129	Drive	ME1-SFI-Motor electronics	ME1_H	•	•	0	•		*		
As of 09/99	SL	129	Chassis	ASR-Acceleration Slip Regulation	ASR34_H	•	•	0	•	•	*		
As of 09/99	SL	129	Chassis	ESP-Electronic stability program	ESP35_H	•	•	0	•	•	*	1	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	<u>l function p</u>	<u>olease re</u>	fer to the special	function table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
As of 09/99	SL	129	Chassis	ASR-Acceleration Slip Regulation	ASR30_H	•	•	0	•	•	*		
As of 09/99	SL	129	Chassis	ESP-Electronic stability program	ESP30_H	•	•	0	•	•	*		0040
As of 09/99	SL	129	Chassis	ETS-Electronic traction system	ETS30_H	•	•	0	•	•	*		
As of 09/99	SL	129	Chassis	ESP-Electronic stability program	ESP34_H	•	•	0	•	•	*		
As of 09/99	SL	129	Chassis	BAS-Brake assist	BAS_H	•	•	0	•	•	*		
As of 09/99	SL	129	Body	AB-Airbag	ZAE_H	•	•	0	•		*		
As of 09/99	SL	129	Body	HRA-Headlamp range adjustment	LWR1_H	•	•	0	•		*		
As of 09/99	SL	129	Body	RFL-Radio frequency locking/electric central locking	FFZ_H	•	•	0	•	•	*		
As of 09/99	SL	129	Body	APS-Auto pilot system	APS_H	•	•	0	•	•	*		
As of 09/99	SL	129	Information and communication	ICM-Instrument cluster with maintenance interval display	KIW_H	•	•	0	•	•	*	•	0002
As of 09/99	SL	129	Information and communication	ICM-Instrument cluster with maintenance interval display	KIL	•	•	•	•	•	•		0002
As of 09/99	SL	129	Information and communication	TELE AID-Emergency call system	ECALLECE	•	•	•	•	•	•		
As of 09/99	SL	129	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
As of 09/99	SL	129	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
As of 09/99	SL	129	Information and communication	DN-Dynamic navigation by means of CTEL	TELEDZS	•	•	•	•	•	0	0	
As of 09/99	SL	129	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
As of 09/99	SL	129	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
As of 09/99	SL	129	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
As of 09/99	SL	129	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable) (D2B)	TELE	•	•	•	•	0	0	0	
As of 09/99	SL	129	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable) (D2B)	UHI	•	•	•	•	•	0		
As of 09/99	SL	129	Air conditioning	AAC-Automatic air conditioning	KLA_H	•	•	0	•		*		
As of 09/99	SL	129	Air conditioning	STH-Stationary heater	STH_H	•	•	0	•	•	*		
A11	SLR	199	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
A11	SLR	199	Drive	ESM-Electronic selector module	EWM220	•	•	•	•	•	*	•	
A11	SLR	199	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
A11	SLR	199	Chassis	SBC-Sensotronic Brake Control	EHB_ASG	•	•	•	•	•	0	0	0006 0007 0008 0038 0039



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	<u>lease re</u>	fer to the special fo	inction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
A11	SLR	199	Chassis	ESP-Electronic stability program	EHB_FSG	•	•	•	•	•	•	•	0014
A11	SLR	199	Chassis	TPC-Tire pressure monitor	RDK220	•	•	•	•	•	*	•	0005 0009
A11	SLR	199	Chassis	TPC-Tire pressure monitor	TPMLS	•	•	•	•	•	•	•	0005
A11	SLR	199	Body	EZS-Electronic ignition switch	EZS230	•	•	•	•	•	*	0	
A11	SLR	199	Body	OCP-Overhead control panel	DBE230	•	•	•	•	•	*	•	
A11	SLR	199	Body	LCP-Lower control panel	UBF230	•	•	•	•	•	*	•	
A11	SLR	199	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMF230	•	•	•	•	•	*	•	
A11	SLR	199	Body	Pass-side SAM-Passenger-side signal acquisition and actuation module	SAMB230	•	•	•	•	•	*	•	
A11	SLR	199	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH230	•	•	•	•	•	*	•	
A11	SLR	199	Body	BNS-Vehicle power supply control module	BNS230	•	•	•	•	•	*	0	
A11	SLR	199	Body	HRA-FR-Front right headlamp range control	ALWRM203_230	•	•	•	•	•	0	•	
A11	SLR	199	Body	HRA-FL-Front left headlamp range control	ALWRS203_230	•	•	•	•	•	0	0	
A11	SLR	199	Body	RS-Roadster soft top	VSG_X199	•	•	•	•	•	•	0	
A11	SLR	199	Body	CGW-Central gateway	ZGW220	•	•	•	•	0	0	0	0016 0017 0018
A11	SLR	199	Body	AB-Airbag	ARMADA215_22 0_230	•	•	•	•	•	•	0	0041
A11	SLR	199	Body	WSS-Weight sensing system	WSS171	•	•	•	•	•	0	0	0005
A11	SLR	199	Body	ACL [ZLB]-Air brake (spoiler) and central locking control unit	ACL199	•	•	•	•	•	•	•	
A11	SLR	199	Body	System diagnosis(CAN)	SD211	•	•	•	•	•	•		
A11	SLR	199	Information and communication	SCM [MRM]-Steering column module	MRM230	•	•	•	•	•	*		
A11	SLR	199	Information and communication	ICM-Instrument cluster with maintenance interval display	KI230	•	•	•	•	•	0	•	0002
A11	SLR	199	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
A11	SLR	199	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
A11	SLR	199	Information and communication	SOUND- Sound system	SOUND	•	•	0	•	•	•	0	
A11	SLR	199	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	0	
A11	SLR	199	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		



NOTES:

• This function is supported.

- ▲ This function is the new feature in this version.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	<u>lease re</u>	<u>fer to the special</u>	function table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
A11	SLR	199	Information and communication	E-call [Japan]-Telematic system	TAIDJAP2	•	•	•	•	•	•		
A11	SLR	199	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
A11	SLR	199	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
A11	SLR	199	Seats and doors	DCM-L-Door control module left	TSGVL230	•	•	•	•	•	*		
A11	SLR	199	Seats and doors	DCM-R-Door control module right	TSGVR230	•	•	•	•	•	*		
A11	SLR	199	Air conditioning	AAC-Automatic air conditioning	KLA230	•	•	•	•	•	*	•	
Up to 05/2005	SLK	171	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
Up to 05/2005	SLK	171	Drive	SEQ-Sequentronic automated manual transmission	KSG	•	•	•	•	•	•		
Up to 05/2005	SLK	171	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
Up to 05/2005	SLK	171	Drive	ESM-Electronic selector module	EWM203	•	•	•	•	•	0	•	0003
Up to 05/2005	SLK	171	Drive	ME-SFI-Motor electronics	SIM4LSE	•	•	•	•	•	•	•	0013
Up to 05/2005	SLK	171	Drive	ME-SFI-Motor electronics	SIM4LDE	•	•	•	•	•	•	•	0013
Up to 05/2005	SLK	171	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
Up to 05/2005	SLK	171	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
Up to 05/2005	SLK	171	Chassis	ESP-Electronic stability program	ESPMK25	•	•	•	•	•	•		0047, 0015
Up to 05/2005	SLK	171	Body	CGW-Central gateway	ZGW171	•	•	•	•	•	0	0	0016 0017 0018
Up to 05/2005	SLK	171	Body	EZS-Electronic ignition switch	EZS211	•	•	•	•	•	0	*	0027 0028 0029 0030 0031 0032 0033 0034 0035 0036 0037
Up to 05/2005	SLK	171	Body	System diagnosis(CAN)	SD211	•	•	•	•	•	•		
Up to 05/2005	SLK	171	Body	AB-Airbag	ARMADA	•	•	•	•	•	•	0	0003 0010 0041
Up to 05/2005	SLK	171	Body	VR-Vario roof	VSG_R171	•	•	•	•	•	0	•	
Up to 05/2005	SLK	171	Body	UCP-Upper control panel	OBF171	•	•	•	•	•	0	•	
Up to 05/2005	SLK	171	Body	OCP-Overhead control panel	DBE171	•	•	•	•	•	0	•	
Up to 05/2005	SLK	171	Body	SAM-F-Signal acquisition and actuation module front	SAMV171	•	•	•	•	•	0	•	
Up to 05/2005	SLK	171	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH171	•	•	•	•	•	0	•	
Up to 05/2005	SLK	171	Body	HRA-Automatic headlamp range adjustment and headlamp control	ALWR211	•	•	•	•	•	0	•	0005 0009
Up to 05/2005	SLK	171	Information and communication	PTS-Parktronic system	PTS211	•	•	•	•	•	•	•	
Up to 05/2005	SLK	171	Information and communication	SCM [MRM]-Steering column module	MRM171	•	•	•	•	•	•	•	



NOTES:

This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

As for specia	1 function p	olease re	fer to the special f	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
Up to 05/2005	SLK	171	Information and communication	IC-Instrument cluster	KI171	•	•	•	•	•	0	•	
Up to 05/2005	SLK	171	Information and communication	ASSYST-Active Service System	WIA171	•	•	0	•	•	0	0	0001
Up to 05/2005	SLK	171	Information and communication	ASSYST PLUS-PLUS Active Service System	WR171	•	•	0	•	•	•	0	0002
Up to 05/2005	SLK	171	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
Up to 05/2005	SLK	171	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
Up to 05/2005	SLK	171	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
Up to 05/2005	SLK	171	Information and communication	AUDIO	XHU	•	•	•	•	•	•	•	0003
Up to 05/2005	SLK	171	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•	•	
Up to 05/2005	SLK	171	Information and communication	NAVI-Navigation system	XNAVIH	•	•	0	•	•	•		
Up to 05/2005	SLK	171	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
Up to 05/2005	SLK	171	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
Up to 05/2005	SLK	171	Information and communication	COMAND or AUDIO	HU25	•	•	•	•	•	•		
Up to 05/2005	SLK	171	Information and communication	SOUND- Sound system	SOUND25	•	•	•	•	•	•		
Up to 05/2005	SLK	171	Information and communication	UCI	UCI25	•	•	•	•	•	•	0	
Up to 05/2005	SLK	171	Information and communication	DAB-Digital radio	DAB25	•	•	•	•	•	0		
Up to 05/2005	SLK	171	Information and communication	SDAR-Satellite radio(Valid for USA)	SDARS25	•	•	•	•	•	•		
Up to 05/2005	SLK	171	Information and communication	TV-TV tuner	TV25	•	•	•	•	•	•		
Up to 05/2005	SLK	171	Information and communication	CTEL-Cellular telephone(JAPAN)	CBJ25	•	•	•	•	•	0		
Up to 05/2005	SLK	171	Information and communication	GPS box	XGPSB0X	•	•	0	•	•	•	0	
Up to 05/2005	SLK	171	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	



NOTES:

- This function is supported.
- ▲ This function is the new feature in this version.
- O This function is not supported.

 ** This function may be supported, which depends on the actual condition of the vehicle.

 ** As for special function please refer to the special function table.

As for special	l function p		fer to the special f	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
Up to 05/2005	SLK	171	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
Up to 05/2005	SLK	171	Information and communication	TELE AID-Telematic servicesMB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
Up to 05/2005	SLK	171	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
Up to 05/2005	SLK	171	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
Up to 05/2005	SLK	171	Seats and doors	DCM-L-Door control module left	TSGVL171	•	•	•	•	•	0	•	
Up to 05/2005	SLK	171	Seats and doors	DCM-R-Door control module right	TSGVR171	•	•	•	•	•	0	•	
Up to 05/2005	SLK	171	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164	•	•	•	•	•	0	•	
Up to 05/2005	SLK	171	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164	•	•	•	•	•	0	•	
Up to 05/2005	SLK	171	Seats and doors	HS-Seat heater	SHZ171	•	•	•	•	•	0	•	
Up to 05/2005	SLK	171	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	KLA171	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
As of 06/2005	SLK	171	Drive	ETC-Electronic transmission control	EGS53	•	•	•	•	•	•	•	
As of 06/2005	SLK	171	Drive	SEQ-Sequentronic automated manual transmission	KSG	•	•	•	•	•	•		
As of 06/2005	SLK	171	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
As of 06/2005	SLK	171	Drive	ESM-Electronic selector module	EWM203	•	•	•	•	•	0	•	0003
As of 06/2005	SLK	171	Drive	ME-SFI-Motor electronics	SIM4LSE	•	•	•	•	•	•	•	0013
As of 06/2005	SLK	171	Drive	ME-SFI-Motor electronics	SIM4LDE	•	•	•	•	•	•	•	0013
As of 06/2005	SLK	171	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004
As of 06/2005	SLK	171	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
As of 06/2005	SLK	171	Chassis	ESP-Electronic stability program	ESPMK25	•	•	•	•	•	•		0047, 0015
As of 06/2005	SLK	171	Chassis	TPC-Tire pressure monitor	TPM_209	•	•	•	•	•	•	•	0005
As of 06/2005	SLK	171	Body	CGW-Central gateway	ZGW171	•	•	•	•	•	0	0	0016 0017 0018
As of 06/2005	SLK	171	Body	EZS-Electronic ignition switch	EZS211	•	•	•	•	•	0	*	0027 0028 0029 0030 0031 0032 0033 0034 0035 0036 0037
As of 06/2005	SLK	171	Body	System diagnosis(CAN)	SD211	•	•	•	•	•	•		
As of 06/2005	SLK	171	Body	AB-Airbag	ARMADA	•	•	•	•	•	•	0	0003 0010 0041
As of 06/2005	SLK	171	Body	WSS-Weight sensing system	WSS171	•	•	•	•	•	0	0	0005



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease re	<u>fer to the special f</u>	function table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes		Freeze Frame	Active Test	Special Function
As of 06/2005	SLK	171	Body	VR-Vario roof	VSG_R171	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Body	UCP-Upper control panel	OBF171	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Body	OCP-Overhead control panel	DBE171	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Body	SAM-F-Signal acquisition and actuation module front	SAMV171	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH171	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Body	HRA-Automatic headlamp range adjustment and headlamp control	ALWR211	•	•	•	•	•	0	•	0005 0009
As of 06/2005	SLK	171	Information and communication	PTS-Parktronic system	PTS211	•	•	•	•	•	•	•	
As of 06/2005	SLK	171	Information and communication	PTS-Parktronic system	PTS211MOPF	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Information and communication	SCM [MRM]-Steering column module	MRM171	•	•	•	•	•	•	•	
As of 06/2005	SLK	171	Information and communication	IC-Instrument cluster	KI171	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Information and communication	ASSYST-Active Service System	WIA171	•	•	0	•	•	0	0	0001
As of 06/2005	SLK	171	Information and communication	ASSYST PLUS-PLUS Active Service System	WR171	•	•	0	•	•	•	0	0002
As of 06/2005	SLK	171	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
As of 06/2005	SLK	171	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
As of 06/2005	SLK	171	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
As of 06/2005	SLK	171	Information and communication	AUDIO	XHU	•	•	•	•	•	•	•	0003
As of 06/2005	SLK	171	Information and communication	COMAND or AUDIO	хнијр	•	•	0	•	•	•	•	
As of 06/2005	SLK	171	Information and communication	NAVI-Navigation system	XNAVIH	•	•	0	•	•	•		
As of 06/2005	SLK	171	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
As of 06/2005	SLK	171	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
As of 06/2005	SLK	171	Information and communication	COMAND or AUDIO	HU25	•	•	•	•	•	•		
As of 06/2005	SLK	171	Information and communication	SOUND- Sound system	SOUND25	•	•	•	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special i	function p	<u>lease re</u> i	fer to the special fu	inction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 06/2005	SLK	171	Information and communication	UCI	UCI25	•	•	•	•	•	•	0	
As of 06/2005	SLK	171	Information and communication	DAB-Digital radio	DAB25	•	•	•	•	•	0		
As of 06/2005	SLK	171	Information and communication	SDAR-Satellite radio(Valid for USA)	SDARS25	•	•	•	•	•	•		
As of 06/2005	SLK	171	Information and communication	TV-TV tuner	TV25	•	•	•	•	•	•		
As of 06/2005	SLK	171	Information and communication	CTEL-Cellular telephone(JAPAN)	CBJ25	•	•	•	•	•	0		
As of 06/2005	SLK	171	Information and communication	GPS box	XGPSBOX	•	•	0	•	•	•	0	
As of 06/2005	SLK	171	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
As of 06/2005	SLK	171	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
As of 06/2005	SLK	171	Information and communication	TELE AID-Telematic servicesMB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
As of 06/2005	SLK	171	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
As of 06/2005	SLK	171	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
As of 06/2005	SLK	171	Seats and doors	DCM-L-Door control module left	TSGVL171	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Seats and doors	DCM-R-Door control module right	TSGVR171	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Seats and doors	HS-Seat heater	SHZ171	•	•	•	•	•	0	•	
As of 06/2005	SLK	171	Air conditioning	C-AAC-Convenience automatic air conditioning/AAC-Automatic air conditioning/HEAT-Automatic heater	KLA171	•	•	•	•	•	0	•	
A11	SLK	170(16- pin diagnost ic socket)	Drive	ETC-Electronic transmission control	EGS	•	•	0	•	•	*	•	
A11	SLK	170 (16- pin diagnost ic socket)	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	<u>lease re</u>	<u>fer to the special fu</u>	unction table.									
Model year	Model	Mode1	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes		Erase Codes		Freeze Frame	Active Test	Special Function
A11	SLK	170(16- pin diagnost ic socket)	Drive	ESM-Electronic selector module	EWM210	•	•	0	•	•	*	•	
A11	SLK	170(16- pin diagnost ic socket)	Drive	ME-SFI-Motor electronics	SIM4	•	•	•	•	•	•	•	0013
A11	SLK	170(16- pin diagnost ic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
A11	SLK	170(16- pin diagnost ic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
A11	SLK	170 (16- pin diagnost ic socket)	Chassis	ESP-Electronic stability program	ESP203_1	•	•	•	•	•	•		0047
A11	SLK	170(16- pin diagnost ic socket)	Chassis	ESP-Electronic stability program	ESPMK25	•	•	•	•	•	•		0047, 0015
A11	SLK	170(16- pin diagnost ic socket)	Chassis	BAS-Brake assist	BAS203	•	•	0	•	•	•	0	
A11	SLK	170(16- pin diagnost ic socket)	Chassis	VP-Vacuum pump brake booster	UP28	•	•	•	•	•	•	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	<u>lease re</u>	<u>fer to the special fu</u>	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes		Erase Codes		Freeze Frame	Active Test	Special Function
A11	SLK	170(16- pin diagnost ic socket)	Body	AB-Airbag	ZAE_H	•	•	0	•		*		
A11	SLK	170(16- pin diagnost ic socket)	Body	RFL-Radio frequency locking/electric central locking	FFZ_H	•	•	0	•	•	*		
A11	SLK	170(16- pin diagnost ic socket)	Body	PSE-Pneumatic system equipment	PSZ_H	•	•	0	•	•	*		
A11	SLK	170(16- pin diagnost ic socket)	Body	CCM-Multifunction control module	SKF_H	•	•	0	•	•	*		
A11	SLK	170(16- pin diagnost ic socket)	Body	VR-Vario roof	VD_H	•	•	0	•	•	*	•	
A11	SLK	170(16- pin diagnost ic socket)	Body	HRA-Headlamp range adjustment	LWR170	•	•	•	•	•	*	0	
A11	SLK	170(16- pin diagnost ic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	KIW_H	•	•	0	•	•	*	•	0002
A11	SLK	170(16- pin diagnost ic socket)	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease re	<u>fer to the special fu</u>	inction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
A11	SLK	170 (16- pin diagnost ic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	0	
A11	SLK	170(16- pin diagnost ic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		
A11	SLK	170(16- pin diagnost ic socket)	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
A11	SLK	170 (16- pin diagnost ic socket)	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
A11	SLK	170 (16- pin diagnost ic socket)	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
A11	SLK	170(16- pin diagnost ic socket)	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
A11	SLK	170(16- pin diagnost ic socket)	Air conditioning	TAC-Automatic temperature control	TAU_H	•	•	0	•		*	•	
A11	SLK	170(16- pin diagnost ic socket)	Air conditioning	AAC-Automatic air conditioning	KLA_H	•	•	0	•		*		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	<u>lease re</u>	<u>fer to the special fu</u>	unction table.									
Model year	Model	Mode1	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes		Erase Codes		Freeze Frame	Active Test	Special Function
A11	SLK	170(16- pin diagnost ic socket)	Air conditioning	STH-Stationary heater	STH_H	•	•	0	•	•	*		
A11	SLK	170(38- pin diagnost ic socket)	Drive	ETC-Electronic transmission control	EGS_H	•	•	0	•		*		
A11	SLK	170(38- pin diagnost ic socket)	Drive	HFM-SFI-Hot film engine management	НБМ_Н	•	•	0	•		*		
A11	SLK	170(38- pin diagnost ic socket)	Drive	ME2-SFI-Motor electronics 2	ME2_H	•	•	0	•	•	*		
A11	SLK	170(38- pin diagnost ic socket)	Chassis	ABS-Antilock brake system	ABS30_H	•	•	0	•	•	*		
A11	SLK	170(38- pin diagnost ic socket)	Chassis	ASR-Acceleration Slip Regulation	ASR30_H	•	•	0	•	•	*		
A11	SLK	170(38- pin diagnost ic socket)	Chassis	ETS-Electronic traction system	ETS30_H	•	•	0	•	•	*		
A11	SLK	170(38- pin diagnost ic socket)	Chassis	BAS-Brake assist	BAS_H	•	•	0	•	•	*		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for specia	l function	please refer t	to the special fu	nction table.									
Model year	Model	Model Con Series Gro	trol Unit	System Name	DiagName	Ecu Info.	Read Codes	Event Memory			Freeze Frame	Active Test	Special Function
A11	SLK	170 (38- pin diagnost Body ic socket)	,	AB-Airbag	ZAE_H	•	•	0	•		*		
A11	SLK	170 (38- pin diagnost Body ic socket)		RFL-Radio frequency locking/electric central locking	FFZ_H	•	•	0	•	•	*		
A11	SLK	170(38- pin diagnost Body ic socket)	,	PSE-Pneumatic system equipment	PSZ_H	•	•	0	•	•	*		
A11	SLK	170(38- pin diagnost Body ic socket)	,	CCM-Multifunction control module	SKF_H	•	•	0	•	•	*		
A11	SLK	170(38- pin diagnost Body ic socket)	,	VR-Vario roof	VD_H	•	•	0	•	•	*	•	
A11	SLK	diagnost		ICM-Instrument cluster with maintenance interval display	KIW_H	•	•	0	•	•	*	•	0002
A11	SLK		ormation and nunication	AUDIO	AUDIO	•	•	•	•	•	•	•	
A11	SLK			CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	Ο	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	1	fer to the special fo	unction table.									
Model year	Model	Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes		Erase Codes		Freeze Frame	Active Test	Special Function
A11	SLK	170 (38- pin diagnost ic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		
A11	SLK	170 (38- pin diagnost ic socket)	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
A11	SLK	170(38- pin diagnost ic socket)	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
A11	SLK	170(38- pin diagnost ic socket)	Air conditioning	TAC-Automatic temperature control	TAU_H	•	•	0	•		*	•	
A11	SLK	170(38- pin diagnost ic socket)	Air conditioning	AAC-Automatic air conditioning	KLA_H	•	•	0	•		*		
A11	M-Class	164	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
A11	M-Class	164	Drive	VG-Transfer case	VG164	•	•	•	•	•	•	•	
A11	M-Class	164	Drive	HAQ-Interwheel differential lock at rear axle	HAQ164	•	•	•	•	•	•		
A11	M-Class	164	Drive	ISM-Intelligent servo module	ISM	•	•	•	•	•	•	*	
A11	M-Class	164	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
A11	M-Class	164	Drive	FSCU-Fuel pump	FSCM212	•	•	•	•	•	•		
A11	M-Class	164	Drive	DTR-Distronic	ARS210	•	•	•	•	•	•	0	
A11	M-Class	164	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
A11	M-Class	164	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
A11	M-Class	164	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	ME97AMG	•	•	•	•	•	•	•	0004 0013
A11	M-Class	164	Drive	FSCU Left-Control unit 'Left fuel pump'	FSCM_AMG_DB_ A_1	•	•	•	•	•	•		
A11	M-Class	164	Drive	FSCU Right-Control unit 'Right fuel pump'	FSCM_AMG_DB_ B_1	•	•	•	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease re	fer to the special f	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes		Erase Codes		Freeze Frame	Active Test	Special Function
A11	M-Class	164	Drive	CDI 4-Common Rail Diesel Injection	CR4	•	•	•	•	•	•	*	0013
A11	M-Class	164	Drive	CDI 6BIN5-Common Rail Diesel Injection	CR6BIN5	•	•	•	•	•	•		0013
A11	M-Class	164	Drive	SCR-Selective Catalytic Reduction	SCRCM	•	•	•	•	•	•	•	
A11	M-Class	164	Drive	CDI 5-Common Rail Diesel Injection	CR5	•	•	•	•	•	•		0013 0019 0022
A11	M-Class	164	Chassis	ESP-Electronic stability program	ESP164	•	•	•	•	•	•		0005, 0047, 0015
A11	M-Class	164	Chassis	Suspension	LF164	•	•	•	•	•	0	*	0048, 0049, 0056, 0 057, 0059
A11	M-Class	164	Chassis	TPC-Tire pressure monitor	TPMLS	•	•	•	•	•	•	•	0005
A11	M-Class	164	Body	CGW-Central gateway	ZGW164	•	•	•	•	0	0	0	0016 0017 0018
A11	M-Class	164	Body	EZS-Electronic ignition switch	EZS164	•	•	•	•	•	0	0	
A11	M-Class	164	Body	EZS-Electronic ignition switch	EIS_164	•	•	•	•	•	•	0	
A11	M-Class	164	Body	KG-Keyless Go	KG164	•	•	•	•	•	•	•	
A11	M-Class	164	Body	AB-Airbag	ARCADE164	•	•	•	•	•	•		0041
A11	M-Class	164	Body	OCP-Overhead control panel	DBE164	•	•	•	•	•	•	•	
A11	M-Class	164	Body	WSS-Weight sensing system	WSS	•	•	•	•	•	•	0	0005
A11	M-Class	164	Body	UCP-Upper control panel	0BF164	•	•	•	•	•	0	•	
A11	M-Class	164	Body	HBF (Rear control panel)-Rear control field	HBF164	•	•	•	•	•	0	•	
A11	M-Class	164	Body	SAM-F-Signal acquisition and actuation module front	SAMV164	•	•	•	•	•	•	*	
A11	M-Class	164	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH164	•	•	•	•	•	0	*	
A11	M-Class	164	Body	RevETR-RF-Right front reversible emergency tensioning retractor	RGSR164	•	•	•	•	•	•	•	
A11	M-Class	164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	RGSL164	•	•	•	•	•	•	•	
A11	M-Class	164	Body	HRA-Automatic headlamp range adjustment and headlamp control	ALWR211	•	•	•	•	•	0	•	0005 0009
A11	M-Class	164	Body	XALWA-L-Xenon headlamp, left	XALWA211_L	•	•	•	•	•	•	•	
A11	M-Class	164	Body	XALWA-R-Xenon headlamp, right	XALWA211_R	•	•	•	•	•	•	•	
A11	M-Class	164	Body	System diagnosis(CAN)	SD164	•	•	0	•	•	•		
A11	M-Class	164	Information and communication	SCM [MRM]-Steering column module	MRM164	•	•	•	•	•	•	•	0005
A11	M-Class	164	Information and communication	CM-Compass module	CM164	•	•	•	•	•	•	0	
A11	M-Class	164	Information and communication	IC-Instrument cluster	KI164	•	•	•	•	•	0	•	
A11	M-Class	164	Information and communication	ASSYST-Active Service System	WIA164	•	•	0	•	•	0	0	0001



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease re	<u>fer to the special f</u>	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes		Erase Codes			Active Test	Special Function
A11	M-Class	164	Information and communication	ASSYST PLUS-PLUS Active Service System	WR164	•	•	0	•	•	•	0	0002
A11	M-Class	164	Information and communication	PTS-Parktronic system	PTS164	•	•	•	•	•	0		
A11	M-Class	164	Information and communication	PTS-Parktronic system	PTS211MOPF	•	•	•	•	•	0	•	
A11	M-Class	164	Information and communication	RFK-Backup camera	DRVM164	•	•	•	•	•	•	0	
A11	M-Class	164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
A11	M-Class	164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
A11	M-Class	164	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
A11	M-Class	164	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
A11	M-Class	164	Information and communication	AUDIO	XHU	•	•	•	•	•	•	•	0003
A11	M-Class	164	Information and communication	COMAND or AUDIO	ХНИЈР	•	•	0	•	•	•	•	
A11	M-Class	164	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•	•	
A11	M-Class	164	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
A11	M-Class	164	Information and communication	SOUND- Sound system	XSNDHB	•	•	0	•	•	•		
A11	M-Class	164	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
A11	M-Class	164	Information and communication	NAVI-Navigation system	XMCSNAV	•	•	•	•	•	•	•	
A11	M-Class	164	Information and communication	AVE-H-Rear audio video unit	XAVS	•	•	•	•	•	•	•	
A11	M-Class	164	Information and communication	CTEL-Cellular telephone	XTELJP	•	•	•	•	•	•	0	
A11	M-Class	164	Information and communication	COMAND or AUDIO	HU25	•	•	•	•	•	•		
A11	M-Class	164	Information and communication	SOUND- Sound system	SOUND25	•	•	•	•	•	•		
A11	M-Class	164	Information and communication	UCI	UCI25	•	•	•	•	•	•	0	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease rei	<u>fer to the special f</u>	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes				Freeze Frame	Active Test	Special Function
A11	M-Class	164	Information and communication	DAB-Digital radio	DAB25	•	•	•	•	•	0		
A11	M-Class	164	Information and communication	SDAR-Satellite radio(Valid for USA)	SDARS25	•	•	•	•	•	•		
A11	M-Class	164	Information and communication	TV-TV tuner	TV25	•	•	•	•	•	•		
A11	M-Class	164	Information and communication	CTEL-Cellular telephone(JAPAN)	CBJ25	•	•	•	•	•	0		
A11	M-Class	164	Information and communication	AVE-H-Rear audio video unit	FU25	•	•	•	•	•	•		
A11	M-Class	164	Information and communication	Left rear screen	DISP_RL	•	•	•	•	•	•		
A11	M-Class	164	Information and communication	Right rear screen	DISP_RR	•	•	•	•	•	•		
A11	M-Class	164	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
A11	M-Class	164	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
A11	M-Class	164	Information and communication	TELE AID-Telematic servicesMB Info, Roadside assistance(USA, Canada), Telediagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
A11	M-Class	164	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
A11	M-Class	164	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
A11	M-Class	164	Seats and doors	DCM-FL-Door control module front left	TSGVL164	•	•	•	•	•	0	•	
A11	M-Class	164	Seats and doors	DCM-FR-Door control module front right	TSGVR164	•	•	•	•	•	0	•	
A11	M-Class	164	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164_1	•	•	•	•	•	•	•	
A11	M-Class	164	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164_1	•	•	•	•	•	•	•	
A11	M-Class	164	Seats and doors	DS-LF-Left front dynamic seat	FDSVL211	•	•	•	•	•	•	•	
A11	M-Class	164	Seats and doors	DS-RF-Right front dynamic seat	FDSVR211	•	•	•	•	•	•	•	
A11	M-Class	164	Seats and doors	DSP-Pneumatic pump for dynamic seat	PFDS211	•	•	•	•	•	•	•	
A11	M-Class	164	Seats and doors	REDC-Rear-end door closing control module	HFS164	•	•	•	•	•	0	•	
A11	M-Class	164	Seats and doors	REDC-Rear-end door closing control module	PTCM164	•	•	•	•	•	•	•	
A11	M-Class	164	Seats and doors	HS-Seat heater	SHZ164	•	•	•	•	•	0	•	
A11	M-Class	164	Air conditioning	AAC-Automatic air conditioning	KLA164	•	•	•	•	•	•	*	
A11	M-Class	164	Air conditioning	HSW-Heated steering wheel	SHZ164_1	•	•	•	•	•	0	*	
A11	M-Class	164	Air conditioning	STH-Stationary heater with remote control	STH164	•	•	•	•	•	•	*	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for specia	1 function p	<u>lease re</u>	fer to the special	function table.	_								
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
A11	M-Class	163	Drive	ETC-Electronic transmission control	EGS_H	•	•	0	•		*		
A11	M-Class	163	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
A11	M-Class	163	Drive	ESM-Electronic selector module	EWM210	•	•	0	•	•	*	•	
A11	M-Class	163	Drive	HFM-SFI-Hot film engine management	HFM_H	•	•	0	•		*		
A11	M-Class	163	Drive	ME2-SFI-Motor electronics 2	ME2_H	•	•	0	•	•	*		
A11	M-Class	163	Drive	VG-Transfer case	VG_H	•	•	0	•	•	*		
A11	M-Class	163	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
A11	M-Class	163	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
A11	M-Class	163	Drive	CDI 2-Common Rail Diesel Injection	CR2	•	•	•	•	•	•	*	
A11	M-Class	163	Drive	CDI-V-Common Rail Diesel Injection	CRV	•	•	•	•	•	•		
A11	M-Class	163	Chassis	ESP-Electronic stability program	ESPMK25	•	•	•	•	•	•		0047, 0015
A11	M-Class	163	Chassis	ESP-Electronic stability program	ESP30_H	•	•	0	•	•	*		0040
A11	M-Class	163	Chassis	ESP-Electronic stability program	ESP34_H	•	•	0	•	•	*		
A11	M-Class	163	Chassis	ESP-Electronic stability program	ESP35_H	•	•	0	•	•	*		
A11	M-Class	163	Chassis	ETS-Electronic traction system	ETS30_H	•	•	0	•	•	*		
A11	M-Class	163	Chassis	ETS-Electronic traction system	ETS34_H	•	•	0	•	•	*		
A11	M-Class	163	Chassis	BAS-Brake assist	BAS_H	•	•	0	•	•	*		
A11	M-Class	163	Chassis	VP-Vacuum pump brake booster	UP28	•	•	•	•	•	•	•	
A11	M-Class	163	Body	AB-Airbag	AB2TR_H	•	•	0	•		*		
A11	M-Class	163	Body	AB-Airbag	ARMIN	•	•	0	•	•	*	0	
A11	M-Class	163	Body	EAM-Extended activity module	EAMK	•	•	0	•	•	*	•	
A11	M-Class	163	Body	AAM-All Activity Module	AAM_H	•	•	0	•	•	*	•	
A11	M-Class	163	Body	AAM-All Activity Module	AAM2K	•	•	0	•	•	*	•	
A11	M-Class	163	Body	DAS-Drive authorization system	FBM	•	•	•	•	•	*	0	
A11	M-Class	163	Body	HRA-Headlamp range adjustment	LWR163	•	•	•	•	•	0	•	
A11	M-Class	163	Body	LCP-Lower operating panel with power window function	FH163	•	•	•	•	•	*	•	
A11	M-Class	163	Body	SEM-Security Module	SEM_H	•	•	0	•		*		
A11	M-Class	163	Information and communication	ICM-Instrument cluster with maintenance interval display	KIW_H	•	•	0	•	•	*	•	0002
A11	M-Class	163	Information and communication	PTS-Parktronic system	PTS163	•	•	•	•	•	*	•	
A11	M-Class	163	Information and communication	COMAND	COMAND	•	•	0	•	•	•	•	
A11	M-Class	163	Information and communication	MCS-Modular control system	MCS	•	•	0	•	•	•		



NOTES:

This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p	lease rei	fer to the special f	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory			Freeze Frame	Active Test	Special Function
A11	M-Class	163	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
A11	M-Class	163	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	0	
A11	M-Class	163	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		
A11	M-Class	163	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
A11	M-Class	163	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
A11	M-Class	163	Information and communication	SOUND- Sound system	SOUND	•	•	0	•	•	•	0	
A11	M-Class	163	Information and communication	MCS navigation-Navigation in MCS	MCSNAV	•	•	0	•	•	•		
A11	M-Class	163	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
A11	M-Class	163	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
A11	M-Class	163	Air conditioning	STH-Stationary heater	STH_H	•	•	0	•	•	*		
A11	M-Class	163	Air conditioning	AAC-Automatic air conditioning	KLA163	•	•	•	•	•	•	•	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Drive	ESM-Electronic selector module	EWM210	•	•	0	•	•	*	•	
Up to 03/2004	G-Class	463 (16- pin diagnost ic socket)	Drive	VG-Transfer case	VGS463	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

As for specia	1 function	please refer to the special	function table.									
Model year	Mode1	Model Control Unit Series Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory			Freeze Frame	Active Test	Special Function
Up to 03/2004	G-Class	463 (16- pin diagnost Drive ic socket)	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
Up to 03/2004	G-Class	463(16- pin diagnost Drive ic socket)	CDI-V-Common Rail Diesel Injection	CRV	•	•	•	•	•	•		
Up to 03/2004	G-Class	463(16- pin diagnost Drive ic socket)	CDI 2-Common Rail Diesel Injection	CR2	•	•	•	•	•	•	*	
Up to 03/2004	G-Class	463(16- pin diagnost Chassis ic socket)	ABS-Antilock brake system	ABS50	•	•	•	•	•	*	•	
Up to 03/2004	G-Class	463(16- pin diagnost Chassis ic socket)	ESP-Electronic stability program	ESP	•	•	•	•	•	*	•	
Up to 03/2004	G-Class	463(16- pin diagnost Body ic socket)	AB-Airbag	ARMIN	•	•	0	•	•	*	0	
Up to 03/2004	G-Class	463(16- pin diagnost Body ic socket)	EZS-Electronic ignition switch	EZS463	•	•	•	•	•	0	0	0034
Up to 03/2004	G-Class	463 (16- pin diagnost Body ic socket)	EZS-Electronic ignition switch	EZS209	•	•	•	•	•	0	0	0034



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

As for special function places refer

* This function may be supported, which depends on the actual condition of the vehicle.

As for special	function p		fer to the special fo	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)		UCP-Upper control panel	0BF203	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Body	SAM-F-Signal acquisition and actuation module front	SAMV463	•	•	•	•	•	0	*	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH463	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463 (16- pin diagnost ic socket)	Body	OCP-Overhead control panel	DBE463	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463 (16- pin diagnost ic socket)	Body	MSS-Special vehicle multifunction control module	MSS203	•	•	•	•	•	0	•	0003
Up to 03/2004	G-Class	463 (16- pin diagnost ic socket)	Body	AHE-Trailer recognition	AAG203	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463 (16- pin diagnost ic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	KI203	•	•	•	•	•	0	*	0002
Up to 03/2004	G-Class	463 (16- pin diagnost ic socket)	Information and communication	SCM [MRM]-Steering column module	MRM211	•	•	•	•	•	•	•	0005



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special:	function p	<u>lease re</u>	<u>fer to the special fu</u>	inction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
Up to 03/2004	G-Class	463 (16- pin diagnost ic socket)	Information and communication	SCM [MRM]-Steering column module	MRM171	•	•	•	•	•	•	•	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Information and communication	D2B-COMAND, MCS or AUDIO	AVN	•	•	•	•	•	•		
Up to 03/2004	G-Class	463 (16- pin diagnost ic socket)	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Information and communication	COMAND	COMAND	•	•	0	•	•	•	•	
Up to 03/2004	G-Class	463 (16- pin diagnost ic socket)	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	0	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

As for special function places refer

As for special	function p		fer to the special fu	unction table.									
Model year	Mode1		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Information and communication	TV-TV tuner	TV	•	•	•	•		•	•	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Information and communication	E-call [Japan]-Telematic system	TAIDJAP2	•	•	•	•	•	•		
Up to 03/2004	G-Class	463 (16- pin diagnost ic socket)	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
Up to 03/2004	G-Class	463 (16- pin diagnost ic socket)	Seats and doors	DCM-FL-Door control module front left	TSGVL203	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Seats and doors	DCM-FR-Door control module front right	TSGVR203	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Seats and doors	DCM-RL-Door control module rear left	TSGHL203	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Seats and doors	DCM-RR-Door control module rear right	TSGHR203	•	•	•	•	•	0	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

As for special function places refer

As for special	function p		fer to the special fu	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB203	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB211	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	SSGF203	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463 (16- pin diagnost ic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	SSGF211	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463 (16- pin diagnost ic socket)	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164	•	•	•	•	•	0	•	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Air conditioning	AAC-Automatic air conditioning	KLA203	•	•	•	•	•	•	•	
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Air conditioning	STH-Stationary heater	STH203	•	•	•	•	•	•	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

As for special function places refer

As for special	function		fer to the special f	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
Up to 03/2004	G-Class	463(16- pin diagnost ic socket)	Air conditioning	HSW-Heated steering wheel	LRK_211	•	•	•	•	•	•	•	0003 0005
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Drive	ESM-Electronic selector module	EWM210	•	•	0	•	•	*	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Drive	VG-Transfer case	VGS463	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Drive	CDI-V-Common Rail Diesel Injection	CRV	•	•	•	•	•	•		
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Drive	CDI 2-Common Rail Diesel Injection	CR2	•	•	•	•	•	•	*	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

As for special function places refer

As for special	function		fer to the special f	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
From 04/2004 to 08/2006	G-Class	463(16- pin	Chassis	ABS-Antilock brake system	ABS50	•	•	•	•	•	*	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Chassis	ESP-Electronic stability program	ESP	•	•	•	•	•	*	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Body	EZS-Electronic ignition switch	EZS209	•	•	•	•	•	0	0	0034
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Body	AB-Airbag	ARMIN	•	•	0	•	•	*	0	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Body	UCP-Upper control panel	0BF203	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Body	SAM-F-Signal acquisition and actuation module front	SAMV463	•	•	•	•	•	0	*	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH463	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Body	OCP-Overhead control panel	DBE463	•	•	•	•	•	0	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

As for special function places refer

As for special	function p		fer to the special fu	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Body	MSS-Special vehicle multifunction control module	MSS203	•	•	•	•	•	0	•	0003
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Body	AHE-Trailer recognition	AAG203	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnost ic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	KI203	•	•	•	•	•	0	*	0002
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnost ic socket)	Information and communication	SCM [MRM]-Steering column module	MRM211	•	•	•	•	•	•	•	0005
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnost ic socket)	Information and communication	SCM [MRM]-Steering column module	MRM171	•	•	•	•	•	•	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Information and communication	D2B-COMAND, MCS or AUDIO	AVN	•	•	•	•	•	•		
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnost ic socket)	Information and communication	COMAND	COMAND	•	•	0	•	•	•	•	



NOTES:

This function is supported.

▲ This function is the new feature in this version.

As for special	function p		fer to the special fo	unction table.									
Model year	Model	Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes					Active Test	Special Function
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnost ic socket)	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnost ic socket)	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnost ic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	0	
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnost ic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnost ic socket)	Information and communication	TV-TV tuner	TV	•	•	•	•		•	•	
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnost ic socket)	Information and communication	E-call [Japan]-Telematic system	TAIDJAP2	•	•	•	•	•	•		
From 04/2004 to 08/2006	G-Class	463 (16- pin diagnost ic socket)	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	



NOTES:

This function is supported.

▲ This function is the new feature in this version.

As for special	function p		fer to the special f	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Seats and doors	DCM-FL-Door control module front left	TSGVL203	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Seats and doors	DCM-FR-Door control module front right	TSGVR203	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Seats and doors	DCM-RL-Door control module rear left	TSGHL203	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Seats and doors	DCM-RR-Door control module rear right	TSGHR203	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB203	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB211	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	SSGF203	•	•	•	•	•	0	•	



NOTES:

This function is supported.

▲ This function is the new feature in this version.

As for special	function p		fer to the special fu	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	SSGF211	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164	•	•	•	•	•	0	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Air conditioning	AAC-Automatic air conditioning	KLA203	•	•	•	•	•	•	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Air conditioning	STH-Stationary heater	STH203	•	•	•	•	•	•	•	
From 04/2004 to 08/2006	G-Class	463(16- pin diagnost ic socket)	Air conditioning	HSW-Heated steering wheel	SHZ164_1	•	•	•	•	•	0	*	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Drive	ESM-Electronic selector module	EWM210	•	•	0	•	•	*	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

As for special function places references

As for special	function	please refer to the special	function table.									
Model year	Model	Model Control Unit Series Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes		Freeze Frame	Active Test	Special Function
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost Drive ic socket)	VG-Transfer case	VGS463	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost Drive ic socket)	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost Drive ic socket)	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost Drive ic socket)	CDI 4-Common Rail Diesel Injection	CR4	•	•	•	•	•	•	*	0013
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnost Chassis ic socket)	ABS-Antilock brake system	ABS50	•	•	•	•	•	*	•	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost Chassis ic socket)	ESP-Electronic stability program	ESP	•	•	•	•	•	*	•	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost Chassis ic socket)	ESP-Electronic stability program	ESP463	•	•	•	•	•	•	0	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost Body ic socket)	EZS-Electronic ignition switch	EZS209	•	•	•	•	•	0	0	0034



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

As for special function places refer

As for special	function p		fer to the special f	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)		AB-Airbag	ARMIN	•	•	0	•	•	*	0	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Body	UCP-Upper control panel	0BF203	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Body	SAM-F-Signal acquisition and actuation module front	SAMV463	•	•	•	•	•	0	*	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH463	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Body	OCP-Overhead control panel	DBE463	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Body	ALWR-Headlamp range adjustment	ALWR906	•	•	•	•	•	•	*	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Body	MSS-Special vehicle multifunction control module	MSS203	•	•	•	•	•	0	•	0003
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Body	AHE-Trailer recognition	AAG203	•	•	•	•	•	0	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

As for special function places refer

As for special	function p		fer to the special fu	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	KI203	•	•	•	•	•	0	*	0002
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	SCM [MRM]-Steering column module	MRM211	•	•	•	•	•	•	•	0005
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnost ic socket)	Information and communication	SCM [MRM]-Steering column module	MRM171	•	•	•	•	•	•	•	
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnost ic socket)	Information and communication	D2B-COMAND, MCS or AUDIO	AVN	•	•	•	•	•	•		
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnost ic socket)	Information and communication	AUDIO	AUDIO	•	•	•	•	•	•	•	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	COMAND	COMAND	•	•	0	•	•	•	•	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

As for special function places refer

As for special	function p	lease re	fer to the special fu	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	0	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	UHI- Cellular telephone 1 (fixed installation or portable)(D2B)	UHI	•	•	•	•	•	0		
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnost ic socket)	Information and communication	TV-TV tuner	TV	•	•	•	•		•	•	
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnost ic socket)	Information and communication	E-call [Japan]-Telematic system	TAIDJAP2	•	•	•	•	•	•		
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	E-call [USA]-Telematic system	TAIDUSA2	•	•	•	•	•	•	0	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	CTEL over K-wire-Telematic system	HANNA	•	•	•	•	0	0	0	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003



NOTES:

This function is supported.

▲ This function is the new feature in this version.

As for special	function p		fer to the special fu	unction table.									
Model year	Mode1		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory		Live Data		Active Test	Special Function
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnost ic socket)	Information and communication	AUDIO	XHU	•	•	•	•	•	•	•	0003
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	COMAND or AUDIO	XHUJP	•	•	0	•	•	•	•	
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnost ic socket)	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnost ic socket)	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnost ic socket)	Information and communication	SOUND- Sound system	XSNDHB	•	•	0	•	•	•		
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	NAVI-Navigation system	XMCSNAV	•	•	•	•	•	•	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

As for special function places refer

As for special	function p		fer to the special fu	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnost ic socket)	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnost ic socket)	Information and communication	TELE AID-Telematic servicesRemote door unlocking,Remote door locking	XLCTREM	•	•	•	•		•	0	
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnost ic socket)	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Seats and doors	DCM-FL-Door control module front left	TSGVL203	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Seats and doors	DCM-FR-Door control module front right	TSGVR203	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Seats and doors	DCM-RL-Door control module rear left	TSGHL203	•	•	•	•	•	0	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

As for special function places refer

As for special	function p		fer to the special f	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Seats and doors	DCM-RR-Door control module rear right	TSGHR203	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB203	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnost ic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB211	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnost ic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463 (16- pin diagnost ic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	SSGF203	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	SSGF211	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164	•	•	•	•	•	0	•	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost ic socket)	Air conditioning	AAC-Automatic air conditioning	KLA203	•	•	•	•	•	•	•	



NOTES:

This function is supported.

▲ This function is the new feature in this version.

As for special	function	<u>please refer to the speci</u>	al function table.									
Model year	Model	Model Control Unit Series Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory				Active Test	Special Function
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost Air conditioning ic socket)	STH-Stationary heater	STH203	•	•	•	•	•	•	•	
From 09/2006 to 02/2007	G-Class	463(16- pin diagnost Air conditioning ic socket)	HSW-Heated steering wheel	SHZ164_1	•	•	•	•	•	0	*	
As of 03/2007	G-Class	463(16- pin diagnost Drive ic socket)	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
As of 03/2007	G-Class	463(16- pin diagnost Drive ic socket)	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
As of 03/2007	G-Class	463(16- pin diagnost Drive ic socket)	ESM-Electronic selector module	EWM210	•	•	0	•	•	*	•	
As of 03/2007	G-Class	463(16- pin diagnost Drive ic socket)	VG-Transfer case	VGS463	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463(16- pin diagnost Drive ic socket)	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
As of 03/2007	G-Class	463(16- pin diagnost Drive ic socket)	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004



NOTES:

This function is supported.

▲ This function is the new feature in this version.

As for special	function		fer to the special f	unction table.									
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
As of 03/2007	G-Class	463(16- pin diagnost ic socket)		CDI 4-Common Rail Diesel Injection	CR4	•	•	•	•	•	•	*	0013
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Chassis	ABS-Antilock brake system	ABS50	•	•	•	•	•	*	•	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Chassis	ESP-Electronic stability program	ESP	•	•	•	•	•	*	•	
As of 03/2007	G-Class	ic socket)	Chassis	ESP-Electronic stability program	ESP463	•	•	•	•	•	•	0	
As of 03/2007	G-Class	ic socket)	Chassis	TPC-Tire pressure monitor	TPM_209	•	•	•	•	•	•	•	0005
As of 03/2007	G-Class	463 (16- pin diagnost ic socket)	Body	EZS-Electronic ignition switch	EZS209	•	•	•	•	•	0	0	0034
As of 03/2007	G-Class	463 (16- pin diagnost ic socket)	Body	AB-Airbag	ARMIN	•	•	0	•	•	*	0	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Body	UCP-Upper control panel	0BF203	•	•	•	•	•	0	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

As for special function places refer

As for special	function p		fer to the special fu	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Body	SAM-F-Signal acquisition and actuation module front	SAMV463	•	•	•	•	•	0	*	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH463	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Body	OCP-Overhead control panel	DBE463	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Body	ALWR-Headlamp range adjustment	ALWR906	•	•	•	•	•	•	*	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Body	MSS-Special vehicle multifunction control module	MSS203	•	•	•	•	•	0	•	0003
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Body	AHE-Trailer recognition	AAG203	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	KI203M	•	•	•	•	•	0	•	0002
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	SCM [MRM]-Steering column module	MRM211	•	•	•	•	•	•	•	0005



NOTES:

This function is supported.

▲ This function is the new feature in this version.

As for special	function p		fer to the special fu	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
As of 03/2007	G-Class	463 (16- pin diagnost ic socket)	Information and communication	SCM [MRM]-Steering column module	MRM171	•	•	•	•	•	•	•	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	AUDIO	XHU	•	•	•	•	•	•	•	0003
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	COMAND or AUDIO	ХНИЈР	•	•	0	•	•	•	•	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	SOUND- Sound system	XSNDHB	•	•	0	•	•	•		



NOTES:

This function is supported.

▲ This function is the new feature in this version.

As for special	function p		fer to the special fu	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory		Live Data		Active Test	Special Function
As of 03/2007	G-Class	463 (16- pin diagnost ic socket)	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	NAVI-Navigation system	XMCSNAV	•	•	•	•	•	•	•	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	COMAND or AUDIO	HU25	•	•	•	•	•	•		
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	SOUND- Sound system	SOUND25	•	•	•	•	•	•		
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	UCI	UCI25	•	•	•	•	•	•	0	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	DAB-Digital radio	DAB25	•	•	•	•	•	0		-
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	SDAR-Satellite radio(Valid for USA)	SDARS25	•	•	•	•	•	•		



NOTES:

This function is supported.

▲ This function is the new feature in this version.

As for special	function p		fer to the special fu	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
As of 03/2007	G-Class	463 (16- pin diagnost ic socket)	Information and communication	TV-TV tuner	TV25	•	•	•	•	•	•		
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	CTEL-Cellular telephone(JAPAN)	CBJ25	•	•	•	•	•	0		
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	TELE AID-Telematic servicesRemote door unlocking,Remote door locking	XLCTREM	•	•	•	•		•	0	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Seats and doors	DCM-FL-Door control module front left	TSGVL203	•	•	•	•	•	0	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

** This function may be As for special function please refer to the special function table.

As for special	<u>function p</u>	<u>lease re</u>	<u>fer to the special fu</u>	unction table.									
Model year	Mode1	Mode1	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
As of 03/2007	G-Class	463 (16- pin diagnost ic socket)	Seats and doors	DCM-FR-Door control module front right	TSGVR203	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Seats and doors	DCM-RL-Door control module rear left	TSGHL203	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Seats and doors	DCM-RR-Door control module rear right	TSGHR203	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463 (16- pin diagnost ic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB203	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463 (16- pin diagnost ic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB211	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	SSGF203	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	Seats and doors	ESA driver-Electric seat adjustment driver	SSGF211	•	•	•	•	•	0	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

** This function may be As for special function please refer to the special function table.

As for special	function	please refer to the special	function table.									
Model year	Model	Model Control Unit Series Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory			Freeze Frame	Active Test	Special Function
As of 03/2007	G-Class	463(16- pin diagnost ic socket)	ESA driver-Electric seat adjustment driver (with memory)	SSGF164	•	•	•	•	•	0	•	
As of 03/2007	G-Class	463(16- pin diagnost Air conditioning ic socket)	AAC-Automatic air conditioning	KLA203	•	•	•	•	•	•	•	
As of 03/2007	G-Class	463 (16- pin diagnost Air conditioning ic socket)	STH-Stationary heater	STH203	•	•	•	•	•	•	•	
	G-Class	463(16- pin diagnost Air conditioning ic socket)	HSW-Heated steering wheel	SHZ164_1	•	•	•	•	•	0	*	
All	G-Class	463 (38- pin diagnost Drive ic socket)	ETC-Electronic transmission control	EGS_H	•	•	0	•		*		
A11	G-Class	463 (38- pin diagnost Drive ic socket)	ESM-Electronic selector module	EWM210	•	•	0	•	•	*	•	
All	G-Class	463(38- pin diagnost Drive ic socket)	ME2-SFI-Motor electronics 2	ME2_H	•	•	0	•	•	*		
All	G-Class	463(38- pin diagnost Drive ic socket)	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

As for special	function p	<u>lease re</u>	<u>fer to the special f</u>	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes				Freeze Frame	Active Test	Special Function
A11	G-Class	463 (38- pin diagnost ic socket)	Drive	HFM-SFI-Hot film engine management	HFM2_H	•	•	0	•		*		
A11	G-Class	463(38- pin diagnost ic socket)	Drive	HFM-SFI-Hot film engine management	НБМ_Н	•	•	0	•		*		
A11	G-Class	463 (38- pin diagnost ic socket)	Chassis	ABS-Antilock brake system	ABS30_H	•	•	0	•	•	*		
A11	G-Class	463 (38- pin diagnost ic socket)	Body	AB-Airbag	ZAE_H	•	•	0	•		*		
A11	G-Class	463 (38- pin diagnost ic socket)	Body	APS-Auto pilot system	APS_H	•	•	0	•	•	*		
A11	G-Class	463 (38- pin diagnost ic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	KIW_H	•	•	0	•	•	*	•	0002
A11	G-Class	463 (38- pin diagnost ic socket)	Information and communication	ICM-Instrument cluster with maintenance interval display	KIL	•	•	•	•	•	•		0002
A11	G-Class	463 (38- pin diagnost ic socket)	Information and communication	AUDIO	AUD10	•	•	•	•	•	•	•	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

** This function may be As for special function please refer to the special function table.

As for special:	function p	<u>lease re</u> :	<u>fer to the special fu</u>	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
A11	G-Class	463 (38- pin diagnost ic socket)	Information and communication	CTEL- Cellular telephone 1 (fixed installation or portable)(D2B)	TELE	•	•	•	•	0	0	0	
A11	G-Class	463 (38- pin diagnost ic socket)	Information and communication	VCS-Voice control system	SBS	•	•	0	•		0	0	
A11	G-Class	463(38- pin diagnost ic socket)	Information and communication	CDC-CD changer	CDC	•	•	•	•	0	0	0	
A11	G-Class	463 (38- pin diagnost ic socket)	Air conditioning	STH-Stationary heater	STH_H	•	•	0	•	•	*		
A11	G-Class	461(16- pin diagnost ic socket)	Drive	ETC-Electronic transmission control	EGS52	•	•	•	•	•	•	•	
A11	G-Class	461(16- pin diagnost ic socket)	Drive	ESM-Electronic selector module	EWM210	•	•	0	•	•	*	•	
A11	G-Class	461(16- pin diagnost ic socket)	Drive	VG-Transfer case	VGS463	•	•	•	•	•	0	•	
A11	G-Class	461(16- pin diagnost ic socket)	Drive	CDI 2-Common Rail Diesel Injection	CR2	•	•	•	•	•	•	*	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

As for specia	1 function p	lease re	fer to the special f	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes			Active Test	Special Function
A11	G-Class	461(16- pin diagnost ic socket)	Chassis	ABS-Antilock brake system	ABS50	•	•	•	•	•	*	•	
A11	G-Class	461(16- pin diagnost ic socket)	Body	AB-Airbag	ARMIN	•	•	0	•	•	*	0	
A11	G-Class	461(16- pin diagnost ic socket)	Information and communication	WSP immobilizer	FBS414	•	•	•	•	•	*		
A11	G-Class	461(16- pin diagnost ic socket)	Information and communication	IC-Instrument cluster	KI461	•	•	•	•	•	*	•	
A11	G-Class	461(16- pin diagnost ic socket)	Air conditioning	STH-Stationary heater	STH_H	•	•	0	•	•	*		
A11	GL-Class	X 164	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
A11	GL-Class	X 164	Drive	VG-Transfer case	VG164	•	•	•	•	•	•	•	
A11	GL-Class	X 164	Drive	HAQ-Interwheel differential lock at rear axle	HAQ164	•	•	•	•	•	•		
A11	GL-Class	X 164	Drive	ISM-Intelligent servo module	ISM	•	•	•	•	•	•	*	
A11	GL-Class	X 164	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
A11	GL-Class	X 164	Drive	FSCU-Fuel pump	FSCM212	•	•	•	•	•	•		
A11	GL-Class	X 164	Drive	DTR-Distronic	ARS210	•	•	•	•	•	•	0	
A11	GL-Class	X 164	Drive	CDI 4-Common Rail Diesel Injection	CR4	•	•	•	•	•	•		0013
A11	GL-Class	X 164	Drive	CDI 5-Common Rail Diesel Injection	CR5	•	•	•	•	•	•		0013 0019 0022
A11	GL-Class	X 164	Chassis	ESP-Electronic stability program	ESP164	•	•	•	•	•	•		0005, 0047, 0015
A11	GL-Class	X 164	Chassis	Suspension	LF164	•	•	•	•	•	0		0048, 0049, 0056, 0 057, 0059
A11	GL-Class	X 164	Chassis	TPC-Tire pressure monitor	TPMLS	•	•	•	•	•	•	•	0005
A11	GL-Class	X 164	Body	CGW-Central gateway	ZGW164	•	•	•	•	0	0	0	0016 0017 0018



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

As for special	function p	lease re:	<u>fer to the special f</u>	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
A11	GL-Class	X 164	Body	EZS-Electronic ignition switch	EZS164	•	•	•	•	•	0	0	
A11	GL-Class	X 164	Body	EZS-Electronic ignition switch	EIS_164	•	•	•	•	•	•	0	
A11	GL-Class	X 164	Body	KG-Keyless Go	KG164	•	•	•	•	•	•	•	
A11	GL-Class	X 164	Body	AB-Airbag	ARCADE164	•	•	•	•	•	•		0041
A11	GL-Class	X 164	Body	OCP-Overhead control panel	DBE164	•	•	•	•	•	•	•	
A11	GL-Class	X 164	Body	WSS-Weight sensing system	WSS	•	•	•	•	•	•	0	0005
A11	GL-Class	X 164	Body	UCP-Upper control panel	0BF164	•	•	•	•	•	0	•	
A11	GL-Class	X 164	Body	HBF (Rear control panel)-Rear control field	HBF164	•	•	•	•	•	0	•	
A11	GL-Class	X 164	Body	SAM-F-Signal acquisition and actuation module front	SAMV164	•	•	•	•	•	•	*	
A11	GL-Class	X 164	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH164	•	•	•	•	•	0	*	
A11	GL-Class	X 164	Body	RevETR-RF-Right front reversible emergency tensioning retractor	RGSR164	•	•	•	•	•	•	•	
A11	GL-Class	X 164	Body	RevETR-LF-Left front reversible emergency tensioning retractor	RGSL164	•	•	•	•	•	•	•	
A11	GL-Class	X 164	Body	HRA-Automatic headlamp range adjustment and headlamp control	ALWR211	•	•	•	•	•	0	•	0005 0009
A11	GL-Class	X 164	Body	XALWA-L-Xenon headlamp, left	XALWA211_L	•	•	•	•	•	•	•	
A11	GL-Class	X 164	Body	XALWA-R-Xenon headlamp, right	XALWA211_R	•	•	•	•	•	•	•	
A11	GL-Class	X 164	Body	System diagnosis(CAN)	SD164	•	•	0	•	•	•		
A11	GL-Class	X 164	Information and communication	SCM [MRM]-Steering column module	MRM164	•	•	•	•	•	•	•	0005
A11	GL-Class	X 164	Information and communication	CM-Compass module	CM164	•	•	•	•	•	•	0	
A11	GL-Class	X 164	Information and communication	IC-Instrument cluster	KI164	•	•	•	•	•	0	•	
A11	GL-Class	X 164	Information and communication	ASSYST-Active Service System	WIA164	•	•	0	•	•	0	0	0001
A11	GL-Class	X 164	Information and communication	ASSYST PLUS-PLUS Active Service System	WR164	•	•	0	•	•	•	0	0002
A11	GL-Class	X 164	Information and communication	PTS-Parktronic system	PTS164	•	•	•	•	•	0		
A11	GL-Class	X 164	Information and communication	PTS-Parktronic system	PTS211M0PF	•	•	•	•	•	0	•	
A11	GL-Class	X 164	Information and communication	RFK-Backup camera	DRVM164	•	•	•	•	•	•	0	
A11	GL-Class	X 164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

As for special	function p	lease re	<u>fer to the special f</u>	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
A11	GL-Class	X 164	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
A11	GL-Class	X 164	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
A11	GL-Class	X 164	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
A11	GL-Class	X 164	Information and communication	AUDIO	XHU	•	•	•	•	•	•	•	0003
A11	GL-Class	X 164	Information and communication	COMAND or AUDIO	ХНИЈР	•	•	0	•	•	•	•	
A11	GL-Class	X 164	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•	•	
A11	GL-Class	X 164	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
A11	GL-Class	X 164	Information and communication	SOUND- Sound system	XSNDHB	•	•	0	•	•	•		
A11	GL-Class	X 164	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
A11	GL-Class	X 164	Information and communication	NAVI-Navigation system	XMCSNAV	•	•	•	•	•	•	•	
A11	GL-Class	X 164	Information and communication	AVE-H-Rear audio video unit	XAVS	•	•	•	•	•	•	•	
A11	GL-Class	X 164	Information and communication	CTEL-Cellular telephone	XTELJP	•	•	•	•	•	•	0	
A11	GL-Class	X 164	Information and communication	COMAND or AUDIO	HU25	•	•	•	•	•	•		
A11	GL-Class	X 164	Information and communication	SOUND- Sound system	SOUND25	•	•	•	•	•	•		
A11	GL-Class	X 164	Information and communication	UCI	UCI25	•	•	•	•	•	•	0	
A11	GL-Class	X 164	Information and communication	DAB-Digital radio	DAB25	•	•	•	•	•	0		
A11	GL-Class	X 164	Information and communication	SDAR-Satellite radio(Valid for USA)	SDARS25	•	•	•	•	•	•		
A11	GL-Class	X 164	Information and communication	TV-TV tuner	TV25	•	•	•	•	•	•		
A11	GL-Class	X 164	Information and communication	CTEL-Cellular telephone(JAPAN)	СВЈ25	•	•	•	•	•	0		
A11	GL-Class	X 164	Information and communication	AVE-H-Rear audio video unit	FU25	•	•	•	•	•	•		
A11	GL-Class	X 164	Information and communication	Left rear screen	DISP_RL	•	•	•	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

** This function may be As for special function please refer to the special function table.

As for special	function p	<u>lease re</u>	<u>fer to the special fu</u>	unction table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
A11	GL-Class	X 164	Information and communication	Right rear screen	DISP_RR	•	•	•	•	•	•		
A11	GL-Class	X 164	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
A11	GL-Class	X 164	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
A11	GL-Class	X 164	Information and communication	TELE AID-Telematic servicesMB Info,Roadside assistance(USA, Canada),Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
A11	GL-Class	X 164	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
A11	GL-Class	X 164	Information and communication	TELE AID-Telematic servicesRemote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
A11	GL-Class	X 164	Seats and doors	DCM-FL-Door control module front left	TSGVL164	•	•	•	•	•	0	•	
A11	GL-Class	X 164	Seats and doors	DCM-FR-Door control module front right	TSGVR164	•	•	•	•	•	0	•	
A11	GL-Class	X 164	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164_1	•	•	•	•	•	•	•	
A11	GL-Class	X 164	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164_1	•	•	•	•	•	•	•	
A11	GL-Class	X 164	Seats and doors	DS-LF-Left front dynamic seat	FDSVL211	•	•	•	•	•	•	•	
A11	GL-Class	X 164	Seats and doors	DS-RF-Right front dynamic seat	FDSVR211	•	•	•	•	•	•	•	
A11	GL-Class	X 164	Seats and doors	DSP-Pneumatic pump for dynamic seat	PFDS211	•	•	•	•	•	•	•	
A11	GL-Class	X 164	Seats and doors	ERA-Electric fold-down backrest system (3rd seat row)	SSGH164	•	•	•	•	•	•	*	
A11	GL-Class	X 164	Seats and doors	REDC-Rear-end door closing control module	HFS164	•	•	•	•	•	0	•	
A11	GL-Class	X 164	Seats and doors	REDC-Rear-end door closing control module	PTCM164	•	•	•	•	•	•	•	
A11	GL-Class	X 164	Seats and doors	HS-Seat heater	SHZ164	•	•	•	•	•	0	•	
A11	GL-Class	X 164	Air conditioning	AAC-Automatic air conditioning	KLA164	•	•	•	•	•	•	*	
A11	GL-Class	X 164	Air conditioning	HSW-Heated steering wheel	SHZ164_1	•	•	•	•	•	0	*	
A11	GL-Class	X 164	Air conditioning	STH-Stationary heater with remote control	STH164	•	•	•	•	•	•	*	
A11	R-Class	251	Drive	ISM-Intelligent servo module	ISM	•	•	•	•	•	•	*	
A11	R-Class	251	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
A11	R-Class	251	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004 0013
A11	R-Class	251	Drive	FSCU-Fuel pump	FSCM212	•	•	•	•	•	•		
A11	R-Class	251	Drive	DTR-Distronic	ARS210	•	•	•	•	•	•	0	
A11	R-Class	251	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28	•	•	•	•	•	•	•	0004
A11	R-Class	251	Drive	ME-SFI 2.8-Motor electronics 2.8	ME28AMG	•	•	•	•	•	•	•	0004
A11	R-Class	251	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	ME97AMG	•	•	•	•	•	•	•	0004 0013



NOTES:

This function is supported.

▲ This function is the new feature in this version.

As for special	l function p	lease re	fer to the special	function table.									
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory			Freeze Frame	Active Test	Special Function
A11	R-Class	251	Drive	FSCU Left-Control unit 'Left fuel pump'	FSCM_AMG_DB_ A_1	•	•	•	•	•	•		
A11	R-Class	251	Drive	FSCU Right-Control unit 'Right fuel pump'	FSCM_AMG_DB_ B_1	•	•	•	•	•	•		
A11	R-Class	251	Drive	CDI 4-Common Rail Diesel Injection	CR4	•	•	•	•	•	•	*	0013
A11	R-Class	251	Drive	CDI 6BIN5-Common Rail Diesel Injection	CR6BIN5	•	•	•	•	•	•		0013
A11	R-Class	251	Drive	SCR-Selective Catalytic Reduction	SCRCM	•	•	•	•	•	•	•	
A11	R-Class	251	Chassis	ESP-Electronic stability program	ESP164	•	•	•	•	•	•		0047, 0015
A11	R-Class	251	Chassis	Suspension	LF164	•	•	•	•	•	0	*	0048, 0049, 0056, 0 057, 0059
A11	R-Class	251	Chassis	Suspension	EHNR211	•	•	•	•	•	•	*	0042
A11	R-Class	251	Chassis	TPC-Tire pressure monitor	TPMLS	•	•	•	•	•	•	•	0005
A11	R-Class	251	Body	CGW-Central gateway	ZGW164	•	•	•	•	0	0	0	0016 0017 0018
A11	R-Class	251	Body	EZS-Electronic ignition switch	EZS164	•	•	•	•	•	0	0	
A11	R-Class	251	Body	EZS-Electronic ignition switch	EIS_164	•	•	•	•	•	•	0	
A11	R-Class	251	Body	KG-Keyless Go	KG164	•	•	•	•	•	•	•	
A11	R-Class	251	Body	AB-Airbag	ARCADE164	•	•	•	•	•	•		0041
A11	R-Class	251	Body	OCP-Overhead control panel	DBE164	•	•	•	•	•	•	•	
A11	R-Class	251	Body	WSS-Weight sensing system	WSS	•	•	•	•	•	•	0	0005
A11	R-Class	251	Body	UCP-Upper control panel	0BF164	•	•	•	•	•	0	•	
A11	R-Class	251	Body	HBF (Rear control panel)-Rear control field	HBF164	•	•	•	•	•	0	•	
A11	R-Class	251	Body	SAM-F-Signal acquisition and actuation module front	SAMV164	•	•	•	•	•	•	*	
A11	R-Class	251	Body	REAR SAM-Rear signal acquisition and actuation module	SAMH164	•	•	•	•	•	0	*	
A11	R-Class	251	Body	RevETR-RF-Right front reversible emergency tensioning retractor	RGSR164	•	•	•	•	•	•	•	
A11	R-Class	251	Body	RevETR-LF-Left front reversible emergency tensioning retractor	RGSL164	•	•	•	•	•	•	•	
A11	R-Class	251	Body	HRA-Automatic headlamp range adjustment and headlamp control	ALWR211	•	•	•	•	•	0	•	0005 0009
A11	R-Class	251	Body	System diagnosis(CAN)	SD164	•	•	0	•	•	•		
A11	R-Class	251	Information and communication	SCM [MRM]-Steering column module	MRM164	•	•	•	•	•	•	•	0005
A11	R-Class	251	Information and communication	CM-Compass module	CM164	•	•	•	•	•	•	0	
A11	R-Class	251	Information and communication	IC-Instrument cluster	KI164	•	•	•	•	•	0	•	



NOTES:

This function is supported.

▲ This function is the new feature in this version.

As for special	l function p	lease re	fer to the special f	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
A11	R-Class	251	Information and communication	ASSYST-Active Service System	WIA164	•	•	0	•	•	0	0	0001
A11	R-Class	251	Information and communication	ASSYST PLUS-PLUS Active Service System	WR164	•	•	0	•	•	•	0	0002
A11	R-Class	251	Information and communication	PTS-Parktronic system	PTS164	•	•	•	•	•	0		
A11	R-Class	251	Information and communication	PTS-Parktronic system	PTS211MOPF	•	•	•	•	•	0	•	
A11	R-Class	251	Information and communication	RFK-Backup camera	DRVM164	•	•	•	•	•	•	0	
A11	R-Class	251	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XAGW	•	•	•	•	•	•		0003
A11	R-Class	251	Information and communication	AGW-Audio gateway (MOST network management, diagnosis gateway, radio tuner)	XHUAGW	•	•	•	•	•	•		0003
A11	R-Class	251	Information and communication	CDC-CD changer	XCDC	•	•	0	•	•	•	0	
A11	R-Class	251	Information and communication	VCS-Voice control system	XSBS	•	•	0	•		•		
A11	R-Class	251	Information and communication	AUDIO	XHU	•	•	•	•	•	•	•	0003
A11	R-Class	251	Information and communication	COMAND or AUDIO	хнијр	•	•	0	•	•	•	•	
A11	R-Class	251	Information and communication	TV-TV tuner	XTV	•	•	0	•	•	•	•	
A11	R-Class	251	Information and communication	TV-TV tuner(AGW)	TV211	•	•	•	•	•	•		
A11	R-Class	251	Information and communication	SOUND- Sound system	XSNDHB	•	•	0	•	•	•		
A11	R-Class	251	Information and communication	CTEL-Mobile phone adapter with universal interface	XUHI	•	•	•	•	•	•	0	
A11	R-Class	251	Information and communication	NAVI-Navigation system	XMCSNAV	•	•	•	•	•	•	•	
A11	R-Class	251	Information and communication	AVE-H-Rear audio video unit	XAVS	•	•	•	•	•	•	•	
A11	R-Class	251	Information and communication	CTEL-Cellular telephone	XTELJP	•	•	•	•	•	•	0	
A11	R-Class	251	Information and communication	COMAND or AUDIO	HU25	•	•	•	•	•	•		
A11	R-Class	251	Information and communication	SOUND- Sound system	SOUND25	•	•	•	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

			er to the special fu	niction table.									
Model year l	Mode1		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
A11 I	R-Class	251	Information and communication	UCI	UCI25	•	•	•	•	•	•	0	
A11 I	R-Class	251	Information and communication	DAB-Digital radio	DAB25	•	•	•	•	•	0		
A11	R-Class	251	Information and communication	SDAR-Satellite radio(Valid for USA)	SDARS25	•	•	•	•	•	•		
A11 I	R-Class	251	Information and communication	TV-TV tuner	TV25	•	•	•	•	•	•		
A11 I	R-Class	251	Information and communication	CTEL-Cellular telephone(JAPAN)	CBJ25	•	•	•	•	•	0		
A11 I	R-Class	251	Information and communication	AVE-H-Rear audio video unit	FU25	•	•	•	•	•	•		
A11 I	R-Class	251	Information and communication	Left rear screen	DISP_RL	•	•	•	•	•	•		
A11 I	R-Class	251	Information and communication	Right rear screen	DISP_RR	•	•	•	•	•	•		
A11 I	R-Class	251	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
A11 I	R-Class	251	Information and communication	TELE AID-Telematic servicesEmergency call	XLCTECL	•	•	•	•		•	0	
A11	R-Class	251	Information and communication	TELE AID-Telematic servicesMB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)	XLCTSERV	•	•	•	•		•	0	
A11 I	R-Class	251	Information and communication	TELE AID-Telematic servicesStolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
A11 I	R-Class	251	Information and communication	TELE AID-Telematic servicesRemote door unlocking,Remote door locking	XLCTREM	•	•	•	•		•	0	
All I	R-Class	251	Seats and doors	DCM-FL-Door control module front left	TSGVL164	•	•	•	•	•	0	•	
A11 I	R-Class	251	Seats and doors	DCM-FR-Door control module front right	TSGVR164	•	•	•	•	•	0	•	
A11 I	R-Class	251	Seats and doors	ESA driver-Electric seat adjustment driver (with memory)	SSGF164_1	•	•	•	•	•	•	•	
A11 I	R-Class	251	Seats and doors	ESA passenger-Electric seat adjustment passenger	SSGB164_1	•	•	•	•	•	•	•	
A11 I	R-Class	251	Seats and doors	DS-LF-Left front dynamic seat	FDSVL211	•	•	•	•	•	•	•	
A11 I	R-Class	251	Seats and doors	DS-RF-Right front dynamic seat	FDSVR211	•	•	•	•	•	•	•	
A11 I	R-Class	251	Seats and doors	DSP-Pneumatic pump for dynamic seat	PFDS211	•	•	•	•	•	•	•	
A11 I	R-Class	251	Seats and doors	REDC-Rear-end door closing control module	HFS164	•	•	•	•	•	0	•	
A11 I	R-Class	251	Seats and doors	REDC-Rear-end door closing control module	PTCM164	•	•	•	•	•	•	•	
A11 I	R-Class	251	Seats and doors	HS-Seat heater	SHZ164	•	•	•	•	•	0	•	
A11 I	R-Class	251	Air conditioning	AAC-Automatic air conditioning	KLA164	•	•	•	•	•	•	*	
A11	R-Class	251	Air conditioning	STH-Stationary heater with remote control	STH164	•	•	•	•	•	•	*	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

As for special	l function p		fer to the special :	function table.			l - 1		1_		-		
Model year	Model		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory			Freeze Frame	Active Test	Special Function
A11	R-Class	251	Air conditioning	HSW-Heated steering wheel	SHZ164_1	•	•	•	•	•	0	*	
As of 2010	E-Class	212	Drive	ETC-Electronic transmission control	EGS53	•	•	•	•	•	•	•	
As of 2010	E-Class	212	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
As of 2010	E-Class	212	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004
As of 2010	E-Class	212	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	ME97AMG	•	•	•	•	•	•	•	0004 0013
As of 2010	E-Class	212	Drive	MED 9.7-Motor electronics for direct injection 9.7	MED97	•	•	•	•	•	•	*	0013
As of 2010	E-Class	212	Drive	ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EVO' (N3/10)	SIM271DE20_X	•	•	•	•	•	•	A	
As of 2010	E-Class	212	Drive	FSCU-Fuel pump	FSCM212	•	•	•	•	•	•		
As of 2010	E-Class	212	Drive	ESM-Electronic selector module	TSLM_204	•	•	•	•	•	•	•	
As of 2010	E-Class	212	Drive	ISM-Shift module (A80)	DSM	A	A	A	A	A	A		
As of 2010	E-Class	212	Drive	CDI 6-Common Rail Diesel Injection	CR6	•	•	•	•	•	•		0013 0023 0024 0025 0026
As of 2010	E-Class	212	Drive	CDID-Common Rail Diesel Injection	CRD2	•	•	•	•	0	•	A	
As of 2010	E-Class	212	Drive	SCR-Selective Catalytic Reduction	SCRCM	•	•	•	•	•	•	•	
As of 2010	E-Class	212	Drive	SGR-Radar sensors control unit	RDU_212	A	A	A	A	A	A		
As of 2010	E-Class	212	Chassis	ESP-Electronic stability program	ESP212_X	•	•	•	•	•	•	A	
As of 2010	E-Class	212	Chassis	TPC-Tire pressure monitor	TPM_204	•	•	•	•	•	•	•	0005
As of 2010	E-Class	212	Chassis	AIRMATIC-AIRMATIC	SPC_204_X	A	A	A	A	A	A	A	0048, 0049, 0051
As of 2010	E-Class	212	Body	CGW-Central gateway	CGW_204	•	•	•	•	•	•	0	
As of 2010	E-Class	212	Body	CGW-Central gateway	CGW_212	•	•	•	•	A	•		
As of 2010	E-Class	212	Body	EZS-Electronic ignition lock	EIS_212	•	•	•	•	•	•	A	
As of 2010	E-Class	212	Body	KG-Keyless Go	KG_204	•	•	•	•	•	•	•	
As of 2010	E-Class	212	Body	KG-KEYLESS GO(N69/5)	KG_212_X	•	•	•	•	•	•	A	
As of 2010	E-Class	212	Body	SRS-Supplemental restraint system (N2/10)	ORC_172	•	•	•	•	A	•	0	
As of 2010	E-Class	212	Body	SRS-Supplemental restraint system	ORC_212	•	•	•	•	•	•	0	
As of 2010	E-Class	212	Body	WSS-Weight sensing system	OCM_204	•	•	•	•	•	•	0	0005
As of 2010	E-Class	212	Body	OCP-Overhead control panel(N70)	ROOF_212_X	•	•	•	•	•	•	A	
As of 2010	E-Class	212	Body	PSD-Control mudule 'Panoramic sliding roof' (A98)	TSSR_212_X	•	•	•	•	•	•	A	
As of 2010	E-Class	212	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMF_204	•	•	•	•	•	•	•	
As of 2010	E-Class	212	Body	Driver-side SAM-Driver signal acquisition and actuation module	SAMF_172	•	•	•	•	•	•	A	
As of 2010	E-Class	212	Body	Driver-side SAM-Driver signal acquisition and actuation module	SAMF_212	•	•	•	•	•			



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

** This function may be As for special function please refer to the special function table.

As for special	function p	<u>lease re</u>	fer to the special f	unction table.									
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
As of 2010	E-Class	212	Body	REAR SAM-Rear signal acquisition and actuation module	SAMR_204	•	•	•	•	•	•	•	
As of 2010	E-Class	212	Body	Rear SAM-Rear signal acquisition and actuation module	SAMR_212	•	•	•	•	A	•		
As of 2010	E-Class	212	Body	Trailer recognition module	TM_212	•	•	•	•	•	•		
As of 2010	E-Class	212	Body	Multifunction control unit-Multifunction control unit (N26/14)	MPM_212	•	•	•	•	•	•	A	
As of 2010	E-Class	212	Body	RevETR-LF-Left front reversible emergency tensioning retractor	RBTMFL_204	•	•	•	•	•	•	•	
As of 2010	E-Class	212	Body	RevETR-LF-Left front reversible emergency tensioning retractor(A76)	RBTMFL_204_X	•	•	•	•	•	•		
As of 2010	E-Class	212	Body	RevETR-RF-Right front reversible emergency tensioning retractor	RBTMFR_204	•	•	•	•	•	•		
As of 2010	E-Class	212	Body	RevETR-RF-Right front reversible emergency tensioning retractor(A76/1)	RBTMFR_204_X	•	•	•	•	•	•		
As of 2010	E-Class	212	Body	XALWA-L-Left xenon headlamp(E1n1)	HLM_LT_212	•	•	•	•	•	•	A	
As of 2010	E-Class	212	Body	XALWA-R-Right xenon headlamp(E2n1)	HLM_RT_212	•	•	•	•	•	•	A	
As of 2010	E-Class	212	Information and communication	ES-Electrical power steering	EPS212	•	•	•	•	•	0		
As of 2010	E-Class	212	Information and communication	NSA-Night View Assist	NV221	•	•	•	•	•	0		
As of 2010	E-Class	212	Information and communication	ICM-Instrument cluster with maintenance interval display	IC_204	•	•	•	•	•	•	•	0002
As of 2010	E-Class	212	Information and communication	PTS-PARKTRONIC (N62)	PTS_212	•	•	•	•	•	•	A	
As of 2010	E-Class	212	Information and communication	RFK-Backup camera	DRVM221	•	•	•	•	•	•	0	
As of 2010	E-Class	212	Information and communication	SCCM-Steering column module(N80)	SCCM_212	•	•	•	•	•	•	A	
As of 2010	E-Class	212	Information and communication	COMAND or AUDIO	HU_204	•	•	•	•	•	•		
As of 2010	E-Class	212	Information and communication	COMAND or AUDIO	HU_204_X	•	•	•	•	•	•		
As of 2010	E-Class	212	Information and communication	COU [ZBE]-Central operating unit	CTRLC_204	•	•	•	•	•	•	•	
As of 2010	E-Class	212	Information and communication	ZBE-Audio/COMAND operating unit(A40/9)	CTRLC_204_X	•	•	•	•	•	•		
As of 2010	E-Class	212	Information and communication	ZAN-Central display	DISPC_204	•	•	•	•	•	•		
As of 2010	E-Class	212	Information and communication	TV-TV tuner(AGW)	TV221	•	•	•	•	•	•		
As of 2010	E-Class	212	Information and communication	CTEL-Cellular telephone(JAPAN)	TELJP_204	•	•	•	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

As for special :	function p	lease rei	fer to the special fi	inction table.									
Model year	Mode1		Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory			Freeze Frame	Active Test	Special Function
As of 2010	E-Class	212	Information and communication	DAB-Digital radio	DAB_204	•	•	•	•	•	•		
As of 2010	E-Class	212	Information and communication	SOUND- Sound system	SOUND_204	•	•	•	•	•	•		
As of 2010	E-Class	212	Information and communication	SDAR-Satellite radio(Valid for USA)	SDAR221	•	•	•	•	•	•		
As of 2010	E-Class	212	Information and communication	UCI	UCI_204	•	•	•	•	•	•	0	
As of 2010	E-Class	212	Information and communication	AVE-H-Rear audio video unit	FU	•	•	•	•	•	•		
As of 2010	E-Class	212	Information and communication	Left rear screen	DISP_RL	•	•	•	•	•	•		
As of 2010	E-Class	212	Information and communication	Right rear screen	DISP_RR	•	•	•	•	•	•		
As of 2010	E-Class	212	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
As of 2010	E-Class	212	Information and communication	TELE AID-Telematic services Emergency call	XLCTECL	•	•	•	•		•	0	
As of 2010	E-Class	212	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)		•	•	•	•		•	0	
As of 2010	E-Class	212	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
As of 2010	E-Class	212	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
As of 2010	E-Class	212	Information and communication	MFK-Multifunction camera	MPC212	A	A	A	A	A	A		
As of 2010	E-Class	212	Seats and doors	DSP-Pneumatic pump for dynamic seat	PFDS221	•	•	•	•	•	•	•	
As of 2010	E-Class	212	Seats and doors	DCU-LF-Left front door	DMFL_212	•	•	•	•	•	•		
As of 2010	E-Class	212	Seats and doors	DCU-RF-Right front door	DMFR_212	•	•	•	•	•	A		
As of 2010	E-Class	212	Seats and doors	DCU-LR-Left rear door	DMRL_212	•	•	•	•	•	•	A	
As of 2010	E-Class	212	Seats and doors	DCU-RR-Right rear door	DMRR_212	•	•	•	•	•	•	A	
As of 2010	E-Class	212	Seats and doors	AMKS-LF-Active multicontour seat(N32/19)	MCMSFL_212_X	•	•	•	•	•	•	A	
As of 2010	E-Class	212	Seats and doors	AMKS-RF-Active multicontour seat(N32/22)	MCMSFR_212_X	•	•	•	•	•	•	A	
As of 2010	E-Class	212	Seats and doors	TLC-Trunk lid control	PTCM_1	•	•	•	•	•	•	•	
As of 2010	E-Class	212	Seats and doors	ESA driver	SEATD_204	•	•	•	•	•	•	•	
As of 2010	E-Class	212	Seats and doors	ESA passenger	SEATP_204	•	•	•	•	•	•	•	
As of 2010	E-Class	212	Seats and doors	ESA-Electirc seat adjustment 'Front passenger' (N32/2)	SEATP_204_X	•	•	•	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Model year	Model	Mode1	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
As of 2010	E-Class	212	Seats and doors	SIH-FOND-Rear passenger compartment seat heater	HM_212	A		Memor y ▲		A		1030	T dilection
As of 2010	E-Class	212	Air conditioning	Stationary heater	STH212	•	•	•	•	•	•		
As of 2010	E-Class	212	Air conditioning	AAC-Air conditioining	HVAC_212	•	•	•	•	•	•	A	
As of 2010	E-Class	212	Air conditioning	LRH-Steering wheel heater	HMSW_212_X	•	•	•	•	0	A		
As of 2010	E-Class	207	Drive	ETC-Electronic transmission control	EGS53	•	•	•	•	•	•	•	
As of 2010	E-Class	207	Drive	ETC-Electronic transmission control	VGSNAG2	•	•	•	•	•	•	0	
As of 2010	E-Class	207	Drive	ME 9.7-Motor electronics 9.7	ME97	•	•	•	•	•	•	*	0004
As of 2010	E-Class	207	Drive	ME 9.7 (AMG)-Motor electronics 9.7 (AMG)	ME97AMG	•	•	•	•	•	•	•	0004 0013
As of 2010	E-Class	207	Drive	MED 9.7-Motor electronics for direct injection 9.7	MED97	•	•	•	•	•	•	*	0013
As of 2010	E-Class	207	Drive	ME - Motor electronics 'SIM271DE20' for combustion engine 'M271EV0' (N3/10)	SIM271DE20_X	•	•	•	•	•	•	A	
As of 2010	E-Class	207	Drive	FSCU-Fuel pump	FSCM212	•	•	•	•	•	•		
As of 2010	E-Class	207	Drive	ESM-Electronic selector module	TSLM_204	•	•	•	•	•	•	•	
As of 2010	E-Class	207	Drive	CDI 6-Common Rail Diesel Injection	CR6	•	•	•	•	•	•		0013 0023 0024 0025 0026
As of 2010	E-Class	207	Drive	CDID-Common Rail Diesel Injection	CRD2	•	•	•	•	0	•	A	
As of 2010	E-Class	207	Drive	SGR-Radar sensors control unit	RDU_212	A	A	A	A	A	A		
As of 2010	E-Class	207	Chassis	ESP-Electronic stability program	ESP212_X	•	•	•	•	•	•	A	
As of 2010	E-Class	207	Chassis	AIRMATIC-AIRMATIC	SPC_204_X	A	A	A	•	A	A	A	0048, 0049, 0051
As of 2010	E-Class	207	Chassis	AIRSCARF-AIRSCARF system (N25/7)	AS_207	•	•	•	•	•	•	A	
As of 2010	E-Class	207	Body	CGW-Central gateway	CGW_204	•	•	•	•	•	•	0	
As of 2010	E-Class	207	Body	CGW-Central gateway	CGW_212	•	•	•	•	•	•		
As of 2010	E-Class	207	Body	EZS-Electronic ignition switch	EIS_204	•	•	•	•	•	•	0	
As of 2010	E-Class	207	Body	KG-Keyless Go	KG_204	•	•	•	•	•	•	•	
As of 2010	E-Class	207	Body	KG-KEYLESS GO(N69/5)	KG_212_X	•	•	•	•	•	•	A	
As of 2010	E-Class	207	Body	SRS-Supplemental restraint system	ORC_212	•	•	•	•	•	•	0	
As of 2010	E-Class	207	Body	WSS-Weight sensing system	OCM_204	•	•	•	•	•	•	0	0005
As of 2010	E-Class	207	Body	OCP-Overhead control panel	R00F_204	•	•	•	•	•	•	•	
As of 2010	E-Class	207	Body	PSD-Control mudule 'Panoramic sliding roof' (A98)	TSSR_212_X	•	•	•	•	•	•	A	
As of 2010	E-Class	207	Body	Dr-side SAM-Driver signal acquisition and actuation module	SAMF_204	•	•	•	•	•	•	•	
As of 2010	E-Class	207	Body	Driver-side SAM-Driver signal acquisition and actuation module	SAMF_172	•	•	•	•	•	•	A	



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

** This function may be As for special function please refer to the special function table.

As for special function please refer to the special function table.													
Model year	Model	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes		Erase Codes	Live Data	Freeze Frame	Active Test	Special Function
As of 2010	E-Class	207	Body	Driver-side SAM-Driver signal acquisition and actuation module	SAMF_212	•	•	•	•	A			
As of 2010	E-Class	207	Body	REAR SAM-Rear signal acquisition and actuation module	SAMR_204	•	•	•	•	•	•	•	
As of 2010	E-Class	207	Body	Rear SAM-Rear signal acquisition and actuation module	SAMR_212	•	•	•	•	A	A		
As of 2010	E-Class	207	Body	Trailer recognition module	TM_212	•	•	•	•	•	•		
As of 2010	E-Class	207	Body	RevETR-LF-Left front reversible emergency tensioning retractor	RBTMFL_204	•	•	•	•	•	•	•	
As of 2010	E-Class	207	Body	RevETR-LF-Left front reversible emergency tensioning retractor(A76)	RBTMFL_204_X	•	•	•	•	•	•		
As of 2010	E-Class	207	Body	RevETR-RF-Right front reversible emergency tensioning retractor	RBTMFR_204	•	•	•	•	•	•		
As of 2010	E-Class	207	Body	RevETR-RF-Right front reversible emergency tensioning retractor(A76/1)	RBTMFR_204_X	•	•	•	•	•	•		
As of 2010	E-Class	207	Body	XALWA-L-Left xenon headlamp(E1n1)	HLM_LT_212	•	•	•	•	•	•	A	
As of 2010	E-Class	207	Body	XALWA-R-Right xenon headlamp(E2n1)	HLM_RT_212	•	•	•	•	•	•	A	
As of 2010	E-Class	207	Information and communication	ES-Electrical power steering	EPS212	•	•	•	•	•	•	•	
As of 2010	E-Class	207	Information and communication	ICM-Instrument cluster with maintenance interval display	IC_204	•	•	•	•	•	•		0002
As of 2010	E-Class	207	Information and communication	PTS-PARKTRONIC (N62)	PTS_212	•	•	•	•	•	•	A	
As of 2010	E-Class	207	Information and communication	RFK-Backup camera	DRVM221	•	•	•	•	•	•	0	
As of 2010	E-Class	207	Information and communication	SCCM-Steering column module(N80)	SCCM_212	•	•	•	•	•	•	A	
As of 2010	E-Class	207	Information and communication	COMAND or AUDIO	HU_204	•	•	•	•	•	•		
As of 2010	E-Class	207	Information and communication	COMAND or AUDIO	HU_204_X	•	•	•	•	•	•		
As of 2010	E-Class	207	Information and communication	COU [ZBE]-Central operating unit	CTRLC_204	•	•	•	•	•	•	•	
As of 2010	E-Class	207	Information and communication	ZBE-Audio/COMAND operating unit(A40/9)	CTRLC_204_X	•	•	•	•	•	•		
As of 2010	E-Class	207	Information and communication	ZAN-Central display	DISPC_204	•	•	•	•	•	•		
As of 2010	E-Class	207	Information and communication	TV-TV tuner(AGW)	TV221	•	•	•	•	•	•		
As of 2010	E-Class	207	Information and communication	CTEL-Cellular telephone(JAPAN)	TELJP_204	•	•	•	•	•	•		
As of 2010	E-Class	207	Information and communication	DAB-Digital radio	DAB_204	•	•	•	•	•	•		



NOTES:

• This function is supported.

▲ This function is the new feature in this version.

O This function is not supported.

* This function may be supported, which depends on the actual condition of the vehicle.

O This function is not supported.

** This function may be As for special function please refer to the special function table.

As for special function please refer to the special function table.													
Model year	Mode1	Model Series	Control Unit Groups	System Name	DiagName	Ecu Info.	Read Codes	Event Memory	Erase Codes	Live Data		Active Test	Special Function
As of 2010	E-Class	207	Information and communication	SOUND- Sound system	SOUND_204	•	•	•	•	•	•		
As of 2010	E-Class	207	Information and communication	SDAR-Satellite radio(Valid for USA)	SDAR221	•	•	•	•	•	•		
As of 2010	E-Class	207	Information and communication	UCI	UCI_204	•	•	•	•	•	•	0	
As of 2010	E-Class	207	Information and communication	TELE AID-Control unit	XLCT	•	•	•	•	•	•	0	
As of 2010	E-Class	207	Information and communication	TELE AID-Telematic services Emergency call	XLCTECL	•	•	•	•		•	0	
As of 2010	E-Class	207	Information and communication	TELE AID-Telematic services MB Info, Roadside assistance(USA, Canada), Tele diagnosis(ECE)		•	•	•	•		•	0	
As of 2010	E-Class	207	Information and communication	TELE AID-Telematic services Stolen vehicle tracking	XLCTTRK	•	•	•	•		•	0	
As of 2010	E-Class	207	Information and communication	TELE AID-Telematic services Remote door unlocking, Remote door locking	XLCTREM	•	•	•	•		•	0	
As of 2010	E-Class	207	Information and communication	SG-FOND-Rear control unit (N22/6)	CRCM_207	•	•	•	•	•	•	A	
As of 2010	E-Class	207	Information and communication	MFK-Multifunction camera	MPC212	A	A	A	A	A	A		
As of 2010	E-Class	207	Seats and doors	DCU-LF-Left front door	DMFL_212	•	•	•	•	•	•		
As of 2010	E-Class	207	Seats and doors	DCU-RF-Right front door	DMFR_212	•	•	•	•	•	A		
As of 2010	E-Class	207	Seats and doors	ESA driver	SEATD_204	•	•	•	•	•	•	•	
As of 2010	E-Class	207	Seats and doors	ESA passenger	SEATP_204	•	•	•	•	•	•	•	
As of 2010	E-Class	207	Seats and doors	ESA-Electirc seat adjustment 'Front passenger' (N32/2)	SEATP_204_X	•	•	•	•	•	•		
As of 2010	E-Class	207	Air conditioning	Stationary heater	STH212	•	•	•	•	•	•		
As of 2010	E-Class	207	Air conditioning	AAC-Air conditioining	HVAC_212	•	•	•	•	•	•	A	
A11	S-Class	221	Chassis	ABR-Adaptive Brake	RBS221	A	A	A	A	A			
A11	M-Class	164	Chassis	ABR-Adaptive Brake	RBS164	A	A	A	A	A			



Special_Function

index	Specil Function Name	index	Specil Function Name
0001	ASSYST Setting	0023	Teach-in process after replacement of component Diesel particulate filter
0002	Service Reset	0024	Teaching in the diesel particulate filter after replacing the engine control unit
0003	Read coding and change if necessary.	0025	Activate fuel pump
0004	Variant coding	0026	Rapid teach-in of zero quantity calibration values
0005	Initial startup	0027	Initial startup of control unit EZS
0006	Deactivate system	0028	Initial startup of control unit ESL
0007	Activate system	0029	Disable key or key track
8000	Customer complaints (without fault codes)	0030	Once again authorize key or key track.// (DEF@KL15)
0009	Control unit adaptations	0031	Once again authorize key or key track.// (!(DEF@KL15))
0010	Chassis number	0032	Program replacement keys
0011	Sliding/tilting roof	0033	Activate control module N73 (EIS [EZS] control unit).
0012	Calibration of the torque sensor	0034	Activate control module N26/5 (Electric steering lock control module)
0013	Learning of the throttle valve stop	0035	Key assignment or key track assignment to a memory block number
0014	Road test	0036	Writing of the VIN
0015	Tire pressure loss warner (Activating)	0037	Telematic service 'Remote door unlocking' (TELE AID)
0016	Vehicle data	0038	Brake counter update and recalculate lifetime
0017	Modification year or model year	0039	Replace hydraulic brake system fluid./Bleed brake system.
0018	All codes	0040	Zero point variation steering angle and lateral acceleration sensor
0019	Replace component Diesel particulate filter	0041	Steering variant
0020	Reprogram diesel particulate filter in control unit N3/9 (CDI control unit)	0042	Pneumatic tests
0021	Teach in component Y94 (Quantity control valve)	0043	Initial test/ Oil condition check/ Oil level check
0022	Teaching in the diesel particulate filter after replacing the engine control unit	0044	Diagnosis routines
0045	Calibration of compnent B24/12(ABC lateral acceleration sensor)	0052	Load adjustment
0046	Calibration of the plunger travel sensors	0056	Pneumatic test of component A9/1 (AIRmatic compressor unit)
0047	Erase zero point offset error of component N49 (Steering angle sensor)	0057	Pneumatic test of component A9/1y1 (AIRmatic pressure release valve)
0048	Initial startup with automatic takeover of settings of previous control unit	0058	Replacement of control module N80(Steering column module)
0049	Initial startup with manual settings input for new control unit/Level calibration	0059	Reset compressor operating time
0050	Initializing:Rain sensor,Steering column module	0060	Reset of calibration
0051	Level calibration		