- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
(All MYO5) Escape/Tribute/Maverick/Mariner	2. 3L	DURATEC-HE / I4	2005 MY	4X4	•	•		
(All MY05) Escape/Tribute/Maverick/Mariner	2. 3L	DURATEC-HE / I4	2005 MY	ABS		•		
(All MY05) Escape/Tribute/Maverick/Mariner	2.3L	DURATEC-HE / I4	2005 MY	GEM		•		
(All MY05) Escape/Tribute/Maverick/Mariner	2. 3L	DURATEC-HE / I4	2005 MY	IC		•		
(All MY05) Escape/Tribute/Maverick/Mariner	2. 3L	DURATEC-HE / I4	2005 MY	PAM		•		
(All MY05) Escape/Tribute/Maverick/Mariner	2. 3L	DURATEC-HE / I4	2005 MY	PCM		•		
(All MY05) Escape/Tribute/Maverick/Mariner	2. 3L	DURATEC-HE / I4	2005 MY	RCM		•		
(All MY05) Escape/Tribute/Maverick/Mariner	3. 0L	4V	2005 MY	4X4		•		
(All MYO5) Escape/Tribute/Maverick/Mariner	3. 0L	4V	2005 MY	ABS		•		
(All MY05) Escape/Tribute/Maverick/Mariner	3. 0L	4V	2005 MY	GEM		•		
(All MY05) Escape/Tribute/Maverick/Mariner	3. 0L	4V	2005 MY	IC	•	•		
(All MY05) Escape/Tribute/Maverick/Mariner	3. 0L	4V	2005 MY	PAM	•	•	•	
(All MYO5) Escape/Tribute/Maverick/Mariner	3. 0L	4V	2005 MY	PCM	•	•		
(All MY05) Escape/Tribute/Maverick/Mariner	3. 0L	4V	2005 MY	RCM		•		
AEROSTAR	3. 0L	Other	1996 MY	PCM		•		
AEROSTAR	3. 0L	Other	1997 MY	PCM				
AEROSTAR	4. 0L	Other	1996 MY	PCM		•		
AEROSTAR	4. 0L	Other	1997 MY	PCM		•		
BT-50 / Ranger	2. 2L	F2	2007 MY	ABS/TCS		•		
BT-50 / Ranger	2. 2L	F2	2007 MY	PCM		•		
BT-50 / Ranger	2. 2L	F2	2007 MY	RCM	•	•	•	0
BT-50 / Ranger	2. 5L	WL	2007 MY	ABS/TCS	•	•	•	
BT-50 / Ranger	2.5L	WL	2007 MY	PCM	•	•	•	
BT-50 / Ranger	2.5L	WL	2007 MY	RCM	•	•	•	0
BT-50 / Ranger	2.5L	WL_CD	2007 MY	ABS/TCS	•	•	•	
BT-50 / Ranger	2.5L	WL_CD	2007 MY	PCM		•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
BT-50 / Ranger	2.5L	WL_CD	2007 MY	RCM	•	•		0
BT-50 / Ranger	2.5L	WL_CD	2007 MY	TCM	•	•		
BT-50 / Ranger	2.6L	G6	2007 MY	ABS/TCS	•	•		
BT-50 / Ranger	2.6L	G6	2007 MY	PCM		•		
BT-50 / Ranger	2.6L	G6	2007 MY	RCM	•	•	•	0
BT-50 / Ranger	3. 0L	WE-CD	2007 MY	ABS/TCS	•	•	•	
BT-50 / Ranger	3. 0L	WE-CD	2007 MY	PCM	•	•	•	
BT-50 / Ranger	3. 0L	WE-CD	2007 MY	RCM	•	•	•	0
BT-50 / Ranger	3. 0L	WE-CD	2007 MY	TCM	•	•		
BT-50 / Ranger	4. 0L	V6 SOHC	2007 MY	ABS/TCS	•		•	
BT-50 / Ranger	4. 0L	V6 SOHC	2007 MY	ES0F		•	•	
BT-50 / Ranger	4. 0L	V6 SOHC	2007 MY	PCM		•		•
BT-50 / Ranger	4. 0L	V6 SOHC	2007 MY	RCM	•	•	•	0
Cougar	2. 0L	Zetec	1998.75 MY	ABS/TCS	•	•	•	•
Cougar	2. 0L	Zetec	1998.75 MY	CSM		•	0	
Cougar	2. 0L	Zetec	1998.75 MY	HEC	•	•	•	
Cougar	2. 0L	Zetec	1998.75 MY	IAB			•	0
Cougar	2. 0L	Zetec	1998.75 MY	PCM			•	
Cougar	2. 0L	Zetec	1999 MY	ABS/TCS	•	•	•	•
Cougar	2. 0L	Zetec	1999 MY	CSM	•	•	•	
Cougar	2. 0L	Zetec	1999 MY	HEC		•	•	
Cougar	2. 0L	Zetec	1999 MY	IAB	•	•		0
Cougar	2. 0L	Zetec	1999 MY	PCM	•	•	•	•
Cougar	2. 0L	Zetec	2000 MY	ABS/TCS	•	•		•
Cougar	2. 0L	Zetec	2000 MY	CSM	•	•		
Cougar	2. 0L	Zetec	2000 MY	HEC	•	•		

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Cougar	2. 0L	Zetec	2000 MY	IAB	•	•		0
Cougar	2. 0L	Zetec	2000 MY	PCM	•	•		
Cougar	2. 0L	Zetec	2000.5 MY	ABS/TCS	•	•		
Cougar	2.0L	Zetec	2000.5 MY	CSM		•	0	
Cougar	2. 0L	Zetec	2000.5 MY	HEC	•	•		
Cougar	2. 0L	Zetec	2000.5 MY	IAB	•	•		0
Cougar	2. 0L	Zetec	2000.5 MY	PCM	•	•		
Cougar	2. 0L	Zetec	2002 MY	ABS/TCS	•	•		
Cougar	2. 0L	Zetec	2002 MY	CSM	•	•		
Cougar	2. 0L	Zetec	2002 MY	HEC	•	•		
Cougar	2. 0L	Zetec	2002 MY	IAB	•	•		0
Cougar	2. 0L	Zetec	2002 MY	PCM	•	•		•
Cougar	2.5L	Duratec-VE	1998.75 MY	ABS/TCS	•	•		
Cougar	2.5L	Duratec-VE	1998.75 MY	CSM	•	•	0	
Cougar	2.5L	Duratec-VE	1998.75 MY	HEC				
Cougar	2.5L	Duratec-VE	1998.75 MY	IAB		•		0
Cougar	2.5L	Duratec-VE	1998.75 MY	PCM	•	•		
Cougar	2.5L	Duratec-VE	1999 MY	ABS/TCS	•	•		
Cougar	2.5L	Duratec-VE	1999 MY	CSM	•	•		
Cougar	2.5L	Duratec-VE	1999 MY	HEC	•	•		
Cougar	2. 5L	Duratec-VE	1999 MY	IAB	•	•		0
Cougar	2.5L	Duratec-VE	1999 MY	PCM	•	•	•	
Cougar	2.5L	Duratec-VE	1999.75 MY	ABS/TCS	•	•	•	
Cougar	2. 5L	Duratec-VE	1999.75 MY	CSM	•	•	0	
Cougar	2. 5L	Duratec-VE	1999.75 MY	HEC	•	•		•
Cougar	2.5L	Duratec-VE	1999.75 MY	IAB	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Cougar	2.5L	Duratec-VE	1999.75 MY	PCM		•		
Cougar	2. 5L	Duratec-VE	2000 MY	ABS/TCS		•		
Cougar	2. 5L	Duratec-VE	2000 MY	CSM		•		
Cougar	2.5L	Duratec-VE	2000 MY	HEC		•		
Cougar	2. 5L	Duratec-VE	2000 MY	IAB		•		0
Cougar	2. 5L	Duratec-VE	2000 MY	PCM		•		
Cougar	2. 5L	Duratec-VE	2000.5 MY	ABS/TCS		•		
Cougar	2. 5L	Duratec-VE	2000.5 MY	CSM		•	0	
Cougar	2.5L	Duratec-VE	2000.5 MY	HEC		•		
Cougar	2.5L	Duratec-VE	2000.5 MY	IAB		•		0
Cougar	2. 5L	Duratec-VE	2000.5 MY	PCM		•		
Cougar	2. 5L	Duratec-VE	2001 MY	MC		•		0
Cougar	2.5L	Duratec-VE	2001 MY	REM		•		0
Cougar	2.5L	Duratec-VE	2002 MY	ABS/TCS				
Cougar	2.5L	Duratec-VE	2002 MY	CSM				
Cougar	2.5L	Duratec-VE	2002 MY	HEC		•		
Cougar	2. 5L	Duratec-VE	2002 MY	IAB		•		0
Cougar	2. 5L	Duratec-VE	2002 MY	PCM		•		
Cougar	3.8L	Other	1996 MY	ABS/TCS		•		
Cougar	3.8L	Other	1996 MY	HEC		•		
Cougar	3.8L	Other	1996 MY	PCM		•		
Cougar	3.8L	Other	1997 MY	ABS/TCS		•	•	
Cougar	3.8L	Other	1997 MY	HEC	•	•	•	
Cougar	3.8L	Other	1997 MY	PCM	•	•		•
Cougar	4. 6L	2V	1994 MY	ABS/TCS	•	•		•
Cougar	4.6L	2V	1994 MY	HEC		•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Cougar	4.6L	2V	1994 MY	PCM		•		
Cougar	4. 6L	2V	1995 MY	ABS/TCS		•		
Cougar	4. 6L	2V	1995 MY	HEC		•		
Cougar	4.6L	2V	1995 MY	PCM		•		
Cougar	4. 6L	2V	1996 MY	ABS/TCS		•		
Cougar	4. 6L	2V	1996 MY	HEC		•		
Cougar	4. 6L	2V	1996 MY	PCM		•		
Cougar	4. 6L	2V	1997 MY	ABS/TCS		•		
Cougar	4. 6L	2V	1997 MY	HEC		•		
Cougar	4.6L	2V	1997 MY	PCM		•		
Crown Victoria	4. 6L	2V	1995 MY	ABS/TCS		•		0
Crown Victoria	4.6L	2V	1995 MY	DDM		•		0
Crown Victoria	4.6L	2V	1995 MY	DSM		•		0
Crown Victoria	4. 6L	2V	1995 MY	EATC		•		0
Crown Victoria	4. 6L	2V	1995 MY	LCM		•		0
Crown Victoria	4. 6L	2V	1995 MY	PCM		•		
Crown Victoria	4. 6L	2V	1996 MY	ABS/TCS		•		
Crown Victoria	4. 6L	2V	1996 MY	DDM		•		
Crown Victoria	4. 6L	2V	1996 MY	DSM		•		
Crown Victoria	4. 6L	2V	1996 MY	EATC		•		0
Crown Victoria	4. 6L	2V	1996 MY	IAB		•		0
Crown Victoria	4. 6L	2V	1996 MY	LCM		•	•	•
Crown Victoria	4.6L	2V	1996 MY	PCM	•	•		
Crown Victoria	4.6L	2V	1997 MY	ABS/TCS	•	•	•	•
Crown Victoria	4.6L	2V	1997 MY	DDM	•	•	•	•
Crown Victoria	4.6L	2V	1997 MY	DSM	•	•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Crown Victoria	4.6L	2V	1997 MY	EATC		•		0
Crown Victoria	4.6L	2V	1997 MY	IAB		•		0
Crown Victoria	4.6L	2V	1997 MY	LCM		•		
Crown Victoria	4.6L	2V	1997 MY	PCM		•		
Crown Victoria	4.6L	2V	1998 MY	ABS/TCS		•		•
Crown Victoria	4.6L	2V	1998 MY	DDM		•		
Crown Victoria	4.6L	2V	1998 MY	EATC		•		0
Crown Victoria	4.6L	2V	1998 MY	ECS		•		0
Crown Victoria	4.6L	2V	1998 MY	LCM		•		
Crown Victoria	4.6L	2V	1998 MY	PATS	•	•		
Crown Victoria	4.6L	2V	1998 MY	PCM		•		
Crown Victoria	4.6L	2V	1999 MY	ABS/TCS	•	•		
Crown Victoria	4.6L	2V	1999 MY	DDM		•		
Crown Victoria	4.6L	2V	1999 MY	EATC		•		0
Crown Victoria	4.6L	2V	1999 MY	ECS		•		0
Crown Victoria	4.6L	2V	1999 MY	LCM		•		
Crown Victoria	4.6L	2V	1999 MY	PATS		•		
Crown Victoria	4.6L	2V	1999 MY	PCM		•		
Crown Victoria	4.6L	2V	2000 MY	ABS/TCS		•		•
Crown Victoria	4.6L	2V	2000 MY	DDM		•		•
Crown Victoria	4.6L	2V	2000 MY	EATC		•		0
Crown Victoria	4. 6L	2V	2000 MY	ECS		•	•	0
Crown Victoria	4.6L	2V	2000 MY	LCM	•	•	•	
Crown Victoria	4. 6L	2V	2000 MY	PATS	•	•		•
Crown Victoria	4. 6L	2V	2000 MY	PCM	•	•	•	•
Crown Victoria	4.6L	2V	2000 MY	RCM	•	•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Crown Victoria	4.6L	2V	2002 MY	ABS/TCS		•		
Crown Victoria	4.6L	2V	2002 MY	DDM		•		
Crown Victoria	4.6L	2V	2002 MY	EATC		•		0
Crown Victoria	4. 6L	2V	2002 MY	LCM		•		
Crown Victoria	4. 6L	2V	2002 MY	PATS		•		
Crown Victoria	4. 6L	2V	2002 MY	PCM		•		
Crown Victoria	4. 6L	2V	2002 MY	RCM		•	•	
Crown Victoria	4. 6L	2V	2003 MY	ABS/TCS		•	•	
Crown Victoria	4. 6L	2V	2003 MY	DDM		•		
Crown Victoria	4. 6L	2V	2003 MY	EATC	•	•	•	0
Crown Victoria	4. 6L	2V	2003 MY	FIM		•	•	0
Crown Victoria	4. 6L	2V	2003 MY	LCM		•	•	•
Crown Victoria	4. 6L	2V	2003 MY	PCM		•	•	
Crown Victoria	4.6L	2V	2003 MY	RASM		•		
Crown Victoria	4. 6L	2V	2003 MY	RCM		•		
Crown Victoria	4. 6L	2V	2003 MY	VAPS		•		
Crown Victoria	4. 6L	2V	2004 MY	ABS/TCS		•	•	
Crown Victoria	4. 6L	2V	2004 MY	DDM		•	•	
Crown Victoria	4. 6L	2V	2004 MY	EATC		•	•	0
Crown Victoria	4. 6L	2V	2004 MY	FIM		•	•	0
Crown Victoria	4. 6L	2V	2004 MY	LCM	•			
Crown Victoria	4. 6L	2V	2004 MY	MC	•	•	•	0
Crown Victoria	4. 6L	2V	2004 MY	PCM		•	•	•
Crown Victoria	4. 6L	2V	2004 MY	RASM	•	•	•	•
Crown Victoria	4. 6L	2V	2004 MY	RCM	•	•	•	•
Crown Victoria	4. 6L	2V	2004 MY	VAPS	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Crown Victoria	4.6L	2V	2005 MY	ABS		•		
Crown Victoria	4.6L	2V	2005 MY	DDM		•		
Crown Victoria	4.6L	2V	2005 MY	EATC		•		0
Crown Victoria	4.6L	2V	2005 MY	FSSM		•		
Crown Victoria	4.6L	2V	2005 MY	LCM		•		
Crown Victoria	4.6L	2V	2005 MY	MC		•		0
Crown Victoria	4.6L	2V	2005 MY	PCM		•		
Crown Victoria	4. 6L	2V	2005 MY	RASM	•	•	•	
Crown Victoria	4. 6L	2V	2005 MY	RCM		•		
Crown Victoria	4. 6L	2V	2005 MY	VAPS	•	•	•	
Crown Victoria	4. 6L	2V	2006 MY	ABS	•	•	•	•
Crown Victoria	4. 6L	2V	2006 MY	DDM	•	•	•	•
Crown Victoria	4. 6L	2V	2006 MY	EATC	•	•	•	0
Crown Victoria	4.6L	2V	2006 MY	FSSM		•		
Crown Victoria	4.6L	2V	2006 MY	IC		•		
Crown Victoria	4. 6L	2V	2006 MY	LCM		•		•
Crown Victoria	4. 6L	2V	2006 MY	MC	•	•	•	0
Crown Victoria	4. 6L	2V	2006 MY	PCM	•	•	•	•
Crown Victoria	4. 6L	2V	2006 MY	RASM	•	•	•	•
Crown Victoria	4. 6L	2V	2006 MY	RCM		•	•	
Crown Victoria	4.6L	2V	2006 MY	VAPS	•	•	•	•
Crown Victoria	4.6L	2V	2007 MY	ABS	•	•	•	•
Crown Victoria	4. 6L	2V	2007 MY	DDM		•		•
Crown Victoria	4.6L	2V	2007 MY	EATC	•	•		0
Crown Victoria	4.6L	2V	2007 MY	FSSM	•	•	•	•
Crown Victoria	4. 6L	2V	2007 MY	IC	•	•		•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Crown Victoria	4.6L	2V	2007 MY	LCM		•		
Crown Victoria	4.6L	2V	2007 MY	MC		•		0
Crown Victoria	4.6L	2V	2007 MY	PCM		•		
Crown Victoria	4.6L	2V	2007 MY	RCM		•		0
Crown Victoria	4.6L	2V	2007 MY	VDM		•		•
Crown Victoria	4.6L	2V	2008 MY	ABS		•		
Crown Victoria	4.6L	2V	2008 MY	DDM		•		•
Crown Victoria	4.6L	2V	2008 MY	FSSM	•	•	•	•
Crown Victoria	4. 6L	2V	2008 MY	IC		•		
Crown Victoria	4. 6L	2V	2008 MY	LCM	•	•	•	
Crown Victoria	4. 6L	2V	2008 MY	MC	•	•	•	0
Crown Victoria	4. 6L	2V	2008 MY	PCM	•	•	•	•
Crown Victoria	4. 6L	2V	2008 MY	RCM	•	•	•	0
Crown Victoria	4.6L	2V	2008 MY	VDM	•	•	•	•
Crown Victoria	4. 6L	2V	2009 MY	ABS		•		
Crown Victoria	4.6L	2V	2009 MY	DDM		•		
Crown Victoria	4.6L	2V	2009 MY	FSSM		•	•	•
Crown Victoria	4.6L	2V	2009 MY	IC		•	•	•
Crown Victoria	4. 6L	2V	2009 MY	LCM	•	•	•	•
Crown Victoria	4. 6L	2V	2009 MY	MC	•	•	•	0
Crown Victoria	4.6L	2V	2009 MY	PCM		•	•	•
Crown Victoria	4. 6L	2V	2009 MY	RCM	•	•	•	0
Crown Victoria	4. 6L	2V	2009 MY	VDM	•	•		•
Crown Victoria	4. 6L	2V	2010 MY	ABS	•	•		•
Crown Victoria	4. 6L	2V	2010 MY	DDM	•	•	•	_
Crown Victoria	4. 6L	2V	2010 MY	FSSM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Crown Victoria	4.6L	2V	2010 MY	IC				
Crown Victoria	4.6L	2V	2010 MY	MC		•		0
Crown Victoria	4.6L	2V	2010 MY	PCM		•		
Crown Victoria	4.6L	2V	2010 MY	RCM		•		0
Crown Victoria	4.6L	2V	2010 MY	VDM		•		
Crown Victoria	4.6L	2V_NGV	1996 MY	ABS/TCS		•		
Crown Victoria	4.6L	2V_NGV	1996 MY	DDM		•		
Crown Victoria	4.6L	2V_NGV	1996 MY	DSM		•		
Crown Victoria	4.6L	2V NGV	1996 MY	FIM		•		0
Crown Victoria	4.6L	2V_NGV	1996 MY	IAB		•		0
Crown Victoria	4.6L	2V_NGV	1996 MY	LCM		•		
Crown Victoria	4.6L	2V_NGV	1996 MY	PCM		•		
Crown Victoria	4.6L	2V_NGV	1997 MY	ABS/TCS		•		
Crown Victoria	4.6L	2V_NGV	1997 MY	DDM		•		
Crown Victoria	4.6L	2V NGV	1997 MY	DSM				
Crown Victoria	4.6L	2V_NGV	1997 MY	FIM		•		0
Crown Victoria	4.6L	2V_NGV	1997 MY	IAB		•		0
Crown Victoria	4.6L	2V_NGV	1997 MY	LCM		•		
Crown Victoria	4.6L	2V_NGV	1997 MY	PCM		•		
Crown Victoria	4.6L	2V_NGV	1998 MY	ABS/TCS		•		
Crown Victoria	4.6L	2V_NGV	1998 MY	DDM		•	•	
Crown Victoria	4.6L	2V_NGV	1998 MY	EATC		•	•	0
Crown Victoria	4.6L	2V_NGV	1998 MY	ECS	•	•		0
Crown Victoria	4. 6L	2V_NGV	1998 MY	FIM	•	•	•	0
Crown Victoria	4. 6L	2V_NGV	1998 MY	LCM	•	•	•	•
Crown Victoria	4.6L	2V_NGV	1998 MY	PATS		•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Crown Victoria		2V_NGV	1998 MY	PCM		•		
Crown Victoria	4.6L	2V_NGV	1999 MY	ABS/TCS				
Crown Victoria	4.6L	2V_NGV	1999 MY	DDM				
Crown Victoria	4. 6L	2V NGV	1999 MY	EATC		•		0
Crown Victoria	4.6L	2V_NGV	1999 MY	ECS		•		0
Crown Victoria	4. 6L	2V_NGV	1999 MY	FIM		•		0
Crown Victoria	4. 6L	2V_NGV	1999 MY	LCM		•		•
Crown Victoria	4. 6L	2V_NGV	1999 MY	PATS		•		•
Crown Victoria	4.6L	2V NGV	1999 MY	PCM		•		
Crown Victoria	4.6L	2V NGV	2000 MY	ABS/TCS	•	•		
Crown Victoria	4. 6L	2V_NGV	2000 MY	DDM		•		•
Crown Victoria	4.6L	2V_NGV	2000 MY	EATC	•	•		0
Crown Victoria	4. 6L	2V_NGV	2000 MY	ECS		•		0
Crown Victoria	4. 6L	2V_NGV	2000 MY	FIM		•		0
Crown Victoria	4. 6L	2V NGV	2000 MY	LCM		•		
Crown Victoria	4. 6L	2V_NGV	2000 MY	PATS	•	•		•
Crown Victoria	4. 6L	2V_NGV	2000 MY	PCM		•		
Crown Victoria	4. 6L	2V_NGV	2000 MY	RCM	•	•	•	•
Crown Victoria	4. 6L	Other	1995 MY	ABS/TCS	•	•	•	0
Crown Victoria	4. 6L	Other	1995 MY	PCM	•	•	•	•
E-Series	4. 2L	Other	1997 MY	ABS/TCS			•	
E-Series	4. 2L	Other	1997 MY	ECS	•	•		
E-Series	4. 2L	Other	1997 MY	PCM	•	•	•	
E-Series	4. 2L	Other	1998 MY	ABS/TCS	•	•	•	•
E-Series		Other	1998 MY	ECS	•	•	•	
E-Series	4. 2L	Other	1998 MY	PCM	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
E-Series	4. 2L	Other	1999 MY	ABS/TCS		•		
E-Series	4. 2L	Other	1999 MY	ECS		•	•	
E-Series	4. 2L	Other	1999 MY	PCM		•		
E-Series	4. 2L	Other	2000 MY	ABS/TCS		•	•	•
E-Series	4. 2L	Other	2000 MY	ECS		•	•	
E-Series	4. 2L	Other	2000 MY	PCM		•	•	
E-Series	4. 2L	Other	2002 MY	ABS/TCS	•	•	•	
E-Series	4. 2L	Other	2002 MY	ECS	•	•	•	
E-Series	4. 2L	0ther	2002 MY	PCM	•	•	•	
E-Series	4. 2L	0ther	2003 MY	ABS/TCS	•	•	•	
E-Series	4. 2L	Other	2003 MY	ECS	•	•	•	
E-Series	4. 2L	Other	2003 MY	PCM	•	•	•	•
E-Series	4.6L	2V	2003 MY	ABS/TCS	•	•	•	•
E-Series	4.6L	2V	2003 MY	ECS	•	•	•	
E-Series	4.6L	2V	2003 MY	PCM	•	•	•	
E-Series	4.6L	2V	2004 MY	ABS/TCS	•	•	•	
E-Series	4.6L	2V	2004 MY	IC			•	
E-Series	4.6L	2V	2004 MY	PCM	•	•	•	•
E-Series	4.6L	2V	2004 MY	RAP	•	•	•	•
E-Series	4.6L	2V	2004 MY	RCM	•	•	•	0
E-Series	4.6L	2V	2005 MY	ABS/TCS	•	•	•	•
E-Series	4.6L	2V	2005 MY	IC	•	•	•	•
E-Series	4.6L	2V	2005 MY	PCM	•	•	•	•
E-Series	4.6L	2V	2005 MY	RAP	•	•	•	•
E-Series	4.6L	2V	2005 MY	RCM	•	•	•	0
E-Series	4.6L	2V	2006 MY	ABS	•	•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
E-Series	4. 6L	2V	2006 MY	ABS/TCS				
E-Series	4. 6L	2V	2006 MY	IC		•		
E-Series	4. 6L	2V	2006 MY	PCM		•		
E-Series	4. 6L	2V	2006 MY	RAP		•	•	
E-Series	4. 6L	2V	2006 MY	RCM		•		0
E-Series	4. 6L	2V	2007 MY	ABS		•		
E-Series	4. 6L	2V	2007 MY	ABS/TCS	•	•	•	•
E-Series	4. 6L	2V	2007 MY	IC		•	•	•
E-Series	4. 6L	2V	2007 MY	PAM		•	•	
E-Series	4. 6L	2V	2007 MY	PCM	•		•	
E-Series	4.6L	2V	2007 MY	RCM			•	0
E-Series	4. 6L	2V	2007 MY	VSM		•	•	
E-Series	4. 6L	2V	2008 MY	ABS		•	•	•
E-Series	4. 6L	2V	2008 MY	IC		•	•	•
E-Series	4. 6L	2V	2008 MY	PAM		•		
E-Series	4. 6L	2V	2008 MY	PCM	•		•	
E-Series	4. 6L	2V	2008 MY	RCM		•	•	0
E-Series	4. 6L	2V	2008 MY	VSM		•	•	
E-Series	4. 6L	2V	2009 MY	ABS	•	•	•	•
E-Series	4. 6L	2V	2009 MY	ACM	•	•	•	•
E-Series	4. 6L	2V	2009 MY	GEM/SJB	•	•	•	•
E-Series	4. 6L	2V	2009 MY	IPC	•	•	•	•
E-Series	4. 6L	2V	2009 MY	PAM	•	•	•	•
E-Series	4. 6L	2V	2009 MY	PCM	•	•	•	•
E-Series	4. 6L	2V	2009 MY	RCM	•	•	•	0
E-Series	4.6L	2V	2009 MY	TBC	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
E-Series	4.6L	2V	2010 MY	ABS	•	•		•
E-Series	4.6L	2V	2010 MY	ACM		•	•	
E-Series	4.6L	2V	2010 MY	GEM/SJB		•	•	
E-Series	4. 6L	2V	2010 MY	GPSM			•	0
E-Series	4.6L	2V	2010 MY	IPC		•	•	
E-Series	4. 6L	2V	2010 MY	PAM			•	
E-Series	4. 6L	2V	2010 MY	PCM			•	
E-Series	4. 6L	2V	2010 MY	RCM		•	•	0
E-Series	4. 6L	2V	2010 MY	SDARS		•	•	
E-Series	4. 6L	2V	2010 MY	TBC			•	0
E-Series	4. 6L	Other	1997 MY	ABS/TCS			•	
E-Series	4. 6L	Other	1997 MY	ECS			•	
E-Series	4.6L	Other	1997 MY	PCM		•	•	
E-Series	4.6L	Other	1998 MY	ABS/TCS		•	•	
E-Series	4. 6L	Other	1998 MY	ECS		•	•	
E-Series	4. 6L	Other	1998 MY	PCM		•	•	
E-Series	4.6L	Other	1999 MY	ABS/TCS		•	•	
E-Series	4.6L	Other	1999 MY	ECS		•	•	
E-Series	4.6L	Other	1999 MY	PCM		•	•	
E-Series	4.6L	Other	2000 MY	ABS/TCS		•		
E-Series	4. 6L	Other	2000 MY	ECS			•	
E-Series	4.6L	Other	2000 MY	PCM		•	•	
E-Series	4. 6L	Other	2002 MY	ABS/TCS	•	•	•	
E-Series	4. 6L	0ther	2002 MY	ECS		•	•	
E-Series	4. 6L	0ther	2002 MY	PCM		•	•	
E-Series	4. 9L	GFP	1996 MY	ABS/TCS		•		0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
E-Series	4. 9L	GFP	1996 MY	PCM		•		
E-Series	4. 9L	Other	1996 MY	ABS/TCS		•		0
E-Series	4. 9L	Other	1996 MY	PCM		•		
E-Series	5. 0L	Other	1996 MY	ABS/TCS		•	•	0
E-Series	5. 0L	Other	1996 MY	PCM		•		
E-Series	5. 4L	2V	2004 MY	ABS/TCS		•		
E-Series	5. 4L	2V	2004 MY	AFCM		•		0
E-Series	5. 4L	2V	2004 MY	IC		•	•	
E-Series	5. 4L	2V	2004 MY	PCM		•	•	
E-Series	5. 4L	2V	2004 MY	RAP			•	
E-Series	5. 4L	2V	2004 MY	RCM			•	0
E-Series	5. 4L	2V	2005 MY	ABS/TCS		•	•	
E-Series	5. 4L	2V	2005 MY	IC		•	•	
E-Series	5. 4L	2V	2005 MY	PCM		•	•	
E-Series	5. 4L	2V	2005 MY	RAP		•		
E-Series	5. 4L	2V	2005 MY	RCM		•	•	0
E-Series	5. 4L	2V	2006 MY	ABS		•	•	
E-Series	5. 4L	2V	2006 MY	ABS/TCS			•	
E-Series	5. 4L	2V	2006 MY	IC		•	•	•
E-Series	5. 4L	2V	2006 MY	PCM		•	•	•
E-Series	5. 4L	2V	2006 MY	RAP	•	•	•	•
E-Series	5. 4L	2V	2006 MY	RCM	•	•	•	0
E-Series	5. 4L	2V	2007 MY	ABS	•		•	•
E-Series	5. 4L	2V	2007 MY	ABS/TCS	•	•	•	•
E-Series	5. 4L	2V	2007 MY	IC	•	•	•	•
E-Series	5. 4L	2V	2007 MY	PAM	•	•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
E-Series	5. 4L	2V	2007 MY	PCM		•		
E-Series	5. 4L	2V	2007 MY	RCM		•	•	0
E-Series	5. 4L	2V	2007 MY	VSM		•		
E-Series	5. 4L	2V	2008 MY	ABS	•	•	•	
E-Series	5. 4L	2V	2008 MY	IC		•	•	
E-Series	5. 4L	2V	2008 MY	PAM		•	•	
E-Series	5. 4L	2V	2008 MY	PCM		•	•	
E-Series	5. 4L	2V	2008 MY	RCM		•	•	0
E-Series	5. 4L	2V	2008 MY	VSM		•	•	•
E-Series	5. 4L	2V	2009 MY	ABS		•	•	•
E-Series	5. 4L	2V	2009 MY	ACM	•	•		•
E-Series	5. 4L	2V	2009 MY	GEM/SJB	•	•		•
E-Series	5. 4L	2V	2009 MY	IPC	•	•	•	•
E-Series	5. 4L	2V	2009 MY	PAM		•	•	
E-Series	5. 4L	2V	2009 MY	PCM		•	•	•
E-Series	5. 4L	2V	2009 MY	RCM	•	•	•	0
E-Series	5. 4L	2V	2009 MY	TBC		•	•	0
E-Series	5. 4L	2V	2010 MY	ABS	•	•		•
E-Series	5. 4L	2V	2010 MY	ACM	•	•		•
E-Series	5. 4L	2V	2010 MY	GEM/SJB	•	•		•
E-Series	5. 4L	2V	2010 MY	GPSM	•	•	•	0
E-Series	5. 4L	2V	2010 MY	IPC	•	•	•	•
E-Series	5. 4L	2V	2010 MY	PAM	•	•	•	•
E-Series	5. 4L	2V	2010 MY	PCM	•	•	•	•
E-Series	5. 4L	2V	2010 MY	RCM	•	•	•	0
E-Series	5. 4L	2V	2010 MY	SDARS	•	•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
E-Series	5. 4L	2V	2010 MY	TBC		•		0
E-Series	5. 4L	BIF	1999 MY	ABS/TCS		•	•	
E-Series	5. 4L	BIF	1999 MY	AFCM		•	•	0
E-Series	5. 4L	BIF	1999 MY	ECS			•	
E-Series	5. 4L	BIF	1999 MY	PCM		•	•	
E-Series	5. 4L	NGV	1997 MY	ABS/TCS		•	•	
E-Series	5. 4L	NGV	1997 MY	ECS		•	•	
E-Series	5. 4L	NGV	1997 MY	PCM		•	•	
E-Series	5. 4L	NGV	1998 MY	ABS/TCS	•	•	•	
E-Series	5. 4L	NGV	1998 MY	ECS	•	•	•	
E-Series	5. 4L	NGV	1998 MY	FIM	•	•	•	0
E-Series	5. 4L	NGV	1998 MY	PCM	•	•	•	•
E-Series	5. 4L	NGV	1999 MY	ABS/TCS	•	•	•	•
E-Series	5. 4L	NGV	1999 MY	ECS		•	•	
E-Series	5. 4L	NGV	1999 MY	FIM	•	•	•	0
E-Series	5. 4L	NGV	1999 MY	PCM			•	
E-Series	5. 4L	NGV	2000 MY	ABS/TCS			•	
E-Series	5. 4L	NGV	2000 MY	ECS	•	•	•	
E-Series	5. 4L	NGV	2000 MY	FIM	•	•	•	0
E-Series	5. 4L	NGV	2000 MY	PCM		•	•	•
E-Series	5. 4L	Other	1997 MY	ABS/TCS	•	•	•	•
E-Series	5. 4L	Other	1997 MY	ECS	•	•	•	
E-Series	5. 4L	Other	1997 MY	PCM	•	•	•	•
E-Series	5. 4L	Other	1998 MY	ABS/TCS		•	•	•
E-Series	5. 4L	Other	1998 MY	ECS	•	•	•	
E-Series	5. 4L	Other	1998 MY	PCM	•	•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
E-Series		Other	1999 MY	ABS/TCS		•		
E-Series	5. 4L	Other	1999 MY	ECS		•		
E-Series	5. 4L	Other	1999 MY	PCM		•		
E-Series	5. 4L	0ther	2000 MY	ABS/TCS		•		
E-Series	5. 4L	Other	2000 MY	ECS		•		
E-Series	5. 4L	Other	2000 MY	PCM		•		
E-Series	5. 4L	Other	2002 MY	ABS/TCS		•		
E-Series	5. 4L	Other	2002 MY	AFCM		•		0
E-Series	5. 4L	Other	2002 MY	ECS		•		
E-Series	5. 4L	Other	2002 MY	FIM		•		0
E-Series	5. 4L	Other	2002 MY	PCM	•	•	•	
E-Series	5. 4L	Other	2003 MY	ABS/TCS		•		
E-Series	5. 4L	Other	2003 MY	AFCM		•		0
E-Series	5. 4L	Other	2003 MY	ECS		•		
E-Series	5. 4L	Other	2003 MY	FIM		•		0
E-Series	5. 4L	0ther	2003 MY	PCM		•		
E-Series	5.8L	Other	1996 MY	ABS/TCS		•		0
E-Series	5. 8L	Other	1996 MY	PCM		•	•	•
E-Series	6. 0L	Direct Injection - Turbo	2004 MY	ABS/TCS	•	•	•	•
E-Series	6. 0L	Direct Injection - Turbo	2004 MY	IC		•		•
E-Series	6. 0L	Direct Injection - Turbo	2004 MY	PCM	•	•	•	
E-Series	6. 0L	Direct Injection - Turbo		RAP	•	•		•
E-Series	6. 0L	Direct Injection - Turbo	2004 MY	RCM	•	•		0
E-Series	6. 0L	Direct Injection - Turbo	2004 MY	TCM	•	•	•	•
E-Series	6. 0L	Direct Injection - Turbo	2005 MY	ABS/TCS	•	•	•	•
E-Series	6. 0L	Direct Injection - Turbo	2005 MY	IC	•	•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
E-Series	6. 0L	Direct Injection - Turbo	2005 MY	PCM	•	•		
E-Series	6. 0L	Direct Injection - Turbo	2005 MY	RAP	•	•		
E-Series	6. 0L	Direct Injection - Turbo	2005 MY	RCM	•	•		0
E-Series	6. 0L	Direct Injection - Turbo	2005 MY	TCM		•		
E-Series	6. 0L	Direct Injection - Turbo	2006 MY	ABS	•	•	•	
E-Series	6. 0L	Direct Injection - Turbo	2006 MY	ABS/TCS	•	•		
E-Series	6. 0L	Direct Injection - Turbo	2006 MY	IC	•	•		
E-Series	6. 0L	Direct Injection - Turbo	2006 MY	PCM	•	•		
E-Series	6. 0L	Direct Injection - Turbo	2006 MY	RAP		•		
E-Series	6. 0L	Direct Injection - Turbo	2006 MY	RCM		•		0
E-Series	6. 0L	Direct Injection - Turbo	2006 MY	TCM	•	•	•	
E-Series	6. 0L	Direct Injection - Turbo	2007 MY	ABS	•	•		
E-Series	6. 0L	Direct Injection - Turbo	2007 MY	ABS/TCS	•	•		
E-Series	6. 0L	Direct Injection - Turbo	2007 MY	IC	•	•		
E-Series	6. 0L	Direct Injection - Turbo	2007 MY	PAM	•	•		
E-Series	6. 0L	Direct Injection - Turbo	2007 MY	PCM	•	•		
E-Series	6. 0L	Direct Injection - Turbo	2007 MY	RCM	•	•		0
E-Series	6. 0L	Direct Injection - Turbo	2007 MY	TCM	•	•		
E-Series	6. 0L	Direct Injection - Turbo	2007 MY	VSM	•	•		
E-Series	6. 0L	Direct Injection - Turbo	2008 MY	ABS	•	•		
E-Series	6. 0L	Direct Injection - Turbo	2008 MY	IC	•	•		
E-Series	6. 0L	Direct Injection - Turbo	2008 MY	PAM	•	•	•	
E-Series	6. 0L	Direct Injection - Turbo	2008 MY	PCM	•	•		
E-Series	6. 0L	Direct Injection - Turbo	2008 MY	RCM	•	•		0
E-Series	6. 0L	Direct Injection - Turbo	2008 MY	TCM	•	•		
E-Series	6.0L	Direct Injection - Turbo	2008 MY	VSM	•	•		•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
E-Series	6. 0L	Direct Injection - Turbo	2009 MY	ABS		•		
E-Series	6. 0L	Direct Injection - Turbo	2009 MY	ACM		•		
E-Series	6. 0L	Direct Injection - Turbo	2009 MY	GEM/SJB		•		
E-Series	6. 0L	Direct Injection - Turbo	2009 MY	IPC		•		
E-Series	6. 0L	Direct Injection - Turbo	2009 MY	PAM		•		
E-Series	6. 0L	Direct Injection - Turbo	2009 MY	PCM		•		
E-Series	6. 0L	Direct Injection - Turbo	2009 MY	RCM		•		0
E-Series	6. 0L	Direct Injection - Turbo	2009 MY	TBC		•	•	0
E-Series	6. 0L	Direct Injection - Turbo	2009 MY	TCM		•		
E-Series	6. 0L	Direct Injection - Turbo	2010 MY	ABS		•		
E-Series	6. 0L	Direct Injection - Turbo	2010 MY	ACM	•	•	•	
E-Series	6. 0L	Direct Injection - Turbo	2010 MY	GEM/SJB	•	•	•	
E-Series	6. 0L	Direct Injection - Turbo	2010 MY	GPSM	•	•	•	0
E-Series	6. 0L	Direct Injection - Turbo	2010 MY	IPC		•	•	•
E-Series	6. 0L	Direct Injection - Turbo	2010 MY	PAM		•		
E-Series	6. 0L	Direct Injection - Turbo	2010 MY	PCM		•		
E-Series	6. 0L	Direct Injection - Turbo	2010 MY	RCM		•	•	0
E-Series	6. 0L	Direct Injection - Turbo	2010 MY	SDARS		•	•	
E-Series	6. 0L	Direct Injection - Turbo	2010 MY	TBC		•	•	0
E-Series	6. 0L	Direct Injection - Turbo	2010 MY	TCM	•	•	•	•
E-Series	6.8L	2V	2004 MY	ABS/TCS		•	•	•
E-Series	6.8L	2V	2004 MY	IC		•		•
E-Series	6.8L	2V	2004 MY	PCM	•	•	•	•
E-Series	6.8L	2V	2004 MY	RAP	•	•		•
E-Series	6.8L		2004 MY	RCM	•	•	•	0
E-Series	6.8L	2V	2005 MY	ABS/TCS	•	•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
E-Series	6.8L	2V	2005 MY	IC		•		
E-Series	6.8L	2V	2005 MY	PCM		•	•	
E-Series	6.8L	2V	2005 MY	RAP		•		
E-Series	6.8L	2V	2005 MY	RCM		•	•	0
E-Series	6.8L	2V	2006 MY	ABS		•	•	
E-Series	6.8L	2V	2006 MY	ABS/TCS		•	•	
E-Series	6.8L	2V	2006 MY	IC		•	•	
E-Series	6.8L	2V	2006 MY	PCM		•	•	
E-Series	6.8L	2V	2006 MY	RAP		•	•	
E-Series	6.8L	2V	2006 MY	RCM		•	•	0
E-Series	6.8L	2V	2007 MY	ABS		•	•	
E-Series	6.8L	2V	2007 MY	ABS/TCS		•	•	
E-Series	6.8L	2V	2007 MY	IC		•	•	•
E-Series	6.8L	2V	2007 MY	PAM		•	•	
E-Series	6.8L	2V	2007 MY	PCM		•	•	
E-Series	6.8L	2V	2007 MY	RCM		•	•	0
E-Series	6.8L	2V	2007 MY	VSM		•	•	
E-Series	6.8L	2V	2008 MY	ABS		•	•	
E-Series	6.8L	2V	2008 MY	IC		•	•	
E-Series	6.8L	2V	2008 MY	PAM		•	•	
E-Series	6.8L	2V	2008 MY	PCM	•	•	•	•
E-Series	6.8L	2V	2008 MY	RCM	•	•	•	0
E-Series	6. 8L	2V	2008 MY	VSM	•	•	•	•
E-Series	6. 8L	2V	2009 MY	ABS	•	•	•	•
E-Series	6. 8L	2V	2009 MY	ACM	•	•	•	•
E-Series	6. 8L	2V	2009 MY	GEM/SJB	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
E-Series	6.8L	2V	2009 MY	IPC		•		
E-Series	6.8L	2V	2009 MY	PAM		•		
E-Series	6.8L	2V	2009 MY	PCM		•		
E-Series	6.8L	2V	2009 MY	RCM		•	•	0
E-Series	6.8L	2V	2009 MY	TBC		•		0
E-Series	6.8L	2V	2010 MY	ABS		•		
E-Series	6.8L	2V	2010 MY	ACM		•	•	
E-Series	6.8L	2V	2010 MY	GEM/SJB		•	•	
E-Series	6.8L	2V	2010 MY	GPSM		•	•	0
E-Series	6.8L	2V	2010 MY	IPC	•		•	
E-Series	6.8L	2V	2010 MY	PAM			•	
E-Series	6.8L	2V	2010 MY	PCM		•	•	
E-Series	6.8L	2V	2010 MY	RCM		•	•	0
E-Series	6.8L	2V	2010 MY	SDARS		•	•	
E-Series	6.8L	2V	2010 MY	TBC		•	•	0
E-Series	6.8L	Other	1997 MY	ABS/TCS		•	•	•
E-Series	6.8L	Other	1997 MY	ECS		•	•	
E-Series	6.8L	Other	1997 MY	PCM			•	
E-Series	6.8L	Other	1998 MY	ABS/TCS		•	•	•
E-Series	6.8L	Other	1998 MY	ECS		•	•	
E-Series	6.8L	Other	1998 MY	PCM	•	•	•	•
E-Series	6.8L	Other .	1999 MY	ABS/TCS	•	•	•	•
E-Series	6.8L	Other	1999 MY	ECS	•		•	
E-Series	6.8L	Other	1999 MY	PCM	•	•	•	•
E-Series	6.8L	Other	2000 MY	ABS/TCS	•	•	•	•
E-Series	6.8L	Other	2000 MY	ECS		•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
E-Series	6.8L	Other	2000 MY	PCM	•	•		
E-Series	6.8L	Other	2002 MY	ABS/TCS		•		
E-Series	6.8L	Other	2002 MY	ECS		•		
E-Series	6.8L	Other	2002 MY	PCM		•		
E-Series	6.8L	0ther	2003 MY	ABS/TCS		•		
E-Series	6.8L	Other	2003 MY	ECS	•	•	•	
E-Series	6.8L	Other	2003 MY	PCM		•	•	•
E-Series	7. 3L	Direct Injection - Turbo	1995 MY	ABS/TCS		•		0
E-Series	7. 3L	Direct Injection - Turbo	1995 MY	PCM		•		
E-Series	7. 3L	Direct Injection - Turbo	1996 MY	ABS/TCS		•		0
E-Series	7. 3L	Direct Injection - Turbo	1996 MY	PCM	•	•	•	•
E-Series	7. 3L	Direct Injection - Turbo	1997 MY	ABS/TCS		•	•	•
E-Series	7. 3L	Direct Injection - Turbo	1997 MY	ECS		•	•	
E-Series	7. 3L	Direct Injection - Turbo	1997 MY	PCM		•	•	•
E-Series	7. 3L	Direct Injection - Turbo	1998 MY	ABS/TCS		•		
E-Series	7. 3L	Direct Injection - Turbo	1998 MY	ECS	•	•	•	
E-Series	7. 3L	Direct Injection - Turbo	1998 MY	PCM		•	•	
E-Series	7. 3L	Direct Injection - Turbo	1999 MY	ABS/TCS		•	•	
E-Series	7. 3L	Direct Injection - Turbo	1999 MY	ECS		•	•	
E-Series	7. 3L	Direct Injection - Turbo	1999 MY	PCM		•		
E-Series	7. 3L	Direct Injection - Turbo	2000 MY	ABS/TCS		•		
E-Series	7. 3L	Direct Injection - Turbo	2000 MY	ECS	•	•	•	
E-Series	7. 3L	Direct Injection - Turbo	2000 MY	PCM	•	•	•	
E-Series	7. 3L	Direct Injection - Turbo	2002 MY	ABS/TCS	•	•	•	
E-Series	7. 3L	Direct Injection - Turbo	2002 MY	ECS	•	•	•	
E-Series	7. 3L	Direct Injection - Turbo	2002 MY	PCM	•	•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
E-Series	7. 3L	Direct Injection - Turbo	2003 MY	ABS/TCS		•		
E-Series	7. 3L	Direct Injection - Turbo	2003 MY	ECS		•		
E-Series	7. 3L	Direct Injection - Turbo	2003 MY	PCM		•		
E-Series	7. 5L	Other	1996 MY	ABS/TCS		•		0
E-Series	7. 5L	Other	1996 MY	PCM		•		
E-Series Shuttle Bus	6.8L	H2ICE	2006 MY	ABS/TCS		•		
E-Series Shuttle Bus	6.8L	H2ICE	2006 MY	AFCM		•	•	
E-Series Shuttle Bus	6.8L	H2ICE	2006 MY	EMM		•	•	
E-Series Shuttle Bus	6.8L	H2ICE	2006 MY	IC		•		
E-Series Shuttle Bus	6.8L	H2ICE	2006 MY	PCM	•	•	•	
E-Series Shuttle Bus	6.8L	H2ICE	2006 MY	RCM	•	•	•	0
Escort	1. 3L	Endura-E	1995.5 MY	ABS	•	•	•	0
Escort	1. 3L	Endura-E	1995.5 MY	ABS/TCS		•	•	•
Escort	1. 3L	Endura-E	1995.5 MY	CSM		•		0
Escort	1. 3L	Endura-E	1995.5 MY	HEC		•		
Escort	1. 3L	Endura-E	1995.5 MY	PATS		•		0
Escort		Endura-E	1995.5 MY	PATS		•	0	•
Escort	1. 3L	Endura-E	1995.5 MY	PCM		•	•	•
Escort	1. 3L	Endura-E	1996 MY	ABS/TCS		•	•	•
Escort	1. 3L	Endura-E	1996 MY	CSM	•	•	•	0
Escort	1. 3L	Endura-E	1996 MY	HEC		•	•	•
Escort	1. 3L	Endura-E	1996 MY	PATS		•		0
Escort	1. 3L	Endura-E	1996 MY	PATS	•	•	0	•
Escort		Endura-E	1996 MY	PCM	•	•	•	•
Escort		Endura-E	1997 MY	ABS/TCS	•	•	•	•
Escort		Endura-E	1997 MY	CSM	•	•		0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escort	1. 3L	Endura-E	1997 MY	HEC				
Escort	1. 3L	Endura-E	1997 MY	PATS		•		0
Escort	1. 3L	Endura-E	1997 MY	PATS		•	0	
Escort	1. 3L	Endura-E	1997 MY	PCM		•		
Escort	1. 3L	Endura-E	1998 MY	ABS		•		0
Escort	1. 3L	Endura-E	1998 MY	ABS/TCS		•		
Escort	1. 3L	Endura-E	1998 MY	CSM		•		0
Escort	1. 3L	Endura-E	1998 MY	HEC		•		
Escort	1. 3L	Endura-E	1998 MY	PATS				0
Escort	1. 3L	Endura-E	1998 MY	PCM				
Escort	1.4L	1.4 PT-E SFI	1994 MY	ABS/TCS		•		
Escort	1. 4L	1.4 PT-E SFI	1994 MY	CSM		•		0
Escort	1.4L	1.4 PT-E SFI	1994 MY	HEC		•		
Escort	1.4L	1.4 PT-E SFI	1994 MY	PATS		•		0
Escort	1.4L	1.4 PT-E SFI	1994 MY	PATS			0	
Escort	1.4L	1.4 PT-E SFI	1994 MY	PCM				
Escort	1.4L	1.4 PT-E SFI	1994.5 MY	ABS/TCS		•		
Escort	1.4L	1.4 PT-E SFI	1994.5 MY	CSM		•		0
Escort	1.4L	1.4 PT-E SFI	1994.5 MY	HEC		•		
Escort	1.4L	1.4 PT-E SFI	1994.5 MY	PATS		•		0
Escort	1.4L	1.4 PT-E SFI	1994.5 MY	PATS			0	
Escort	1.4L	1.4 PT-E SFI	1994.5 MY	PCM		•		
Escort	1.4L	1.4 PT-E SFI	1995 MY	ABS		•		0
Escort	1.4L	1.4 PT-E SFI	1995 MY	ABS/TCS		•	•	
Escort	1. 4L	1.4 PT-E SFI	1995 MY	CSM				0
Escort	1.4L	1.4 PT-E SFI	1995 MY	HEC	•	•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escort	1.4L	1.4 PT-E SFI	1995 MY	PATS	•	•		0
Escort	1.4L	1.4 PT-E SFI	1995 MY	PCM	•	•		
Escort	1.4L	1.4 PT-E SFI	1997.75 MY	ABS	•	•		0
Escort	1.4L	1.4 PT-E SFI	1997.75 MY	ABS/TCS	•	•		
Escort	1.4L	1.4 PT-E SFI	1997.75 MY	CSM	•	•		0
Escort	1.4L	1.4 PT-E SFI	1997.75 MY	HEC	•	•		
Escort	1.4L	1.4 PT-E SFI	1997.75 MY	PATS	•	•		0
Escort	1.4L	1.4 PT-E SFI	1997.75 MY	PATS	•	•	0	
Escort	1.4L	1.4 PT-E SFI	1997.75 MY	PCM	•	•		
Escort	1.4L	1.4 PT-E SFI	1998 MY	ABS		•		0
Escort	1.4L	1.4 PT-E SFI	1998 MY	ABS/TCS	•	•		
Escort	1.4L	1.4 PT-E SFI	1998 MY	CSM	•	•		0
Escort	1.4L	1.4 PT-E SFI	1998 MY	HEC	•	•		
Escort	1.4L	1.4 PT-E SFI	1998 MY	PATS	•	•		0
Escort	1.4L	1.4 PT-E SFI	1998 MY	PCM	•	•		
Escort	1.6L	PT-E	Other	ABS/TCS		•		
Escort	1.6L	PT-E	Other	CSM	•	•		0
Escort	1.6L	PT-E	Other	HEC	•	•		
Escort	1.6L	PT-E	Other	PATS	•	•		0
Escort	1.6L	PT-E	Other	PATS	•	•	0	
Escort	1.6L	PT-E	Other	PCM	•	•		
Escort	1.6L	Zetec	1993 MY	ABS/TCS	•	•	•	
Escort	1.6L	Zetec	1993 MY	CSM	•	•	•	0
Escort	1.6L	Zetec	1993 MY	HEC	•	•		•
Escort	1.6L	Zetec	1993 MY	PATS	•	•		0
Escort	1.6L	Zetec	1993 MY	PATS	•	•	0	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escort	1.6L	Zetec	1993 MY	PCM		•		
Escort	1.6L	Zetec	1993.5 MY	ABS/TCS		•	•	
Escort	1.6L	Zetec	1993.5 MY	CSM		•	•	0
Escort	1.6L	Zetec	1993.5 MY	HEC		•	•	•
Escort	1.6L	Zetec	1993.5 MY	PATS		•	•	0
Escort	1.6L	Zetec	1993.5 MY	PATS		•	0	•
Escort	1.6L	Zetec	1993.5 MY	PCM	•			
Escort	1. 6L	Zetec	1994 MY	ABS/TCS	•	•	•	
Escort	1.6L	Zetec	1994 MY	CSM	•	•	•	0
Escort	1.6L	Zetec	1994 MY	HEC	•			
Escort	1.6L	Zetec	1994 MY	PATS	•	•	0	
Escort	1. 6L	Zetec	1994.5 MY	ABS/TCS	•	•		
Escort	1. 6L	Zetec	1994.5 MY	CSM	•	•	•	0
Escort	1. 6L	Zetec	1994.5 MY	HEC	•	•	•	
Escort	1.6L	Zetec	1994.5 MY	PATS	•	•	0	
Escort	1.6L	Zetec	1995 MY	ABS	•			0
Escort	1. 6L	Zetec	1995 MY	ABS/TCS	•	•	•	•
Escort	1.6L	Zetec	1995 MY	CSM	•			0
Escort	1. 6L	Zetec	1995 MY	HEC	•	•	•	
Escort	1. 6L	Zetec	1995 MY	PATS	•	•	0	
Escort	1.6L	Zetec	1995.5 MY	ABS	•	•	•	0
Escort	1. 6L	Zetec	1995.5 MY	ABS/TCS	•	•	•	•
Escort	1. 6L	Zetec	1995.5 MY	CSM	•	•	•	0
Escort	1. 6L	Zetec	1995.5 MY	HEC	•	•	•	•
Escort	1. 6L	Zetec	1995.5 MY	PATS	•	•	•	0
Escort	1. 6L	Zetec	1995.5 MY	PATS	•	•	0	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escort	1.6L	Zetec	1995.5 MY	PCM		•		
Escort	1.6L	Zetec	1996 MY	ABS/TCS				
Escort	1.6L	Zetec	1996 MY	CSM				0
Escort	1.6L	Zetec	1996 MY	HEC				
Escort	1.6L	Zetec	1996 MY	PATS				0
Escort	1.6L	Zetec	1996 MY	PATS		•	0	
Escort	1.6L	Zetec	1996 MY	PCM		•		
Escort	1.6L	Zetec	1996. 5 MY	ABS		•		0
Escort	1.6L	Zetec	1996.5 MY	ABS/TCS		•		
Escort	1.6L	Zetec	1996.5 MY	CSM		•		0
Escort	1.6L	Zetec	1996.5 MY	HEC				
Escort	1.6L	Zetec	1996.5 MY	PATS		•	0	
Escort	1.6L	Zetec	1997 MY	ABS/TCS				
Escort	1.6L	Zetec	1997 MY	CSM				0
Escort	1.6L	Zetec	1997 MY	HEC				
Escort	1.6L	Zetec	1997 MY	PATS				0
Escort	1.6L	Zetec	1997 MY	PCM				
Escort	1.6L	Zetec	1997.75 MY	ABS				0
Escort	1.6L	Zetec	1997.75 MY	ABS/TCS				
Escort	1.6L	Zetec	1997.75 MY	CSM				0
Escort	1.6L	Zetec	1997.75 MY	HEC				
Escort	1.6L	Zetec	1997.75 MY	PATS		•	0	
Escort	1.6L	Zetec	1998 MY	ABS	•	•		0
Escort	1.6L	Zetec	1998 MY	ABS/TCS	•	•		
Escort	1.6L	Zetec	1998 MY	CSM	•	•		0
Escort	1.6L	Zetec	1998 MY	HEC				

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escort	1.6L	Zetec	1998 MY	PATS		•	•	0
Escort	1.6L	Zetec	1998 MY	PCM				
Escort	1.6L	Zetec Rocam	2000.5 MY	ABS/TCS				
Escort	1.6L	Zetec Rocam	2000.5 MY	CSM				0
Escort	1.6L	Zetec Rocam	2000.5 MY	HEC		•		
Escort	1.6L	Zetec Rocam	2000.5 MY	PATS				0
Escort	1.6L	Zetec Rocam	2000.5 MY	PATS			0	
Escort	1.6L	Zetec Rocam	2000. 5 MY	PCM		•		
Escort	1.8L	Endura-DE	1996 MY	ABS/TCS				
Escort	1.8L	Endura-DE	1996 MY	CSM		•		0
Escort	1.8L	Endura-DE	1996 MY	HEC		•		
Escort	1.8L	Endura-DE	1996 MY	PATS		•		0
Escort	1.8L	Endura-DE	1996 MY	PATS		•	0	
Escort	1.8L	Endura-DE	1996 MY	PCM		•		
Escort	1.8L	Endura-DE	1996 MY	PCM				0
Escort	1.8L	Endura-DE	1997 MY	ABS/TCS		•		
Escort	1.8L	Endura-DE	1997 MY	CSM		•		0
Escort	1.8L	Endura-DE	1997 MY	HEC		•		
Escort	1.8L	Endura-DE	1997 MY	PATS		•		0
Escort	1.8L	Endura-DE	1997 MY	PATS		•	0	
Escort	1.8L	Endura-DE	1997 MY	PCM		•		
Escort	1.8L	Endura-DE	1997 MY	PCM	•	•	•	0
Escort	1.8L	Endura-DE	1997.5 MY	ABS	•	•	•	0
Escort	1.8L	Endura-DE	1997.5 MY	ABS/TCS	•	•	•	
Escort	1.8L	Endura-DE	1997.5 MY	CSM	•	•	•	0
Escort	1.8L	Endura-DE	1997.5 MY	HEC	•	•		

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escort	1.8L	Endura-DE	1997.5 MY	PATS				0
Escort	1.8L	Endura-DE	1997.5 MY	PATS		•	0	
Escort	1.8L	Endura-DE	1997.5 MY	PCM		•		
Escort	1.8L	Endura-DE	1997.5 MY	PCM		•		0
Escort	1.8L	Endura-DE	Other	ABS/TCS		•		
Escort	1.8L	Endura-DE	Other	CSM		•		0
Escort	1.8L	Endura-DE	Other	HEC		•		
Escort	1.8L	Endura-DE	Other	PATS		•	•	0
Escort	1.8L	Endura-DE	Other	PATS		•	0	
Escort	1.8L	Endura-DE	Other	PCM		•	•	
Escort	1.8L	Endura-DE	Other	PCM		•	•	0
Escort	1.8L	Other	1996 MY	ABS/TCS		•	•	•
Escort	1.8L	Other	1996 MY	CSM		•	•	0
Escort	1.8L	Other	1996 MY	HEC		•		
Escort	1.8L	Other	1996 MY	PATS		•	0	
Escort	1.8L	Other	1996 MY	PCM		•	•	0
Escort	1.8L	Zetec	1992 MY	ABS/TCS		•	•	
Escort	1.8L	Zetec	1992 MY	CSM		•	•	0
Escort	1.8L	Zetec	1992 MY	HEC		•	•	
Escort	1.8L	Zetec	1992 MY	PATS		•	•	0
Escort	1.8L	Zetec	1992 MY	PATS	•		0	
Escort	1.8L	Zetec	1992 MY	PCM	•	•	•	•
Escort	1.8L	Zetec	1994 MY	ABS/TCS	•	•	•	•
Escort	1.8L	Zetec	1994 MY	CSM	•	•	•	0
Escort	1.8L	Zetec	1994 MY	HEC	•	•	•	•
Escort	1.8L	Zetec	1994 MY	PATS	•	•	0	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escort	1.8L	Zetec	1995 MY	ABS				0
Escort	1.8L	Zetec	1995 MY	ABS/TCS		•		
Escort	1.8L	Zetec	1995 MY	CSM		•		0
Escort	1.8L	Zetec	1995 MY	HEC		•		
Escort	1.8L	Zetec	1995 MY	PATS	•	•	0	
Escort	1.8L	Zetec	1995.5 MY	ABS		•		0
Escort	1.8L	Zetec	1995.5 MY	ABS/TCS	•	•		
Escort	1.8L	Zetec	1995.5 MY	CSM	•	•	•	0
Escort	1.8L	Zetec	1995.5 MY	HEC	•	•	•	
Escort	1.8L	Zetec	1995.5 MY	PATS	•	•	0	
Escort	1.8L	Zetec	1996 MY	ABS/TCS	•	•	•	
Escort	1.8L	Zetec	1996 MY	CSM	•	•	•	0
Escort	1.8L	Zetec	1996 MY	HEC	•	•	•	•
Escort	1.8L	Zetec	1996 MY	PATS	•	•	•	0
Escort	1.8L	Zetec	1996 MY	PATS			0	
Escort	1.8L	Zetec	1996 MY	PCM		•	•	
Escort	1.8L	Zetec	1997 MY	ABS/TCS	•	•	•	
Escort	1.8L	Zetec	1997 MY	CSM	•	•	•	0
Escort	1.8L	Zetec	1997 MY	HEC	•	•	•	•
Escort	1.8L	Zetec	1997 MY	PATS	•	•	•	0
Escort	1.8L	Zetec	1997 MY	PATS			0	•
Escort	1.8L	Zetec	1997 MY	PCM	•	•	•	•
Escort	1.8L	Zetec	1997.75 MY	ABS	•	•	•	0
Escort	1.8L	Zetec	1997.75 MY	ABS/TCS	•	•	•	•
Escort	1.8L	Zetec	1997.75 MY	CSM	•	•	•	0
Escort	1.8L	Zetec	1997.75 MY	HEC	•	•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escort	1.8L	Zetec	1997.75 MY	PATS				0
Escort	1.8L	Zetec	1997.75 MY	PATS		•	0	
Escort	1.8L	Zetec	1997.75 MY	PCM		•		
Escort	1.8L	Zetec	1998 MY	ABS		•	•	0
Escort	1.8L	Zetec	1998 MY	ABS/TCS		•		
Escort	1.8L	Zetec	1998 MY	CSM		•		0
Escort	1.8L	Zetec	1998 MY	HEC		•		
Escort	1.8L	Zetec	1998 MY	PATS		•	•	0
Escort	1.8L	Zetec	1998 MY	PCM		•	•	
Escort	1. 9L	Other	1996 MY	ABS/TCS		•	•	
Escort	1. 9L	Other	1996 MY	PATS		•	0	
Escort	1. 9L	Other	1996 MY	PCM		•	•	
Escort	2. OL	DOHC Cosworth	1994.75 MY	ABS/TCS		•	•	
Escort	2. OL	DOHC Cosworth	1994.75 MY	PATS		•	0	
Escort	2. OL	DOHC Cosworth	1994.75 MY	PCM		•	•	
Escort	2. OL	DOHC Cosworth	1995 MY	ABS		•		0
Escort	2. OL	DOHC Cosworth	1995 MY	ABS/TCS		•	•	
Escort	2. OL	DOHC Cosworth	1995 MY	PATS		•	0	
Escort	2. OL	DOHC Cosworth	1995 MY	PCM		•	•	
Escort	2. OL	SPI	1997 MY	ABS/TCS		•	•	
Escort	2. 0L	SPI	1997 MY	PATS	•	•	0	
Escort	2. 0L	SPI	1997 MY	PCM		•	•	
Escort	2. 0L	SPI	1997 MY	RAP		•	•	
Escort	2. 0L	SPI	1998 MY	ABS	•	•	•	0
Escort	2. 0L	SPI	1998 MY	ABS/TCS	•	•	•	•
Escort	2. 0L	SPI	1998 MY	ECS	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escort	2. 0L	SPI	1998 MY	PATS				0
Escort	2. 0L	SPI	1998 MY	PCM		•		
Escort	2. 0L	SPI	1998 MY	RAP		•		
Escort	2. 0L	SPI	1999 MY	ABS		•		0
Escort	2. 0L	SPI	1999 MY	ABS/TCS		•		•
Escort	2. 0L	SPI	1999 MY	ECS		•		0
Escort	2. 0L	SPI	1999 MY	PATS		•	0	
Escort	2. 0L	SPI	1999 MY	PCM		•		
Escort	2. 0L	SPI	1999 MY	RAP				
Escort	2. 0L	SPI	2000 MY	ABS/TCS		•		
Escort	2. 0L	SPI	2000 MY	ECS		•		0
Escort	2. 0L	SPI	2000 MY	PATS		•	0	
Escort	2. 0L	SPI	2000 MY	PCM		•		
Escort	2. 0L	SPI	2000 MY	RAP		•		
Escort	2. 0L	SPI	2002 MY	ABS/TCS				
Escort	2. 0L	SPI	2002 MY	ECS				0
Escort	2. 0L	SPI	2002 MY	PATS		•	0	
Escort	2. 0L	SPI	2002 MY	PCM		•		
Escort	2. 0L	SPI	2002 MY	RAP		•		
Escort	2. 0L	Zetec	1998 MY	ABS		•		0
Escort	2. 0L	Zetec	1998 MY	ABS/TCS		•	•	
Escort	2. 0L	Zetec	1998 MY	ECS		•	•	0
Escort	2. 0L	Zetec	1998 MY	PATS	•	•	•	0
Escort	2. 0L	Zetec	1998 MY	PCM	•	•	•	•
Escort	2. 0L	Zetec	1998 MY	RAP	•	•	•	•
Escort	2. 0L	Zetec	1999 MY	ABS		•		0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Escort	2. 0L	Zetec	1999 MY	ABS/TCS		•	•	
Escort	2. 0L	Zetec	1999 MY	ECS		•	•	0
Escort	2. 0L	Zetec	1999 MY	PATS		•	0	
Escort	2. 0L	Zetec	1999 MY	PCM	•	•	•	•
Escort	2. 0L	Zetec	1999 MY	RAP		•	•	
Escort	2. 0L	Zetec	2000 MY	ABS/TCS		•	•	•
Escort	2. 0L	Zetec	2000 MY	ECS			•	0
Escort	2. 0L	Zetec	2000 MY	PATS		•	0	•
Escort	2. 0L	Zetec	2000 MY	PCM	•	•	•	•
Escort	2. 0L	Zetec	2000 MY	RAP	•		•	
Escort	2. 0L	Zetec	2002 MY	ABS/TCS			•	
Escort	2. OL	Zetec	2002 MY	ECS	•	•	•	0
Escort	2. 0L	Zetec	2002 MY	PATS	•	•	0	•
Escort	2. 0L	Zetec	2002 MY	PCM		•	•	•
Escort	2. 0L	Zetec	2002 MY	RAP	•	•	•	•
Escort	2. 0L	Zetec	2003 MY	ABS/TCS	•		•	
Escort	2. 0L	Zetec	2003 MY	ECS			•	0
Escort	2. 0L	Zetec	2003 MY	PATS			0	
Escort	2. 0L	Zetec	2003 MY	PCM		•	•	•
Escort	2. 0L	Zetec	2003 MY	RAP		•	•	•
Excursion	5. 4L	2V	2004 MY	ABS/TCS	•	•	•	
Excursion	5. 4L	2V	2004 MY	DSM	•	•	•	•
Excursion	5. 4L	2V	2004 MY	EATC	•	•	•	•
Excursion	5. 4L	2V	2004 MY	ECS	•	•	•	
Excursion	5. 4L	2V	2004 MY	GEM	•	•	•	•
Excursion	5. 4L	2V	2004 MY	HEC	•	•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Excursion	5. 4L	2V	2004 MY	OTC		•		0
Excursion	5. 4L	2V	2004 MY	PAM		•		0
Excursion	5. 4L	2V	2004 MY	PATS		•		
Excursion	5. 4L	2V	2004 MY	PCM		•		
Excursion	5. 4L	2V	2004 MY	VSM		•		
Excursion	5. 4L	2V	2005 MY	ABS/TCS		•	•	•
Excursion	5. 4L	2V	2005 MY	DSM		•	•	•
Excursion	5. 4L	2V	2005 MY	EATC	•	•	•	•
Excursion	5. 4L	2V	2005 MY	GEM		•		
Excursion	5. 4L	2V	2005 MY	HEC	•	•	•	
Excursion	5. 4L	2V	2005 MY	PAM	•	•	•	•
Excursion	5. 4L	2V	2005 MY	PATS	•	•	•	•
Excursion	5. 4L	2V	2005 MY	PCM	•	•	•	•
Excursion	5. 4L	2V	2005 MY	RCM		•		
Excursion	5. 4L	2V	2005 MY	VSM		•		
Excursion	5. 4L	Other	2000 MY	ABS/TCS		•		•
Excursion	5. 4L	Other	2000 MY	ECS		•	•	
Excursion		Other	2000 MY	GEM		•	•	•
Excursion	5. 4L	Other	2000 MY	MC	•	•	•	0
Excursion	5. 4L	Other	2000 MY	PAM	•	•	•	•
Excursion	5. 4L	Other	2000 MY	PATS	•	•	•	
Excursion	5. 4L	Other	2000 MY	PCM	•	•		•
Excursion	5. 4L	Other	2002 MY	ABS/TCS	•	•		•
Excursion	5. 4L	Other	2002 MY	CSM	•	•		•
Excursion	5. 4L	Other	2002 MY	DSM	•	•		•
Excursion		Other	2002 MY	EATC	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Excursion	5. 4L	Other	2002 MY	ECS		•		
Excursion	5. 4L	Other	2002 MY	GEM		•		
Excursion	5. 4L	Other	2002 MY	HEC		•		
Excursion	5. 4L	Other	2002 MY	OTC		•		0
Excursion	5. 4L	Other	2002 MY	PAM		•		0
Excursion	5. 4L	Other	2002 MY	PATS		•		•
Excursion	5. 4L	Other	2002 MY	PCM		•		
Excursion	5. 4L	Other	2003 MY	ABS/TCS		•		•
Excursion	5. 4L	Other	2003 MY	DSM		•		
Excursion	5. 4L	Other	2003 MY	EATC		•		
Excursion	5. 4L	Other	2003 MY	ECS		•	•	
Excursion	5. 4L	Other	2003 MY	GEM		•		
Excursion	5. 4L	Other	2003 MY	HEC		•		•
Excursion	5. 4L	Other	2003 MY	OTC		•		0
Excursion	5. 4L	Other	2003 MY	PAM		•		0
Excursion	5. 4L	Other	2003 MY	PATS		•		
Excursion	5. 4L	Other	2003 MY	PCM		•		•
Excursion	5. 4L	Other	2003 MY	VSM		•		
Excursion	6. 0L	Direct Injection - Turbo	2003 MY	ABS/TCS	•	•	•	•
Excursion	6. 0L	Direct Injection - Turbo	2003 MY	DSM		•		•
Excursion	6. 0L	Direct Injection - Turbo	2003 MY	EATC		•		
Excursion	6. 0L	Direct Injection - Turbo	2003 MY	ECS	•	•		
Excursion	6. 0L	Direct Injection - Turbo	2003 MY	GEM	•	•		
Excursion	6. 0L	Direct Injection - Turbo	2003 MY	HEC	•	•	•	•
Excursion	6. 0L	Direct Injection - Turbo	2003 MY	OTC	•	•	•	0
Excursion	6. 0L	Direct Injection - Turbo	2003 MY	PAM	•	•		0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Excursion	6. 0L	Direct Injection - Turbo	2003 MY	PATS		•		
Excursion	6. 0L	Direct Injection - Turbo	2003 MY	PCM		•		
Excursion	6. 0L	Direct Injection - Turbo	2003 MY	TCM		•		
Excursion	6. 0L	Direct Injection - Turbo	2003 MY	VSM		•		
Excursion	6. 0L	Direct Injection - Turbo	2004 MY	ABS/TCS		•	•	
Excursion	6. 0L	Direct Injection - Turbo	2004 MY	DSM		•		
Excursion	6.0L	Direct Injection - Turbo	2004 MY	EATC		•		
Excursion	6.0L	Direct Injection - Turbo	2004 MY	ECS		•		
Excursion	6. 0L	Direct Injection - Turbo	2004 MY	GEM				
Excursion	6. 0L	Direct Injection - Turbo	2004 MY	HEC		•		
Excursion	6.0L	Direct Injection - Turbo	2004 MY	OTC		•		0
Excursion	6. 0L	Direct Injection - Turbo	2004 MY	PAM		•		0
Excursion	6. 0L	Direct Injection - Turbo	2004 MY	PATS		•		
Excursion	6.0L	Direct Injection - Turbo	2004 MY	PCM		•		
Excursion	6. 0L	Direct Injection - Turbo	2004 MY	TCM		•		
Excursion	6.0L	Direct Injection - Turbo	2004 MY	VSM		•		
Excursion	6.0L	Direct Injection - Turbo	2005 MY	ABS/TCS		•		
Excursion	6.0L	Direct Injection - Turbo	2005 MY	DSM		•		
Excursion	6.0L	Direct Injection - Turbo	2005 MY	EATC		•		
Excursion	6.0L	Direct Injection - Turbo	2005 MY	GEM		•		
Excursion	6. 0L	Direct Injection - Turbo	2005 MY	HEC	•	•		
Excursion	6. 0L	Direct Injection - Turbo	2005 MY	PAM	•	•		•
Excursion	6. 0L	Direct Injection - Turbo	2005 MY	PATS	•	•		
Excursion	6. 0L	Direct Injection - Turbo	2005 MY	PCM	•	•		
Excursion	6. 0L	Direct Injection - Turbo	2005 MY	RCM		•		
Excursion	6. 0L	Direct Injection - Turbo	2005 MY	TCM	•	•		

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Excursion	6. 0L	Direct Injection - Turbo	2005 MY	VSM	•	•		
Excursion	6.8L	2V	2004 MY	ABS/TCS		•		
Excursion	6.8L	2V	2004 MY	DSM		•		•
Excursion	6.8L	2V	2004 MY	EATC		•		
Excursion	6.8L	2V	2004 MY	ECS		•		
Excursion	6.8L	2V	2004 MY	GEM		•		
Excursion	6.8L	2V	2004 MY	HEC		•		
Excursion	6.8L	2V	2004 MY	OTC		•	•	0
Excursion	6.8L	2V	2004 MY	PAM		•		0
Excursion	6.8L	2V	2004 MY	PATS		•		
Excursion	6.8L	2V	2004 MY	PCM	•	•	•	
Excursion	6.8L	2V	2004 MY	VSM	•	•	•	•
Excursion	6.8L	2V	2005 MY	ABS/TCS	•	•	•	•
Excursion	6.8L	2V	2005 MY	DSM		•	•	
Excursion	6.8L	2V	2005 MY	EATC		•		
Excursion	6.8L	2V	2005 MY	GEM	•		•	
Excursion	6.8L	2V	2005 MY	HEC		•	•	•
Excursion	6.8L	2V	2005 MY	PAM		•	•	•
Excursion	6.8L	2V	2005 MY	PATS	•	•	•	•
Excursion	6.8L	2V	2005 MY	PCM	•	•	•	•
Excursion	6.8L	2V	2005 MY	RCM		•	•	•
Excursion	6.8L	2V	2005 MY	VSM	•	•		•
Excursion		Other	2000 MY	ABS/TCS	•	•	•	•
Excursion			2000 MY	ECS	•	•		
Excursion				GEM	•	•	•	•
Excursion			2000 MY	MC	•	•		0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Excursion	6.8L	Other	2000 MY	PAM	•	•		•
Excursion	6.8L	Other	2000 MY	PATS		•		
Excursion	6.8L	Other	2000 MY	PCM		•		
Excursion	6.8L	Other	2002 MY	ABS/TCS		•		
Excursion	6.8L	Other	2002 MY	CSM		•		
Excursion	6.8L	Other	2002 MY	DSM	•	•	•	•
Excursion	6.8L	Other	2002 MY	EATC		•	•	•
Excursion	6.8L	Other	2002 MY	ECS	•	•	•	
Excursion	6.8L	Other	2002 MY	GEM		•		•
Excursion		Other	2002 MY	HEC	•		•	•
Excursion		Other	2002 MY	OTC	•	•	•	0
Excursion	6.8L	Other	2002 MY	PAM	•	•	•	0
Excursion	6.8L	Other	2002 MY	PATS	•	•	•	•
Excursion	6.8L	Other	2002 MY	PCM	•	•	•	•
Excursion	6.8L	Other	2003 MY	ABS/TCS		•		
Excursion	6.8L	Other	2003 MY	DSM		•		
Excursion	6.8L	Other	2003 MY	EATC	•	•	•	•
Excursion	6.8L	Other	2003 MY	ECS		•	•	
Excursion	6.8L	Other	2003 MY	GEM	•	•	•	•
Excursion	6.8L	Other	2003 MY	HEC	•	•	•	•
Excursion	6.8L	Other	2003 MY	OTC	•	•	•	0
Excursion		Other	2003 MY	PAM	•	•		0
Excursion	6.8L	Other	2003 MY	PATS	•	•	•	
Excursion	6. 8L	Other	2003 MY	PCM	•	•		•
Excursion		Other	2003 MY	VSM	•	•		•
Excursion	7. 3L	Direct Injection - Turbo	2000 MY	ABS/TCS	•	•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Excursion	7. 3L	Direct Injection - Turbo	2000 MY	ECS	•	•		
Excursion	7. 3L	Direct Injection - Turbo	2000 MY	GEM	•	•		
Excursion	7. 3L	Direct Injection - Turbo	2000 MY	MC	•	•		0
Excursion	7. 3L	Direct Injection - Turbo	2000 MY	PAM		•		
Excursion	7. 3L	Direct Injection - Turbo	2000 MY	PATS	•	•	•	
Excursion	7. 3L	Direct Injection - Turbo	2000 MY	PCM		•		
Excursion	7. 3L	Direct Injection - Turbo	2002 MY	ABS/TCS		•		
Excursion	7. 3L	Direct Injection - Turbo	2002 MY	CSM	•	•		
Excursion	7. 3L	Direct Injection - Turbo	2002 MY	DSM		•		
Excursion	7. 3L	Direct Injection - Turbo	2002 MY	EATC		•		
Excursion	7. 3L	Direct Injection - Turbo	2002 MY	ECS	•	•	•	
Excursion	7. 3L	Direct Injection - Turbo	2002 MY	GEM		•		
Excursion	7. 3L	Direct Injection - Turbo	2002 MY	HEC		•		
Excursion	7. 3L	Direct Injection - Turbo	2002 MY	OTC	•	•		0
Excursion	7. 3L	Direct Injection - Turbo	2002 MY	PAM		•		0
Excursion	7. 3L	Direct Injection - Turbo	2002 MY	PATS		•		
Excursion	7. 3L	Direct Injection - Turbo	2002 MY	PCM	•	•		
Excursion	7. 3L	Direct Injection - Turbo	2003 MY	ABS/TCS	•	•		
Excursion	7. 3L	Direct Injection - Turbo	2003 MY	DSM	•	•		
Excursion	7. 3L	Direct Injection - Turbo	2003 MY	EATC	•	•		
Excursion	7. 3L	Direct Injection - Turbo	2003 MY	ECS	•	•		
Excursion	7. 3L	Direct Injection - Turbo	2003 MY	GEM	•	•		
Excursion	7. 3L	Direct Injection - Turbo	2003 MY	HEC	•	•		
Excursion	7. 3L	Direct Injection - Turbo		OTC	•	•	•	0
Excursion	7. 3L	Direct Injection - Turbo		PAM	•	•	•	0
Excursion	7. 3L	Direct Injection - Turbo	2003 MY	PATS	•	•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Excursion	7. 3L	Direct Injection - Turbo	2003 MY	PCM	•	•		
Excursion	7. 3L	Direct Injection - Turbo	2003 MY	VSM		•		
Expedition	4.6L	2V	2003 MY	4X4		•		
Expedition	4. 6L	2V	2003 MY	ABS/TCS		•		
Expedition	4.6L		2003 MY	DCSM		•		
Expedition	4.6L	2V	2003 MY	DSM		•		
Expedition	4.6L	2V	2003 MY	EATC		•		
Expedition	4. 6L	2V	2003 MY	HEC		•		
Expedition	4. 6L	2V	2003 MY	PAM		•		0
Expedition	4. 6L	2V	2003 MY	PCM		•		
Expedition	4. 6L	2V	2003 MY	PCSM		•		
Expedition	4.6L		2003 MY	RCM		•		
Expedition	4.6L	2V	2003 MY	TPM		•		
Expedition	4. 6L	2V	2003 MY	VDM		•		
Expedition	4. 6L	2V	2003 MY	VSM		•		
Expedition	4. 6L	2V	2004 MY	4X4		•		•
Expedition	4. 6L	2V	2004 MY	ABS/TCS		•		
Expedition	4. 6L	2V	2004 MY	DCSM		•	•	•
Expedition	4. 6L	2V	2004 MY	DSM	•	•	•	•
Expedition	4. 6L	2V	2004 MY	EATC	•	•	•	•
Expedition	4.6L	2V	2004 MY	HEC	•	•	•	
Expedition	4.6L	2V	2004 MY	PAM	•	•		0
Expedition	4.6L	2V	2004 MY	PCM	•	•	•	
Expedition	4. 6L	2V	2004 MY	PCSM	•	•	•	•
Expedition	4. 6L	2V	2004 MY	RCM	•	•	•	•
Expedition	4.6L	2V	2004 MY	TPM	•	•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Expedition	4.6L	2V	2004 MY	VDM	•	•		•
Expedition	4. 6L	2V	2004 MY	VSM		•		
Expedition	4. 6L	Other	1997 MY	4WAS		•		
Expedition	4.6L	Other	1997 MY	ABS/TCS		•		
Expedition	4.6L	Other	1997 MY	GEM		•		
Expedition	4.6L	Other	1997 MY	IAB		•		
Expedition	4.6L	Other	1997 MY	PATS		•		
Expedition	4.6L	Other	1997 MY	PCM		•		
Expedition	4.6L	Other	1997 MY	RAP				
Expedition	4. 6L	Other	1998 MY	4WAS		•		
Expedition	4. 6L	Other	1998 MY	ABS/TCS		•		
Expedition	4. 6L	Other	1998 MY	GEM				
Expedition	4. 6L	Other	1998 MY	IAB		•		
Expedition	4. 6L	Other	1998 MY	PATS		•		
Expedition	4. 6L	Other	1998 MY	PCM		•		
Expedition	4.6L	Other	1998 MY	RAP		•		
Expedition	4.6L	Other	1998 MY	RCC		•		0
Expedition	4. 6L	Other	1999 MY	4WAS				
Expedition		Other	1999 MY	ABS/TCS				
Expedition	4. 6L	Other	1999 MY	EATC		•		0
Expedition	4. 6L	Other	1999 MY	GEM		•		
Expedition	4. 6L	Other	1999 MY	HEC		•		
Expedition	4.6L	0ther	1999 MY	PCM	•	•	•	
Expedition	4.6L	0ther	1999 MY	RAP	•	•		
Expedition	4.6L	0ther	1999 MY	RCM	•	•		
Expedition	4.6L	Other	2000 MY	4WAS	•	•		

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Expedition	4. 6L	Other	2000 MY	ABS/TCS		•		
Expedition	4. 6L	Other	2000 MY	DSM		•		
Expedition	4. 6L	Other	2000 MY	EATC		•		0
Expedition	4.6L	Other	2000 MY	GEM		•	•	
Expedition	4. 6L	Other	2000 MY	HEC		•		
Expedition	4. 6L	Other	2000 MY	PAM		•	•	
Expedition	4. 6L	Other	2000 MY	PCM		•		
Expedition	4. 6L	Other	2000 MY	RAP		•	•	
Expedition	4. 6L	Other	2000 MY	RCM		•	•	
Expedition	5. 4L	2V	2003 MY	4X4		•	•	
Expedition	5. 4L	2V	2003 MY	ABS/TCS		•	•	•
Expedition	5. 4L	2V	2003 MY	DCSM		•	•	•
Expedition	5. 4L	2V	2003 MY	DSM	•	•	•	•
Expedition	5. 4L	2V	2003 MY	EATC		•	•	
Expedition	5. 4L	2V	2003 MY	HEC		•	•	
Expedition	5. 4L	2V	2003 MY	PAM		•	•	0
Expedition	5. 4L	2V	2003 MY	PCM		•	•	
Expedition	5. 4L	2V	2003 MY	PCSM			•	
Expedition	5. 4L	2V	2003 MY	RCM		•	•	
Expedition	5. 4L	2V	2003 MY	TPM		•	•	
Expedition	5. 4L	2V	2003 MY	VDM	•	•	•	
Expedition	5. 4L	2V	2003 MY	VSM	•	•	•	•
Expedition	5. 4L	2V	2004 MY	4X4	•	•	•	•
Expedition	5. 4L	2V	2004 MY	ABS/TCS	•	•	•	•
Expedition	5. 4L	2V	2004 MY	DCSM	•	•	•	•
Expedition	5. 4L	2V	2004 MY	DSM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Expedition	5. 4L	2V	2004 MY	EATC		•		
Expedition	5. 4L	2V	2004 MY	HEC				
Expedition	5. 4L	2V	2004 MY	PAM				0
Expedition	5. 4L	2V	2004 MY	PCM				
Expedition	5. 4L	2V	2004 MY	PCSM				
Expedition	5. 4L	2V	2004 MY	RCM				
Expedition	5. 4L	2V	2004 MY	TPM		•		
Expedition	5. 4L	2V	2004 MY	VDM		•		
Expedition	5. 4L	2V	2004 MY	VSM		•		
Expedition	5. 4L	3V	2005 MY	4X4		•	•	•
Expedition	5. 4L	3V	2005 MY	ABS		•	•	•
Expedition	5. 4L	3V	2005 MY	DCSM		•	•	•
Expedition	5. 4L	3V	2005 MY	DSM		•	•	•
Expedition	5. 4L	3V	2005 MY	EATC		•	•	•
Expedition	5. 4L	3V	2005 MY	IC		•	•	
Expedition	5. 4L	3V	2005 MY	PAM	•		•	0
Expedition	5. 4L	3V	2005 MY	PCM		•	•	•
Expedition	5. 4L	3V	2005 MY	RCM		•	•	•
Expedition	5. 4L	3V	2005 MY	VDM		•	•	•
Expedition	5. 4L	3V	2005 MY	VSM		•	•	•
Expedition	5. 4L	3V	2006 MY	4X4	•		•	
Expedition	5. 4L	3V	2006 MY	ABS		•		•
Expedition	5. 4L	3V	2006 MY	DCSM		•	•	•
Expedition	5. 4L	3V	2006 MY	DSM	•	•	•	•
Expedition	5. 4L	3V	2006 MY	EATC	•	•	•	•
Expedition	5. 4L	3V	2006 MY	IC		•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Expedition	5. 4L	3V	2006 MY	PAM				0
Expedition	5. 4L	3V	2006 MY	PCM		•		
Expedition	5. 4L	3V	2006 MY	RCM		•		
Expedition	5. 4L	3V	2006 MY	VDM				
Expedition	5. 4L	3V	2006 MY	VSM		•		
Expedition	5. 4L	3V	2007 MY	4X4		•		
Expedition	5. 4L	3V	2007 MY	ABS		•		
Expedition	5. 4L	3V	2007 MY	ACM		•		
Expedition	5. 4L	3V	2007 MY	DCSM				
Expedition	5. 4L	3V	2007 MY	DSM				
Expedition	5. 4L	3V	2007 MY	DSP		•		0
Expedition	5. 4L	3V	2007 MY	EATC		•		
Expedition	5. 4L	3V	2007 MY	GEM		•		
Expedition	5. 4L	3V	2007 MY	IC		•		
Expedition	5. 4L	3V	2007 MY	LTM				0
Expedition	5. 4L	3V	2007 MY	PAM				0
Expedition	5. 4L	3V	2007 MY	PCM		•		
Expedition	5. 4L	3V	2007 MY	RCM		•		
Expedition	5. 4L	3V	2007 MY	RCU		•		0
Expedition	5. 4L	3V	2007 MY	RETM		•	•	0
Expedition	5. 4L	3V	2007 MY	SDARS		•	•	
Expedition	5. 4L	3V	2007 MY	TCM			•	
Expedition	5. 4L	3V	2007 MY	VDM		•	•	
Expedition	5. 4L	3V	2008 MY	4X4	•	•	•	•
Expedition	5. 4L	3V	2008 MY	ABS	•	•	•	•
Expedition	5. 4L	3V	2008 MY	ACM		•		0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Expedition	5. 4L	3V	2008 MY	DCSM		•		
Expedition	5. 4L	3V	2008 MY	DSM		•		
Expedition	5. 4L	3V	2008 MY	DSP		•		0
Expedition	5. 4L	3V	2008 MY	GEM/SJB		•		
Expedition	5. 4L	3V	2008 MY	HVAC		•		
Expedition	5. 4L	3V	2008 MY	IC		•		
Expedition	5. 4L	3V	2008 MY	LTM		•	•	0
Expedition	5. 4L	3V	2008 MY	PAM		•	•	0
Expedition	5. 4L	3V	2008 MY	PCM		•		
Expedition	5. 4L	3V	2008 MY	PRB	•	•	•	•
Expedition	5. 4L	3V	2008 MY	RCM		•	•	
Expedition	5. 4L	3V	2008 MY	RCU		•	•	
Expedition	5. 4L	3V	2008 MY	RETM		•	•	0
Expedition	5. 4L	3V	2008 MY	SDARS		•	•	•
Expedition	5. 4L	3V	2008 MY	TCM		•		
Expedition	5. 4L	3V	2008 MY	VDM		•	•	
Expedition	5. 4L	3V	2009 MY	4X4		•	•	
Expedition	5. 4L	3V	2009 MY	ABS		•	•	
Expedition	5. 4L	3V	2009 MY	ACM		•	•	•
Expedition	5. 4L	3V	2009 MY	ACM		•	•	0
Expedition	5. 4L	3V	2009 MY	APIM		•	•	0
Expedition	5. 4L	3V	2009 MY	DCSM		•		
Expedition	5. 4L	3V	2009 MY	DSM		•	•	
Expedition	5. 4L	3V	2009 MY	DSP		•	•	0
Expedition	5. 4L	3V	2009 MY	GEM/SJB	•	•	•	•
Expedition	5. 4L	3V	2009 MY	HVAC	•	•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
Expedition	5. 4L	3V	2009 MY	IC				
Expedition	5. 4L	3V	2009 MY	LTM		•		0
Expedition	5. 4L	3V	2009 MY	PAM		•		0
Expedition	5. 4L	3V	2009 MY	PCM		•	•	
Expedition	5. 4L	3V	2009 MY	PRB		•		
Expedition	5. 4L	3V	2009 MY	RCM		•		
Expedition	5. 4L	3V	2009 MY	RCU		•	•	
Expedition	5. 4L	3V	2009 MY	RETM		•	•	0
Expedition	5. 4L	3V	2009 MY	SDARS		•		
Expedition	5. 4L	3V	2009 MY	TCM		•	•	
Expedition	5. 4L	3V	2009 MY	VDM		•	•	
Expedition	5. 4L	3V	2010 MY	ABS		•	•	
Expedition	5. 4L	3V	2010 MY	ACM	•	•	•	•
Expedition	5. 4L	3V	2010 MY	ACM		•	•	0
Expedition	5. 4L	3V	2010 MY	APIM		•		0
Expedition	5. 4L	3V	2010 MY	DCSM		•	•	
Expedition	5. 4L	3V	2010 MY	DSM		•	•	
Expedition	5. 4L	3V	2010 MY	DSP		•	•	0
Expedition	5. 4L	3V	2010 MY	GEM/SJB	•	•	•	•
Expedition	5. 4L	3V	2010 MY	GPSM	•	•	•	0
Expedition	5. 4L	3V	2010 MY	HVAC	•	•	•	•
Expedition	5. 4L	3V	2010 MY	IC		•		
Expedition	5. 4L	3V	2010 MY	LTM	•	•	•	0
Expedition	5. 4L	3V	2010 MY	PAM	•	•	•	0
Expedition	5. 4L	3V	2010 MY	PCM	•	•	•	•
Expedition	5. 4L	3V	2010 MY	PRB		•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Expedition	5. 4L	3V	2010 MY	RCM				
Expedition	5. 4L	3V	2010 MY	RCU		•		
Expedition	5. 4L	3V	2010 MY	RETM		•		0
Expedition	5. 4L	3V	2010 MY	SDARS		•		
Expedition	5. 4L	3V	2010 MY	TCCM		•		
Expedition	5. 4L	3V	2010 MY	TCM	•	•	•	
Expedition	5. 4L	3V	2010 MY	VDM	•	•		
Expedition	5. 4L	Other	1997 MY	4WAS	•	•	•	
Expedition	5. 4L	Other	1997 MY	ABS/TCS	•	•	•	
Expedition	5. 4L	Other	1997 MY	GEM	•	•	•	
Expedition	5. 4L	Other	1997 MY	IAB	•	•	•	
Expedition	5. 4L	Other	1997 MY	PATS	•	•	•	•
Expedition	5. 4L	Other	1997 MY	PCM	•	•	•	•
Expedition	5. 4L	Other	1997 MY	RAP	•	•	•	
Expedition	5. 4L	Other	1998 MY	4WAS		•		
Expedition	5. 4L	Other	1998 MY	ABS/TCS	•	•	•	
Expedition	5. 4L	Other	1998 MY	GEM	•	•	•	
Expedition	5. 4L	Other	1998 MY	IAB	•		•	
Expedition	5. 4L	Other	1998 MY	PATS	•	•	•	
Expedition	5. 4L	Other	1998 MY	PCM	•	•	•	
Expedition	5. 4L	Other	1998 MY	RAP	•		•	
Expedition	5. 4L	Other	1998 MY	RCC	•	•	•	0
Expedition	5. 4L	Other	1999 MY	4WAS	•	•	•	•
Expedition	5. 4L	Other	1999 MY	ABS/TCS	•	•	•	•
Expedition	5. 4L	Other	1999 MY	EATC	•	•	•	0
Expedition	5. 4L	Other	1999 MY	GEM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Expedition	5. 4L	Other	1999 MY	HEC		•		
Expedition	5. 4L	0ther	1999 MY	PCM		•		
Expedition	5. 4L	0ther	1999 MY	RAP		•		
Expedition	5. 4L	0ther	1999 MY	RCM		•	•	
Expedition	5. 4L	0ther	2000 MY	4WAS		•	•	•
Expedition	5. 4L	Other	2000 MY	ABS/TCS	•	•	•	•
Expedition	5. 4L	Other	2000 MY	DSM	•	•	•	•
Expedition	5. 4L	Other	2000 MY	EATC	•	•	•	0
Expedition	5. 4L	Other	2000 MY	GEM		•	•	
Expedition	5. 4L	Other	2000 MY	HEC		•	•	•
Expedition	5. 4L	0ther	2000 MY	PAM	•	•	•	•
Expedition	5. 4L	Other	2000 MY	PCM			•	
Expedition	5. 4L	Other	2000 MY	RAP	•	•	•	•
Expedition	5. 4L	Other	2000 MY	RCM	•	•	•	
Expedition EL	5. 4L	3V	2007 MY	4X4		•		
Expedition EL	5. 4L	3V	2007 MY	ABS			•	
Expedition EL	5. 4L	3V	2007 MY	ACM	•	•	•	
Expedition EL	5. 4L	3V	2007 MY	DCSM			•	
Expedition EL	5. 4L	3V	2007 MY	DSM	•	•	•	
Expedition EL	5. 4L	3V	2007 MY	DSP	•	•	•	0
Expedition EL	5. 4L	3V	2007 MY	EATC	•	•	•	
Expedition EL	5. 4L	3V	2007 MY	GEM	•	•	•	
Expedition EL	5. 4L	3V	2007 MY	IC	•	•	•	•
Expedition EL	5. 4L	3V	2007 MY	LTM	•	•	•	0
Expedition EL	5. 4L	3V	2007 MY	PAM	•	•	•	0
Expedition EL	5. 4L	3V	2007 MY	PCM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Expedition EL	5. 4L	3V	2007 MY	RCM	•	•	•	•
Expedition EL	5. 4L	3V	2007 MY	RCU		•		0
Expedition EL	5. 4L	3V	2007 MY	RETM		•		0
Expedition EL	5. 4L	3V	2007 MY	SDARS				
Expedition EL	5. 4L	3V	2007 MY	TCM		•		
Expedition EL	5. 4L	3V	2007 MY	VDM		•		
Expedition EL	5. 4L	3V	2008 MY	4X4		•		
Expedition EL	5. 4L	3V	2008 MY	ABS		•		
Expedition EL	5. 4L	3V	2008 MY	ACM				
Expedition EL	5. 4L	3V	2008 MY	DCSM				
Expedition EL	5. 4L	3V	2008 MY	DSM		•		
Expedition EL	5. 4L	3V	2008 MY	DSP		•		0
Expedition EL	5. 4L	3V	2008 MY	GEM/SJB				
Expedition EL	5. 4L	3V	2008 MY	HVAC				
Expedition EL	5. 4L	3V	2008 MY	IC				
Expedition EL	5.4L	3V	2008 MY	LTM				0
Expedition EL	5. 4L	3V	2008 MY	PAM				0
Expedition EL	5. 4L	3V	2008 MY	PCM				
Expedition EL	5. 4L	3V	2008 MY	PRB				
Expedition EL	5. 4L	3V	2008 MY	RCM				
Expedition EL	5. 4L	3V	2008 MY	RCU	•	•		
Expedition EL	5. 4L	3V	2008 MY	RETM	•	•	•	0
Expedition EL	5. 4L	3V	2008 MY	SDARS		•		
Expedition EL	5. 4L	3V	2008 MY	TCM				
Expedition EL	5. 4L	3V	2008 MY	VDM				
Expedition EL	5. 4L	3V	2009 MY	4X4	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Expedition EL	5. 4L	3V	2009 MY	ABS		•		
Expedition EL	5. 4L	3V	2009 MY	ACM		•		
Expedition EL	5. 4L	3V	2009 MY	ACM		•		0
Expedition EL	5. 4L	3V	2009 MY	APIM		•		0
Expedition EL	5. 4L	3V	2009 MY	DCSM		•		
Expedition EL	5. 4L	3V	2009 MY	DSM		•		
Expedition EL	5. 4L	3V	2009 MY	DSP	•	•	•	0
Expedition EL	5. 4L	3V	2009 MY	GEM/SJB	•	•	•	•
Expedition EL	5. 4L	3V	2009 MY	HVAC		•		
Expedition EL	5. 4L	3V	2009 MY	IC		•	•	
Expedition EL	5. 4L	3V	2009 MY	LTM	•	•	•	0
Expedition EL	5. 4L	3V	2009 MY	PAM	•	•	•	0
Expedition EL	5. 4L	3V	2009 MY	PCM	•	•	•	•
Expedition EL	5. 4L	3V	2009 MY	PRB	•	•	•	•
Expedition EL	5. 4L	3V	2009 MY	RCM		•		
Expedition EL	5. 4L	3V	2009 MY	RCU		•		•
Expedition EL	5. 4L	3V	2009 MY	RETM	•	•	•	0
Expedition EL	5. 4L	3V	2009 MY	SDARS	•	•	•	•
Expedition EL	5. 4L	3V	2009 MY	TCM	•	•	•	
Expedition EL	5. 4L	3V	2009 MY	VDM	•	•	•	
Expedition EL	5. 4L	3V	2010 MY	ABS	•	•	•	•
Expedition EL	5. 4L	3V	2010 MY	ACM		•	•	
Expedition EL	5. 4L	3V	2010 MY	ACM	•	•		0
Expedition EL	5. 4L	3V	2010 MY	APIM	•	•	•	0
Expedition EL	5. 4L	3V	2010 MY	DCSM	•	•	•	•
Expedition EL	5. 4L	3V	2010 MY	DSM	•	•		•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Expedition EL	5. 4L	3V	2010 MY	DSP		•		0
Expedition EL	5. 4L	3V	2010 MY	GEM/SJB		•		
Expedition EL	5. 4L	3V	2010 MY	GPSM		•		0
Expedition EL	5. 4L	3V	2010 MY	HVAC		•		
Expedition EL	5. 4L	3V	2010 MY	IC		•		
Expedition EL	5. 4L	3V	2010 MY	LTM		•		0
Expedition EL	5. 4L	3V	2010 MY	PAM		•		0
Expedition EL	5. 4L	3V	2010 MY	PCM		•	•	•
Expedition EL	5. 4L	3V	2010 MY	PRB		•		
Expedition EL	5. 4L	3V	2010 MY	RCM		•		
Expedition EL	5. 4L	3V	2010 MY	RCU	•	•	•	
Expedition EL	5. 4L	3V	2010 MY	RETM	•	•	•	0
Expedition EL	5. 4L	3V	2010 MY	SDARS	•	•	•	•
Expedition EL	5. 4L	3V	2010 MY	TCCM		•	•	•
Expedition EL	5. 4L	3V	2010 MY	TCM		•		
Expedition EL	5. 4L	3V	2010 MY	VDM		•		
Explorer	4. 0L	2V	2006 MY	4X4		•	•	
Explorer	4. 0L	2V	2006 MY	ABS		•	•	
Explorer	4. 0L	2V	2006 MY	ACM	•	•	•	0
Explorer	4. 0L	2V	2006 MY	DSM	•	•	•	•
Explorer	4. 0L	2V	2006 MY	EATC		•	•	•
Explorer	4. 0L	2V	2006 MY	GEM		•		•
Explorer	4. 0L	2V	2006 MY	IC	•	•		
Explorer	4. 0L	2V	2006 MY	OCSM		•		0
Explorer	4. 0L	2V	2006 MY	PAM	•	•	•	•
Explorer	4. 0L	2V	2006 MY	PCM	•	•		

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
Explorer	4. 0L	2V	2006 MY	PRB		•		
Explorer	4. 0L	2V	2006 MY	RCM		•		
Explorer	4. 0L	2V	2006 MY	RETM		•		
Explorer	4. 0L	2V	2006 MY	SDARS		•		
Explorer	4. 0L	2V	2007 MY	4X4		•		
Explorer	4. 0L	2V	2007 MY	ABS		•		
Explorer	4. 0L	2V	2007 MY	ACM		•		0
Explorer	4. 0L	2V	2007 MY	DSM		•	•	•
Explorer	4. 0L	2V	2007 MY	EATC		•		
Explorer	4. 0L	2V	2007 MY	GEM	•	•	•	
Explorer	4. 0L	2V	2007 MY	IC		•	•	
Explorer	4. 0L	2V	2007 MY	OCSM	•	•	•	
Explorer	4. 0L	2V	2007 MY	PAM		•	•	0
Explorer	4. 0L	2V	2007 MY	PCM		•	•	•
Explorer	4. 0L	2V	2007 MY	PRB		•		
Explorer	4. 0L	2V	2007 MY	RCM		•		
Explorer	4. 0L	2V	2007 MY	RETM	•	•	•	0
Explorer	4. 0L	2V	2007 MY	SDARS		•	•	
Explorer	4. 0L	2V	2008 MY	4X4	•	•	•	
Explorer	4. 0L	2V	2008 MY	ABS	•	•	•	•
Explorer	4. 0L	2V	2008 MY	ACM		•	•	0
Explorer	4. 0L	2V	2008 MY	APIM	•	•	•	0
Explorer	4. 0L	2V	2008 MY	DSM	•	•		
Explorer	4. 0L	2V	2008 MY	GEM/SJB	•	•	•	•
Explorer	4. 0L	2V	2008 MY	HVAC	•	•		•
Explorer	4. 0L	2V	2008 MY	IC	•	•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer	4. 0L	2V	2008 MY	OCSM		•		
Explorer	4. 0L	2V	2008 MY	PAM		•		0
Explorer	4. 0L	2V	2008 MY	PCM	•	•		
Explorer	4. 0L	2V	2008 MY	PRB		•		
Explorer	4. 0L	2V	2008 MY	RCM	•	•		
Explorer	4. 0L	2V	2008 MY	RETM	•	•		0
Explorer	4. 0L	2V	2008 MY	SDARS		•		
Explorer	4. 0L	2V	2009 MY	4X4		•		
Explorer	4. 0L	2V	2009 MY	ABS		•		
Explorer	4. 0L	2V	2009 MY	ACM		•	•	•
Explorer	4. 0L	2V	2009 MY	ACM	•	•	•	0
Explorer	4. 0L	2V	2009 MY	APIM	•	•	•	0
Explorer	4. 0L	2V	2009 MY	DSM	•	•	•	•
Explorer	4. 0L	2V	2009 MY	GEM/SJB	•	•	•	•
Explorer	4. 0L	2V	2009 MY	HVAC	•	•		
Explorer	4. 0L	2V	2009 MY	IC	•	•	•	
Explorer	4. 0L	2V	2009 MY	OCSM	•	•	•	
Explorer	4. 0L	2V	2009 MY	PAM	•	•	•	0
Explorer	4. 0L	2V	2009 MY	PCM	•	•	•	•
Explorer	4. 0L	2V	2009 MY	PRB		•		
Explorer	4. 0L	2V	2009 MY	RCM	•		•	
Explorer	4. 0L	2V	2009 MY	RETM	•		•	0
Explorer	4. 0L	2V	2009 MY	SDARS	•	•		•
Explorer	4. 0L	2V	2010 MY	4X4	•	•		•
Explorer	4. 0L	2V	2010 MY	ABS	•	•	•	•
Explorer	4. 0L	2V	2010 MY	ACM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer	4. 0L	2V	2010 MY	ACM		•		0
Explorer	4. 0L	2V	2010 MY	APIM		•		0
Explorer	4. 0L	2V	2010 MY	DSM		•		
Explorer	4. 0L	2V	2010 MY	GEM/SJB		•		
Explorer	4. 0L	2V	2010 MY	GPSM		•		0
Explorer	4. 0L	2V	2010 MY	HVAC		•		
Explorer	4. 0L	2V	2010 MY	IC		•		
Explorer	4. 0L	2V	2010 MY	OCSM		•		
Explorer	4. 0L	2V	2010 MY	PAM		•		0
Explorer	4. 0L	2V	2010 MY	PCM	•	•		
Explorer	4. 0L	2V	2010 MY	PRB		•		
Explorer	4. 0L	2V	2010 MY	RCM	•	•		
Explorer	4. 0L	2V	2010 MY	RETM	•	•		0
Explorer	4. 0L	2V	2010 MY	SDARS		•		
Explorer	4. 0L	Other	1996 MY	ABS/TCS				
Explorer	4. 0L	0ther	1996 MY	ARC		•		0
Explorer	4. 0L	Other	1996 MY	EATC		•		0
Explorer	4. 0L	Other	1996 MY	GEM		•		
Explorer	4. 0L	Other	1996 MY	IAB		•		0
Explorer	4. 0L	Other	1996 MY	PCM		•		
Explorer	4. 0L	Other	1996 MY	RAP		•		
Explorer	4. 0L	Other	1997 MY	ABS/TCS		•	•	
Explorer	4. 0L	Other	1997 MY	ARC	•	•	•	0
Explorer	4. 0L	Other	1997 MY	EATC	•	•		0
Explorer	4. 0L	Other	1997 MY	GEM	•	•		•
Explorer	4. 0L	Other	1997 MY	IAB	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer	4. 0L	Other	1997 MY	PCM		•		
Explorer	4. 0L	Other	1997 MY	RAP		•	•	
Explorer	4. 0L	Other	1998 MY	ABS/TCS		•		
Explorer	4. 0L	Other	1998 MY	ARC		•	•	
Explorer	4. 0L	Other	1998 MY	DSM		•		
Explorer	4. 0L	Other	1998 MY	EATC		•		0
Explorer	4. 0L	Other	1998 MY	GEM		•		
Explorer	4. 0L	Other	1998 MY	IAB		•	•	
Explorer	4. 0L	Other	1998 MY	PAM		•	•	
Explorer	4. 0L	Other	1998 MY	PATS		•	•	
Explorer	4. 0L	Other	1998 MY	PCM		•	•	
Explorer	4. 0L	Other	1998 MY	RAP		•	•	•
Explorer	4. 0L	Other	1999 MY	ABS/TCS		•	•	
Explorer	4. 0L	Other	1999 MY	ARC		•		
Explorer	4. 0L	Other	1999 MY	DSM		•		
Explorer	4. 0L	Other	1999 MY	EATC		•	•	0
Explorer	4. 0L	Other	1999 MY	GEM		•	•	
Explorer	4. 0L	Other	1999 MY	PAM		•	•	
Explorer	4. 0L	Other	1999 MY	PATS		•	•	
Explorer	4. 0L	Other	1999 MY	PCM		•	•	
Explorer	4. 0L	Other	1999 MY	RAP	•	•	•	
Explorer	4. 0L	Other	1999 MY	RCM	•	•	•	•
Explorer	4. 0L	Other	2000 MY	ABS/TCS	•	•	•	•
Explorer	4. 0L	Other	2000 MY	ARC	•	•	•	•
Explorer	4. 0L	Other	2000 MY	DSM	•	•	•	•
Explorer	4. 0L	Other	2000 MY	EATC	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer	4. 0L	Other	2000 MY	GEM	•	•		
Explorer	4. 0L	Other	2000 MY	PAM	•	•		
Explorer	4. 0L	Other	2000 MY	PATS	•	•		
Explorer	4. 0L	Other	2000 MY	PCM	•	•		
Explorer	4. 0L	Other	2000 MY	RAP	•	•		
Explorer	4. 0L	Other	2000 MY	RCM	•	•		
Explorer	4. 0L	V6 OHV	1996 MY	ABS/TCS	•	•		
Explorer	4. 0L	V6 OHV	1996 MY	ARC	•	•	•	0
Explorer	4. 0L	V6 OHV	1996 MY	EATC	•	•		0
Explorer	4. 0L	V6 OHV	1996 MY	GEM	•	•	•	•
Explorer	4. 0L	V6 OHV	1996 MY	IAB	•	•	•	0
Explorer	4. 0L	V6 OHV	1996 MY	PCM	•	•	•	•
Explorer	4. 0L	V6 OHV	1996 MY	RAP	•	•	•	•
Explorer	4. 0L	V6 OHV	1997 MY	ABS/TCS	•	•	•	•
Explorer	4. 0L	V6 OHV	1997 MY	ARC	•	•		0
Explorer	4. 0L	V6 OHV	1997 MY	EATC	•	•	•	0
Explorer	4. 0L	V6 OHV	1997 MY	GEM	•	•	•	•
Explorer	4. 0L	V6 OHV	1997 MY	IAB	•	•	•	0
Explorer	4. 0L	V6 OHV	1997 MY	PCM	•	•	•	•
Explorer	4. 0L	V6 OHV	1997 MY	RAP	•	•	•	•
Explorer	4. 0L	V6 OHV	1998 MY	ABS/TCS	•	•	•	•
Explorer	4. 0L	V6 OHV	1998 MY	ARC	•	•	•	•
Explorer	4. 0L	V6 OHV	1998 MY	DSM	•	•	•	•
Explorer	4. 0L	V6 OHV	1998 MY	EATC	•	•	•	0
Explorer	4. 0L	V6 OHV	1998 MY	GEM	•	•	•	•
Explorer	4. 0L	V6 OHV	1998 MY	IAB	•	•		•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer	4. 0L	V6 OHV	1998 MY	PAM		•		
Explorer	4. 0L	V6 OHV	1998 MY	PATS		•		
Explorer	4. 0L	V6 OHV	1998 MY	PCM		•		
Explorer	4. 0L	V6 OHV	1998 MY	RAP		•	•	
Explorer	4. 0L	V6 OHV	1999 MY	ABS/TCS		•		
Explorer	4. 0L	V6 OHV	1999 MY	ARC	•	•	•	
Explorer	4. 0L	V6 OHV	1999 MY	DSM		•	•	
Explorer	4. 0L	V6 OHV	1999 MY	EATC		•	•	0
Explorer	4. 0L	V6 OHV	1999 MY	GEM		•		
Explorer	4. 0L	V6 OHV	1999 MY	PAM		•	•	
Explorer	4. 0L	V6 OHV	1999 MY	PATS	•	•	•	
Explorer	4. 0L	V6 OHV	1999 MY	PCM		•	•	
Explorer	4. 0L	V6 OHV	1999 MY	RAP		•		
Explorer	4. 0L	V6 OHV	1999 MY	RCM		•		
Explorer	4. 0L	V6 SOHC	1997 MY	ABS/TCS		•		
Explorer	4. 0L	V6 SOHC	1997 MY	ARC		•		0
Explorer	4. 0L	V6 SOHC	1997 MY	EATC		•		0
Explorer	4. 0L	V6 SOHC	1997 MY	GEM		•		
Explorer	4. 0L	V6 SOHC	1997 MY	IAB		•		0
Explorer	4. 0L	V6 SOHC	1997 MY	PCM		•		
Explorer	4. 0L	V6 SOHC	1997 MY	RAP		•	•	
Explorer	4. 0L	V6 SOHC	1998 MY	ABS/TCS		•	•	
Explorer	4. 0L	V6 SOHC	1998 MY	ARC		•	•	
Explorer	4. 0L	V6 SOHC	1998 MY	DSM		•	•	
Explorer	4. 0L	V6 SOHC	1998 MY	EATC		•	•	0
Explorer	4. 0L	V6 SOHC	1998 MY	GEM		•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer	4. 0L	V6 SOHC	1998 MY	IAB		•		
Explorer	4. 0L	V6 SOHC	1998 MY	PAM		•	•	
Explorer	4. 0L	V6 SOHC	1998 MY	PATS		•	•	
Explorer	4. 0L	V6 SOHC	1998 MY	PCM	•	•	•	
Explorer	4. 0L	V6 SOHC	1998 MY	RAP		•	•	
Explorer	4. 0L	V6 SOHC	1999 MY	ABS/TCS		•	•	
Explorer	4. 0L	V6 SOHC	1999 MY	ARC			•	
Explorer	4. 0L	V6 SOHC	1999 MY	DSM		•	•	
Explorer	4. 0L	V6 SOHC	1999 MY	EATC	•	•	•	0
Explorer	4. 0L	V6 SOHC	1999 MY	GEM	•	•	•	
Explorer	4. 0L	V6 SOHC	1999 MY	MC	•	•		0
Explorer	4. 0L	V6 SOHC	1999 MY	PAM				
Explorer	4. 0L	V6 SOHC	1999 MY	PATS		•	•	
Explorer	4. 0L	V6 SOHC	1999 MY	PCM		•	•	
Explorer	4. 0L	V6 SOHC	1999 MY	RAP		•	•	
Explorer	4. 0L	V6 SOHC	1999 MY	RCM	•		•	
Explorer	4. 0L	V6 SOHC	2000 MY	ABS/TCS			•	
Explorer	4. 0L	V6 SOHC	2000 MY	ARC			•	
Explorer	4. 0L	V6 SOHC	2000 MY	DSM	•	•		
Explorer	4. 0L	V6 SOHC	2000 MY	EATC		•	•	0
Explorer	4. 0L	V6 SOHC	2000 MY	GEM	•	•	•	
Explorer	4. 0L	V6 SOHC	2000 MY	PAM	•	•	•	•
Explorer	4. 0L	V6 SOHC	2000 MY	PATS	•	•	•	•
Explorer	4. 0L	V6 SOHC	2000 MY	PCM	•	•	•	•
Explorer	4. 0L	V6 SOHC	2000 MY	RAP	•	•	•	•
Explorer	4. 0L	V6 SOHC	2000 MY	RCM	•	•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer	4. 0L	V6 SOHC	2002 MY	4X4		•		
Explorer	4. 0L	V6 SOHC	2002 MY	ABS/TCS		•	•	
Explorer	4. 0L	V6 SOHC	2002 MY	CSM		•		
Explorer	4. 0L	V6 SOHC	2002 MY	DSM	•	•	•	
Explorer	4. 0L	V6 SOHC	2002 MY	EATC		•	•	
Explorer	4. 0L	V6 SOHC	2002 MY	GEM			•	
Explorer	4. 0L	V6 SOHC	2002 MY	IC			•	
Explorer	4. 0L	V6 SOHC	2002 MY	PAM		•	•	
Explorer	4. 0L	V6 SOHC	2002 MY	PCM	•	•	•	
Explorer	4. 0L	V6 SOHC	2002 MY	RCM	•		•	0
Explorer	4. 0L	V6 SOHC	2002.5 MY	4X4	•	•	•	
Explorer	4. 0L	V6 SOHC	2002.5 MY	ABS/TCS	•	•	•	•
Explorer	4. 0L	V6 SOHC	2002.5 MY	CSM	•	•	•	•
Explorer	4. 0L	V6 SOHC	2002.5 MY	DSM		•	•	
Explorer	4. 0L	V6 SOHC	2002.5 MY	EATC	•	•	•	
Explorer	4. 0L	V6 SOHC	2002.5 MY	HEC	•	•	•	
Explorer	4. 0L	V6 SOHC	2002.5 MY	PAM			•	
Explorer	4. 0L	V6 SOHC	2002.5 MY	PCM	•	•	•	•
Explorer	4. 0L	V6 SOHC	2002.5 MY	RCM	•	•	•	•
Explorer	4. 0L	V6 SOHC	2002.5 MY	TPM		•	•	
Explorer	4. 0L	V6 SOHC	2003 MY	4X4	•	•	•	
Explorer	4. 0L	V6 SOHC	2003 MY	ABS/TCS	•	•	•	•
Explorer	4. 0L	V6 SOHC	2003 MY	DSM	•	•	•	•
Explorer	4. 0L	V6 SOHC	2003 MY	EATC	•	•	•	•
Explorer	4. 0L	V6 SOHC	2003 MY	HEC	•	•	•	•
Explorer	4. 0L	V6 SOHC	2003 MY	PAM	•	•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer	4. 0L	V6 SOHC	2003 MY	PCM		•		
Explorer	4. 0L	V6 SOHC	2003 MY	RCM		•		
Explorer	4. 0L	V6 SOHC	2003 MY	TPM		•		
Explorer	4. 0L	V6 SOHC	2003 MY	VSM		•		
Explorer	4. 0L	V6 SOHC	2004 MY	4X4		•		
Explorer	4. 0L	V6 SOHC	2004 MY	ABS		•		
Explorer	4. 0L	V6 SOHC	2004 MY	DSM		•		
Explorer	4. 0L	V6 SOHC	2004 MY	EATC	•	•	•	•
Explorer	4. 0L	V6 SOHC	2004 MY	IC		•		
Explorer	4. 0L	V6 SOHC	2004 MY	PAM	•	•	•	
Explorer	4. 0L	V6 SOHC	2004 MY	PCM		•	•	
Explorer	4. 0L	V6 SOHC	2004 MY	RCM	•	•	•	•
Explorer	4. 0L	V6 SOHC	2004 MY	TPM	•	•	•	0
Explorer	4. 0L	V6 SOHC	2004 MY	VSM	•	•	•	•
Explorer	4. 0L	V6 SOHC	2005 MY	4X4		•		
Explorer	4. 0L	V6 SOHC	2005 MY	ABS	•	•	•	
Explorer	4. 0L	V6 SOHC	2005 MY	DSM	•	•	•	
Explorer	4. 0L	V6 SOHC	2005 MY	EATC		•	•	
Explorer	4. 0L	V6 SOHC	2005 MY	IC	•	•	•	
Explorer	4. 0L	V6 SOHC	2005 MY	PAM	•	•	•	•
Explorer	4. 0L	V6 SOHC	2005 MY	PCM		•	•	•
Explorer	4. 0L	V6 SOHC	2005 MY	RCM	•	•	•	•
Explorer	4. 0L	V6 SOHC	2005 MY	TPM	•	•	•	
Explorer	4. 0L	V6 SOHC	2005 MY	VSM	•	•	•	•
Explorer	4.6L	2V	2002 MY	4X4	•	•	•	•
Explorer	4.6L	2V	2002 MY	ABS/TCS	•	•		•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer	4.6L	2V	2002 MY	CSM	•	•		
Explorer	4. 6L	2V	2002 MY	DSM	•	•	•	
Explorer	4. 6L	2V	2002 MY	EATC	•	•	•	
Explorer	4.6L	2V	2002 MY	GEM	•		•	
Explorer	4.6L	2V	2002 MY	IC	•	•	•	
Explorer	4.6L	2V	2002 MY	PAM	•	•	•	
Explorer	4.6L	2V	2002 MY	PCM	•		•	
Explorer	4.6L	2V	2002 MY	RCM	•	•	•	0
Explorer	4.6L	2V	2002.5 MY	4X4	•	•	•	
Explorer	4.6L	2V	2002.5 MY	ABS/TCS	•		•	
Explorer	4.6L	2V	2002.5 MY	CSM	•	•	•	•
Explorer	4.6L	2V	2002.5 MY	DSM	•	•	•	•
Explorer	4.6L	2V	2002.5 MY	EATC	•	•	•	•
Explorer	4.6L	2V	2002.5 MY	HEC	•	•	•	
Explorer	4.6L	2V	2002.5 MY	PAM	•	•	•	
Explorer	4.6L	2V	2002.5 MY	PCM	•	•	•	
Explorer	4.6L	2V	2002.5 MY	RCM	•		•	
Explorer	4.6L	2V	2002.5 MY	TPM	•	•	•	•
Explorer	4.6L	2V	2003 MY	4X4	•	•	•	
Explorer	4.6L	2V	2003 MY	ABS/TCS	•	•	•	
Explorer	4.6L	2V	2003 MY	DSM	•	•	•	•
Explorer	4.6L	2V	2003 MY	EATC	•	•	•	•
Explorer	4.6L	2V	2003 MY	HEC	•	•	•	•
Explorer	4.6L	2V	2003 MY	PAM	•	•	•	•
Explorer	4.6L	2V	2003 MY	PCM	•	•	•	•
Explorer	4.6L	2V	2003 MY	RCM	•	•		•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer	4.6L	2V	2003 MY	TPM	•	•		
Explorer	4.6L	2V	2003 MY	VSM		•		
Explorer	4.6L	2V	2004 MY	4X4		•		
Explorer	4.6L	2V	2004 MY	ABS		•		
Explorer	4.6L	2V	2004 MY	DSM		•		
Explorer	4.6L	2V	2004 MY	EATC		•		
Explorer	4.6L	2V	2004 MY	IC		•		
Explorer	4. 6L	2V	2004 MY	PAM	•	•	•	
Explorer	4. 6L	2V	2004 MY	PCM		•		
Explorer	4. 6L	2V	2004 MY	RCM		•	•	
Explorer	4. 6L	2V	2004 MY	TPM	•	•	•	0
Explorer	4. 6L	2V	2004 MY	VSM	•	•	•	
Explorer	4. 6L	2V	2005 MY	4X4	•	•	•	•
Explorer	4. 6L	2V	2005 MY	ABS	•	•	•	
Explorer	4.6L	2V	2005 MY	DSM		•		
Explorer	4. 6L	2V	2005 MY	EATC		•		
Explorer	4. 6L	2V	2005 MY	IC		•	•	
Explorer	4. 6L	2V	2005 MY	PAM		•	•	
Explorer	4. 6L	2V	2005 MY	PCM	•	•	•	
Explorer	4. 6L	2V	2005 MY	RCM	•	•	•	
Explorer	4.6L	2V	2005 MY	TPM	•	•	•	
Explorer	4.6L	2V	2005 MY	VSM	•	•		•
Explorer	4.6L	3V	2006 MY	4X4	•	•	•	•
Explorer	4.6L	3V	2006 MY	ABS	•	•	•	•
Explorer	4.6L	3V	2006 MY	ACM	•	•	•	0
Explorer	4. 6L	3V	2006 MY	DSM	•	•		

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer	4.6L	3V	2006 MY	EATC		•		
Explorer	4.6L	3V	2006 MY	GEM		•		
Explorer	4.6L	3V	2006 MY	IC		•		
Explorer	4.6L	3V	2006 MY	OCSM		•		0
Explorer	4.6L	3V	2006 MY	PAM		•		
Explorer	4.6L	3V	2006 MY	PCM		•		
Explorer	4.6L	3V	2006 MY	PRB	•	•	•	
Explorer	4.6L	3V	2006 MY	RCM	•	•	•	
Explorer	4. 6L	3V	2006 MY	RETM		•		
Explorer	4.6L	3V	2006 MY	SDARS	•	•	•	
Explorer	4.6L	3V	2006 MY	TCM	•	•	•	
Explorer	4. 6L	3V	2007 MY	4X4	•	•	•	
Explorer	4.6L	3V	2007 MY	ABS	•	•	•	
Explorer	4.6L	3V	2007 MY	ACM	•	•	•	0
Explorer	4.6L	3V	2007 MY	DSM		•		
Explorer	4.6L	3V	2007 MY	EATC	•	•	•	
Explorer	4.6L	3V	2007 MY	GEM		•	•	
Explorer	4.6L	3V	2007 MY	IC		•	•	
Explorer	4.6L	3V	2007 MY	OCSM	•	•	•	
Explorer	4.6L	3V	2007 MY	PAM	•	•	•	0
Explorer	4.6L	3V	2007 MY	PCM		•	•	•
Explorer	4. 6L	3V	2007 MY	PRB	•	•	•	•
Explorer	4. 6L	3V	2007 MY	RCM	•	•	•	•
Explorer	4. 6L	3V	2007 MY	RETM		•		0
Explorer	4. 6L	3V	2007 MY	SDARS	•	•	•	•
Explorer	4. 6L	3V	2007 MY	TCM	•	•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer	4.6L	3V	2008 MY	4X4		•		
Explorer	4. 6L	3V	2008 MY	ABS		•		
Explorer	4. 6L	3V	2008 MY	ACM		•		0
Explorer	4.6L	3V	2008 MY	APIM		•		0
Explorer	4. 6L	3V	2008 MY	DSM		•		
Explorer	4. 6L	3V	2008 MY	GEM/SJB		•		
Explorer	4. 6L	3V	2008 MY	HVAC		•		
Explorer	4. 6L	3V	2008 MY	IC		•		
Explorer	4.6L	3V	2008 MY	OCSM		•		
Explorer	4.6L	3V	2008 MY	PAM		•		0
Explorer	4. 6L	3V	2008 MY	PCM		•		
Explorer	4.6L	3V	2008 MY	PRB		•		
Explorer	4.6L	3V	2008 MY	RCM		•		
Explorer	4. 6L	3V	2008 MY	RETM		•		0
Explorer	4. 6L	3V	2008 MY	SDARS		•		
Explorer	4. 6L	3V	2008 MY	TCM		•		
Explorer	4. 6L	3V	2009 MY	4X4		•		
Explorer	4. 6L	3V	2009 MY	ABS		•		
Explorer	4. 6L	3V	2009 MY	ACM	•	•	•	•
Explorer	4. 6L	3V	2009 MY	ACM		•		0
Explorer	4.6L	3V	2009 MY	APIM	•	•	•	0
Explorer	4.6L	3V	2009 MY	DSM		•	•	
Explorer	4.6L	3V	2009 MY	GEM/SJB	•	•	•	
Explorer	4.6L	3V	2009 MY	HVAC	•	•		•
Explorer	4.6L	3V	2009 MY	IC	•	•		
Explorer	4.6L	3V	2009 MY	OCSM	•	•	•	

- This function is supported.
- O This function is not supported.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer	4. 6L	3V	2009 MY	PAM	•	•	•	0
Explorer	4. 6L	3V	2009 MY	PCM	•	•	•	
Explorer	4.6L	3V	2009 MY	PRB				
Explorer	4.6L	3V	2009 MY	RCM				
Explorer	4.6L	3V	2009 MY	RETM		•	•	0
Explorer	4. 6L	3V	2009 MY	SDARS		•	•	
Explorer	4. 6L	3V	2009 MY	TCM		•	•	
Explorer	4. 6L	3V	2010 MY	4X4	•	•	•	
Explorer	4. 6L	3V	2010 MY	ABS				
Explorer	4. 6L	3V	2010 MY	ACM	•		•	
Explorer	4. 6L	3V	2010 MY	ACM	•		•	0
Explorer	4. 6L	3V	2010 MY	APIM	•		•	0
Explorer	4. 6L	3V	2010 MY	DSM	•	•	•	
Explorer	4. 6L	3V	2010 MY	GEM/SJB	•	•	•	
Explorer	4. 6L	3V	2010 MY	GPSM				0
Explorer	4. 6L	3V	2010 MY	HVAC	•		•	
Explorer	4.6L	3V	2010 MY	IC		•	•	
Explorer	4. 6L	3V	2010 MY	OCSM		•	•	
Explorer	4. 6L	3V	2010 MY	PAM	•	•	•	0
Explorer	4. 6L	3V	2010 MY	PCM	•	•	•	
Explorer	4. 6L	3V	2010 MY	PRB	•	•	•	
Explorer	4. 6L	3V	2010 MY	RCM	•		•	
Explorer	4. 6L	3V	2010 MY	RETM	•	•	•	0
Explorer	4. 6L	3V	2010 MY	SDARS	•	•	•	
Explorer	4. 6L	3V	2010 MY	TCM	•	•	•	•
Explorer	5. 0L	Other	1996 MY	ABS/TCS	•	•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer	5. 0L	Other	1996 MY	EATC		•		0
Explorer	5. 0L	Other	1996 MY	GEM		•		
Explorer	5. 0L	Other	1996 MY	IAB		•		0
Explorer	5. 0L	Other	1996 MY	PCM		•		
Explorer	5. 0L	Other	1996 MY	RAP		•		
Explorer	5. 0L	Other	1997 MY	ABS/TCS		•		
Explorer	5. 0L	Other	1997 MY	ARC		•		0
Explorer		Other	1997 MY	EATC	•	•	•	0
Explorer	5. 0L	Other	1997 MY	GEM		•		
Explorer		Other	1997 MY	IAB	•	•	•	0
Explorer	5. 0L	Other	1997 MY	PCM		•	•	
Explorer		Other	1997 MY	RAP	•	•	•	
Explorer	5. 0L	Other	1998 MY	ABS/TCS	•	•	•	•
Explorer		Other	1998 MY	ARC	•	•	•	•
Explorer	5. 0L	Other	1998 MY	DSM		•		
Explorer	5. 0L	Other	1998 MY	EATC	•	•	•	0
Explorer	5. 0L	Other	1998 MY	GEM		•	•	
Explorer	5. 0L	Other	1998 MY	IAB		•	•	
Explorer	5. 0L	Other	1998 MY	PAM	•	•	•	•
Explorer	5. 0L	Other	1998 MY	PATS	•	•	•	•
Explorer	5. 0L	Other	1998 MY	PCM		•	•	•
Explorer	5. 0L	Other	1998 MY	RAP	•	•	•	•
Explorer	5. 0L	Other	1999 MY	ABS/TCS	•	•	•	•
Explorer	5. 0L	Other	1999 MY	ARC	•	•		•
Explorer	5. 0L	Other	1999 MY	DSM	•	•	•	•
Explorer	5. 0L	Other	1999 MY	EATC	•	•		0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer	5. 0L	Other	1999 MY	GEM	•	•	•	
Explorer	5. 0L	Other	1999 MY	PAM	•	•		
Explorer	5. 0L	Other	1999 MY	PATS		•		
Explorer	5. 0L	Other	1999 MY	PCM	•	•	•	
Explorer	5. 0L	Other	1999 MY	RAP	•	•		
Explorer	5. 0L	Other	1999 MY	RCM	•	•	•	
Explorer	5. 0L	Other	2000 MY	ABS/TCS	•	•		
Explorer	5. 0L	Other	2000 MY	ARC	•	•	•	
Explorer	5. 0L	Other	2000 MY	DSM	•	•		
Explorer	5. 0L	Other	2000 MY	EATC	•	•	•	0
Explorer	5. 0L	Other	2000 MY	GEM	•	•	•	
Explorer	5. 0L	Other	2000 MY	PAM	•	•	•	•
Explorer	5. 0L	Other	2000 MY	PATS	•	•	•	
Explorer	5. 0L	Other	2000 MY	PCM	•	•		
Explorer	5. 0L	Other	2000 MY	RAP		•		
Explorer	5. 0L	Other	2000 MY	RCM	•	•	•	
Explorer Sport	4. 0L	V6 SOHC	2000.5 MY	4X4	•	•	•	
Explorer Sport	4. 0L	V6 SOHC	2000.5 MY	ABS/TCS	•	•	•	
Explorer Sport	4. 0L	V6 SOHC	2000.5 MY	GEM	•	•	•	•
Explorer Sport	4. 0L	V6 SOHC	2000.5 MY	PATS	•	•	•	•
Explorer Sport	4. 0L	V6 SOHC	2000.5 MY	PCM	•		•	
Explorer Sport	4. 0L	V6 SOHC	2000.5 MY	RAP	•	•	•	•
Explorer Sport	4. 0L	V6 SOHC	2000.5 MY	RCM		•	•	•
Explorer Sport	4. 0L	V6 SOHC	2001 MY	4X4	•	•	•	•
Explorer Sport	4. 0L	V6 SOHC	2001 MY	ABS/TCS	•	•	•	•
Explorer Sport	4. 0L	V6 SOHC	2001 MY	GEM		•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer Sport	4. 0L	V6 SOHC	2001 MY	PCM		•		
Explorer Sport	4. 0L	V6 SOHC	2001 MY	RAP		•		
Explorer Sport	4. 0L	V6 SOHC	2001 MY	RCM		•		
Explorer Sport	4. 0L	V6 SOHC	2002 MY	4X4		•		
Explorer Sport	4. 0L	V6 SOHC	2002 MY	ABS/TCS		•		•
Explorer Sport	4. 0L	V6 SOHC	2002 MY	GEM		•		•
Explorer Sport	4. 0L	V6 SOHC	2002 MY	PCM		•	•	•
Explorer Sport	4. 0L	V6 SOHC	2002 MY	RAP		•	•	•
Explorer Sport	4. 0L	V6 SOHC	2002 MY	RCM		•		•
Explorer Sport	4. 0L	V6 SOHC	2003 MY	4X4		•	•	
Explorer Sport	4. 0L	V6 SOHC	2003 MY	ABS/TCS		•	•	•
Explorer Sport	4. 0L	V6 SOHC	2003 MY	GEM		•	•	•
Explorer Sport	4. 0L	V6 SOHC	2003 MY	PCM		•	•	•
Explorer Sport	4. 0L	V6 SOHC	2003 MY	RAP		•	•	•
Explorer Sport	4. 0L	V6 SOHC	2003 MY	RCM		•		
Explorer SportTrac	4. 0L	2V	2007 MY	4X4	•		•	
Explorer SportTrac	4. 0L	2V	2007 MY	ABS		•	•	
Explorer SportTrac	4. 0L	2V	2007 MY	ACM			•	0
Explorer SportTrac	4. 0L	2V	2007 MY	EATC		•	•	•
Explorer SportTrac	4. 0L	2V	2007 MY	GEM		•	•	•
Explorer SportTrac	4. 0L	2V	2007 MY	IC	•	•	•	•
Explorer SportTrac	4. 0L	2V	2007 MY	OCSM		•	•	
Explorer SportTrac	4. 0L	2V	2007 MY	PAM		•	•	•
Explorer SportTrac	4. 0L	2V	2007 MY	PCM	•	•	•	•
Explorer SportTrac	4. 0L	2V	2007 MY	RCM	•	•	•	•
Explorer SportTrac	4. 0L	2V	2007 MY	RETM	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer SportTrac	4. 0L	2V	2007 MY	SDARS		•		
Explorer SportTrac	4. 0L	2V	2008 MY	4X4		•		
Explorer SportTrac	4. 0L	2V	2008 MY	ABS		•		
Explorer SportTrac	4. 0L	2V	2008 MY	ACM		•		0
Explorer SportTrac	4. 0L	2V	2008 MY	APIM		•		0
Explorer SportTrac	4. 0L	2V	2008 MY	GEM/SJB		•		
Explorer SportTrac	4. 0L	2V	2008 MY	HVAC		•		
Explorer SportTrac	4. 0L	2V	2008 MY	IC		•		
Explorer SportTrac	4. 0L	2V	2008 MY	OCSM		•		
Explorer SportTrac	4. 0L	2V	2008 MY	PAM		•		
Explorer SportTrac	4. 0L	2V	2008 MY	PCM		•		
Explorer SportTrac	4. 0L	2V	2008 MY	RCM		•		
Explorer SportTrac	4. 0L	2V	2008 MY	RETM		•		0
Explorer SportTrac	4. 0L	2V	2008 MY	SDARS		•		
Explorer SportTrac	4.0L	2V	2009 MY	4X4				
Explorer SportTrac	4.0L	2V	2009 MY	ABS		•		
Explorer SportTrac	4. 0L	2V	2009 MY	ACM		•		
Explorer SportTrac	4. 0L	2V	2009 MY	ACM		•		0
Explorer SportTrac	4. 0L	2V	2009 MY	APIM		•	•	0
Explorer SportTrac	4. 0L	2V	2009 MY	GEM/SJB		•		
Explorer SportTrac	4. 0L	2V	2009 MY	HVAC		•		
Explorer SportTrac	4. 0L	2V	2009 MY	IC		•	•	
Explorer SportTrac	4. 0L	2V	2009 MY	OCSM	•	•	•	
Explorer SportTrac	4. 0L	2V		PAM	•	•		•
Explorer SportTrac	4. 0L	2V	2009 MY	PCM	•	•	•	•
Explorer SportTrac	4. 0L	2V	2009 MY	RCM	•	•		

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer SportTrac	4. 0L	2V	2009 MY	RETM	•	•		0
Explorer SportTrac	4. 0L	2V	2009 MY	SDARS	•	•		
Explorer SportTrac	4. 0L	2V	2010 MY	4X4	•	•		
Explorer SportTrac	4. 0L	2V	2010 MY	ABS	•	•		
Explorer SportTrac	4. 0L	2V	2010 MY	ACM	•	•		
Explorer SportTrac	4. 0L	2V	2010 MY	ACM	•	•		0
Explorer SportTrac	4. 0L	2V	2010 MY	APIM	•	•		0
Explorer SportTrac	4. 0L	2V	2010 MY	GEM/SJB	•	•	•	•
Explorer SportTrac	4. 0L	2V	2010 MY	GPSM	•	•		0
Explorer SportTrac	4. 0L	2V	2010 MY	HVAC	•	•	•	
Explorer SportTrac	4. 0L	2V	2010 MY	IC	•	•	•	
Explorer SportTrac	4. 0L	2V	2010 MY	OCSM	•	•	•	
Explorer SportTrac	4. 0L	2V	2010 MY	PAM	•	•	•	•
Explorer SportTrac	4. 0L	2V	2010 MY	PCM	•	•	•	•
Explorer SportTrac	4. 0L	2V	2010 MY	RCM	•	•		•
Explorer SportTrac	4. 0L	2V	2010 MY	RETM	•		•	0
Explorer SportTrac	4. 0L	2V	2010 MY	SDARS	•	•	•	
Explorer SportTrac	4. 0L	V6 SOHC	2000.5 MY	4X4	•	•	•	•
Explorer SportTrac	4. 0L	V6 SOHC	2000.5 MY	ABS/TCS	•	•	•	•
Explorer SportTrac	4. 0L	V6 SOHC	2000.5 MY	GEM	•	•	•	•
Explorer SportTrac	4. 0L	V6 SOHC	2000.5 MY	PCM	•	•	•	•
Explorer SportTrac	4. 0L	V6 SOHC	2000.5 MY	RAP	•	•	•	•
Explorer SportTrac	4. 0L	V6 SOHC	2000.5 MY	RCM	•	•		•
Explorer SportTrac	4. 0L	V6 SOHC	2001 MY	4X4	•	•		•
Explorer SportTrac	4. 0L	V6 SOHC	2001 MY	ABS/TCS	•	•	•	•
Explorer SportTrac	4. 0L	V6 SOHC	2001 MY	GEM	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer SportTrac	4. 0L	V6 SOHC	2001 MY	PCM	•	•		
Explorer SportTrac	4. 0L	V6 SOHC	2001 MY	RAP	•	•		
Explorer SportTrac	4. 0L	V6 SOHC	2001 MY	RCM	•	•		
Explorer SportTrac	4. 0L	V6 SOHC	2002 MY	4X4		•		
Explorer SportTrac	4. 0L	V6 SOHC	2002 MY	ABS/TCS	•	•		
Explorer SportTrac	4. 0L	V6 SOHC	2002 MY	GEM		•		
Explorer SportTrac	4. 0L	V6 SOHC	2002 MY	PCM	•	•		
Explorer SportTrac	4. 0L	V6 SOHC	2002 MY	RAP	•	•	•	•
Explorer SportTrac	4. 0L	V6 SOHC	2002 MY	RCM	•	•		•
Explorer SportTrac	4. 0L	V6 SOHC	2003 MY	4X4	•	•	•	
Explorer SportTrac	4. 0L	V6 SOHC	2003 MY	ABS/TCS	•	•	•	
Explorer SportTrac	4. 0L	V6 SOHC	2003 MY	GEM	•	•	•	
Explorer SportTrac	4. 0L	V6 SOHC	2003 MY	PCM	•	•	•	•
Explorer SportTrac	4. 0L	V6 SOHC	2003 MY	RAP	•	•	•	•
Explorer SportTrac	4. 0L	V6 SOHC	2003 MY	RCM	•	•		
Explorer SportTrac	4. 0L	V6 SOHC	2004 MY	4X4	•	•	•	
Explorer SportTrac	4. 0L	V6 SOHC	2004 MY	ABS/TCS	•	•	•	
Explorer SportTrac	4. 0L	V6 SOHC	2004 MY	HEC	•	•	•	
Explorer SportTrac	4. 0L	V6 SOHC	2004 MY	PCM	•	•	•	•
Explorer SportTrac	4. 0L	V6 SOHC	2004 MY	RAP	•	•	•	•
Explorer SportTrac	4. 0L	V6 SOHC	2004 MY	RCM	•	•	•	•
Explorer SportTrac	4. 0L	V6 SOHC	2005 MY	4X4	•	•	•	•
Explorer SportTrac	4. 0L	V6 SOHC	2005 MY	ABS/TCS	•	•		•
Explorer SportTrac	4. 0L	V6 SOHC	2005 MY	HEC	•	•		•
Explorer SportTrac	4. 0L	V6 SOHC		PCM	•	•	•	•
Explorer SportTrac	4. 0L	V6 SOHC	2005 MY	RAP	•	•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer SportTrac	4. 0L	V6 SOHC	2005 MY	RCM		•	•	
Explorer SportTrac	4.6L	3V	2007 MY	4X4		•		
Explorer SportTrac	4.6L	3V	2007 MY	ABS		•		
Explorer SportTrac	4.6L	3V	2007 MY	ACM		•		0
Explorer SportTrac	4.6L	3V	2007 MY	EATC		•		
Explorer SportTrac	4.6L	3V	2007 MY	GEM		•		
Explorer SportTrac	4.6L	3V	2007 MY	IC		•		
Explorer SportTrac	4.6L	3V	2007 MY	OCSM	•	•	•	
Explorer SportTrac	4. 6L	3V	2007 MY	PAM		•		
Explorer SportTrac	4.6L	3V	2007 MY	PCM		•	•	
Explorer SportTrac	4.6L	3V	2007 MY	RCM	•	•	•	•
Explorer SportTrac	4.6L	3V	2007 MY	RETM	•	•	•	0
Explorer SportTrac	4.6L	3V	2007 MY	SDARS	•	•	•	•
Explorer SportTrac	4.6L	3V	2007 MY	TCM	•	•	•	
Explorer SportTrac	4. 6L	3V	2008 MY	4X4		•		
Explorer SportTrac	4.6L	3V	2008 MY	ABS		•	•	
Explorer SportTrac	4.6L	3V	2008 MY	ACM		•	•	0
Explorer SportTrac	4.6L	3V	2008 MY	APIM	•	•	•	0
Explorer SportTrac	4.6L	3V	2008 MY	GEM/SJB	•	•	•	
Explorer SportTrac	4. 6L	3V	2008 MY	HVAC	•	•	•	•
Explorer SportTrac	4. 6L	3V	2008 MY	IC	•	•	•	
Explorer SportTrac	4. 6L	3V	2008 MY	OCSM	•	•	•	
Explorer SportTrac	4. 6L	3V	2008 MY	PAM		•	•	•
Explorer SportTrac	4. 6L	3V	2008 MY	PCM	•	•	•	•
Explorer SportTrac	4. 6L	3V	2008 MY	RCM	•	•	•	
Explorer SportTrac	4. 6L	3V	2008 MY	RETM	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer SportTrac	4.6L	3V	2008 MY	SDARS		•		
Explorer SportTrac	4.6L	3V	2008 MY	TCM		•		
Explorer SportTrac	4.6L	3V	2009 MY	4X4		•		
Explorer SportTrac	4.6L	3V	2009 MY	ABS		•		
Explorer SportTrac	4.6L	3V	2009 MY	ACM		•		
Explorer SportTrac	4.6L	3V	2009 MY	ACM		•		0
Explorer SportTrac	4.6L	3V	2009 MY	APIM		•		0
Explorer SportTrac	4.6L	3V	2009 MY	GEM/SJB		•		
Explorer SportTrac	4.6L	3V	2009 MY	HVAC		•		
Explorer SportTrac	4.6L	3V	2009 MY	IC		•		
Explorer SportTrac	4.6L	3V	2009 MY	OCSM		•		
Explorer SportTrac	4.6L	3V	2009 MY	PAM		•		
Explorer SportTrac	4.6L	3V	2009 MY	PCM		•		
Explorer SportTrac	4.6L	3V	2009 MY	RCM		•		
Explorer SportTrac	4.6L	3V	2009 MY	RETM		•		0
Explorer SportTrac	4.6L	3V	2009 MY	SDARS		•		
Explorer SportTrac	4.6L	3V	2009 MY	TCM		•		
Explorer SportTrac	4.6L	3V	2010 MY	4X4		•		
Explorer SportTrac	4.6L	3V	2010 MY	ABS		•		
Explorer SportTrac	4.6L	3V	2010 MY	ACM		•		
Explorer SportTrac	4.6L	3V	2010 MY	ACM		•		0
Explorer SportTrac	4. 6L	3V	2010 MY	APIM	•	•		0
Explorer SportTrac	4.6L	3V	2010 MY	GEM/SJB	•	•	•	
Explorer SportTrac	4.6L	3V	2010 MY	GPSM	•	•	•	0
Explorer SportTrac	4. 6L	3V	2010 MY	HVAC	•	•	•	•
Explorer SportTrac	4.6L	3V	2010 MY	IC	•	•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Explorer SportTrac	4.6L	3V	2010 MY	OCSM	•	•	•	
Explorer SportTrac	4.6L	3V	2010 MY	PAM	•	•	•	
Explorer SportTrac	4.6L	3V	2010 MY	PCM	•	•		
Explorer SportTrac	4.6L	3V	2010 MY	RCM	•	•	•	
Explorer SportTrac	4.6L	3V	2010 MY	RETM	•	•	•	0
Explorer SportTrac	4.6L	3V	2010 MY	SDARS	•	•		
Explorer SportTrac	4.6L	3V	2010 MY	TCM	•	•	•	
F-250 Light Duty	4. 2L	Other	1999 MY	ABS/TCS	•	•	•	
F-250 Light Duty	4. 2L	Other	1999 MY	GEM	•	•		
F-250 Light Duty	4. 2L	Other	1999 MY	IC	•	•	•	•
F-250 Light Duty	4. 2L	Other	1999 MY	PCM	•	•	•	•
F-250 Light Duty	4. 2L	Other	1999 MY	RAP	•	•	•	•
F-250 Light Duty	4. 2L	Other	1999 MY	RCM	•	•	•	0
F-250 Light Duty	4.6L	Other	1997 MY	ABS/TCS	•	•	•	
F-250 Light Duty	4.6L	Other	1997 MY	GEM	•	•		
F-250 Light Duty	4.6L	Other	1997 MY	IAB	•	•	•	
F-250 Light Duty	4.6L	Other	1997 MY	PCM	•	•	•	
F-250 Light Duty	4.6L	Other	1997 MY	RAP	•		•	
F-250 Light Duty	4.6L	Other	1998 MY	ABS/TCS	•	•	•	•
F-250 Light Duty	4.6L	Other	1998 MY	GEM	•	•	•	•
F-250 Light Duty	4.6L	Other	1998 MY	IAB	•		•	
F-250 Light Duty	4.6L	Other	1998 MY	PCM	•	•	•	•
F-250 Light Duty	4.6L	Other	1998 MY	RAP		•	•	•
F-250 Light Duty	4.6L	Other	1999 MY	ABS/TCS	•	•	•	•
F-250 Light Duty	4.6L	Other	1999 MY	GEM	•	•	•	•
F-250 Light Duty	4.6L	Other	1999 MY	IC		•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-250 Light Duty	4.6L	Other	1999 MY	PCM	•	•		
F-250 Light Duty	4. 6L	Other	1999 MY	RAP	•	•	•	
F-250 Light Duty	4.6L	Other	1999 MY	RCM	•	•		
F-250 Light Duty	4.6L	Other	2000 MY	ABS/TCS	•	•		
F-250 Light Duty	4.6L	Other	2000 MY	GEM	•	•		
F-250 Light Duty	4.6L	Other	2000 MY	IC	•	•		
F-250 Light Duty	4. 6L	Other	2000 MY	PCM	•	•	•	
F-250 Light Duty		Other	2000 MY	RAP	•	•	•	
F-250 Light Duty	4. 6L	Other	2000 MY	RCM	•	•		
F-250 Light Duty	5. 4L	BIF	1998 MY	ABS/TCS	•	•	•	
F-250 Light Duty	5. 4L	BIF	1998 MY	AFCM	•	•	•	0
F-250 Light Duty	5. 4L	BIF	1998 MY	GEM	•	•	•	•
F-250 Light Duty	5. 4L	BIF	1998 MY	IAB	•	•	•	
F-250 Light Duty	5. 4L	BIF	1998 MY	PCM	•	•	•	
F-250 Light Duty	5. 4L	BIF	1998 MY	RAP	•	•		
F-250 Light Duty	5. 4L	BIF	1999 MY	ABS/TCS	•	•		•
F-250 Light Duty	5. 4L	BIF	1999 MY	AFCM	•	•	•	0
F-250 Light Duty		BIF	1999 MY	GEM	•	•	•	
F-250 Light Duty	5. 4L	BIF	1999 MY	IC	•	•	•	
F-250 Light Duty	5. 4L	BIF	1999 MY	PCM	•	•	•	
F-250 Light Duty	5. 4L	BIF	1999 MY	RAP	•	•	•	•
F-250 Light Duty	5. 4L	BIF	1999 MY	RCM	•	•	•	•
F-250 Light Duty	5. 4L	NGV	1997 MY	ABS/TCS	•	•		•
F-250 Light Duty	5. 4L	NGV	1997 MY	FIM	•	•	•	0
F-250 Light Duty	5. 4L	NGV	1997 MY	GEM	•	•	•	•
F-250 Light Duty	5. 4L	NGV	1997 MY	IAB	•	•		

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-250 Light Duty	5. 4L	NGV	1997 MY	PCM		•		
F-250 Light Duty	5. 4L	NGV	1997 MY	RAP		•		
F-250 Light Duty	5. 4L	NGV	1998 MY	ABS/TCS		•		
F-250 Light Duty	5. 4L	NGV	1998 MY	FIM		•		0
F-250 Light Duty	5. 4L	NGV	1998 MY	GEM		•		
F-250 Light Duty	5. 4L	NGV	1998 MY	IAB		•		
F-250 Light Duty	5. 4L	NGV	1998 MY	PCM		•	•	
F-250 Light Duty	5. 4L	NGV	1998 MY	RAP		•	•	
F-250 Light Duty	5. 4L	NGV	1999 MY	ABS/TCS		•		
F-250 Light Duty	5. 4L	NGV	1999 MY	FIM		•		0
F-250 Light Duty	5. 4L	NGV	1999 MY	GEM		•		
F-250 Light Duty	5. 4L	NGV	1999 MY	IC		•	•	•
F-250 Light Duty	5. 4L	NGV	1999 MY	PCM		•	•	•
F-250 Light Duty	5. 4L	NGV	1999 MY	RAP		•	•	
F-250 Light Duty	5. 4L	NGV	1999 MY	RCM		•		
F-250 Light Duty	5. 4L	NGV	2000 MY	ABS/TCS		•		
F-250 Light Duty	5. 4L	NGV	2000 MY	FIM		•	•	0
F-250 Light Duty	5. 4L	NGV	2000 MY	GEM		•	•	
F-250 Light Duty	5. 4L	NGV	2000 MY	IC		•	•	
F-250 Light Duty	5. 4L	NGV	2000 MY	PCM		•	•	•
F-250 Light Duty	5. 4L	NGV	2000 MY	RAP	•			
F-250 Light Duty	5. 4L	NGV	2000 MY	RCM	•	•	•	•
F-250 Light Duty	5. 4L	Other	1997 MY	ABS/TCS		•	•	•
F-250 Light Duty	5. 4L	Other	1997 MY	GEM	•	•	•	•
F-250 Light Duty	5. 4L	Other	1997 MY	IAB	•	•	•	•
F-250 Light Duty	5. 4L	Other	1997 MY	PCM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-250 Light Duty	5. 4L	Other	1997 MY	RAP	•	•		
F-250 Light Duty	5. 4L	Other	1998 MY	ABS/TCS		•		
F-250 Light Duty	5. 4L	Other	1998 MY	GEM		•		
F-250 Light Duty	5. 4L	Other	1998 MY	IAB		•		
F-250 Light Duty	5. 4L	Other	1998 MY	PCM		•		
F-250 Light Duty	5. 4L	Other	1998 MY	RAP		•		
F-250 Light Duty	5. 4L	Other	1999 MY	ABS/TCS		•		
F-250 Light Duty	5. 4L	Other	1999 MY	GEM		•		
F-250 Light Duty	5. 4L	Other	1999 MY	IC		•		
F-250 Light Duty	5. 4L	Other	1999 MY	PCM		•		
F-250 Light Duty	5. 4L	Other	1999 MY	RAP	•	•	•	•
F-250 Light Duty	5. 4L	Other	1999 MY	RCM		•		
F-250 Light Duty	5. 4L	Other	2000 MY	ABS/TCS		•		•
F-250 Light Duty	5. 4L	Other	2000 MY	GEM		•		
F-250 Light Duty	5. 4L	Other	2000 MY	IC		•		
F-250 Light Duty	5. 4L	Other	2000 MY	PCM		•		
F-250 Light Duty	5. 4L	Other	2000 MY	RAP		•		
F-250 Light Duty	5. 4L	Other	2000 MY	RCM		•		
F-Series Super Duty	4. 2L	Direct Injection - Turbo	2003 MY	ABS/TCS	•	•	•	
F-Series Super Duty	4. 2L	Direct Injection - Turbo	2003 MY	FOH		•		
F-Series Super Duty	4. 2L	Direct Injection - Turbo	2003 MY	GEM		•		
F-Series Super Duty	4. 2L	Direct Injection - Turbo	2003 MY	HEC		•	0	
F-Series Super Duty	4. 2L	Direct Injection - Turbo	2003 MY	OTC	•	•	•	0
F-Series Super Duty	4. 2L	Direct Injection - Turbo	2003 MY	PAM	•	•	•	
F-Series Super Duty	4. 2L	Direct Injection - Turbo	2003 MY	PATS	•	•	•	•
F-Series Super Duty	4. 2L	Direct Injection - Turbo	2003 MY	PCM	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	4. 2L	Direct Injection - Turbo	2003 MY	RCM		•		
F-Series Super Duty	4. 2L	Direct Injection - Turbo	2003 MY	VSM		•		
F-Series Super Duty	4. 2L	Other	2001 MY	ABS/TCS		•		
F-Series Super Duty	4. 2L	Other	2001 MY	ECS		•		0
F-Series Super Duty	4. 2L	Other	2001 MY	GEM		•		
F-Series Super Duty	4. 2L	Other	2001 MY	OTC		•		0
F-Series Super Duty	4. 2L	Other	2001 MY	PAM		•		
F-Series Super Duty	4. 2L	Other	2001 MY	PCM		•		
F-Series Super Duty	4. 2L	Other	2001 MY	RCM		•		0
F-Series Super Duty	5. 4L	2V	2004 MY	ABS/TCS		•		
F-Series Super Duty	5. 4L	2V	2004 MY	GEM	•	•	•	
F-Series Super Duty	5. 4L	2V	2004 MY	HEC		•	•	•
F-Series Super Duty	5. 4L	2V	2004 MY	OTC		•		0
F-Series Super Duty	5. 4L	2V	2004 MY	PAM		•		
F-Series Super Duty	5. 4L	2V	2004 MY	PATS		•		
F-Series Super Duty	5. 4L	2V	2004 MY	PCM		•		
F-Series Super Duty	5. 4L	2V	2004 MY	RCM		•		
F-Series Super Duty	5. 4L	2V	2004 MY	VSM		•		
F-Series Super Duty	5. 4L	2V	2005 MY	ABS		•		
F-Series Super Duty	5. 4L	2V	2005 MY	EATC		•		
F-Series Super Duty	5. 4L	2V	2005 MY	GEM		•		•
F-Series Super Duty	5. 4L	2V	2005 MY	IC	•	•		
F-Series Super Duty	5. 4L	2V	2005 MY	PAM	•	•	•	
F-Series Super Duty	5. 4L	2V	2005 MY	PCM	•	•	•	
F-Series Super Duty	5. 4L	2V	2005 MY	RCM	•	•	•	
F-Series Super Duty	5. 4L	2V	2005 MY	TBC	•	•		0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	5. 4L	2V	2005 MY	VSM	•	•		
F-Series Super Duty	5. 4L	2V	2006 MY	ABS		•		
F-Series Super Duty	5. 4L	2V	2006 MY	EATC		•		
F-Series Super Duty	5. 4L	2V	2006 MY	GEM		•		
F-Series Super Duty	5. 4L	2V	2006 MY	IC	•	•	•	
F-Series Super Duty	5. 4L	2V	2006 MY	PAM	•	•	•	
F-Series Super Duty	5. 4L	2V	2006 MY	PCM	•	•	•	
F-Series Super Duty	5. 4L	2V	2006 MY	RCM	•	•	•	
F-Series Super Duty	5. 4L	2V	2006 MY	TBC	•	•	•	0
F-Series Super Duty	5. 4L	2V	2006 MY	VSM	•		•	
F-Series Super Duty	5. 4L	2V	2008 MY	4X4	•		•	
F-Series Super Duty	5. 4L	2V	2008 MY	ABS	•	•	•	
F-Series Super Duty	5. 4L	2V	2008 MY	ACM	•	•	•	0
F-Series Super Duty	5. 4L	2V	2008 MY	DSM	•	•	•	
F-Series Super Duty	5. 4L	2V	2008 MY	GEM/SJB		•		
F-Series Super Duty	5. 4L	2V	2008 MY	HVAC	•		•	•
F-Series Super Duty	5. 4L	2V	2008 MY	IC	•	•	•	
F-Series Super Duty	5. 4L	2V	2008 MY	PAM	•	•	•	•
F-Series Super Duty	5. 4L	2V	2008 MY	PCM	•	•	•	•
F-Series Super Duty	5. 4L	2V	2008 MY	RCM	•	•	•	•
F-Series Super Duty	5. 4L	2V	2008 MY	RETM	•	•	•	0
F-Series Super Duty	5. 4L	2V	2008 MY	SDARS	•	•	•	
F-Series Super Duty	5. 4L	2V	2008 MY	TBC		•	•	0
F-Series Super Duty	5. 4L	3V	2005 MY	ABS	•	•	•	•
F-Series Super Duty	5. 4L	3V	2005 MY	EATC	•	•	•	•
F-Series Super Duty	5. 4L	3V	2005 MY	GEM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	5. 4L	3V	2005 MY	IC		•		
F-Series Super Duty	5. 4L	3V	2005 MY	PAM		•	•	
F-Series Super Duty	5. 4L	3V	2005 MY	PCM				
F-Series Super Duty	5. 4L	3V	2005 MY	RCM		•		
F-Series Super Duty	5. 4L	3V	2005 MY	TBC		•	•	0
F-Series Super Duty	5. 4L	3V	2005 MY	VSM		•	•	•
F-Series Super Duty	5. 4L	3V	2006 MY	ABS		•	•	
F-Series Super Duty	5. 4L	3V	2006 MY	EATC		•	•	
F-Series Super Duty	5. 4L	3V	2006 MY	GEM		•	•	
F-Series Super Duty	5. 4L	3V	2006 MY	IC			•	
F-Series Super Duty	5. 4L	3V	2006 MY	PAM			•	
F-Series Super Duty	5. 4L	3V	2006 MY	PCM			•	
F-Series Super Duty	5. 4L	3V	2006 MY	RCM	•	•	•	•
F-Series Super Duty	5. 4L	3V	2006 MY	TBC	•	•	•	0
F-Series Super Duty	5. 4L	3V	2006 MY	VSM	•	•	•	•
F-Series Super Duty	5. 4L	3V	2007 MY	ABS	•	•	•	•
F-Series Super Duty	5. 4L	3V	2007 MY	EATC			•	
F-Series Super Duty	5. 4L	3V	2007 MY	GEM			•	
F-Series Super Duty	5. 4L	3V	2007 MY	IC	•	•	•	•
F-Series Super Duty	5. 4L	3V	2007 MY	PAM	•	•	•	•
F-Series Super Duty	5. 4L	3V	2007 MY	PCM		•	•	•
F-Series Super Duty	5. 4L	3V	2007 MY	RCM	•	•	•	
F-Series Super Duty	5. 4L	3V	2007 MY	TBC	•	•	•	0
F-Series Super Duty	5. 4L	3V	2007 MY	VSM	•	•	•	•
F-Series Super Duty	5. 4L	3V	2008 MY	4X4	•	•	•	•
F-Series Super Duty	5. 4L	3V	2008 MY	ABS	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	5. 4L	3V	2008 MY	ACM		•		0
F-Series Super Duty	5. 4L	3V	2008 MY	DSM		•		
F-Series Super Duty	5. 4L	3V	2008 MY	GEM/SJB		•		
F-Series Super Duty	5. 4L	3V	2008 MY	HVAC		•		
F-Series Super Duty	5. 4L	3V	2008 MY	IC		•		
F-Series Super Duty	5. 4L	3V	2008 MY	PAM		•		
F-Series Super Duty	5. 4L	3V	2008 MY	PCM		•		
F-Series Super Duty	5. 4L	3V	2008 MY	RCM	•	•	•	•
F-Series Super Duty	5. 4L	3V	2008 MY	RETM		•	•	0
F-Series Super Duty	5. 4L	3V	2008 MY	SDARS		•	•	
F-Series Super Duty	5. 4L	3V	2008 MY	TBC	•	•	•	0
F-Series Super Duty	5. 4L	3V	2009 MY	4X4	•	•	•	
F-Series Super Duty	5. 4L	3V	2009 MY	ABS	•	•	•	•
F-Series Super Duty	5. 4L	3V	2009 MY	ACM	•	•	•	•
F-Series Super Duty	5. 4L	3V	2009 MY	APIM		•	•	0
F-Series Super Duty	5. 4L	3V	2009 MY	DSM		•	•	
F-Series Super Duty	5. 4L	3V	2009 MY	GEM/SJB	•	•	•	
F-Series Super Duty	5. 4L	3V	2009 MY	HVAC	•	•	•	
F-Series Super Duty	5. 4L	3V	2009 MY	IC	•	•	•	•
F-Series Super Duty	5. 4L	3V	2009 MY	PAM	•	•	•	•
F-Series Super Duty	5. 4L	3V	2009 MY	PCM	•	•	•	•
F-Series Super Duty	5. 4L	3V	2009 MY	RCM			•	
F-Series Super Duty	5. 4L	3V	2009 MY	RETM	•	•	•	0
F-Series Super Duty	5. 4L	3V	2009 MY	SDARS	•	•	•	
F-Series Super Duty	5. 4L	3V	2009 MY	TBC	•	•	•	0
F-Series Super Duty	5. 4L	3V	2010 MY	4X4	•	•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	5. 4L	3V	2010 MY	ABS				
F-Series Super Duty	5. 4L	3V	2010 MY	ACM		•		
F-Series Super Duty	5. 4L	3V	2010 MY	APIM		•		0
F-Series Super Duty	5. 4L	3V	2010 MY	DSM				
F-Series Super Duty	5. 4L	3V	2010 MY	GEM/SJB		•		
F-Series Super Duty	5. 4L	3V	2010 MY	GPSM		•		0
F-Series Super Duty	5. 4L	3V	2010 MY	HVAC		•		
F-Series Super Duty	5. 4L	3V	2010 MY	IC		•		
F-Series Super Duty	5. 4L	3V	2010 MY	PAM		•		
F-Series Super Duty	5. 4L	3V	2010 MY	PCM		•		
F-Series Super Duty	5. 4L	3V	2010 MY	RCM		•		
F-Series Super Duty	5. 4L	3V	2010 MY	RETM		•		0
F-Series Super Duty	5. 4L	3V	2010 MY	SDARS		•		
F-Series Super Duty	5. 4L	3V	2010 MY	TBC		•		0
F-Series Super Duty	5. 4L	BIF	1999 MY	ABS/TCS				
F-Series Super Duty	5. 4L	BIF	1999 MY	AFCM		•		0
F-Series Super Duty	5. 4L	BIF	1999 MY	ECS		•		0
F-Series Super Duty	5. 4L	BIF	1999 MY	GEM		•		
F-Series Super Duty	5. 4L	BIF	1999 MY	OTC		•		0
F-Series Super Duty	5. 4L	BIF	1999 MY	PCM		•		
F-Series Super Duty	5. 4L	Other	1999 MY	ABS/TCS		•		
F-Series Super Duty	5. 4L	Other	1999 MY	ECS			•	0
F-Series Super Duty	5. 4L	Other	1999 MY	GEM	•	•	•	
F-Series Super Duty	5. 4L	Other	1999 MY	OTC	•	•	•	0
F-Series Super Duty	5. 4L	Other	1999 MY	PCM	•	•	•	•
F-Series Super Duty	5. 4L	Other	2000 MY	ABS/TCS	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	5. 4L	Other	2000 MY	ECS		•		0
F-Series Super Duty	5. 4L	Other	2000 MY	GEM	•	•	•	
F-Series Super Duty	5. 4L	Other	2000 MY	OTC		•		0
F-Series Super Duty	5. 4L	Other	2000 MY	PATS		•		
F-Series Super Duty	5. 4L	Other	2000 MY	PCM		•		
F-Series Super Duty	5. 4L	Other	2001 MY	ABS/TCS		•		
F-Series Super Duty	5. 4L	Other	2001 MY	ECS		•		0
F-Series Super Duty	5. 4L	Other	2001 MY	GEM	•	•	•	•
F-Series Super Duty	5. 4L	Other	2001 MY	OTC		•	•	0
F-Series Super Duty	5. 4L	Other	2001 MY	PAM		•	•	
F-Series Super Duty	5. 4L	Other	2001 MY	PCM			•	
F-Series Super Duty	5. 4L	Other	2001 MY	RCM	•	•	•	0
F-Series Super Duty	5. 4L	Other	2002 MY	ABS/TCS	•	•	•	
F-Series Super Duty	5. 4L	Other	2002 MY	CSM	•	•	•	•
F-Series Super Duty	5. 4L	Other	2002 MY	GEM		•	•	
F-Series Super Duty	5. 4L	Other	2002 MY	HEC		•	•	
F-Series Super Duty	5. 4L	Other	2002 MY	OTC	•	•	•	0
F-Series Super Duty	5. 4L	Other	2002 MY	PAM	•	•	•	
F-Series Super Duty	5. 4L	Other	2002 MY	PATS	•	•	•	•
F-Series Super Duty	5. 4L	Other	2002 MY	PCM	•	•	•	•
F-Series Super Duty	5. 4L	Other	2002 MY	RCM			•	
F-Series Super Duty	5. 4L	Other	2003 MY	ABS/TCS	•	•		
F-Series Super Duty	5. 4L	Other	2003 MY	FOH	•	•	•	
F-Series Super Duty	5. 4L	Other	2003 MY	GEM	•	•	•	•
F-Series Super Duty	5. 4L	Other	2003 MY	HEC	•	•	•	•
F-Series Super Duty	5. 4L	Other	2003 MY	OTC	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	5. 4L	Other	2003 MY	PAM		•		
F-Series Super Duty	5. 4L	Other	2003 MY	PATS		•		
F-Series Super Duty	5. 4L	Other	2003 MY	PCM		•		
F-Series Super Duty	5. 4L	Other	2003 MY	RCM		•	•	
F-Series Super Duty	5. 4L	Other	2003 MY	VSM		•		
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2003 MY	ABS/TCS		•	•	
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2003 MY	FOH		•	•	
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2003 MY	GEM		•		
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2003 MY	HEC		•	•	
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2003 MY	OTC	•		•	0
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2003 MY	PAM			•	
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2003 MY	PATS			•	
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2003 MY	PCM		•	•	
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2003 MY	RCM		•	•	
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2003 MY	TCM		•	•	
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2003 MY	VSM			•	
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2004 MY	ABS/TCS	•	•	•	
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2004 MY	FOH	•	•	•	
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2004 MY	GEM		•	•	
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2004 MY	HEC		•	•	
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2004 MY	OTC	•		•	0
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2004 MY	PAM			•	
F-Series Super Duty	6. 0L	Direct Injection - Turbo		PATS		•	•	•
F-Series Super Duty	6. 0L	Direct Injection - Turbo		PCM		•	•	•
F-Series Super Duty	6. 0L	Direct Injection - Turbo		RCM		•	•	•
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2004 MY	TCM	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2004 MY	VSM		•		
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2005 MY	ABS		•		•
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2005 MY	EATC		•		
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2005 MY	GEM		•		
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2005 MY	IC		•		
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2005 MY	PAM		•		
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2005 MY	PCM		•		
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2005 MY	RCM		•		•
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2005 MY	TBC		•		0
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2005 MY	TCM		•		
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2005 MY	VSM		•		
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2006 MY	ABS		•		
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2006 MY	EATC		•		
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2006 MY	GEM		•		•
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2006 MY	IC		•		
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2006 MY	PAM		•		•
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2006 MY	PCM		•		
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2006 MY	RCM		•	•	•
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2006 MY	TBC	•	•	•	0
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2006 MY	TCM		•		•
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2006 MY	VSM	•	•	•	
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2007 MY	ABS		•	•	
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2007 MY	EATC	•	•	•	
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2007 MY	GEM	•	•	•	•
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2007 MY	IC	•	•	•	•
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2007 MY	PAM	•	•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2007 MY	PCM	•	•		•
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2007 MY	RCM				
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2007 MY	TBC				0
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2007 MY	TCM		•		
F-Series Super Duty	6. 0L	Direct Injection - Turbo	2007 MY	VSM		•		
F-Series Super Duty	6. 2L	2V	2011 MY	ABS		•		
F-Series Super Duty	6. 2L	2V	2011 MY	ACM				
F-Series Super Duty	6. 2L	2V	2011 MY	ACM				0
F-Series Super Duty	6. 2L	2V	2011 MY	APIM				0
F-Series Super Duty	6. 2L	2V	2011 MY	BCM#1				
F-Series Super Duty	6. 2L	2V	2011 MY	DCSM	•	•	•	
F-Series Super Duty	6. 2L	2V	2011 MY	DSM		•		
F-Series Super Duty	6. 2L	2V	2011 MY	GPSM				0
F-Series Super Duty	6. 2L	2V	2011 MY	HVAC				
F-Series Super Duty	6. 2L	2V	2011 MY	IPC				
F-Series Super Duty	6. 2L	2V	2011 MY	PAM		•		0
F-Series Super Duty	6. 2L	2V	2011 MY	PCM		•	•	
F-Series Super Duty	6. 2L	2V	2011 MY	RCM		•	•	0
F-Series Super Duty	6. 2L	2V	2011 MY	SCCM	•	•	•	0
F-Series Super Duty	6. 2L	2V	2011 MY	SDARS				•
F-Series Super Duty	6. 2L	2V	2011 MY	TBC	•	•	•	0
F-Series Super Duty	6. 2L	2V	2011 MY	TCCM	•	•		•
F-Series Super Duty	6. 2L	2V	2011 MY	TPM	•	•	•	0
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2008 MY	4X4	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2008 MY	ABS	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2008 MY	ACM	•	•	•	0
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2008 MY	AHCM	•	•	•	0
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2008 MY	CDIM	•	•	•	0
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2008 MY	DSM	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2008 MY	GEM/SJB	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2008 MY	HVAC	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2008 MY	IC	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2008 MY	PAM	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2008 MY	PCM	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2008 MY	RCM	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2008 MY	RETM	•	•	•	0
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2008 MY	SDARS	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2008 MY	TBC	•	•	•	0
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2008 MY	TCM	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2009 MY	4X4	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2009 MY	ABS	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2009 MY	ACM	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2009 MY	AHCM	•	•	•	0
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2009 MY	APIM	•	•	•	0
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2009 MY	CDIM	•	•	•	0
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2009 MY	DSM	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2009 MY	GEM/SJB	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2009 MY	HVAC	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2009 MY	IC	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2009 MY	PAM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2009 MY	PCM	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2009 MY	RCM	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2009 MY	RETM	•	•	•	0
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2009 MY	SDARS	•	•	•	
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2009 MY	TBC	•	•	•	0
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2009 MY	TCM	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	4X4	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	ABS	•	•	•	
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	ACM	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	AHCM	•	•	•	0
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	APIM	•	•	•	0
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	CDIM	•	•	•	0
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	DSM	•	•	•	•

- This function is supported.
- O This function is not supported.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	GEM/SJB	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	GPSM	•	•	•	0
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	HVAC	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	IC	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	PAM	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	PCM	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	RCM	•	•	•	•
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	RETM	•	•	•	0
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	SDARS	•	•	•	
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	TBC	•	•	•	0
F-Series Super Duty	6. 4L	Power Stroke - Direct Injection Turbo Diesel	2010 MY	TCM	•	•	•	•
F-Series Super Duty	6.7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	ABS	•	•	•	•
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	ACM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	ACM	•	•	•	0
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	AHCM	•	•	•	0
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	APIM	•	•	•	0
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	BCM#1	•	•	•	•
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	CDIM	•	•	•	0
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	DCSM	•	•	•	•
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	DSM	•	•	•	•
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	GPSM	•	•	•	0
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	HVAC	•	•	•	•
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	IPC	•	•	•	•
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	PAM	•	•	•	0
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	PCM	•	•	•	•
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	RCM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	SCCM	•	•	•	0
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	SDARS	•	•	•	•
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	TBC	•	•	•	0
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	TCCM	•	•	•	•
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	TCM	•	•	•	•
F-Series Super Duty	6. 7L	Power Stroke - Direct Injection Turbo Diesel	2011 MY	TPM	•	•	•	0
F-Series Super Duty	6.8L	2V	2004 MY	ABS/TCS		•		•
F-Series Super Duty	6.8L	2V	2004 MY	GEM		•		•
F-Series Super Duty	6.8L	2V	2004 MY	HEC				
F-Series Super Duty	6.8L	2V	2004 MY	OTC		•		0
F-Series Super Duty	6.8L	2V	2004 MY	PAM		•		
F-Series Super Duty	6.8L	2V	2004 MY	PATS	•	•	•	
F-Series Super Duty	6.8L	2V	2004 MY	PCM		•		
F-Series Super Duty	6.8L	2V	2004 MY	RCM		•		
F-Series Super Duty	6.8L	2V	2004 MY	VSM	•	•		
F-Series Super Duty	6.8L	2V	2005 MY	ABS		•		
F-Series Super Duty	6.8L	2V	2005 MY	EATC	•	•		
F-Series Super Duty	6.8L	2V	2005 MY	GEM				
F-Series Super Duty	6.8L	2V	2005 MY	IC		•		
F-Series Super Duty	6. 8L	2V	2005 MY	PAM		•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	6.8L	2V	2005 MY	PCM		•		
F-Series Super Duty	6.8L	2V	2005 MY	RCM	•	•	•	
F-Series Super Duty	6.8L	2V	2005 MY	TBC		•		0
F-Series Super Duty	6.8L	2V	2005 MY	VSM	•	•		
F-Series Super Duty	6.8L	2V	2006 MY	ABS	•	•		
F-Series Super Duty	6.8L	2V	2006 MY	EATC	•	•		
F-Series Super Duty	6.8L	2V	2006 MY	GEM	•	•	•	•
F-Series Super Duty	6.8L	2V	2006 MY	IC	•	•	•	•
F-Series Super Duty	6.8L	2V	2006 MY	PAM	•	•	•	
F-Series Super Duty	6.8L	2V	2006 MY	PCM	•		•	
F-Series Super Duty	6.8L	2V	2006 MY	RCM	•	•	•	
F-Series Super Duty	6.8L	2V	2006 MY	TBC	•	•	•	0
F-Series Super Duty	6.8L	2V	2006 MY	VSM	•	•	•	•
F-Series Super Duty	6.8L	2V	2007 MY	ABS	•	•	•	•
F-Series Super Duty	6.8L	2V	2007 MY	EATC	•	•	•	
F-Series Super Duty	6.8L	2V	2007 MY	GEM	•	•	•	
F-Series Super Duty	6.8L	2V	2007 MY	IC	•	•	•	
F-Series Super Duty	6.8L	2V	2007 MY	PAM	•	•	•	
F-Series Super Duty	6.8L	2V	2007 MY	PCM	•	•	•	•
F-Series Super Duty	6.8L	2V	2007 MY	RCM	•	•	•	
F-Series Super Duty	6.8L	2V	2007 MY	TBC	•	•	•	0
F-Series Super Duty	6.8L	2V	2007 MY	VSM	•	•	•	•
F-Series Super Duty	6.8L	2V	2008 MY	4X4	•	•	•	•
F-Series Super Duty	6.8L	2V	2008 MY	ABS	•	•	•	•
F-Series Super Duty	6.8L	2V	2008 MY	ACM	•	•	•	0
F-Series Super Duty	6.8L	2V	2008 MY	DSM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	6.8L	2V	2008 MY	GEM/SJB	•	•		
F-Series Super Duty	6.8L	2V	2008 MY	HVAC		•		
F-Series Super Duty	6.8L	2V	2008 MY	IC		•		
F-Series Super Duty	6.8L	2V	2008 MY	PAM		•		
F-Series Super Duty	6.8L	2V	2008 MY	PCM		•		
F-Series Super Duty	6.8L	2V	2008 MY	RCM		•		
F-Series Super Duty	6.8L	2V	2008 MY	RETM	•	•	•	0
F-Series Super Duty	6.8L	2V	2008 MY	SDARS	•	•	•	
F-Series Super Duty	6.8L	2V	2008 MY	TBC		•		0
F-Series Super Duty	6.8L	3V	2005 MY	ABS	•	•	•	
F-Series Super Duty	6.8L	3V	2005 MY	EATC		•	•	
F-Series Super Duty	6.8L	3V	2005 MY	GEM	•	•	•	•
F-Series Super Duty	6.8L	3V	2005 MY	IC	•	•	•	•
F-Series Super Duty	6.8L	3V	2005 MY	PAM	•	•	•	•
F-Series Super Duty	6.8L	3V	2005 MY	PCM		•		
F-Series Super Duty	6.8L	3V	2005 MY	RCM		•		
F-Series Super Duty	6.8L	3V	2005 MY	TBC		•	•	0
F-Series Super Duty	6.8L	3V	2005 MY	VSM		•	•	•
F-Series Super Duty	6.8L	3V	2006 MY	ABS	•	•	•	•
F-Series Super Duty	6.8L	3V	2006 MY	EATC	•	•	•	•
F-Series Super Duty	6.8L	3V	2006 MY	GEM		•	•	•
F-Series Super Duty	6.8L	3V	2006 MY	IC	•	•	•	•
F-Series Super Duty	6.8L	3V	2006 MY	PAM	•	•		•
F-Series Super Duty	6.8L	3V	2006 MY	PCM	•	•	•	•
F-Series Super Duty	6.8L	3V	2006 MY	RCM	•	•		•
F-Series Super Duty	6.8L	3V	2006 MY	TBC	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	6.8L	3V	2006 MY	VSM		•		
F-Series Super Duty	6.8L	3V	2007 MY	ABS		•		
F-Series Super Duty	6.8L	3V	2007 MY	EATC		•		
F-Series Super Duty	6.8L	3V	2007 MY	GEM		•		
F-Series Super Duty	6.8L	3V	2007 MY	IC		•		
F-Series Super Duty	6.8L	3V	2007 MY	PAM		•		
F-Series Super Duty	6.8L	3V	2007 MY	PCM	•	•	•	•
F-Series Super Duty	6.8L	3V	2007 MY	RCM	•	•	•	
F-Series Super Duty	6.8L	3V	2007 MY	TBC		•	•	0
F-Series Super Duty	6.8L	3V	2007 MY	VSM	•	•	•	•
F-Series Super Duty	6.8L	3V	2008 MY	4X4		•	•	
F-Series Super Duty	6.8L	3V	2008 MY	ABS	•	•	•	
F-Series Super Duty	6.8L	3V	2008 MY	ACM	•	•	•	0
F-Series Super Duty	6.8L	3V	2008 MY	DSM	•	•	•	•
F-Series Super Duty	6.8L	3V	2008 MY	GEM/SJB		•	•	•
F-Series Super Duty	6.8L	3V	2008 MY	HVAC		•	•	
F-Series Super Duty	6.8L	3V	2008 MY	IC		•	•	
F-Series Super Duty	6.8L	3V	2008 MY	PAM	•	•	•	•
F-Series Super Duty	6.8L	3V	2008 MY	PCM	•	•	•	•
F-Series Super Duty	6.8L	3V	2008 MY	RCM	•	•	•	•
F-Series Super Duty	6.8L	3V	2008 MY	RETM	•	•	•	0
F-Series Super Duty	6.8L	3V	2008 MY	SDARS	•	•	•	
F-Series Super Duty	6. 8L	3V	2008 MY	TBC	•	•	•	0
F-Series Super Duty	6.8L	3V	2009 MY	4X4	•	•	•	•
F-Series Super Duty	6.8L	3V	2009 MY	ABS	•	•	•	•
F-Series Super Duty	6.8L	3V	2009 MY	ACM		•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	6.8L	3V	2009 MY	APIM		•		0
F-Series Super Duty	6.8L	3V	2009 MY	DSM	•	•	•	
F-Series Super Duty	6.8L	3V	2009 MY	GEM/SJB		•		
F-Series Super Duty	6.8L	3V	2009 MY	HVAC		•		
F-Series Super Duty	6.8L	3V	2009 MY	IC		•		
F-Series Super Duty	6.8L	3V	2009 MY	PAM		•		
F-Series Super Duty	6.8L	3V	2009 MY	PCM	•	•	•	•
F-Series Super Duty	6.8L	3V	2009 MY	RCM	•	•	•	•
F-Series Super Duty	6.8L	3V	2009 MY	RETM		•		0
F-Series Super Duty	6.8L	3V	2009 MY	SDARS		•	•	
F-Series Super Duty	6.8L	3V	2009 MY	TBC	•	•	•	0
F-Series Super Duty	6.8L	3V	2010 MY	4X4	•	•	•	
F-Series Super Duty	6.8L	3V	2010 MY	ABS	•	•	•	
F-Series Super Duty	6.8L	3V	2010 MY	ACM	•	•	•	
F-Series Super Duty	6.8L	3V	2010 MY	APIM		•		0
F-Series Super Duty	6.8L	3V	2010 MY	DSM		•	•	
F-Series Super Duty	6.8L	3V	2010 MY	GEM/SJB	•	•	•	
F-Series Super Duty	6.8L	3V	2010 MY	GPSM	•	•	•	0
F-Series Super Duty	6.8L	3V	2010 MY	HVAC	•	•	•	•
F-Series Super Duty	6.8L	3V	2010 MY	IC	•	•	•	
F-Series Super Duty	6.8L	3V	2010 MY	PAM			•	
F-Series Super Duty	6.8L	3V	2010 MY	PCM	•	•	•	•
F-Series Super Duty	6.8L	3V	2010 MY	RCM	•	•	•	•
F-Series Super Duty	6.8L	3V	2010 MY	RETM	•	•	•	0
F-Series Super Duty	6.8L	3V	2010 MY	SDARS	•	•	•	
F-Series Super Duty	6.8L	3V	2010 MY	TBC	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	6.8L	3V	2011 MY	ABS	•	•		
F-Series Super Duty	6.8L	3V	2011 MY	ACM		•		
F-Series Super Duty	6.8L	3V	2011 MY	ACM		•		0
F-Series Super Duty	6.8L	3V	2011 MY	APIM		•		0
F-Series Super Duty	6.8L	3V	2011 MY	BCM#1		•		
F-Series Super Duty	6.8L	3V	2011 MY	DCSM		•		
F-Series Super Duty	6.8L	3V	2011 MY	DSM		•		
F-Series Super Duty	6.8L	3V	2011 MY	GPSM		•		0
F-Series Super Duty	6.8L	3V	2011 MY	HVAC		•		
F-Series Super Duty	6.8L	3V	2011 MY	IPC				
F-Series Super Duty	6.8L	3V	2011 MY	PAM	•	•		0
F-Series Super Duty	6.8L	3V	2011 MY	PCM	•	•	•	
F-Series Super Duty	6.8L	3V	2011 MY	RCM		•		0
F-Series Super Duty	6.8L	3V	2011 MY	SCCM		•		0
F-Series Super Duty	6.8L	3V	2011 MY	SDARS				
F-Series Super Duty	6.8L	3V	2011 MY	TBC				0
F-Series Super Duty	6.8L	3V	2011 MY	TCCM		•		
F-Series Super Duty	6.8L	3V	2011 MY	TPM		•		0
F-Series Super Duty	6.8L	Other	1999 MY	ABS/TCS		•		
F-Series Super Duty	6.8L	Other	1999 MY	ECS		•		0
F-Series Super Duty	6.8L	Other	1999 MY	GEM	•	•	•	
F-Series Super Duty	6.8L	Other	1999 MY	OTC	•		•	0
F-Series Super Duty	6.8L	Other	1999 MY	PCM	•	•	•	
F-Series Super Duty	6.8L	Other	2000 MY	ABS/TCS		•	•	•
F-Series Super Duty	6.8L	Other	2000 MY	AFCM	•	•	•	0
F-Series Super Duty	6.8L	Other	2000 MY	ECS	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	6.8L	Other	2000 MY	GEM		•	•	
F-Series Super Duty	6.8L	Other	2000 MY	OTC		•	•	0
F-Series Super Duty	6.8L	Other	2000 MY	PATS		•		
F-Series Super Duty	6.8L	Other	2000 MY	PCM		•		
F-Series Super Duty	6.8L	Other	2001 MY	ABS/TCS		•		
F-Series Super Duty	6.8L	Other	2001 MY	AFCM		•	•	0
F-Series Super Duty	6.8L	Other	2001 MY	ECS		•		0
F-Series Super Duty	6.8L	Other	2001 MY	GEM		•	•	
F-Series Super Duty	6.8L	Other	2001 MY	OTC		•		0
F-Series Super Duty	6.8L	Other	2001 MY	PAM		•	•	
F-Series Super Duty	6.8L	Other	2001 MY	PCM			•	
F-Series Super Duty	6.8L	Other	2001 MY	RCM		•	•	0
F-Series Super Duty	6.8L	Other	2002 MY	ABS/TCS		•	•	
F-Series Super Duty	6.8L	Other	2002 MY	CSM		•		
F-Series Super Duty	6.8L	Other	2002 MY	GEM		•		
F-Series Super Duty	6.8L	Other	2002 MY	HEC		•	•	
F-Series Super Duty	6.8L	Other	2002 MY	OTC		•	•	0
F-Series Super Duty	6.8L	Other	2002 MY	PAM		•	•	
F-Series Super Duty	6.8L	Other	2002 MY	PATS		•	•	
F-Series Super Duty	6.8L	Other	2002 MY	PCM	•	•	•	•
F-Series Super Duty	6.8L	Other	2002 MY	RCM	•			
F-Series Super Duty	6.8L	Other	2003 MY	ABS/TCS	•	•	•	•
F-Series Super Duty	6.8L	Other	2003 MY	FOH		•	•	
F-Series Super Duty	6.8L	Other	2003 MY	GEM	•	•	•	•
F-Series Super Duty	6.8L	Other	2003 MY	HEC	•	•	•	•
F-Series Super Duty	6.8L	Other	2003 MY	OTC	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	6.8L	Other	2003 MY	PAM		•		
F-Series Super Duty	6.8L	Other	2003 MY	PATS		•		
F-Series Super Duty	6.8L	Other	2003 MY	PCM		•		
F-Series Super Duty	6.8L	Other	2003 MY	RCM		•	•	
F-Series Super Duty	6.8L	Other	2003 MY	VSM			•	
F-Series Super Duty	7. 3L	Direct Injection - Turbo	1999 MY	ABS/TCS			•	
F-Series Super Duty	7. 3L	Direct Injection - Turbo	1999 MY	ECS			•	0
F-Series Super Duty	7. 3L	Direct Injection - Turbo		GEM		•	•	
F-Series Super Duty	7. 3L	Direct Injection - Turbo	1999 MY	OTC	•	•	•	0
F-Series Super Duty	7. 3L	Direct Injection - Turbo	1999 MY	PCM	•	•	•	•
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2000 MY	ABS/TCS	•	•	•	•
F-Series Super Duty	7. 3L	Direct Injection - Turbo		ECS	•	•	•	0
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2000 MY	GEM		•	•	
F-Series Super Duty	7. 3L	Direct Injection - Turbo		OTC		•	•	0
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2000 MY	PATS	•	•	•	•
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2000 MY	PCM	•		•	
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2001 MY	ABS/TCS			•	
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2001 MY	ECS			•	0
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2001 MY	GEM		•	•	•
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2001 MY	OTC		•	•	0
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2001 MY	PAM	•		•	
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2001 MY	PCM			•	
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2001 MY	RCM		•	•	0
F-Series Super Duty	7. 3L	Direct Injection - Turbo		ABS/TCS	•	•	•	•
F-Series Super Duty	7. 3L	Direct Injection - Turbo		CSM	•	•	•	•
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2002 MY	GEM	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2002 MY	HEC		•		
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2002 MY	OTC		•		0
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2002 MY	PAM		•		
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2002 MY	PATS		•		
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2002 MY	PCM		•		
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2002 MY	RCM		•		
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2003 MY	ABS/TCS		•		
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2003 MY	FOH		•		
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2003 MY	GEM		•		
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2003 MY	HEC		•		
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2003 MY	OTC		•		0
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2003 MY	PAM		•		
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2003 MY	PATS		•		
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2003 MY	PCM		•		
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2003 MY	RCM		•		
F-Series Super Duty	7. 3L	Direct Injection - Turbo	2003 MY	VSM		•		
Fiesta	1.3L	BZ	2008.75 MY	ABS		•		0
Fiesta	1.3L	BZ	2008.75 MY	ACM		•		0
Fiesta	1.3L	BZ	2008.75 MY	BCMii		•		0
Fiesta	1.3L	BZ	2008.75 MY	FCDIM		•		0
Fiesta	1.3L	BZ	2008.75 MY	HVAC		•		0
Fiesta	1.3L	BZ	2008.75 MY	IPC		•		
Fiesta	1. 3L	BZ	2008.75 MY	PCM	•	•		
Fiesta	1. 3L	BZ	2008.75 MY	PSCM	•	•		0
Fiesta	1. 3L	BZ	2008.75 MY	RCM	•	•		0
Fiesta	1.3L	BZ	2008.75 MY	RFA	•	•		0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta	1. 3L	BZ	2008.75 MY	SRM		•		0
Fiesta	1. 3L	DURATEC 8V	2002 MY	ABS/TCS		•		
Fiesta	1. 3L	DURATEC 8V	2002 MY	GEM		•		
Fiesta	1. 3L	DURATEC 8V	2002 MY	IC		•		
Fiesta	1. 3L	DURATEC 8V	2002 MY	PCM		•		
Fiesta	1. 3L	DURATEC 8V	2002 MY	RCM		•		0
Fiesta	1. 3L	DURATEC 8V	2006 MY	ABS/TCS		•		
Fiesta	1. 3L	DURATEC 8V	2006 MY	ACM	•	•	•	0
Fiesta	1. 3L	DURATEC 8V	2006 MY	EATC		•		
Fiesta	1. 3L	DURATEC 8V	2006 MY	GEM		•	•	
Fiesta	1. 3L	DURATEC 8V	2006 MY	IC	•	•	•	
Fiesta	1. 3L	DURATEC 8V	2006 MY	PCM	•	•	•	
Fiesta	1. 3L	DURATEC 8V	2006 MY	RCM	•	•	•	0
Fiesta	1. 3L	DURATEC 8V	2006 MY	SRM		•		0
Fiesta	1. 4L	DURATEC 16V	2002 MY	ABS/TCS		•		
Fiesta	1. 4L	DURATEC 16V	2002 MY	GEM		•	•	
Fiesta	1. 4L	DURATEC 16V	2002 MY	IC	•	•	•	
Fiesta	1. 4L	DURATEC 16V	2002 MY	PCM	•	•	•	
Fiesta	1. 4L	DURATEC 16V	2002 MY	RCM	•	•	•	0
Fiesta	1. 4L	DURATEC 16V	2002 MY	TCM	•	•	•	0
Fiesta	1. 4L	DURATEC 16V	2006 MY	ABS/TCS			•	
Fiesta	1. 4L	DURATEC 16V	2006 MY	ACM	•	•		0
Fiesta	1. 4L	DURATEC 16V	2006 MY	EATC	•	•	•	
Fiesta	1.4L	DURATEC 16V	2006 MY	GEM	•	•	•	
Fiesta	1. 4L	DURATEC 16V	2006 MY	IC	•	•	•	•
Fiesta	1. 4L	DURATEC 16V	2006 MY	PCM	•	•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta	1.4L	DURATEC 16V	2006 MY	RCM		•		0
Fiesta	1.4L	DURATEC 16V	2006 MY	SRM		•		0
Fiesta	1.4L	DURATEC 16V	2006 MY	TCM		•		0
Fiesta	1.4L	DURATEC 16V	2008.75 MY	ABS				0
Fiesta	1.4L	DURATEC 16V	2008.75 MY	ACM		•		0
Fiesta	1.4L	DURATEC 16V	2008.75 MY	BCMii				0
Fiesta	1.4L	DURATEC 16V	2008.75 MY	FCDIM				0
Fiesta	1.4L	DURATEC 16V	2008.75 MY	HVAC				0
Fiesta	1.4L	DURATEC 16V	2008.75 MY	IPC				
Fiesta	1.4L	DURATEC 16V	2008.75 MY	PCM				0
Fiesta	1.4L	DURATEC 16V	2008.75 MY	PSCM		•		0
Fiesta	1.4L	DURATEC 16V	2008.75 MY	RCM				0
Fiesta	1.4L	DURATEC 16V	2008.75 MY	RFA		•		0
Fiesta	1.4L	DURATEC 16V	2008.75 MY	SRM				0
Fiesta	1.4L	DURATEC 16V	2008.75 MY	TCM				0
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	ABS/TCS	•	•	•	•
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	GEM	•	•	•	•
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	IC	•	•	•	•
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	PCM	•	•	•	•
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	RCM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	TCM	•	•	•	0
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	ABS/TCS	•	•	•	•
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	ACM	•	•	•	0
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	EATC	•	•	•	•
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	GEM	•	•	•	
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	IC	•	•	•	•
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	PCM	•	•	•	•
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	RCM	•	•	•	0
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	SRM	•	•	•	0
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	TCM	•	•	•	0
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	ABS	•	•	•	0
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	ACM	•	•	•	0
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	BCMii	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	FCDIM	•	•	•	0
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	HVAC	•	•	•	0
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	IPC	•	•	•	•
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	PCM	•	•	•	0
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	PSCM	•	•	•	0
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	RCM	•	•	•	0
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	RFA	•	•	•	0
Fiesta	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	SRM	•	•	•	0
Fiesta	1.5L	BZ	2008.75 MY	ABS		•		0
Fiesta	1.5L	BZ	2008.75 MY	ACM		•		0
Fiesta	1.5L	BZ	2008.75 MY	BCMii		•		0
Fiesta	1.5L	BZ	2008.75 MY	FCDIM		•		0
Fiesta	1.5L	BZ	2008.75 MY	HVAC		•		0
Fiesta	1.5L	BZ	2008.75 MY	IPC	•	•	•	
Fiesta	1.5L	BZ	2008.75 MY	PCM	•	•		
Fiesta	1.5L	BZ	2008.75 MY	PSCM		•		0
Fiesta	1. 5L	BZ	2008.75 MY	RCM	•	•		0
Fiesta	1.5L	BZ	2008.75 MY	RFA	•	•		0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta	1.5L	BZ	2008.75 MY	SRM	•	•		0
Fiesta	1.6L	DURATEC 16V	2002 MY	ABS/TCS	•	•	•	
Fiesta	1.6L	DURATEC 16V	2002 MY	GEM		•		
Fiesta	1.6L	DURATEC 16V	2002 MY	IC		•		
Fiesta	1.6L	DURATEC 16V	2002 MY	PCM		•		
Fiesta	1.6L	DURATEC 16V	2002 MY	RCM	•	•		0
Fiesta	1.6L	DURATEC 16V	2002 MY	TCM	•	•		0
Fiesta	1.6L	DURATEC 16V	2006 MY	ABS/TCS	•	•	•	
Fiesta	1.6L	DURATEC 16V	2006 MY	ACM	•	•		0
Fiesta	1.6L	DURATEC 16V	2006 MY	EATC	•	•		
Fiesta	1.6L	DURATEC 16V	2006 MY	GEM	•	•	•	
Fiesta	1.6L	DURATEC 16V	2006 MY	IC	•	•	•	
Fiesta	1.6L	DURATEC 16V	2006 MY	PCM	•	•	•	
Fiesta	1.6L	DURATEC 16V	2006 MY	RCM	•	•		0
Fiesta	1.6L	DURATEC 16V	2006 MY	SRM		•		0
Fiesta	1.6L	DURATEC 16V	2006 MY	TCM	•	•		0
Fiesta	1.6L	DURATEC VCT	2008.75 MY	ABS	•	•	•	0
Fiesta	1.6L	DURATEC VCT	2008.75 MY	ACM	•	•	•	0
Fiesta	1.6L	DURATEC VCT	2008.75 MY	BCMii	•	•	•	0
Fiesta	1.6L	DURATEC VCT	2008.75 MY	FCDIM	•	•	•	0
Fiesta	1.6L	DURATEC VCT	2008.75 MY	HVAC	•		•	0
Fiesta	1.6L	DURATEC VCT	2008.75 MY	IPC	•	•		•
Fiesta	1.6L	DURATEC VCT	2008.75 MY	PCM	•	•		0
Fiesta	1.6L	DURATEC VCT	2008.75 MY	PSCM	•	•	•	0
Fiesta	1.6L	DURATEC VCT		RCM	•	•		0
Fiesta	1.6L	DURATEC VCT	2008.75 MY	RFA	•	•		0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta	1.6L	DURATEC VCT	2008.75 MY	SRM	•	•	•	0
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	ABS/TCS	•	•	•	•
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	EPS	•	•	•	0
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	GEM	•	•	•	•
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	IC	•	•	•	•
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	PCM	•	•	•	•
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	RCM	•	•	•	0
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	ABS/TCS	•	•	•	•
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	ACM	•	•	•	0
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	EATC	•	•	•	•
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	EPS	•	•	•	0
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	GEM	•	•	•	
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	IC	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	PCM	•	•	•	•
Fiesta	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	RCM	•	•	•	0
Fiesta	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	SRM	•	•	•	0
Fiesta	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	ABS	•	•	•	0
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	ACM	•	•	•	0
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	BCMii	•	•	•	0
Fiesta	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	FCDIM	•	•	•	0
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	HVAC	•	•	•	0
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	IPC	•	•	•	•
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	PCM	•	•	•	0
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	PSCM	•	•	•	0
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	RCM	•	•	•	0
Fiesta	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	RFA	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	SRM	•	•	•	0
Fiesta	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.75 MY	ABS	•	•	•	0
Fiesta	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.75 MY	ACM	•	•	•	0
Fiesta	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.75 MY	BCMii	•	•	•	0
Fiesta	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.75 MY	FCDIM	•	•	•	0
Fiesta	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.75 MY	HVAC	•	•	•	0
Fiesta	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.75 MY	IPC	•	•	•	•
Fiesta	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.75 MY	PCM	•	•	•	0
Fiesta	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.75 MY	PSCM	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.75 MY	RCM	•	•	•	0
Fiesta	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.75 MY	RFA	•	•	•	0
Fiesta	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.75 MY	SRM	•	•	•	0
Fiesta	1.6L	TiVCT	2011 MY	ACM	•	•	•	0
Fiesta	1.6L	TiVCT	2011 MY	APIM		•		0
Fiesta	1.6L	TiVCT	2011 MY	FCDIM				
Fiesta	1.6L	TiVCT	2011 MY	GPSM				0
Fiesta	1.6L	TiVCT	2011 MY	IPC				
Fiesta	1.6L	TiVCT	2011 MY	OCSM				0
Fiesta	1.6L	TiVCT	2011 MY	PCM	•		•	
Fiesta	1.6L	TiVCT	2011 MY	RCM				0
Fiesta	1.6L	TiVCT	2011 MY	TCM				
Fiesta	1_25L	DURATEC 16V	2002 MY	ABS/TCS				
Fiesta	1_25L	DURATEC 16V	2002 MY	GEM				
Fiesta	1 25L	DURATEC 16V	2002 MY	IC				
Fiesta	1_25L	DURATEC 16V	2002 MY	PCM	•	•		
Fiesta	1_25L	DURATEC 16V	2002 MY	RCM	•	•		0
Fiesta	1_25L	DURATEC 16V	2006 MY	ABS/TCS	•	•	•	
Fiesta	1_25L	DURATEC 16V	2006 MY	ACM				0
Fiesta	1_25L	DURATEC 16V	2006 MY	EATC	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta	1_25L	DURATEC 16V	2006 MY	GEM		•		
Fiesta	1_25L	DURATEC 16V	2006 MY	IC				
Fiesta	1_25L	DURATEC 16V	2006 MY	PCM				
Fiesta	1_25L	DURATEC 16V	2006 MY	RCM				0
Fiesta	1_25L	DURATEC 16V	2006 MY	SRM				0
Fiesta	1_25L	DURATEC 16V	2008.75 MY	ABS				0
Fiesta	1_25L	DURATEC 16V	2008.75 MY	ACM				0
Fiesta	1_25L	DURATEC 16V	2008.75 MY	BCMii				0
Fiesta	1 25L	DURATEC 16V	2008.75 MY	FCDIM				0
Fiesta	1_25L	DURATEC 16V	2008.75 MY	HVAC				0
Fiesta	1_25L	DURATEC 16V	2008.75 MY	IPC		•		
Fiesta	1_25L	DURATEC 16V	2008.75 MY	PCM		•		0
Fiesta	1_25L	DURATEC 16V	2008.75 MY	PSCM		•		0
Fiesta	1_25L	DURATEC 16V	2008.75 MY	RCM		•		0
Fiesta	1 25L	DURATEC 16V	2008.75 MY	RFA				0
Fiesta	1_25L	DURATEC 16V	2008.75 MY	SRM				0
Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006. 25	ABS/TCS	•	•	•	•
Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006. 25	GEM	•	•	•	•
Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006. 25	IC	•	•	•	
Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006. 25	PCM	•	•	•	•
Fiesta / Ikon	1 4 DV4	Duratorq Turbo Diesel Common Rail Injection	2006. 25	RCM	•	•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta / Ikon	1.4L	DURATEC 16V	2006. 25	ABS/TCS		•	•	•
Fiesta / Ikon	1.4L	DURATEC 16V	2006. 25	GEM		•		
Fiesta / Ikon	1.4L	DURATEC 16V	2006. 25	IC		•		
Fiesta / Ikon	1.4L	DURATEC 16V	2006. 25	PCM		•		
Fiesta / Ikon	1.4L	DURATEC 16V	2006. 25	RCM		•	•	
Fiesta / Ikon	1.6L	DURATEC 16V	2006. 25	ABS/TCS		•		
Fiesta / Ikon	1.6L	DURATEC 16V	2006. 25	GEM		•		
Fiesta / Ikon	1.6L	DURATEC 16V	2006. 25	IC		•		
Fiesta / Ikon	1.6L	DURATEC 16V	2006. 25	PCM				
Fiesta / Ikon	1.6L	DURATEC 16V	2006. 25	RCM		•		
Fiesta / Mazda_121 / Bantam	1. 0L	HCS	1996.75 MY	ABS/TCS		•	•	0
Fiesta / Mazda_121 / Bantam	1. 0L	HCS	1996.75 MY	CSM		•		0
Fiesta / Mazda_121 / Bantam	1. 0L	HCS	1996.75 MY	HEC		•		
Fiesta / Mazda_121 / Bantam	1. 0L	HCS	1996.75 MY	PCM		•		
Fiesta / Mazda 121 / Bantam	1. 0L	HCS	1997.5 MY	ABS/TCS		•		0
Fiesta / Mazda 121 / Bantam	1.0L	HCS	1997.5 MY	CSM		•		0
Fiesta / Mazda_121 / Bantam	1. 0L	HCS	1997.5 MY	HEC		•	•	
Fiesta / Mazda_121 / Bantam	1. 0L	HCS	1997.5 MY	PCM		•		
Fiesta / Mazda_121 / Bantam	1. 0L	HCS	1999 MY	ABS/TCS		•		0
Fiesta / Mazda_121 / Bantam	1. 0L	HCS	1999 MY	CSM		•		0
Fiesta / Mazda 121 / Bantam	1. 0L	HCS	1999 MY	ECS		•		0
Fiesta / Mazda_121 / Bantam	1. 0L	HCS	1999 MY	HEC		•	•	•
Fiesta / Mazda_121 / Bantam	1. 0L	HCS	1999 MY	PCM		•		•
Fiesta / Mazda_121 / Bantam	1. 0L	Zetec Rocam	1999 MY	ABS/TCS		•		0
Fiesta / Mazda_121 / Bantam	1. 0L	Zetec Rocam	1999 MY	CSM		•		0
Fiesta / Mazda_121 / Bantam	1. 0L	Zetec Rocam	1999 MY	ECS	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta / Mazda_121 / Bantam	1. 0L	Zetec Rocam	1999 MY	HEC				
Fiesta / Mazda_121 / Bantam	1. 0L	Zetec Rocam	1999 MY	PCM		•		
Fiesta / Mazda_121 / Bantam	1. 0L	Zetec Rocam	1999.75 MY	ABS/TCS		•		0
Fiesta / Mazda 121 / Bantam	1. 0L	Zetec Rocam	1999.75 MY	CSM		•		0
Fiesta / Mazda_121 / Bantam	1. 0L	Zetec Rocam	1999.75 MY	ECS		•		0
Fiesta / Mazda_121 / Bantam	1. 0L	Zetec Rocam	1999.75 MY	GEM		•		
Fiesta / Mazda_121 / Bantam	1. 0L	Zetec Rocam	1999.75 MY	HEC		•		
Fiesta / Mazda_121 / Bantam	1. 0L	Zetec Rocam	1999.75 MY	PCM		•	•	
Fiesta / Mazda 121 / Bantam	1. 3L	Endura-E	1996 MY	ABS/TCS		•		0
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1996 MY	CSM		•		0
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1996 MY	HEC		•	•	
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1996 MY	PCM		•	•	
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1996.75 MY	ABS/TCS		•	•	0
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1996.75 MY	CSM		•		0
Fiesta / Mazda 121 / Bantam	1. 3L	Endura-E	1996.75 MY	HEC				
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1996.75 MY	PCM		•		
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1997.5 MY	ABS/TCS		•	•	0
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1997.5 MY	CSM		•	•	0
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1997.5 MY	HEC		•	•	
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1997.5 MY	PCM		•	•	
Fiesta / Mazda 121 / Bantam	1. 3L	Endura-E	19985 MY	ABS/TCS	•			0
Fiesta / Mazda 121 / Bantam	1. 3L	Endura-E	19985 MY	CSM				0
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	19985 MY	HEC		•	•	
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	19985 MY	PCM	•	•	•	•
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1999 MY	ABS/TCS	•	•	•	0
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1999 MY	CSM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1999 MY	ECS	•	•		0
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1999 MY	HEC	•	•	•	•
Fiesta / Mazda_121 / Bantam	1. 3L	Endura-E	1999 MY	PCM		•		
Fiesta / Mazda 121 / Bantam	1.3L	Endura-E	1999.5 MY	ABS/TCS		•		0
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1999.5 MY	CSM		•		0
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1999.5 MY	ECS		•		0
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1999.5 MY	GEM		•		
Fiesta / Mazda_121 / Bantam	1.3L	Endura-E	1999.5 MY	HEC		•		
Fiesta / Mazda 121 / Bantam	1. 3L	Endura-E	1999.5 MY	PCM		•		
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1994 MY	ABS/TCS	•	•	•	0
Fiesta / Mazda_121 / Bantam	1.4L	1.4 PT-E SFI	1994 MY	CSM	•	•	•	0
Fiesta / Mazda_121 / Bantam	1.4L	1.4 PT-E SFI	1994 MY	HEC	•	•	•	•
Fiesta / Mazda_121 / Bantam	1.4L	1.4 PT-E SFI	1994.5 MY	ABS/TCS	•	•	•	0
Fiesta / Mazda_121 / Bantam	1.4L	1.4 PT-E SFI	1994.5 MY	CSM		•		0
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1994.5 MY	HEC		•		
Fiesta / Mazda 121 / Bantam	1.4L	1.4 PT-E SFI	1996 MY	ABS/TCS		•		0
Fiesta / Mazda_121 / Bantam	1.4L	1.4 PT-E SFI	1996 MY	CSM		•	•	0
Fiesta / Mazda_121 / Bantam	1.4L	1.4 PT-E SFI	1996 MY	HEC		•	•	•
Fiesta / Mazda_121 / Bantam	1.4L	PT-E	2000 MY	ABS/TCS	•	•	•	0
Fiesta / Mazda_121 / Bantam	1.4L	PT-E	2000 MY	CSM	•	•	•	0
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000 MY	ECS	•	•	•	0
Fiesta / Mazda 121 / Bantam	1.4L	PT-E	2000 MY	HEC		•	•	
Fiesta / Mazda_121 / Bantam	1.4L	РТ-Е	2000 MY	PCM	•	•		0
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1996.5 MY	ABS/TCS	•	•	•	0
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1996.5 MY	CSM	•	•	•	0
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1996.5 MY	HEC	•	•		•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1996.5 MY	PCM		•		
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1996.75 MY	ABS/TCS		•		0
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1996.75 MY	CSM		•		0
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1996.75 MY	HEC		•		
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1996.75 MY	PCM		•		
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1997 MY	ABS/TCS		•		0
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1997 MY	CSM		•		0
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1997 MY	HEC		•		
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	1997 MY	PCM				
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1997.5 MY	ABS/TCS		•		0
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1997.5 MY	CSM		•		0
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1997.5 MY	HEC		•		
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1997.5 MY	PCM		•		
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	19985 MY	ABS/TCS				0
Fiesta / Mazda 121 / Bantam	1.4L	Zetec-SE	19985 MY	CSM				0
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	19985 MY	HEC				
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	19985 MY	PCM	•			
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1999.5 MY	ABS/TCS				0
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1999.5 MY	CSM				0
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1999.5 MY	ECS				0
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1999.5 MY	GEM				
Fiesta / Mazda_121 / Bantam	1.4L	Zetec-SE	1999.5 MY	HEC	•	•		
Fiesta / Mazda_121 / Bantam	1. 4L	Zetec-SE	1999.5 MY	PCM	•	•		
Fiesta / Mazda_121 / Bantam	1.6L	Other	2001 MY	ABS/TCS	•	•	•	0
Fiesta / Mazda_121 / Bantam	1.6L	Other	2001 MY	CSM	•	•		0
Fiesta / Mazda_121 / Bantam	1.6L	Other	2001 MY	GEM		•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta / Mazda_121 / Bantam	1.6L	Other	2001 MY	HEC	•	•		
Fiesta / Mazda_121 / Bantam	1.6L	Other	2001 MY	PATS	•	•		
Fiesta / Mazda_121 / Bantam	1.6L	Other	2001 MY	PCM	•	•		0
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999 MY	ABS/TCS	•	•		0
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999 MY	CSM	•	•		0
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999 MY	ECS	•	•		0
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999 MY	HEC	•	•		
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999 MY	PCM	•	•		
Fiesta / Mazda 121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	ABS/TCS	•	•		0
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	CSM	•	•		0
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	ECS	•	•	•	0
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	GEM	•	•		
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	HEC	•	•		
Fiesta / Mazda_121 / Bantam	1.6L	Zetec Rocam	1999.75 MY	PCM	•	•		
Fiesta / Mazda 121 / Bantam	1.6L	Zetec-SE	2000 MY	ABS/TCS				0
Fiesta / Mazda_121 / Bantam	1.6L	Zetec-SE	2000 MY	CSM		•		0
Fiesta / Mazda_121 / Bantam	1.6L	Zetec-SE	2000 MY	ECS	•	•		0
Fiesta / Mazda_121 / Bantam	1.6L	Zetec-SE	2000 MY	GEM	•	•		
Fiesta / Mazda_121 / Bantam	1.6L	Zetec-SE	2000 MY	HEC	•	•		
Fiesta / Mazda_121 / Bantam	1.6L	Zetec-SE	2000 MY	PCM	•	•		
Fiesta / Mazda 121 / Bantam	1.8L	Endura DI	2000 MY	ABS/TCS	•	•		0
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000 MY	CSM	•	•		0
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000 MY	ECS	•	•		0
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000 MY	FIP	•	•	•	0
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000 MY	GEM	•	•	•	•
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000 MY	HEC	•	•		

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000 MY	PATS		•		
Fiesta / Mazda_121 / Bantam	1.8L	Endura DI	2000 MY	PCM		•		
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996. 25 MY	ABS/TCS		•		0
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	1996.25 MY	CSM		•		0
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996.25 MY	ECS		•		0
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996.25 MY	HEC		•		
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996.25 MY	PATS		•		
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	1996.25 MY	PCM		•	•	0
Fiesta / Mazda 121 / Bantam	1.8L	Endura-DE	Other	ABS/TCS		•		0
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	Other	CSM		•		0
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	Other	ECS		•	•	0
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	Other	HEC		•	•	
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	Other	PATS		•	•	
Fiesta / Mazda_121 / Bantam	1.8L	Endura-DE	Other	PCM		•		0
Fiesta / Mazda 121 / Bantam	1.8L	Zetec	1992 MY	ABS/TCS		•		0
Fiesta / Mazda_121 / Bantam	1.8L	Zetec	1992 MY	CSM		•		0
Fiesta / Mazda_121 / Bantam	1.8L	Zetec	1992 MY	HEC		•	•	
Fiesta / Mazda_121 / Bantam	1.8L	Zetec	1994.5 MY	ABS/TCS		•	•	0
Fiesta / Mazda_121 / Bantam	1.8L	Zetec	1994.5 MY	CSM		•	•	0
Fiesta / Mazda_121 / Bantam	1.8L	Zetec	1994.5 MY	HEC	•	•	•	
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1996 MY	ABS/TCS	•			0
Fiesta / Mazda 121 / Bantam	1_25L	Zetec-SE	1996 MY	CSM				0
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	1996 MY	HEC	•	•	•	
Fiesta / Mazda 121 / Bantam	1_25L	Zetec-SE	1996 MY	PCM	•	•	•	•
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	1997.5 MY	ABS/TCS	•	•	•	0
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	1997.5 MY	CSM				0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	1997.5 MY	HEC		•		
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	1997.5 MY	PCM		•		
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	19985 MY	ABS/TCS		•		0
Fiesta / Mazda 121 / Bantam	1_25L	Zetec-SE	19985 MY	CSM		•		0
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	19985 MY	HEC		•		
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	19985 MY	PCM		•		
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	1999 MY	ABS/TCS		•		0
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	1999 MY	CSM		•		0
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1999 MY	ECS		•		0
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	1999 MY	HEC		•		
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	1999 MY	PCM		•		
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	1999.5 MY	ABS/TCS		•		0
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	1999.5 MY	CSM		•		0
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	1999.5 MY	ECS		•		0
Fiesta / Mazda 121 / Bantam	1 25L	Zetec-SE	1999.5 MY	GEM				
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	1999.5 MY	HEC		•		
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	1999.5 MY	PCM		•		
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	2000 MY	ABS/TCS		•		0
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	2000 MY	CSM		•		0
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	2000 MY	ECS		•		0
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	2000 MY	GEM		•		
Fiesta / Mazda 121 / Bantam	1_25L	Zetec-SE	2000 MY	HEC		•	•	
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	2000 MY	PATS	•	•	•	
Fiesta / Mazda_121 / Bantam	1_25L	Zetec-SE	2000 MY	PCM	•	•	•	
Fiesta 3-Door	1. 3L	DURATEC 8V	2002 MY	ABS/TCS		•		
Fiesta 3-Door	1. 3L	DURATEC 8V	2002 MY	GEM	•	•		

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta 3-Door	1. 3L	DURATEC 8V	2002 MY	IC	•	•		
Fiesta 3-Door	1. 3L	DURATEC 8V	2002 MY	PCM	•	•		
Fiesta 3-Door	1. 3L	DURATEC 8V	2002 MY	RCM	•	•		
Fiesta 3-Door	1. 3L	DURATEC 8V	2006 MY	ABS/TCS	•	•		
Fiesta 3-Door	1. 3L	DURATEC 8V	2006 MY	ACM	•	•		0
Fiesta 3-Door	1. 3L	DURATEC 8V	2006 MY	EATC	•	•		
Fiesta 3-Door	1. 3L	DURATEC 8V	2006 MY	GEM	•	•		
Fiesta 3-Door	1. 3L	DURATEC 8V	2006 MY	IC	•	•	•	
Fiesta 3-Door	1. 3L	DURATEC 8V	2006 MY	PCM	•	•		
Fiesta 3-Door	1. 3L	DURATEC 8V	2006 MY	RCM	•	•	•	0
Fiesta 3-Door	1. 3L	DURATEC 8V	2006 MY	SRM	•	•	•	0
Fiesta 3-Door	1. 4L	DURATEC 16V	2002 MY	ABS/TCS	•	•	•	•
Fiesta 3-Door	1.4L	DURATEC 16V	2002 MY	GEM	•	•	•	•
Fiesta 3-Door	1.4L	DURATEC 16V	2002 MY	IC	•	•		
Fiesta 3-Door	1.4L	DURATEC 16V	2002 MY	PCM	•	•		
Fiesta 3-Door	1.4L	DURATEC 16V	2002 MY	RCM	•	•		
Fiesta 3-Door	1.4L	DURATEC 16V	2002 MY	TCM	•	•	•	0
Fiesta 3-Door	1.4L	DURATEC 16V	2006 MY	ABS/TCS	•	•	•	
Fiesta 3-Door	1.4L	DURATEC 16V	2006 MY	ACM	•	•	•	0
Fiesta 3-Door	1.4L	DURATEC 16V	2006 MY	EATC	•	•	•	•
Fiesta 3-Door	1.4L	DURATEC 16V	2006 MY	GEM	•	•	•	
Fiesta 3-Door	1.4L	DURATEC 16V	2006 MY	IC	•	•	•	
Fiesta 3-Door	1. 4L	DURATEC 16V	2006 MY	PCM	•	•		•
Fiesta 3-Door	1.4L	DURATEC 16V	2006 MY	RCM	•	•	•	0
Fiesta 3-Door	1. 4L	DURATEC 16V	2006 MY	SRM	•	•		0
Fiesta 3-Door	1. 4L	DURATEC 16V	2006 MY	TCM	•	•		0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	ABS/TCS	•	•	•	•
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	GEM	•	•	•	•
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	IC	•	•	•	•
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	PCM	•	•	•	•
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	RCM	•	•	•	
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	TCM	•	•	•	0
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	ABS/TCS	•	•	•	•
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	ACM	•	•	•	0
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	EATC	•	•	•	•
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	GEM	•	•	•	•
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	IC	•	•	•	•
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	PCM	•	•	•	•
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	RCM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta 3-Door	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	SRM	•	•	•	0
Fiesta 3-Door	1.4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	TCM	•	•	•	0
Fiesta 3-Door	1.6L	DURATEC 16V	2002 MY	ABS/TCS		•		•
Fiesta 3-Door	1.6L	DURATEC 16V	2002 MY	GEM				
Fiesta 3-Door	1.6L	DURATEC 16V	2002 MY	IC				
Fiesta 3-Door	1.6L	DURATEC 16V	2002 MY	PCM		•		
Fiesta 3-Door	1.6L	DURATEC 16V	2002 MY	RCM		•	•	
Fiesta 3-Door	1.6L	DURATEC 16V	2002 MY	TCM		•	•	0
Fiesta 3-Door	1.6L	DURATEC 16V	2006 MY	ABS/TCS	•	•	•	
Fiesta 3-Door	1.6L	DURATEC 16V	2006 MY	ACM	•	•	•	0
Fiesta 3-Door	1.6L	DURATEC 16V	2006 MY	EATC	•	•	•	•
Fiesta 3-Door	1.6L	DURATEC 16V	2006 MY	GEM	•	•	•	•
Fiesta 3-Door	1.6L	DURATEC 16V	2006 MY	IC		•		
Fiesta 3-Door	1.6L	DURATEC 16V	2006 MY	PCM			•	
Fiesta 3-Door	1.6L	DURATEC 16V	2006 MY	RCM		•	•	0
Fiesta 3-Door	1. 6L	DURATEC 16V	2006 MY	SRM	•	•	•	0
Fiesta 3-Door	1.6L	DURATEC 16V	2006 MY	TCM	•	•	•	0
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	ABS/TCS	•	•	•	•
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	EPS	•	•	•	0
Fiesta 3-Door	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	GEM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
Fiesta 3-Door	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	IC	•	•	•	•
Fiesta 3-Door	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	PCM	•	•	•	•
Fiesta 3-Door	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	RCM	•	•	•	
Fiesta 3-Door	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	ABS/TCS	•	•	•	•
Fiesta 3-Door	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	ACM	•	•	•	0
Fiesta 3-Door	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	EATC	•	•	•	•
Fiesta 3-Door	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	EPS	•	•	•	0
Fiesta 3-Door	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	GEM	•	•	•	•
Fiesta 3-Door	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	IC	•	•	•	
Fiesta 3-Door	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	PCM	•	•	•	•
Fiesta 3-Door	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	RCM	•	•	•	0
Fiesta 3-Door	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	SRM	•	•	•	0
Fiesta 3-Door	1_25L	DURATEC 16V	2002 MY	ABS/TCS	•	•	•	•
Fiesta 3-Door	1_25L	DURATEC 16V	2002 MY	GEM				

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fiesta 3-Door	1_25L	DURATEC 16V	2002 MY	IC		•		
Fiesta 3-Door	1_25L	DURATEC 16V	2002 MY	PCM		•		
Fiesta 3-Door	1_25L	DURATEC 16V	2002 MY	RCM		•		
Fiesta 3-Door	1_25L	DURATEC 16V	2006 MY	ABS/TCS		•		
Fiesta 3-Door	1_25L	DURATEC 16V	2006 MY	ACM		•		0
Fiesta 3-Door	1_25L	DURATEC 16V	2006 MY	EATC	•	•		
Fiesta 3-Door	1_25L	DURATEC 16V	2006 MY	GEM	•	•		
Fiesta 3-Door	1_25L	DURATEC 16V	2006 MY	IC	•	•	•	•
Fiesta 3-Door	1 25L	DURATEC 16V	2006 MY	PCM	•	•		
Fiesta 3-Door	1_25L	DURATEC 16V	2006 MY	RCM	•	•		0
Fiesta 3-Door	1_25L	DURATEC 16V	2006 MY	SRM	•	•	•	0
Fiesta 3-Door	2. 0L	DURATEC-HE / I4	2002 MY	ABS/TCS	•	•	•	
Fiesta 3-Door	2. 0L	DURATEC-HE / I4	2002 MY	GEM	•	•	•	•
Fiesta 3-Door	2. 0L	DURATEC-HE / I4	2002 MY	IC	•	•		
Fiesta 3-Door	2. 0L	DURATEC-HE / I4	2002 MY	PCM		•		
Fiesta 3-Door	2. 0L	DURATEC-HE / I4	2002 MY	RCM	•	•		
Fiesta 3-Door	2. 0L	DURATEC-HE / I4	2006 MY	ABS/TCS	•	•	•	
Fiesta 3-Door	2. 0L	DURATEC-HE / I4	2006 MY	ACM	•	•	•	0
Fiesta 3-Door	2. 0L	DURATEC-HE / I4	2006 MY	EATC	•	•	•	•
Fiesta 3-Door	2. 0L	DURATEC-HE / I4	2006 MY	GEM	•	•	•	
Fiesta 3-Door	2. 0L	DURATEC-HE / I4	2006 MY	IC		•	•	
Fiesta 3-Door	2. 0L	DURATEC-HE / I4	2006 MY	PCM		•		•
Fiesta 3-Door	2. 0L	DURATEC-HE / I4	2006 MY	RCM	•	•		0
Fiesta 3-Door	2. 0L	DURATEC-HE / I4	2006 MY	SRM	•	•	•	0
Focus	1. 4L	DURATEC 16V	2003.25 MY	ABS	•	•		•
Focus	1.4L	DURATEC 16V	2003.25 MY	ACM	•	•		0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.4L	DURATEC 16V	2003.25 MY	CDP	•	•		0
Focus	1.4L	DURATEC 16V	2003. 25 MY	D_DCU	•	•		•
Focus	1.4L	DURATEC 16V	2003. 25 MY	EATC	•	•		
Focus	1.4L	DURATEC 16V	2003.25 MY	FFH	•	•		
Focus	1.4L	DURATEC 16V	2003.25 MY	GDM	•	•		0
Focus	1.4L	DURATEC 16V	2003. 25 MY	GEM	•	•		
Focus	1.4L	DURATEC 16V	2003. 25 MY	HCM	•	•		0
Focus	1.4L	DURATEC 16V	2003. 25 MY	IC	•	•		
Focus	1.4L	DURATEC 16V	2003.25 MY	NAV	•	•		0
Focus	1.4L	DURATEC 16V	2003.25 MY	P_DCU	•	•		
Focus	1.4L	DURATEC 16V	2003.25 MY	PAM	•	•		0
Focus	1.4L	DURATEC 16V	2003.25 MY	PCM	•	•		
Focus	1.4L	DURATEC 16V	2003.25 MY	RETM	•	•		0
Focus	1.4L	DURATEC 16V	2003. 25 MY	RKE	•	•		0
Focus	1.4L	DURATEC 16V	2003.25 MY	RL DCU				
Focus	1.4L	DURATEC 16V	2003.25 MY	RR_DCU		•		
Focus	1.4L	DURATEC 16V	2003.25 MY	SRM	•	•		0
Focus	1.4L	DURATEC 16V	2008. 25 MY	ABS	•	•		
Focus	1.4L	DURATEC 16V	2008. 25 MY	ACM	•	•		0
Focus	1.4L	DURATEC 16V	2008. 25 MY	CDP	•	•		0
Focus	1.4L	DURATEC 16V	2008.25 MY	CMR	•	•		0
Focus	1.4L	DURATEC 16V	2008.25 MY	D_DCU	•	•	•	
Focus	1.4L	DURATEC 16V	2008.25 MY	EATC	•	•	•	
Focus	1.4L	DURATEC 16V	2008.25 MY	EPS	•	•	•	0
Focus	1.4L	DURATEC 16V		FFH	•	•		•
Focus	1.4L	DURATEC 16V	2008.25 MY	GEM	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.4L	DURATEC 16V	2008.25 MY	HCM	•	•		0
Focus	1.4L	DURATEC 16V	2008. 25 MY	IC	•	•	•	•
Focus	1.4L	DURATEC 16V	2008. 25 MY	P_DCU	•	•		
Focus	1.4L	DURATEC 16V	2008. 25 MY	PAM		•		0
Focus	1.4L	DURATEC 16V	2008. 25 MY	PCM		•		
Focus	1.4L	DURATEC 16V	2008. 25 MY	RCM		•		0
Focus	1.4L	DURATEC 16V	2008. 25 MY	RETM		•		0
Focus	1.4L	DURATEC 16V	2008. 25 MY	RKE		•		0
Focus	1.4L	DURATEC 16V	2008. 25 MY	SRM		•		0
Focus	1.4L	DURATEC 16V	MY07_5	ABS	•	•		
Focus	1.4L	DURATEC 16V	MY07_5	ACM		•		0
Focus	1.4L	DURATEC 16V	MY07_5	CDP		•		0
Focus	1.4L	DURATEC 16V	MY07_5	D_DCU		•		
Focus	1.4L	DURATEC 16V	MY07_5	EATC				
Focus	1.4L	DURATEC 16V	MY07 5	FFH				
Focus	1.4L	DURATEC 16V	MY07_5	GDM		•		0
Focus	1.4L	DURATEC 16V	MY07_5	GEM				•
Focus	1.4L	DURATEC 16V	MY07_5	HCM				0
Focus	1.4L	DURATEC 16V	MY07_5	IC				
Focus	1.4L	DURATEC 16V	MY07_5	NAV				0
Focus	1.4L	DURATEC 16V	MY07_5	P_DCU		•		
Focus	1.4L	DURATEC 16V	MY07_5	PAM	•	•		0
Focus	1.4L	DURATEC 16V	MY07_5	PCM	•	•		
Focus	1.4L	DURATEC 16V	MY07_5	RETM	•	•		0
Focus	1.4L	DURATEC 16V	MY07_5	RKE	•	•	•	0
Focus	1.4L	DURATEC 16V	MY07_5	SRM	•	•		0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.4L	Zetec-SE	1999 MY	ABS/TCS		•		•
Focus	1.4L	Zetec-SE	1999 MY	CSM				
Focus	1.4L	Zetec-SE	1999 MY	CTM				
Focus	1.4L	Zetec-SE	1999 MY	ECS				0
Focus	1.4L	Zetec-SE	1999 MY	HEC				•
Focus	1.4L	Zetec-SE	1999 MY	MC				•
Focus	1.4L	Zetec-SE	1999 MY	PATS				0
Focus	1.4L	Zetec-SE	1999 MY	PCM		•		
Focus	1.4L	Zetec-SE	2002 MY	ABS/TCS				
Focus	1.4L	Zetec-SE	2002 MY	EATC		•		
Focus	1.4L	Zetec-SE	2002 MY	ECS		•		0
Focus	1.4L	Zetec-SE	2002 MY	GEM		•		
Focus	1.4L	Zetec-SE	2002 MY	HCM		•		0
Focus	1.4L	Zetec-SE	2002 MY	HEC		•		
Focus	1. 4L	Zetec-SE	2002 MY	MC		•		
Focus	1.4L	Zetec-SE	2002 MY	PATS		•		0
Focus	1.4L	Zetec-SE	2002 MY	PCM		•		
Focus	1.4L	Zetec-SE	2002 MY	RCM		•		
Focus	1.6L	DURATEC 16V	2003.25 MY	ABS		•		
Focus	1.6L	DURATEC 16V	2003.25 MY	ACM		•		0
Focus	1.6L	DURATEC 16V	2003.25 MY	CDP		•	•	0
Focus	1.6L	DURATEC 16V	2003.25 MY	D_DCU	•	•	•	•
Focus	1.6L	DURATEC 16V	2003.25 MY	EATC		•	•	•
Focus	1.6L	DURATEC 16V	2003.25 MY	FFH		•	•	
Focus	1.6L	DURATEC 16V	2003.25 MY	GDM	•	•	•	0
Focus	1.6L	DURATEC 16V	2003.25 MY	GEM		•		

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1. 6L	DURATEC 16V	2003.25 MY	HCM	•	•		0
Focus	1.6L	DURATEC 16V	2003. 25 MY	IC	•	•	•	•
Focus	1.6L	DURATEC 16V	2003.25 MY	NAV	•	•		0
Focus	1.6L	DURATEC 16V	2003.25 MY	P_DCU		•		
Focus	1.6L	DURATEC 16V	2003.25 MY	PAM		•		0
Focus	1.6L	DURATEC 16V	2003.25 MY	PCM		•		
Focus	1.6L	DURATEC 16V	2003. 25 MY	RETM		•		0
Focus	1.6L	DURATEC 16V	2003. 25 MY	RKE		•		0
Focus	1.6L	DURATEC 16V	2003.25 MY	RL DCU		•		
Focus	1.6L	DURATEC 16V	2003.25 MY	RR_DCU	•	•		
Focus	1.6L	DURATEC 16V	2003.25 MY	SRM		•		0
Focus	1.6L	DURATEC 16V	2003.25 MY	TCM	•	•		0
Focus	1.6L	DURATEC 16V	2008. 25 MY	ABS		•		
Focus	1.6L	DURATEC 16V	2008. 25 MY	ACM		•		0
Focus	1.6L	DURATEC 16V	2008.25 MY	CDP				0
Focus	1.6L	DURATEC 16V	2008.25 MY	CMR		•		0
Focus	1.6L	DURATEC 16V	2008.25 MY	D_DCU		•		
Focus	1.6L	DURATEC 16V	2008. 25 MY	EATC		•		
Focus	1.6L	DURATEC 16V	2008. 25 MY	EPS		•		0
Focus	1.6L	DURATEC 16V	2008.25 MY	FFH				
Focus	1.6L	DURATEC 16V	2008.25 MY	GEM		•		
Focus	1.6L	DURATEC 16V	2008.25 MY	HCM	•	•		0
Focus	1.6L	DURATEC 16V	2008.25 MY	IC	•	•		
Focus	1.6L	DURATEC 16V	2008.25 MY	P_DCU	•	•		
Focus	1.6L	DURATEC 16V	2008.25 MY	PAM	•	•	•	0
Focus	1.6L	DURATEC 16V	2008.25 MY	PCM	•	•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.6L	DURATEC 16V	2008.25 MY	RCM	•	•	•	0
Focus	1. 6L	DURATEC 16V	2008. 25 MY	RETM	•	•	•	0
Focus	1. 6L	DURATEC 16V	2008. 25 MY	RKE		•		0
Focus	1. 6L	DURATEC 16V	2008. 25 MY	SRM	•	•		0
Focus	1. 6L	DURATEC 16V	2008. 25 MY	TCM	•	•	•	0
Focus	1. 6L	DURATEC 16V	MY07_5	ABS	•	•	•	
Focus	1. 6L	DURATEC 16V	MY07_5	ACM	•	•	•	0
Focus	1. 6L	DURATEC 16V	MY07_5	CDP	•	•	•	0
Focus	1. 6L	DURATEC 16V	MY07 5	D DCU		•		
Focus	1. 6L	DURATEC 16V	MY07_5	EATC	•	•		
Focus	1. 6L	DURATEC 16V	MY07_5	FFH	•	•	•	
Focus	1. 6L	DURATEC 16V	MY07_5	GDM	•	•	•	0
Focus	1.6L	DURATEC 16V	MY07_5	GEM		•		
Focus	1.6L	DURATEC 16V	MY07_5	HCM		•		0
Focus	1. 6L	DURATEC 16V	MY07 5	IC		•		
Focus	1.6L	DURATEC 16V	MY07_5	NAV		•		0
Focus	1.6L	DURATEC 16V	MY07_5	P_DCU		•		
Focus	1.6L	DURATEC 16V	MY07_5	PAM		•		0
Focus	1.6L	DURATEC 16V	MY07_5	PCM		•		
Focus	1.6L	DURATEC 16V	MY07_5	RETM				0
Focus	1.6L	DURATEC 16V	MY07_5	RKE				0
Focus	1.6L	DURATEC 16V	MY07_5	SRM		•		0
Focus	1.6L	DURATEC 16V	MY07_5	TCM	•	•	•	0
Focus	1.6L	DURATEC VCT	2003.25 MY	ABS		•		
Focus	1.6L	DURATEC VCT	2003.25 MY	ACM		•		0
Focus	1. 6L	DURATEC VCT	2003. 25 MY	CDP	•			0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.6L	DURATEC VCT	2003.25 MY	D_DCU	•	•		
Focus	1.6L	DURATEC VCT	2003.25 MY	EATC	•	•		
Focus	1.6L	DURATEC VCT	2003.25 MY	FFH	•	•		
Focus	1. 6L	DURATEC VCT	2003.25 MY	GDM		•		0
Focus	1.6L	DURATEC VCT	2003.25 MY	GEM	•	•		•
Focus	1.6L	DURATEC VCT	2003.25 MY	HCM				0
Focus	1.6L	DURATEC VCT	2003.25 MY	IC				
Focus	1.6L	DURATEC VCT	2003.25 MY	NAV	•			0
Focus	1.6L	DURATEC VCT	2003.25 MY	P DCU				
Focus	1.6L	DURATEC VCT	2003.25 MY	PAM	•			0
Focus	1.6L	DURATEC VCT	2003.25 MY	PCM	•			
Focus	1.6L	DURATEC VCT	2003.25 MY	RETM				0
Focus	1.6L	DURATEC VCT	2003.25 MY	RKE				0
Focus	1.6L	DURATEC VCT	2003.25 MY	RL_DCU				
Focus	1.6L	DURATEC VCT	2003.25 MY	RR DCU				
Focus	1.6L	DURATEC VCT	2003.25 MY	SRM				0
Focus	1.6L	DURATEC VCT	2008.25 MY	ABS		•		•
Focus	1.6L	DURATEC VCT	2008.25 MY	ACM				0
Focus	1.6L	DURATEC VCT	2008.25 MY	CDP				0
Focus	1.6L	DURATEC VCT	2008.25 MY	CMR				0
Focus	1.6L	DURATEC VCT	2008.25 MY	D_DCU		•		
Focus	1. 6L	DURATEC VCT	2008.25 MY	EATC	•	•		
Focus	1.6L	DURATEC VCT	2008.25 MY	EPS	•	•		0
Focus	1.6L	DURATEC VCT	2008.25 MY	FFH	•	•		•
Focus	1.6L	DURATEC VCT	2008.25 MY	GEM	•	•		•
Focus	1.6L	DURATEC VCT	2008.25 MY	HCM				0

- This function is supported.
- O This function is not supported.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.6L	DURATEC VCT	2008.25 MY	IC	•	•		
Focus	1.6L	DURATEC VCT	2008. 25 MY	P_DCU	•	•	•	
Focus	1.6L	DURATEC VCT	2008. 25 MY	PAM		•		0
Focus	1.6L	DURATEC VCT	2008. 25 MY	PCM		•		
Focus	1.6L	DURATEC VCT	2008. 25 MY	RCM	•	•		0
Focus	1.6L	DURATEC VCT	2008. 25 MY	RETM	•	•		0
Focus	1.6L	DURATEC VCT	2008. 25 MY	RKE	•	•		0
Focus	1.6L	DURATEC VCT	2008. 25 MY	SRM		•		0
Focus	1.6L	DURATEC VCT	MY07 5	ABS		•		
Focus	1.6L	DURATEC VCT	MY07_5	ACM		•	•	0
Focus	1.6L	DURATEC VCT	MY07_5	CDP	•	•	•	0
Focus	1.6L	DURATEC VCT	MY07_5	D_DCU	•	•	•	
Focus	1.6L	DURATEC VCT	MY07_5	EATC	•	•	•	•
Focus	1.6L	DURATEC VCT	MY07_5	FFH	•	•	•	•
Focus	1. 6L	DURATEC VCT	MY07 5	GDM	•	•	•	0
Focus	1. 6L	DURATEC VCT	MY07 5	GEM			•	•
Focus	1. 6L	DURATEC VCT	MY07_5	HCM			•	0
Focus	1. 6L	DURATEC VCT	MY07_5	IC	•	•	•	
Focus	1. 6L	DURATEC VCT	MY07_5	NAV	•	•	•	0
Focus	1. 6L	DURATEC VCT	MY07_5	P_DCU	•	•	•	•
Focus	1.6L	DURATEC VCT	MY07_5	PAM	•	•	•	0
Focus	1.6L	DURATEC VCT	MY07_5	PCM	•	•		•
Focus	1.6L	DURATEC VCT	MY07_5	RETM	•	•	•	0
Focus	1.6L	DURATEC VCT	MY07_5	RKE	•	•	•	0
Focus	1. 6L	DURATEC VCT	MY07 5	SRM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	ABS	•	•	•	•
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	ACM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	CDP	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	D_DCU	•	•	•	•
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	EATC	•	•	•	•
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	EPS	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	FACM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	FFH	•	•	•	•
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	GDM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	GEM	•	•	•	•
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	HCM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	IC	•	•	•	•
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	NAV	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	P_DCU	•	•	•	•
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	PAM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	PCM	•	•	•	•
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	RETM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	RKE	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	RL_DCU	•	•	•	•
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	RR_DCU	•	•	•	•
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	SRM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	TCM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	ABS	•	•	•	•
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	ACM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	CDP	•	•	•	0
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	CMR	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	D_DCU	•	•	•	•
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	EATC	•	•	•	•
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	EPS	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	FACM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	FFH	•	•	•	•
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	GEM	•	•	•	•
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	HCM	•	•	•	0
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	IC	•	•	•	•
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	P_DCU	•	•	•	•
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	PAM	•	•	•	0
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	PCM	•	•	•	•
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	RCM	•	•	•	0
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	RETM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	RKE	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	SRM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	ABS	•	•	•	•
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	ACM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	CDP	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	D_DCU	•	•	•	•
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	EATC	•	•	•	•
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	EPS	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	FACM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	FFH	•	•	•	•
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	GDM	•	•	•	0
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	GEM	•	•	•	•
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	HCM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	IC	•	•	•	•
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	NAV	•	•	•	0
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	P_DCU	•	•	•	•
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	PAM	•	•	•	0
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	PCM	•	•	•	•
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	RETM	•	•	•	0
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	RKE	•	•	•	0
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	SRM	•	•	•	0
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.25 MY	ABS	•	•	•	•
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.25 MY	ACM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008. 25 MY	CDP	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.25 MY	CMR	•	•	•	0
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.25 MY	D_DCU	•	•	•	•
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.25 MY	EATC	•	•	•	•
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.25 MY	EPS	•	•	•	0
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.25 MY	FFH	•	•	•	•
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.25 MY	GEM	•	•	•	•
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.25 MY	НСМ	•	•	•	0
Focus	1. 6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008.25 MY	IC	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008. 25 MY	P_DCU	•	•	•	•
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008. 25 MY	PAM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008. 25 MY	PCM	•	•	•	
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008. 25 MY	RCM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008. 25 MY	RETM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008. 25 MY	RKE	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008. 25 MY	SRM	•	•	•	0
Focus	1.6L	Duratorq Turbo Diesel Common Rail Injection StgV	2008. 25 MY	TCM	•	•	•	0
Focus	1.6L	FFV	2007 MY	ABS/TCS	•	•	•	
Focus	1.6L	FFV	2007 MY	GEM				

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
Focus	1.6L	FFV	2007 MY	IC				
Focus	1.6L	FFV	2007 MY	PCM		•		
Focus	1.6L	FFV	2007 MY	RCM		•		
Focus	1.6L	FFV	2009 MY	ABS/TCS		•		
Focus	1.6L	FFV	2009 MY	EATC		•		
Focus	1.6L	FFV	2009 MY	GEM		•		
Focus	1.6L	FFV	2009 MY	HCM		•		0
Focus	1.6L	FFV	2009 MY	IC		•		
Focus	1.6L	FFV	2009 MY	MC		•		
Focus	1.6L	FFV	2009 MY	PCM				
Focus	1.6L	FFV	2009 MY	RCM		•		
Focus	1.6L	FFV	2010 MY	ABS		•		
Focus	1.6L	FFV	2010 MY	ACM		•		0
Focus	1.6L	FFV	2010 MY	D_DCU		•		
Focus	1.6L	FFV	2010 MY	EATC		•		
Focus	1.6L	FFV	2010 MY	EPS		•		0
Focus	1.6L	FFV	2010 MY	GEM		•		
Focus	1.6L	FFV	2010 MY	HCM		•		0
Focus	1.6L	FFV	2010 MY	IC		•		
Focus	1.6L	FFV	2010 MY	P_DCU		•		
Focus	1.6L	FFV	2010 MY	PAM		•	•	0
Focus	1.6L	FFV	2010 MY	PCM		•	•	
Focus	1.6L	FFV	2010 MY	RCM	•	•	•	0
Focus	1.6L	FFV	2010 MY	RKE	•	•	•	0
Focus	1.6L	FFV	2010 MY	SRM	•	•	•	0
Focus	1.6L	FFV	2010 MY	TCM	•	•		0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.6L	OHC	2009 MY	ABS/TCS		•		
Focus	1.6L	OHC	2009 MY	EATC		•		
Focus	1.6L	OHC	2009 MY	GEM		•		
Focus	1.6L	OHC	2009 MY	HCM		•		0
Focus	1.6L	OHC	2009 MY	IC		•		
Focus	1.6L	OHC	2009 MY	MC	•	•		
Focus	1.6L	OHC	2009 MY	PCM	•	•	•	
Focus	1.6L	OHC	2009 MY	RCM	•	•	•	
Focus	1.6L	Sigma	2010 MY	ABS		•		
Focus	1.6L	Sigma	2010 MY	ACM	•	•	•	0
Focus	1.6L	Sigma	2010 MY	D_DCU	•	•	•	
Focus		Sigma	2010 MY	EATC	•	•	•	
Focus	1.6L	Sigma	2010 MY	EPS	•	•	•	0
Focus	1.6L	Sigma	2010 MY	GEM	•	•	•	
Focus	1.6L	Sigma	2010 MY	HCM		•		0
Focus	1.6L	Sigma	2010 MY	IC	•	•		•
Focus	1.6L	Sigma	2010 MY	P_DCU	•	•	•	•
Focus	1.6L	Sigma	2010 MY	PAM	•	•	•	0
Focus	1.6L	Sigma	2010 MY	PCM	•	•	•	
Focus	1.6L	Sigma	2010 MY	RCM	•	•	•	0
Focus	1.6L	Sigma	2010 MY	RKE		•	•	0
Focus	1.6L	Sigma	2010 MY	SRM		•	•	0
Focus		Sigma	2010 MY	TCM	•	•	•	0
Focus	1.6L	Zetec	1999 MY	ABS/TCS	•	•	•	•
Focus	1.6L	Zetec	1999 MY	CSM	•	•	•	•
Focus	1.6L	Zetec	1999 MY	CTM	•	•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.6L	Zetec	1999 MY	ECS	•	•		0
Focus	1.6L	Zetec	1999 MY	HEC	•	•		
Focus	1.6L	Zetec	1999 MY	PATS	•	•		0
Focus	1.6L	Zetec	1999 MY	PCM		•		
Focus		Zetec	2002 MY	ABS/TCS	•	•		
Focus	1.6L	Zetec	2002 MY	EATC	•	•		
Focus	1.6L	Zetec	2002 MY	ECS	•	•		0
Focus	1.6L	Zetec	2002 MY	GEM	•	•		
Focus	1.6L	Zetec	2002 MY	HCM	•	•		0
Focus	1.6L	Zetec	2002 MY	HEC		•		
Focus	1.6L	Zetec	2002 MY	MC	•	•		
Focus	1.6L	Zetec	2002 MY	PCM	•	•		
Focus	1.6L	Zetec	2002 MY	RCM	•	•		
Focus	1.6L	Zetec Rocam	2002 MY	ABS/TCS	•	•		
Focus	1.6L	Zetec Rocam	2002 MY	EATC	•	•		
Focus	1.6L	Zetec Rocam	2002 MY	ECS		•		0
Focus	1.6L	Zetec Rocam	2002 MY	GEM	•	•		
Focus	1.6L	Zetec Rocam	2002 MY	HCM	•	•		0
Focus	1.6L	Zetec Rocam	2002 MY	HEC	•	•		
Focus	1.6L	Zetec Rocam	2002 MY	MC	•	•		
Focus	1.6L	Zetec Rocam	2002 MY	PCM	•	•		
Focus	1.6L	Zetec Rocam	2002 MY	RCM	•	•	•	•
Focus	1.6L	Zetec-SE	1999 MY	ABS/TCS	•	•	•	
Focus	1.6L	Zetec-SE	1999 MY	CSM	•	•		•
Focus	1.6L	Zetec-SE	1999 MY	CTM	•	•		
Focus	1.6L	Zetec-SE	1999 MY	ECS	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.6L	Zetec-SE	1999 MY	HEC	•	•		
Focus	1.6L	Zetec-SE	1999 MY	MC		•		
Focus	1.6L	Zetec-SE	1999 MY	PATS		•		0
Focus	1.6L	Zetec-SE	1999 MY	PCM		•		
Focus	1.6L	Zetec-SE	2002 MY	ABS/TCS		•	•	
Focus	1.6L	Zetec-SE	2002 MY	EATC		•		
Focus	1.6L	Zetec-SE	2002 MY	ECS		•		0
Focus	1.6L	Zetec-SE	2002 MY	GEM		•		
Focus	1.6L	Zetec-SE	2002 MY	HCM		•		0
Focus	1.6L	Zetec-SE	2002 MY	HEC		•		
Focus	1.6L	Zetec-SE	2002 MY	MC		•	•	
Focus	1.6L	Zetec-SE	2002 MY	PATS	•	•		0
Focus	1.6L	Zetec-SE	2002 MY	PCM	•	•		
Focus	1.6L	Zetec-SE	2002 MY	RCM		•		
Focus	1.8L	DURATEC-HE / I4	2003.25 MY	ABS		•		
Focus	1.8L	DURATEC-HE / I4	2003.25 MY	ACM	•	•		0
Focus	1.8L	DURATEC-HE / I4	2003.25 MY	CDP		•		0
Focus	1.8L	DURATEC-HE / I4	2003.25 MY	D_DCU		•		
Focus	1.8L	DURATEC-HE / I4	2003. 25 MY	EATC		•		
Focus	1.8L	DURATEC-HE / I4	2003. 25 MY	EPS		•		0
Focus	1.8L	DURATEC-HE / I4	2003.25 MY	FFH		•		
Focus	1.8L	DURATEC-HE / I4	2003.25 MY	GDM	•	•	•	0
Focus	1.8L	DURATEC-HE / I4	2003.25 MY	GEM	•	•		
Focus	1.8L	DURATEC-HE / I4		HCM	•	•	•	0
Focus	1.8L	DURATEC-HE / I4		IC	•	•	•	•
Focus	1.8L	DURATEC-HE / I4	2003.25 MY	NAV	•	•		0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.8L	DURATEC-HE / I4	2003.25 MY	P_DCU	•	•		
Focus	1.8L	DURATEC-HE / I4	2003. 25 MY	PAM	•	•		0
Focus	1.8L	DURATEC-HE / I4	2003. 25 MY	PCM	•	•		•
Focus	1.8L	DURATEC-HE / I4	2003.25 MY	RETM	•	•		0
Focus	1.8L	DURATEC-HE / I4	2003.25 MY	RKE	•	•	•	0
Focus	1.8L	DURATEC-HE / I4	2003.25 MY	RL_DCU	•	•		
Focus	1.8L	DURATEC-HE / I4	2003.25 MY	RR_DCU	•	•		
Focus	1.8L	DURATEC-HE / I4	2003. 25 MY	SRM	•	•		0
Focus	1.8L	DURATEC-HE / I4	2003.25 MY	TCM	•	•		0
Focus	1.8L	DURATEC-HE / I4	2008.25 MY	ABS	•	•		
Focus	1.8L	DURATEC-HE / I4	2008.25 MY	ACM	•	•		0
Focus	1.8L	DURATEC-HE / I4	2008.25 MY	CDP	•	•		0
Focus	1.8L	DURATEC-HE / I4	2008.25 MY	CMR	•	•		0
Focus	1.8L	DURATEC-HE / I4	2008. 25 MY	D_DCU	•	•		
Focus	1.8L	DURATEC-HE / I4	2008. 25 MY	EATC	•	•		
Focus	1.8L	DURATEC-HE / I4	2008. 25 MY	EPS	•	•		0
Focus	1.8L	DURATEC-HE / I4	2008.25 MY	FFH	•	•		
Focus	1.8L	DURATEC-HE / I4	2008. 25 MY	GEM	•	•		
Focus	1.8L	DURATEC-HE / I4	2008. 25 MY	HCM	•	•		0
Focus	1.8L	DURATEC-HE / I4	2008. 25 MY	IC	•	•		
Focus	1.8L	DURATEC-HE / I4	2008.25 MY	P_DCU	•	•		
Focus	1.8L	DURATEC-HE / I4	2008.25 MY	PAM	•	•		0
Focus	1.8L	DURATEC-HE / I4	2008.25 MY	PCM	•	•		
Focus	1.8L	DURATEC-HE / I4		RCM	•	•	•	0
Focus	1.8L	DURATEC-HE / I4	2008. 25 MY	RETM	•	•	•	0
Focus	1.8L	DURATEC-HE / I4	2008.25 MY	RKE	•	•		0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.8L	DURATEC-HE / I4	2008. 25 MY	SRM		•		0
Focus	1.8L	DURATEC-HE / I4	MY07_5	ABS		•		
Focus	1.8L	DURATEC-HE / I4	MY07_5	ACM		•		0
Focus	1.8L	DURATEC-HE / I4	MY07_5	CDP				0
Focus	1.8L	DURATEC-HE / I4	MY07_5	D_DCU		•		
Focus	1.8L	DURATEC-HE / I4	MY07_5	EATC		•		
Focus	1.8L	DURATEC-HE / I4	MY07_5	EPS		•		0
Focus	1.8L	DURATEC-HE / I4	MY07_5	FFH		•		
Focus	1.8L	DURATEC-HE / I4	MY07 5	GDM		•		0
Focus	1.8L	DURATEC-HE / I4	MY07_5	GEM		•		
Focus	1.8L	DURATEC-HE / I4	MY07_5	HCM		•		0
Focus	1.8L	DURATEC-HE / I4	MY07_5	IC		•		
Focus	1.8L	DURATEC-HE / I4	MY07_5	NAV		•		0
Focus	1.8L	DURATEC-HE / I4	MY07_5	P_DCU		•		
Focus	1.8L	DURATEC-HE / I4	MY07 5	PAM		•		0
Focus	1.8L	DURATEC-HE / I4	MY07_5	PCM		•		
Focus	1.8L	DURATEC-HE / I4	MY07_5	RETM		•		0
Focus	1.8L	DURATEC-HE / I4	MY07_5	RKE		•		0
Focus	1.8L	DURATEC-HE / I4	MY07_5	SRM		•		0
Focus	1.8L	DURATEC-HE / I4	MY07_5	TCM		•		0
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2001.5 MY	ABS/TCS	•	•	•	•
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2001.5 MY	CSM	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001.5 MY	CTM	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001.5 MY	ECS	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001.5 MY	FFH	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001.5 MY	HEC	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001.5 MY	ICU	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001.5 MY	MC	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2001.5 MY	PCM	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	ABS/TCS	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	EATC	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	ECS	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	FFH	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	GEM	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	HCM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	HEC	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	ICU	•	•	•	0
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	MC	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	PCM	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	RCM	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	ABS	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	ACM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	CDP	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	D_DCU	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	EATC	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	EPS	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	FFH	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	GDM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	GEM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	HCM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	IC	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	NAV	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	P_DCU	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	PAM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	PCM	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	RETM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	RKE	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	RL_DCU	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	RR_DCU	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	SRM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	ABS	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	ACM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	CDP	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	CMR	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	D_DCU	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	EATC	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	EPS	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	FACM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	FFH	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	GEM	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	HCM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	IC	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	P_DCU	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	PAM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	PCM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	RCM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	RETM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	RKE	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	SRM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	ABS	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	ACM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	CDP	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	D_DCU	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	EATC	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	EPS	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	FFH	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	GDM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	GEM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
Focus	1. 8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	HCM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	IC	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	NAV	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	P_DCU	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	PAM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	PCM	•	•	•	•
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	RETM	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	RKE	•	•	•	0
Focus	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	SRM	•	•	•	0
Focus	1.8L	Endura DI	1999 MY	ABS/TCS				•
Focus	1.8L	Endura DI	1999 MY	CSM				
Focus	1.8L	Endura DI	1999 MY	CTM	•	•	•	
Focus	1.8L	Endura DI	1999 MY	ECS	•	•	•	0
Focus	1.8L	Endura DI	1999 MY	FFH	•	•	•	•
Focus	1.8L	Endura DI	1999 MY	FIP	•	•	•	0
Focus	1. 8L	Endura DI	1999 MY	HEC	•	•	•	•
Focus	1.8L	Endura DI	1999 MY	MC				

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.8L	Endura DI	1999 MY	PATS	•	•		0
Focus	1.8L	Endura DI	1999 MY	PCM	•	•		
Focus	1.8L	Endura DI	2002 MY	ABS/TCS	•	•		
Focus	1.8L	Endura DI	2002 MY	EATC	•	•		
Focus	1.8L	Endura DI	2002 MY	ECS	•	•		0
Focus	1.8L	Endura DI	2002 MY	FFH	•	•		•
Focus	1.8L	Endura DI	2002 MY	FIP	•	•		0
Focus	1.8L	Endura DI	2002 MY	GEM	•	•		
Focus	1.8L	Endura DI	2002 MY	HCM	•	•		0
Focus	1.8L	Endura DI	2002 MY	HEC	•	•		
Focus	1.8L	Endura DI	2002 MY	MC	•	•		
Focus	1.8L	Endura DI	2002 MY	PATS	•	•		0
Focus	1.8L	Endura DI	2002 MY	PCM	•	•		
Focus	1.8L	Endura DI	2002 MY	RCM	•	•		
Focus	1.8L	Zetec	1999 MY	ABS/TCS	•	•		
Focus	1.8L	Zetec	1999 MY	AFCM		•		0
Focus	1.8L	Zetec	1999 MY	CSM	•	•		
Focus	1.8L	Zetec	1999 MY	CTM	•	•		
Focus	1.8L	Zetec	1999 MY	ECS	•	•	•	0
Focus	1.8L	Zetec	1999 MY	HEC	•	•		
Focus	1.8L	Zetec	1999 MY	MC	•	•		
Focus	1.8L	Zetec	1999 MY	PATS	•	•	•	0
Focus	1.8L	Zetec	1999 MY	PCM	•	•	•	•
Focus	1.8L	Zetec	2002 MY	ABS/TCS	•	•		•
Focus		Zetec		EATC	•	•		•
Focus	1.8L	Zetec	2002 MY	ECS	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	1.8L	Zetec	2002 MY	GEM	•	•		
Focus	1.8L	Zetec	2002 MY	HCM	•	•		0
Focus	1.8L	Zetec	2002 MY	HEC	•	•		
Focus	1.8L	Zetec	2002 MY	MC		•		
Focus	1.8L	Zetec	2002 MY	PCM	•	•		
Focus	1.8L	Zetec	2002 MY	RCM	•	•		
Focus	2.0L	DURATEC 16V	2005.5 MY	ABS/TCS		•		
	2. 0L	DURATEC 16V	2005.5 MY	EATC	•	•		
Focus	2.0L	DURATEC 16V	2005.5 MY	GEM		•		
Focus	2.0L	DURATEC 16V	2005.5 MY	HCM		•		0
Focus	2. 0L	DURATEC 16V	2005.5 MY	IC	•	•		
Focus	2. 0L	DURATEC 16V	2005.5 MY	MC		•		
Focus	2. 0L	DURATEC 16V	2005.5 MY	PCM		•		
Focus	2. 0L	DURATEC 16V	2005.5 MY	RCM	•	•		
Focus	2. 0L	DURATEC-HE / I4	2003.25 MY	ABS		•		
Focus	2. 0L	DURATEC-HE / I4	2003.25 MY	ACM	•	•		0
Focus	2. 0L	DURATEC-HE / I4	2003.25 MY	CDP	•	•		0
Focus	2. 0L	DURATEC-HE / I4	2003.25 MY	D_DCU	•	•		
Focus	2. 0L	DURATEC-HE / I4	2003. 25 MY	EATC	•	•		
Focus	2. 0L	DURATEC-HE / I4	2003. 25 MY	EPS	•	•		0
Focus	2. 0L	DURATEC-HE / I4	2003.25 MY	FFH	•	•		
Focus	2. 0L	DURATEC-HE / I4	2003.25 MY	GDM	•	•	•	0
Focus	2.0L	DURATEC-HE / I4	2003.25 MY	GEM	•	•	•	•
Focus	2. 0L	DURATEC-HE / I4		HCM	•	•		0
Focus	2. 0L	DURATEC-HE / I4		IC	•	•		•
Focus	2. 0L	DURATEC-HE / I4	2003.25 MY	NAV	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	2. 0L	DURATEC-HE / I4	2003.25 MY	P_DCU		•		
Focus	2. 0L	DURATEC-HE / I4	2003. 25 MY	PAM		•		0
Focus	2. 0L	DURATEC-HE / I4	2003. 25 MY	PCM		•		
Focus	2. 0L	DURATEC-HE / I4	2003.25 MY	RETM		•		0
Focus	2. 0L	DURATEC-HE / I4	2003.25 MY	RKE		•		0
Focus	2. 0L	DURATEC-HE / I4	2003.25 MY	RL_DCU		•		
Focus	2. 0L	DURATEC-HE / I4	2003.25 MY	RR_DCU		•		
Focus	2. 0L	DURATEC-HE / I4	2003.25 MY	SRM	•	•	•	0
Focus	2. 0L	DURATEC-HE / I4	2003.25 MY	TCM		•		0
Focus	2. 0L	DURATEC-HE / I4	2005 MY	ABS		•		
Focus	2. 0L	DURATEC-HE / I4	2005 MY	GEM			•	
Focus	2. 0L	DURATEC-HE / I4	2005 MY	IC			•	
Focus	2. 0L	DURATEC-HE / I4	2005 MY	PCM	•	•	•	•
Focus	2. 0L	DURATEC-HE / I4	2005 MY	RCM	•	•	•	
Focus	2. 0L	DURATEC-HE / I4	2006 MY	ABS		•		
Focus	2. 0L	DURATEC-HE / I4	2006 MY	GEM	•		•	
Focus	2. 0L	DURATEC-HE / I4	2006 MY	IC		•	•	
Focus	2. 0L	DURATEC-HE / I4	2006 MY	PCM			•	
Focus	2. 0L	DURATEC-HE / I4	2006 MY	RCM	•	•	•	
Focus	2. 0L	DURATEC-HE / I4	2007 MY	ABS	•	•	•	
Focus	2. 0L	DURATEC-HE / I4	2007 MY	GEM		•	•	•
Focus	2. 0L	DURATEC-HE / I4	2007 MY	IC		•		•
Focus	2. 0L	DURATEC-HE / I4		PCM	•	•	•	•
Focus	2. 0L	DURATEC-HE / I4	2007 MY	RCM	•	•		
Focus	2. 0L	DURATEC-HE / I4	2008 MY	ABS	•	•		•
Focus	2. 0L	DURATEC-HE / I4	2008 MY	ACM	•	•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	2. 0L	DURATEC-HE / I4	2008 MY	APIM		•		0
Focus	2. 0L	DURATEC-HE / I4	2008 MY	FCIM		•		
Focus	2. 0L	DURATEC-HE / I4	2008 MY	FDIM		•		
Focus	2. 0L	DURATEC-HE / I4	2008 MY	GEM/SJB		•		
Focus	2. 0L	DURATEC-HE / I4	2008 MY	HVAC		•		
Focus	2. 0L	DURATEC-HE / I4	2008 MY	IC		•		
Focus	2. 0L	DURATEC-HE / I4	2008 MY	OCSM		•		0
Focus	2. 0L	DURATEC-HE / I4	2008 MY	PCM		•		
Focus	2. 0L	DURATEC-HE / I4	2008 MY	RCM		•		
Focus	2. 0L	DURATEC-HE / I4	2008 MY	SDARS		•		
Focus	2. 0L	DURATEC-HE / I4	2008.25 MY	ABS		•		
Focus	2. 0L	DURATEC-HE / I4	2008.25 MY	ACM	•	•		0
Focus	2. 0L	DURATEC-HE / I4	2008.25 MY	CDP	•	•		0
Focus	2. 0L	DURATEC-HE / I4	2008.25 MY	CMR		•		0
Focus	2. 0L	DURATEC-HE / I4	2008.25 MY	D DCU		•		
Focus	2. 0L	DURATEC-HE / I4	2008. 25 MY	EATC	•	•		
Focus	2. 0L	DURATEC-HE / I4	2008.25 MY	EPS		•		0
Focus	2. 0L	DURATEC-HE / I4	2008.25 MY	FFH		•		
Focus	2. 0L	DURATEC-HE / I4	2008.25 MY	GEM		•		
Focus	2. 0L	DURATEC-HE / I4	2008.25 MY	HCM		•		0
Focus	2. 0L	DURATEC-HE / I4	2008.25 MY	IC		•		
Focus	2. 0L	DURATEC-HE / I4	2008.25 MY	P_DCU	•	•	•	
Focus	2. 0L	DURATEC-HE / I4	2008.25 MY	PAM	•	•	•	0
Focus	2. 0L	DURATEC-HE / I4	2008. 25 MY	PCM	•	•		•
Focus	2. 0L	DURATEC-HE / I4	2008.25 MY	RCM	•	•	•	0
Focus	2. 0L	DURATEC-HE / I4	2008.25 MY	RETM	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	2. 0L	DURATEC-HE / I4	2008.25 MY	RKE		•		0
Focus	2. 0L	DURATEC-HE / I4	2008. 25 MY	SRM		•		0
Focus	2. 0L	DURATEC-HE / I4	2008. 25 MY	TCM		•		0
Focus	2. 0L	DURATEC-HE / I4	2009 MY	ABS		•		
Focus	2. 0L	DURATEC-HE / I4	2009 MY	ACM		•		
Focus	2. 0L	DURATEC-HE / I4	2009 MY	APIM		•		0
Focus	2. 0L	DURATEC-HE / I4	2009 MY	FCIM		•		
	2. 0L	DURATEC-HE / I4	2009 MY	FDIM		•		
Focus	2. 0L	DURATEC-HE / I4	2009 MY	GEM/SJB		•		
Focus	2. 0L	DURATEC-HE / I4	2009 MY	HVAC		•		
Focus	2. 0L	DURATEC-HE / I4	2009 MY	IC		•		
Focus	2. 0L	DURATEC-HE / I4	2009 MY	OCSM		•		0
Focus	2. 0L	DURATEC-HE / I4	2009 MY	PCM		•		
Focus	2. 0L	DURATEC-HE / I4	2009 MY	RCM		•		
Focus	2. 0L	DURATEC-HE / I4	2010 MY	ABS		•		
Focus	2.0L	DURATEC-HE / I4	2010 MY	ACM		•		
Focus	2. 0L	DURATEC-HE / I4	2010 MY	ACM		•		0
Focus	2. 0L	DURATEC-HE / I4	2010 MY	APIM		•		0
Focus	2. 0L	DURATEC-HE / I4	2010 MY	D_DCU		•		
Focus	2. 0L	DURATEC-HE / I4	2010 MY	EATC		•		
Focus	2. 0L	DURATEC-HE / I4	2010 MY	EPS		•		0
Focus	2. 0L	DURATEC-HE / I4	2010 MY	FCIM		•	•	•
Focus	2. 0L	DURATEC-HE / I4	2010 MY	FDIM	•	•	•	•
Focus	2. 0L	DURATEC-HE / I4	2010 MY	GEM	•	•		•
Focus	2. 0L	DURATEC-HE / I4	2010 MY	GEM/SJB	•	•		•
Focus	2. 0L	DURATEC-HE / I4	2010 MY	GPSM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	2. 0L	DURATEC-HE / I4	2010 MY	HCM		•		0
Focus	2. 0L	DURATEC-HE / I4	2010 MY	HVAC		•		
Focus	2. 0L	DURATEC-HE / I4	2010 MY	IC		•		
Focus	2.0L	DURATEC-HE / I4	2010 MY	OCSM		•		0
Focus	2. 0L	DURATEC-HE / I4	2010 MY	P_DCU		•		
Focus	2. 0L	DURATEC-HE / I4	2010 MY	PAM		•		0
Focus	2. 0L	DURATEC-HE / I4	2010 MY	PCM		•		
Focus	2. 0L	DURATEC-HE / I4	2010 MY	PCM		•		0
Focus	2. 0L	DURATEC-HE / I4	2010 MY	RCM		•		
Focus	2. 0L	DURATEC-HE / I4	2010 MY	RCM		•		0
Focus	2. 0L	DURATEC-HE / I4	2010 MY	RKE		•		0
Focus	2. 0L	DURATEC-HE / I4	2010 MY	SRM		•		0
Focus	2. 0L	DURATEC-HE / I4	2010 MY	TCM		•		0
Focus	2. 0L	DURATEC-HE / I4	MY07_5	ABS		•		•
Focus	2. 0L	DURATEC-HE / I4	MY07 5	ACM		•		0
Focus	2.0L	DURATEC-HE / I4	MY07_5	CDP		•		0
Focus	2. 0L	DURATEC-HE / I4	MY07_5	D_DCU		•		
Focus	2. 0L	DURATEC-HE / I4	MY07_5	EATC		•		
Focus	2. 0L	DURATEC-HE / I4	MY07_5	EPS		•		0
Focus	2. 0L	DURATEC-HE / I4	MY07_5	FFH		•		
Focus	2. 0L	DURATEC-HE / I4	MY07 5	GDM	•	•	•	0
Focus	2. 0L	DURATEC-HE / I4	MY07_5	GEM		•	•	•
Focus	2. 0L	DURATEC-HE / I4	MY07_5	HCM	•	•	•	0
Focus	2. 0L	DURATEC-HE / I4	MY07_5	IC	•	•		•
Focus	2. 0L	DURATEC-HE / I4	MY07_5	NAV	•	•	•	0
Focus	2. 0L	DURATEC-HE / I4	MY07_5	P_DCU	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	2. 0L	DURATEC-HE / I4	MY07_5	PAM		•		0
Focus	2. 0L	DURATEC-HE / I4	MY07_5	PCM				
Focus	2. 0L	DURATEC-HE / I4	MY07_5	RETM	•	•	•	0
Focus	2. 0L	DURATEC-HE / I4	MY07_5	RKE				0
Focus	2. 0L	DURATEC-HE / I4	MY07_5	SRM	•	•	•	0
Focus	2. 0L	DURATEC-HE / I4	MY07_5	TCM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	ABS	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	ACM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	CDP	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	D_DCU	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	EATC	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003.25 MY	EPS	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	FACM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	FFH	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	GDM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	GEM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	НСМ	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	IC	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	NAV	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	P_DCU	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	PAM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	PCM	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	RETM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	RKE	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	RL_DCU	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	RR_DCU	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2003. 25 MY	SRM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	ABS	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	ACM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	CDP	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	CMR	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	D_DCU	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	EATC	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	EPS	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	FACM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	FFH	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	GEM	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	НСМ	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	IC	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	P_DCU	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	PAM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	PCM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	RCM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	RETM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	RKE	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	SRM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	TCM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	ABS	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	ACM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	CDP	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	D_DCU	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	EATC	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	EPS	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	FACM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	FFH	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	GDM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	GEM	•	•	•	•
Focus	2. OL	Duratorq Turbo Diesel Common Rail Injection	MY07_5	HCM	•	•	•	0
Focus	2. OL	Duratorq Turbo Diesel Common Rail Injection	MY07_5	IC	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	NAV	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	P_DCU	•	•	•	•
Focus	2. OL	Duratorq Turbo Diesel Common Rail Injection	MY07_5	PAM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	PCM	•	•	•	•
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	RETM	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	RKE	•	•	•	0
Focus	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	SRM	•	•	•	0
Focus	2. OL	FFV	2010 MY	ABS	•		•	•
Focus	2. OL	FFV	2010 MY	ACM	•	•	•	0
Focus	2. 0L	FFV	2010 MY	D_DCU	•	•	•	
Focus	2. 0L	FFV	2010 MY	EATC				

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	2. 0L	FFV	2010 MY	EPS				0
Focus	2. 0L	FFV	2010 MY	GEM		•		
Focus	2. 0L	FFV	2010 MY	HCM		•		0
Focus	2. 0L	FFV	2010 MY	IC		•		
Focus	2. 0L	FFV	2010 MY	P_DCU		•		
Focus	2. 0L	FFV	2010 MY	PAM		•		0
Focus	2. 0L	FFV	2010 MY	PCM		•		
Focus	2. 0L	FFV	2010 MY	RCM	•	•	•	0
Focus	2. 0L	FFV	2010 MY	RKE		•		0
Focus	2. 0L	FFV	2010 MY	SRM		•		0
Focus	2. 0L	FFV	2010 MY	TCM	•	•	•	0
Focus	2. 0L	SPI	2000 MY	ABS/TCS	•	•	•	•
Focus	2. 0L	SPI	2000 MY	CSM	•	•	•	•
Focus	2. 0L	SPI	2000 MY	CTM	•	•	•	
Focus	2. 0L	SPI	2000 MY	ECS		•		0
Focus	2. 0L	SPI	2000 MY	HEC			•	•
Focus	2. 0L	SPI	2000 MY	PCM	•	•	•	
Focus	2. 0L	SPI	2002 MY	ABS/TCS	•	•	•	•
Focus	2. 0L	SPI	2002 MY	EATC	•	•	•	•
Focus	2. 0L	SPI	2002 MY	ECS	•	•	•	0
Focus	2. 0L	SPI	2002 MY	GEM	•	•	•	•
Focus	2. 0L	SPI	2002 MY	HCM	•	•		0
Focus	2. 0L	SPI	2002 MY	HEC	•	•		•
Focus	2. 0L	SPI	2002 MY	MC	•	•	•	•
Focus	2. 0L	SPI	2002 MY	PCM	•	•	•	•
Focus	2. 0L	SPI	2002 MY	RCM	•	•		•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	2. 0L	SPI	2003 MY	ABS/TCS	•	•		
Focus	2. 0L	SPI	2003 MY	GEM	•	•	•	•
Focus	2. 0L	SPI	2003 MY	HEC		•		
Focus	2. 0L	SPI	2003 MY	PCM		•		
Focus	2. 0L	SPI	2003 MY	RCM		•		
Focus	2. 0L	SPI	2004 MY	ABS/TCS		•		
Focus	2. 0L	SPI	2004 MY	GEM		•		
Focus	2. 0L	SPI	2004 MY	HEC	•	•	•	•
Focus	2. 0L	SPI	2004 MY	PCM		•		•
Focus	2. 0L	SPI	2004 MY	RCM		•		
Focus	2. 0L	Zetec	1999 MY	ABS/TCS	•	•	•	
Focus	2. 0L	Zetec	1999 MY	CSM	•	•	•	•
Focus	2. 0L	Zetec	1999 MY	CTM	•	•	•	
Focus	2. 0L	Zetec	1999 MY	ECS	•	•	•	0
Focus	2. 0L	Zetec	1999 MY	HEC		•		•
Focus	2. 0L	Zetec	1999 MY	MC		•		
Focus	2. 0L	Zetec	1999 MY	PATS		•	•	0
Focus	2. 0L	Zetec	1999 MY	PCM		•	•	•
Focus	2. 0L	Zetec	2000 MY	ABS/TCS	•	•	•	•
Focus	2. 0L	Zetec	2000 MY	CSM	•	•	•	•
Focus	2. 0L	Zetec	2000 MY	CTM		•	•	
Focus	2. 0L	Zetec	2000 MY	ECS	•	•		0
Focus	2. 0L	Zetec	2000 MY	HEC	•	•		•
Focus	2. 0L	Zetec	2000 MY	PCM	•	•	•	
Focus	2. 0L	Zetec	2002 MY	ABS/TCS	•	•	•	•
Focus	2. 0L	Zetec	2002 MY	EATC	•	•		•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	2. 0L	Zetec	2002 MY	ECS	•	•		0
Focus	2. 0L	Zetec	2002 MY	GEM	•	•	•	
Focus	2. 0L	Zetec	2002 MY	HCM		•		0
Focus	2. 0L	Zetec	2002 MY	HEC		•		
Focus	2. 0L	Zetec	2002 MY	MC		•		
Focus	2. 0L	Zetec	2002 MY	PCM		•		
Focus	2. 0L	Zetec	2002 MY	RCM		•		
Focus	2. 0L	Zetec	2003 MY	ABS/TCS	•	•	•	•
Focus	2. 0L	Zetec	2003 MY	GEM		•	•	
Focus	2. 0L	Zetec	2003 MY	HEC		•	•	
Focus	2. 0L	Zetec	2003 MY	PCM		•	•	
Focus	2. 0L	Zetec	2003 MY	RCM	•		•	•
Focus	2. 0L	Zetec	2004 MY	ABS/TCS	•	•	•	•
Focus	2. 0L	Zetec	2004 MY	GEM	•	•	•	•
Focus	2. 0L	Zetec	2004 MY	HEC		•	•	
Focus	2. 0L	Zetec	2004 MY	PCM		•	•	
Focus	2. 0L	Zetec	2004 MY	RCM		•	•	
Focus	2. 0L	ZETEC ST	2002 MY	ABS/TCS		•	•	
Focus	2. 0L	ZETEC ST	2002 MY	EATC	•	•	•	•
Focus	2. 0L	ZETEC ST	2002 MY	ECS	•	•	•	0
Focus	2. 0L	ZETEC ST	2002 MY	GEM	•		•	
Focus	2. 0L	ZETEC ST	2002 MY	HCM	•	•		0
Focus	2. 0L	ZETEC ST	2002 MY	HEC	•	•	•	•
Focus	2. 0L	ZETEC ST	2002 MY	MC	•	•	•	•
Focus	2. 0L	ZETEC ST	2002 MY	MC	•	•	•	0
Focus	2. 0L	ZETEC ST	2002 MY	PCM	•	•		•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	2. 0L	ZETEC ST	2002 MY	RCM	•	•		
Focus	2. 0L	ZETEC ST	2003 MY	ABS/TCS		•		
Focus	2. 0L	ZETEC ST	2003 MY	GEM		•		
Focus	2. 0L	ZETEC ST	2003 MY	HEC		•		
Focus	2. 0L	ZETEC ST	2003 MY	PCM	•	•		
Focus	2. 0L	ZETEC ST	2003 MY	RCM	•	•		
Focus	2. 0L	ZETEC ST	2004 MY	ABS/TCS	•	•		
Focus	2. 0L	ZETEC ST	2004 MY	GEM	•	•		
Focus	2. 0L	ZETEC ST	2004 MY	HEC		•		
Focus	2. 0L	ZETEC ST	2004 MY	PCM		•		
Focus	2. 0L	ZETEC ST	2004 MY	RCM		•		
Focus	2. 3L	DURATEC-HE / I4	2003.5 MY	ABS/TCS	•	•	•	•
Focus	2. 3L	DURATEC-HE / I4	2003.5 MY	GEM		•		
Focus	2. 3L	DURATEC-HE / I4	2003.5 MY	IC	•	•		
Focus	2. 3L	DURATEC-HE / I4	2003.5 MY	PCM		•		
Focus	2. 3L	DURATEC-HE / I4	2003.5 MY	RCM		•		
Focus	2. 3L	DURATEC-HE / I4	2004 MY	ABS/TCS	•	•		
	2. 3L	DURATEC-HE / I4	2004 MY	GEM	•	•	•	
Focus	2. 3L	DURATEC-HE / I4	2004 MY	HEC	•	•		
Focus	2. 3L	DURATEC-HE / I4	2004 MY	IC	•	•		
Focus	2. 3L	DURATEC-HE / I4	2004 MY	PCM	•	•		
Focus	2. 3L	DURATEC-HE / I4	2004 MY	RCM	•	•		•
Focus	2. 3L	DURATEC-HE / I4	2005 MY	ABS	•	•	•	
Focus	2. 3L	DURATEC-HE / I4	2005 MY	GEM	•	•		•
Focus	2. 3L	DURATEC-HE / I4	2005 MY	IC	•	•	•	•
Focus	2. 3L	DURATEC-HE / I4	2005 MY	PCM	•	•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	2. 3L	DURATEC-HE / I4	2005 MY	RCM		•		
Focus	2. 3L	DURATEC-HE / I4	2006 MY	ABS		•		
Focus	2. 3L	DURATEC-HE / I4	2006 MY	GEM		•		
Focus	2. 3L	DURATEC-HE / I4	2006 MY	IC		•		
Focus	2. 3L	DURATEC-HE / I4	2006 MY	PCM		•		
Focus	2. 3L	DURATEC-HE / I4	2006 MY	RCM		•		
Focus	2. 3L	DURATEC-HE / I4	2007 MY	ABS		•		
Focus	2. 3L	DURATEC-HE / I4	2007 MY	GEM		•		•
Focus	2. 3L	DURATEC-HE / I4	2007 MY	IC		•		
Focus	2.3L	DURATEC-HE / I4	2007 MY	PCM		•		
Focus	2. 3L	DURATEC-HE / I4	2007 MY	RCM		•		
Focus	2.5L	Duratec RS	2008.25 MY	ABS		•		
Focus	2.5L	Duratec RS	2008.25 MY	ACM		•		0
Focus	2.5L	Duratec RS	2008.25 MY	CDP		•		0
Focus	2.5L	Duratec RS	2008.25 MY	CMR		•		0
Focus	2.5L	Duratec RS	2008. 25 MY	D_DCU		•		
Focus	2.5L	Duratec RS	2008.25 MY	EATC		•		
Focus	2.5L	Duratec RS	2008.25 MY	EPS		•		0
Focus	2.5L	Duratec RS	2008.25 MY	FFH		•		
Focus	2.5L	Duratec RS	2008.25 MY	GEM		•		
Focus	2.5L	Duratec RS	2008. 25 MY	HCM		•		0
Focus	2. 5L	Duratec RS	2008.25 MY	IC		•	•	
Focus	2. 5L	Duratec RS	2008.25 MY	MC	•	•	•	0
Focus	2. 5L	Duratec RS	2008.25 MY	P_DCU	•	•		•
Focus	2. 5L	Duratec RS	2008.25 MY	PAM		•	•	0
Focus	2. 5L	Duratec RS	2008.25 MY	PCM		•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	2.5L	Duratec RS	2008.25 MY	RCM	•	•		0
Focus	2. 5L	Duratec RS	2008.25 MY	RETM	•	•		0
Focus	2. 5L	Duratec RS	2008.25 MY	RKE	•	•		0
Focus	2. 5L	Duratec RS	2008.25 MY	SRM	•	•		0
Focus	2. 5L	15	2003.25 MY	ABS	•	•		•
Focus	2. 5L	15	2003.25 MY	ACM	•	•		0
Focus	2. 5L	15	2003.25 MY	CDP	•	•		0
Focus	2. 5L	15	2003.25 MY	D_DCU	•	•		•
Focus	2. 5L	15	2003.25 MY	EATC	•	•		
Focus	2. 5L	I5	2003.25 MY	EPS	•	•		0
Focus	2. 5L	15	2003.25 MY	FFH	•	•		•
Focus	2. 5L	15	2003.25 MY	GDM	•	•		0
Focus	2. 5L	15	2003.25 MY	GEM	•	•		
Focus	2. 5L	15	2003.25 MY	HCM	•	•		0
Focus	2. 5L	I5	2003.25 MY	IC	•	•		
Focus	2. 5L	15	2003.25 MY	MC		•		
Focus	2. 5L	15	2003.25 MY	NAV	•	•		0
Focus	2. 5L	15	2003.25 MY	P_DCU	•	•		•
Focus	2. 5L	15	2003.25 MY	PAM	•	•		0
Focus	2. 5L	15	2003.25 MY	PCM	•	•		
Focus	2. 5L	I5	2003.25 MY	RETM	•	•		0
Focus	2.5L	I5	2003.25 MY	RKE	•	•	•	0
Focus	2.5L	I5	2003.25 MY	RL_DCU	•	•	•	
Focus	2.5L	I5	2003.25 MY	RR_DCU	•	•	•	
Focus	2.5L	I5	2003.25 MY	SRM	•	•		0
Focus	2.5L	I5	2008.25 MY	ABS	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	2. 5L	I5	2008.25 MY	ACM	•	•		0
Focus	2. 5L	15	2008.25 MY	CDP		•		0
Focus	2. 5L	15	2008.25 MY	CMR		•		0
Focus	2. 5L	15	2008.25 MY	D_DCU		•		
Focus	2. 5L	15	2008.25 MY	EATC		•		
Focus	2. 5L	15	2008.25 MY	EPS		•		0
Focus	2. 5L	15	2008.25 MY	FFH		•		
Focus	2. 5L	15	2008.25 MY	GEM		•		
Focus	2. 5L	15	2008.25 MY	HCM		•		0
Focus	2.5L	15	2008.25 MY	IC		•		
Focus	2. 5L	15	2008.25 MY	MC		•		
Focus	2. 5L	15	2008.25 MY	P_DCU		•		
Focus	2. 5L	15	2008.25 MY	PAM		•		0
Focus	2. 5L	15	2008.25 MY	PCM		•		
Focus	2.5L	15	2008.25 MY	RCM		•		0
Focus	2.5L	15	2008.25 MY	RETM		•		0
Focus	2. 5L	15	2008.25 MY	RKE		•		0
Focus	2. 5L	15	2008.25 MY	SRM		•		0
Focus	2. 5L	15	MY07_5	ABS		•		
Focus	2. 5L	15	MY07_5	ACM		•		0
Focus	2.5L	15	MY07_5	CDP		•		0
Focus	2. 5L	15	MY07_5	D_DCU		•	•	•
Focus	2.5L	I5	MY07_5	EATC	•	•	•	•
Focus	2.5L	I5	MY07_5	EPS	•	•	•	0
Focus	2. 5L	I5	MY07_5	FFH	•	•		•
Focus	2.5L	I5	MY07_5	GDM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus	2. 5L	I5	MY07_5	GEM		•		
Focus	2.5L	15	MY07_5	HCM		•		0
Focus	2.5L	15	MY07_5	IC		•		
Focus	2.5L	I5	MY07_5	MC		•		
Focus	2.5L	15	MY07_5	NAV		•		0
Focus	2.5L	15	MY07_5	P_DCU		•	•	
Focus	2.5L	15	MY07_5	PAM		•		0
	2.5L	15	MY07_5	PCM		•		
Focus	2. 5L	15	MY07 5	RETM		•		0
Focus	2.5L	15	MY07_5	RKE		•		0
Focus	2.5L	15	MY07_5	SRM		•		0
Focus C-MAX	1.4L	DURATEC 16V	2002_75	ABS		•		
Focus C-MAX	1.4L	DURATEC 16V	2002_75	ACM		•		0
Focus C-MAX	1.4L	DURATEC 16V	2002_75	CDP		•		0
Focus C-MAX	1.4L	DURATEC 16V	2002 75	D DCU		•		
Focus C-MAX	1.4L	DURATEC 16V	2002_75	EATC		•		
Focus C-MAX	1.4L	DURATEC 16V	2002_75	EPB		•		0
Focus C-MAX	1.4L	DURATEC 16V	2002_75	FFH		•		
Focus C-MAX	1.4L	DURATEC 16V	2002_75	GDM		•		0
Focus C-MAX	1.4L	DURATEC 16V	2002_75	GEM		•		
Focus C-MAX	1.4L	DURATEC 16V	2002_75	HCM		•		0
Focus C-MAX	1.4L	DURATEC 16V	2002_75	IC	•	•	•	•
Focus C-MAX	1.4L	DURATEC 16V	2002_75	NAV	•	•		0
Focus C-MAX	1.4L	DURATEC 16V	2002_75	P_DCU	•	•	•	•
Focus C-MAX	1.4L	DURATEC 16V	2002_75	PAM	•	•	•	0
Focus C-MAX	1.4L	DURATEC 16V	2002_75	PCM	•	•		

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	1.4L	DURATEC 16V	2002_75	RETM	•	•		0
Focus C-MAX	1. 4L	DURATEC 16V	2002_75	RKE		•		0
Focus C-MAX	1. 4L	DURATEC 16V	2002_75	RL_DCU		•		
Focus C-MAX	1. 4L	DURATEC 16V	2002_75	RR_DCU		•		
Focus C-MAX	1. 4L	DURATEC 16V	2002_75	SRM		•		0
Focus C-MAX	1. 4L	DURATEC 16V	MY07_5	ABS		•		
Focus C-MAX	1. 4L	DURATEC 16V	MY07_5	ACM		•		0
Focus C-MAX	1. 4L	DURATEC 16V	MY07_5	CDP		•		0
Focus C-MAX	1.4L	DURATEC 16V	MY07 5	D DCU				
Focus C-MAX	1. 4L	DURATEC 16V	MY07_5	EATC		•		
Focus C-MAX	1. 4L	DURATEC 16V	MY07_5	EPB		•		0
Focus C-MAX	1. 4L	DURATEC 16V	MY07_5	FFH		•		
Focus C-MAX	1. 4L	DURATEC 16V	MY07_5	GDM		•		0
Focus C-MAX	1. 4L	DURATEC 16V	MY07_5	GEM		•		
Focus C-MAX	1.4L	DURATEC 16V	MY07 5	HCM				0
Focus C-MAX	1.4L	DURATEC 16V	MY07_5	IC				
Focus C-MAX	1. 4L	DURATEC 16V	MY07_5	NAV		•		0
Focus C-MAX	1. 4L	DURATEC 16V	MY07_5	P_DCU		•		
Focus C-MAX	1. 4L	DURATEC 16V	MY07_5	PAM		•		0
Focus C-MAX	1. 4L	DURATEC 16V	MY07_5	PCM		•		
Focus C-MAX	1. 4L	DURATEC 16V	MY07_5	RETM	•	•		0
Focus C-MAX	1.4L	DURATEC 16V	MY07_5	RKE	•			0
Focus C-MAX	1. 4L	DURATEC 16V	MY07_5	SRM				0
Focus C-MAX	1.6L	DURATEC 16V	2002_75	ABS	•	•	•	•
Focus C-MAX	1.6L	DURATEC 16V	2002_75	ACM	•	•	•	0
Focus C-MAX	1.6L	DURATEC 16V	2002_75	CDP		•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	1.6L	DURATEC 16V	2002_75	D_DCU				
Focus C-MAX	1.6L	DURATEC 16V	2002_75	EATC		•		
Focus C-MAX	1.6L	DURATEC 16V	2002_75	EPB		•		0
Focus C-MAX	1.6L	DURATEC 16V	2002_75	FFH		•		
Focus C-MAX	1.6L	DURATEC 16V	2002_75	GDM	•	•		0
Focus C-MAX	1.6L	DURATEC 16V	2002_75	GEM	•	•	•	
Focus C-MAX	1.6L	DURATEC 16V	2002_75	HCM	•	•		0
Focus C-MAX	1.6L	DURATEC 16V	2002_75	IC	•	•	•	
Focus C-MAX	1.6L	DURATEC 16V	2002 75	NAV	•	•	•	0
Focus C-MAX	1.6L	DURATEC 16V	2002_75	P_DCU	•	•	•	
Focus C-MAX	1.6L	DURATEC 16V	2002_75	PAM	•	•	•	0
Focus C-MAX	1.6L	DURATEC 16V	2002_75	PCM	•	•	•	
Focus C-MAX	1.6L	DURATEC 16V	2002_75	RETM	•	•	•	0
Focus C-MAX	1.6L	DURATEC 16V	2002_75	RKE	•	•		0
Focus C-MAX	1.6L	DURATEC 16V	2002 75	RL DCU		•		
Focus C-MAX	1.6L	DURATEC 16V	2002_75	RR_DCU	•	•	•	
Focus C-MAX	1.6L	DURATEC 16V	2002_75	SRM	•	•	•	0
Focus C-MAX	1.6L	DURATEC 16V	2008. 25 MY	ABS	•	•	•	
Focus C-MAX	1.6L	DURATEC 16V	2008. 25 MY	ACM	•	•	•	0
Focus C-MAX	1.6L	DURATEC 16V	2008. 25 MY	CDP	•	•	•	0
Focus C-MAX	1.6L	DURATEC 16V	2008. 25 MY	CMR	•	•	•	0
Focus C-MAX	1.6L	DURATEC 16V	2008.25 MY	D DCU	•		•	
Focus C-MAX	1.6L	DURATEC 16V	2008.25 MY	EATC	•	•	•	•
Focus C-MAX	1.6L	DURATEC 16V	2008.25 MY	EPS	•	•	•	0
Focus C-MAX	1.6L	DURATEC 16V	2008. 25 MY	FFH	•	•	•	•
Focus C-MAX	1.6L	DURATEC 16V	2008.25 MY	GEM		•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	1.6L	DURATEC 16V	2008.25 MY	HCM		•		0
Focus C-MAX	1.6L	DURATEC 16V	2008. 25 MY	IC		•		
Focus C-MAX	1.6L	DURATEC 16V	2008. 25 MY	P_DCU		•		
Focus C-MAX	1.6L	DURATEC 16V	2008. 25 MY	PAM		•		0
Focus C-MAX	1.6L	DURATEC 16V	2008. 25 MY	PCM		•		
Focus C-MAX	1.6L	DURATEC 16V	2008. 25 MY	RCM	•	•		0
Focus C-MAX	1.6L	DURATEC 16V	2008. 25 MY	RETM	•	•		0
Focus C-MAX	1.6L	DURATEC 16V	2008. 25 MY	RKE	•	•	•	0
Focus C-MAX	1. 6L	DURATEC 16V	2008. 25 MY	SRM	•	•		0
Focus C-MAX	1.6L	DURATEC 16V	2008. 25 MY	TCM	•	•		0
Focus C-MAX	1.6L	DURATEC 16V	MY07_5	ABS	•	•	•	
Focus C-MAX	1. 6L	DURATEC 16V	MY07_5	ACM	•	•	•	0
Focus C-MAX	1. 6L	DURATEC 16V	MY07_5	CDP	•	•	•	0
Focus C-MAX	1.6L	DURATEC 16V	MY07_5	D_DCU	•	•	•	
Focus C-MAX	1.6L	DURATEC 16V	MY07 5	EATC		•		
Focus C-MAX	1.6L	DURATEC 16V	MY07_5	EPB	•	•		0
Focus C-MAX	1.6L	DURATEC 16V	MY07_5	FFH	•	•	•	
Focus C-MAX	1.6L	DURATEC 16V	MY07_5	GDM	•	•	•	0
Focus C-MAX	1.6L	DURATEC 16V	MY07_5	GEM	•	•	•	•
Focus C-MAX	1.6L	DURATEC 16V	MY07_5	HCM	•	•	•	0
Focus C-MAX	1.6L	DURATEC 16V	MY07 5	IC		•	•	•
Focus C-MAX	1.6L	DURATEC 16V	MY07_5	NAV	•	•	•	0
Focus C-MAX	1.6L	DURATEC 16V	MY07_5	P_DCU	•	•	•	•
Focus C-MAX	1.6L	DURATEC 16V	MY07_5	PAM	•	•	•	0
Focus C-MAX	1.6L	DURATEC 16V	MY07_5	PCM	•	•	•	•
Focus C-MAX	1. 6L	DURATEC 16V	MY07_5	RETM	•	•		0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	1.6L	DURATEC 16V	MY07_5	RKE				0
Focus C-MAX	1.6L	DURATEC 16V	MY07_5	SRM				0
Focus C-MAX	1.6L	DURATEC VCT	2002_75	ABS				
Focus C-MAX	1.6L	DURATEC VCT	2002_75	ACM		•		0
Focus C-MAX	1.6L	DURATEC VCT	2002_75	CDP		•		0
Focus C-MAX	1.6L	DURATEC VCT	2002_75	D_DCU		•		
Focus C-MAX	1.6L	DURATEC VCT	2002_75	EATC		•		
Focus C-MAX	1.6L	DURATEC VCT	2002_75	EPB	•	•	•	0
Focus C-MAX	1.6L	DURATEC VCT	2002 75	FFH		•		
Focus C-MAX	1.6L	DURATEC VCT	2002_75	GDM	•	•		0
Focus C-MAX	1.6L	DURATEC VCT	2002_75	GEM	•	•	•	
Focus C-MAX	1.6L	DURATEC VCT	2002_75	HCM	•	•	•	0
Focus C-MAX	1.6L	DURATEC VCT	2002_75	IC	•	•	•	
Focus C-MAX	1.6L	DURATEC VCT	2002_75	NAV				0
Focus C-MAX	1.6L	DURATEC VCT	2002 75	P DCU				
Focus C-MAX	1.6L	DURATEC VCT	2002_75	PAM		•		0
Focus C-MAX	1.6L	DURATEC VCT	2002_75	PCM	•	•	•	
Focus C-MAX	1.6L	DURATEC VCT	2002_75	RETM	•	•	•	0
Focus C-MAX	1.6L	DURATEC VCT	2002_75	RKE	•	•	•	0
Focus C-MAX	1.6L	DURATEC VCT	2002_75	RL_DCU	•	•	•	•
Focus C-MAX	1. 6L	DURATEC VCT	2002 75	RR DCU	•	•	•	•
Focus C-MAX	1. 6L	DURATEC VCT	2002 75	SRM	•	•	•	0
Focus C-MAX	1.6L	DURATEC VCT	2008. 25 MY	ABS	•	•	•	•
Focus C-MAX	1.6L	DURATEC VCT	2008.25 MY	ACM	•	•	•	0
Focus C-MAX	1. 6L	DURATEC VCT	2008.25 MY	CDP	•	•	•	0
Focus C-MAX	1.6L	DURATEC VCT	2008.25 MY	CMR	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	1.6L	DURATEC VCT	2008.25 MY	D_DCU		•		
Focus C-MAX	1.6L	DURATEC VCT	2008. 25 MY	EATC		•		
Focus C-MAX	1.6L	DURATEC VCT	2008. 25 MY	EPS		•		0
Focus C-MAX	1.6L	DURATEC VCT	2008.25 MY	FFH		•		
Focus C-MAX	1.6L	DURATEC VCT	2008.25 MY	GEM		•		•
Focus C-MAX	1.6L	DURATEC VCT	2008.25 MY	HCM	•	•		0
Focus C-MAX	1.6L	DURATEC VCT	2008.25 MY	IC	•	•		
Focus C-MAX	1.6L	DURATEC VCT	2008. 25 MY	P_DCU	•	•		
Focus C-MAX	1. 6L	DURATEC VCT	2008. 25 MY	PAM	•	•		0
Focus C-MAX	1.6L	DURATEC VCT	2008. 25 MY	PCM	•	•		•
Focus C-MAX	1.6L	DURATEC VCT	2008. 25 MY	RCM	•	•	•	0
Focus C-MAX	1. 6L	DURATEC VCT	2008. 25 MY	RETM	•	•	•	0
Focus C-MAX	1. 6L	DURATEC VCT	2008. 25 MY	RKE	•	•	•	0
Focus C-MAX	1.6L	DURATEC VCT	2008. 25 MY	SRM	•	•	•	0
Focus C-MAX	1.6L	DURATEC VCT	MY07 5	ABS		•		
Focus C-MAX	1.6L	DURATEC VCT	MY07_5	ACM	•	•		0
Focus C-MAX	1.6L	DURATEC VCT	MY07_5	CDP	•	•	•	0
Focus C-MAX	1.6L	DURATEC VCT	MY07_5	D_DCU	•	•	•	•
Focus C-MAX	1.6L	DURATEC VCT	MY07_5	EATC	•	•	•	•
Focus C-MAX	1.6L	DURATEC VCT	MY07_5	EPB	•	•	•	0
Focus C-MAX	1.6L	DURATEC VCT	MY07 5	FFH			•	
Focus C-MAX	1.6L	DURATEC VCT	MY07 5	GDM	•	•	•	0
Focus C-MAX	1.6L	DURATEC VCT	MY07_5	GEM	•	•	•	•
Focus C-MAX	1.6L	DURATEC VCT	MY07_5	HCM	•	•	•	0
Focus C-MAX	1.6L	DURATEC VCT	MY07_5	IC	•	•	•	•
Focus C-MAX	1. 6L	DURATEC VCT	MY07_5	NAV	•	•		0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	1.6L	DURATEC VCT	MY07_5	P_DCU		•		
Focus C-MAX	1. 6L	DURATEC VCT	MY07_5	PAM				0
Focus C-MAX	1. 6L	DURATEC VCT	MY07_5	PCM	•	•		•
Focus C-MAX	1. 6L	DURATEC VCT	MY07_5	RETM				0
Focus C-MAX	1. 6L	DURATEC VCT	MY07_5	RKE	•	•		0
Focus C-MAX	1. 6L	DURATEC VCT	MY07_5	SRM	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	ABS	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	ACM	•	•	•	0
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	CDP	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	D_DCU	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	EATC	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	EPB	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	EPS	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	FACM	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	FFH	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	GDM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	GEM	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	HCM	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	IC	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	NAV	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	P_DCU	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	PAM	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	PCM	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	RETM	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	RKE	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	RL_DCU	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	RR_DCU	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	SRM	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002_75	TCM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	ABS	•	•	•	•
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	ACM	•	•	•	0
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	CDP	•	•	•	0
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	CMR	•	•	•	0
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	D_DCU	•	•	•	•
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	EATC	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	EPS	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	FACM	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	FFH	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	GEM	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	HCM	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	IC	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	P_DCU	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	PAM	•	•	•	0
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	PCM	•	•	•	•
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	RCM	•	•	•	0
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	RETM	•	•	•	0
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	RKE	•	•	•	0
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	SRM	•	•	•	0
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	ABS	•	•	•	•
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	ACM	•	•	•	0
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	CDP	•	•	•	0
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	D_DCU	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	EATC	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	EPB	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	EPS	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	FACM	•	•	•	0
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	FFH	•	•	•	•
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	GDM	•	•	•	0
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	GEM	•	•	•	•
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	HCM	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	IC	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	NAV	•	•	•	0
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	P_DCU	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	PAM	•	•	•	0
Focus C-MAX	1.6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	PCM	•	•	•	•
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	RETM	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	RKE	•	•	•	0
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	SRM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	1. 6L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	TCM	•	•	•	0
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	ABS				
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	ACM		•		0
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	CDP		•		0
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	D_DCU		•	•	
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	EATC		•	•	
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	EPB		•	•	0
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 75	EPS		•	•	0
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	FFH		•	•	
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	GDM	•	•	•	0
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	GEM		•	•	•
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	HCM		•	•	0
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	IC		•	•	•
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 75	NAV		•	•	0
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	P_DCU	•	•	•	
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	PAM		•	•	0
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	PCM		•	•	•
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	RETM	•	•	•	0
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	RKE	•	•	•	0
Focus C-MAX	1.8L	DURATEC-HE / I4	2002 75	RL DCU		•	•	•
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	RR DCU	•	•	•	•
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	SRM		•	•	0
Focus C-MAX	1.8L	DURATEC-HE / I4	2002_75	TCM	•	•	•	0
Focus C-MAX	1.8L	DURATEC-HE / I4	2008. 25 MY	ABS	•	•	•	•
Focus C-MAX	1.8L	DURATEC-HE / I4	2008. 25 MY	ACM	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	1.8L	DURATEC-HE / I4	2008.25 MY	CDP		•		0
Focus C-MAX	1.8L	DURATEC-HE / I4	2008. 25 MY	CMR		•		0
Focus C-MAX	1.8L	DURATEC-HE / I4	2008. 25 MY	D_DCU		•		
Focus C-MAX	1.8L	DURATEC-HE / I4	2008.25 MY	EATC		•		
Focus C-MAX	1.8L	DURATEC-HE / I4	2008.25 MY	EPS		•		0
Focus C-MAX	1.8L	DURATEC-HE / I4	2008.25 MY	FFH		•		
Focus C-MAX	1.8L	DURATEC-HE / I4	2008. 25 MY	GEM		•		
Focus C-MAX	1.8L	DURATEC-HE / I4	2008. 25 MY	HCM		•		0
Focus C-MAX	1.8L	DURATEC-HE / I4	2008.25 MY	IC		•		
Focus C-MAX	1.8L	DURATEC-HE / I4	2008.25 MY	P_DCU		•		
Focus C-MAX	1.8L	DURATEC-HE / I4	2008.25 MY	PAM		•		0
Focus C-MAX	1.8L	DURATEC-HE / I4	2008.25 MY	PCM		•		
Focus C-MAX	1.8L	DURATEC-HE / I4	2008. 25 MY	RCM		•		0
Focus C-MAX	1.8L	DURATEC-HE / I4	2008. 25 MY	RETM		•		0
Focus C-MAX	1.8L	DURATEC-HE / I4	2008. 25 MY	RKE		•		0
Focus C-MAX	1.8L	DURATEC-HE / I4	2008. 25 MY	SRM		•		0
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	ABS		•		
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	ACM		•		0
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	CDP		•		0
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	D_DCU		•		•
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	EATC		•		•
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	EPB		•	•	0
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	EPS	•	•	•	0
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	FFH	•	•		•
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	GDM	•	•	•	0
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	GEM	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	HCM		•		0
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	IC				
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	NAV				0
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	P_DCU				
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	PAM				0
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	PCM				
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	RETM				0
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	RKE				0
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07 5	SRM				0
Focus C-MAX	1.8L	DURATEC-HE / I4	MY07_5	TCM				0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	ABS	•	•	•	•
Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	ACM	•	•	•	0
Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	CDP	•	•	•	0
Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	D_DCU	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	EATC	•	•	•	•
Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	EPB	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	EPS	•	•	•	0
Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	FFH	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	GDM	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	GEM	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	HCM	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	IC	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	NAV	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	P_DCU	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	PAM	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	PCM	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	RETM	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	RKE	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	RL_DCU	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	RR_DCU	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002_75	SRM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	ABS	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	ACM	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	CDP	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	CMR	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	D_DCU	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	EATC	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	EPS	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	FACM	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	FFH	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	GEM	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	НСМ	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	IC	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	P_DCU	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	PAM	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	PCM	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	RCM	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	RETM	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	RKE	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	SRM	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	ABS	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	ACM	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	CDP	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	D_DCU	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	EATC	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	EPB	•	•	•	0
Focus C-MAX	1. 8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	EPS	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	FFH	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	GDM	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	GEM	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	HCM	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	IC	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	NAV	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	P_DCU	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	PAM	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	PCM	•	•	•	•
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	RETM	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	RKE	•	•	•	0
Focus C-MAX	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	SRM	•	•	•	0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	ABS	•		•	•
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	ACM			•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	CDP	•	•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	D_DCU	•	•		
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	EATC	•	•		
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	EPB	•	•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	EPS	•	•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	FFH	•	•		
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	GDM	•	•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	GEM	•	•		
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002 75	HCM	•	•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	IC	•	•		
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	NAV	•	•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	P_DCU	•	•	•	•
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	PAM	•	•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	PCM	•	•		
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002 75	RETM	•	•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	RKE	•	•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	RL_DCU	•	•		
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	RR_DCU	•	•		
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	SRM	•	•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2002_75	TCM				\circ
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	ABS	•	•		
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	ACM	•	•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	CDP	•	•	•	0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	CMR	•	•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	D_DCU	•	•		
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	EATC	•	•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	EPS		•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	FFH		•		
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	GEM		•		
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	HCM		•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	IC		•		
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	P_DCU		•	•	
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	PAM		•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	PCM		•		•
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	RCM		•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	RETM		•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	RKE		•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	SRM		•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	2008.25 MY	TCM		•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07_5	ABS		•		•
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07 5	ACM		•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07_5	CDP		•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07_5	D_DCU		•		
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07_5	EATC		•		
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07_5	EPB		•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07_5	EPS		•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07_5	FFH		•		•
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07_5	GDM		•	•	0
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07_5	GEM	•	•		
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07_5	HCM	•	•	•	0
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07_5	IC	•	•	•	•
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07_5	NAV	•	•		0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07_5	P_DCU	•	•		
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07_5	PAM		•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07_5	PCM		•		
Focus C-MAX	2. 0L	DURATEC-HE / 14	MY07_5	RETM				0
Focus C-MAX	2.0L	DURATEC-HE / I4	MY07_5	RKE		•		0
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07_5	SRM	•	•	•	0
Focus C-MAX	2. 0L	DURATEC-HE / I4	MY07_5	TCM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	ABS	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	ACM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	CDP	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	D_DCU	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	EATC	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	EPB	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	EPS	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	FACM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	FFH	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	GDM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	GEM	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	НСМ	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	IC	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	NAV	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	P_DCU	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	PAM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	PCM	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	RETM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	RKE	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	RL_DCU	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	RR_DCU	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2002_75	SRM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	ABS	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	ACM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	CDP	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	CMR	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	D_DCU	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	EATC	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	EPS	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	FACM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	FFH	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	GEM	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	HCM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	IC	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	P_DCU	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	PAM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	PCM	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	RCM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	RETM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	RKE	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	SRM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	TCM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	ABS	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	ACM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	CDP	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	D_DCU	•	•	•	•
Focus C-MAX	2. OL	Duratorq Turbo Diesel Common Rail Injection	MY07_5	EATC	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	ЕРВ	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	EPS	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	FACM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	FFH	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	GDM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	GEM	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	HCM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	IC	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	NAV	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	P_DCU	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	PAM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	PCM	•	•	•	•
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	RETM	•	•	•	0
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	RKE	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus C-MAX	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07_5	SRM	•	•	•	0
Focus Cabriolet	1. 6L	DURATEC 16V	2008.25 MY	ABS				
Focus Cabriolet	1.6L	DURATEC 16V	2008.25 MY	ACM				0
Focus Cabriolet	1.6L	DURATEC 16V	2008.25 MY	CDP				0
Focus Cabriolet	1.6L	DURATEC 16V	2008.25 MY	D_DCU				
Focus Cabriolet	1.6L	DURATEC 16V	2008.25 MY	EATC				
Focus Cabriolet	1.6L	DURATEC 16V	2008.25 MY	EPS				0
Focus Cabriolet	1.6L	DURATEC 16V	2008.25 MY	FFH				
Focus Cabriolet	1.6L	DURATEC 16V	2008.25 MY	FTCM				0
Focus Cabriolet	1.6L	DURATEC 16V	2008.25 MY	GEM		•		•
Focus Cabriolet	1.6L	DURATEC 16V	2008.25 MY	HCM		•	•	0
Focus Cabriolet	1.6L	DURATEC 16V	2008.25 MY	IC		•		•
Focus Cabriolet	1.6L	DURATEC 16V	2008.25 MY	P_DCU				
Focus Cabriolet	1.6L	DURATEC 16V	2008.25 MY	PAM				0
Focus Cabriolet	1.6L	DURATEC 16V	2008.25 MY	PCM		•		
Focus Cabriolet	1.6L	DURATEC 16V	2008.25 MY	RCM		•		0
Focus Cabriolet	1.6L	DURATEC 16V	2008.25 MY	RKE		•		0
Focus Cabriolet	1.6L	DURATEC 16V	2008.25 MY	SRM				0
Focus Cabriolet	1.6L	DURATEC 16V	MY06.75	ABS	•	•	•	•
Focus Cabriolet	1.6L	DURATEC 16V	MY06.75	ACM	•	•	•	0
Focus Cabriolet	1.6L	DURATEC 16V	MY06.75	CDP	•		•	0
Focus Cabriolet	1.6L	DURATEC 16V	MY06.75	D_DCU	•			•
Focus Cabriolet	1. 6L	DURATEC 16V	MY06.75	EATC	•	•	•	
Focus Cabriolet	1. 6L	DURATEC 16V	MY06.75	FFH	•	•	•	•
Focus Cabriolet	1. 6L	DURATEC 16V	MY06.75	FTCM	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus Cabriolet	1.6L	DURATEC 16V	MY06.75	GDM		•		0
Focus Cabriolet	1.6L	DURATEC 16V	MY06.75	GEM		•		
Focus Cabriolet	1.6L	DURATEC 16V	MY06.75	HCM		•		0
Focus Cabriolet	1.6L	DURATEC 16V	MY06.75	IC		•		
Focus Cabriolet	1.6L	DURATEC 16V	MY06.75	NAV		•		0
Focus Cabriolet	1.6L	DURATEC 16V	MY06.75	P_DCU	•	•		
Focus Cabriolet	1.6L	DURATEC 16V	MY06.75	PAM	•	•		0
Focus Cabriolet	1.6L	DURATEC 16V	MY06.75	PCM	•	•	•	
Focus Cabriolet	1.6L	DURATEC 16V	MY06.75	RKE	•	•		0
Focus Cabriolet	1.6L	DURATEC 16V	MY06.75	SRM	•	•		0
Focus Cabriolet	1.6L	DURATEC VCT	2008.25 MY	ABS	•	•	•	
Focus Cabriolet	1.6L	DURATEC VCT	2008.25 MY	ACM	•	•	•	0
Focus Cabriolet	1.6L	DURATEC VCT	2008. 25 MY	CDP	•	•	•	0
Focus Cabriolet	1.6L	DURATEC VCT	2008.25 MY	D_DCU	•	•		
Focus Cabriolet	1.6L	DURATEC VCT	2008.25 MY	EATC		•		
Focus Cabriolet	1.6L	DURATEC VCT	2008. 25 MY	EPS	•	•		0
Focus Cabriolet	1.6L	DURATEC VCT	2008.25 MY	FFH	•	•	•	
Focus Cabriolet	1.6L	DURATEC VCT	2008. 25 MY	FTCM	•	•	•	0
Focus Cabriolet	1.6L	DURATEC VCT	2008. 25 MY	GEM	•	•	•	•
Focus Cabriolet	1.6L	DURATEC VCT	2008.25 MY	HCM	•	•	•	0
Focus Cabriolet	1.6L	DURATEC VCT	2008.25 MY	IC	•		•	
Focus Cabriolet	1.6L	DURATEC VCT	2008.25 MY	P_DCU	•	•		•
Focus Cabriolet	1.6L	DURATEC VCT	2008.25 MY	PAM	•	•		0
Focus Cabriolet	1.6L	DURATEC VCT	2008.25 MY	RCM	•	•		0
Focus Cabriolet	1.6L	DURATEC VCT	2008.25 MY	RKE	•	•	•	0
Focus Cabriolet	1.6L	DURATEC VCT	2008. 25 MY	SRM	•	•		0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008.25 MY	ABS		•		
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008. 25 MY	ACM		•		0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008. 25 MY	CDP		•		0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008.25 MY	D_DCU		•		
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008.25 MY	EATC		•		
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008.25 MY	EPS		•		0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008. 25 MY	FFH		•		
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008. 25 MY	FTCM		•		0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008.25 MY	GEM		•		
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008.25 MY	HCM	•	•		0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008.25 MY	IC		•		
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008. 25 MY	P_DCU		•		
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008. 25 MY	PAM		•		0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008. 25 MY	PCM		•		
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008.25 MY	RCM				0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008.25 MY	RKE		•		0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008.25 MY	SRM		•		0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	2008. 25 MY	TCM		•		0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	ABS				
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	ACM		•		0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	CDP		•		0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	D_DCU		•		
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	EATC	•	•		
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	EPS	•	•		0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	FFH	•	•		
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	FTCM	•	•		0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	GDM		•	•	0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	GEM				
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	HCM	•		•	0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	IC	•		•	
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	NAV	•		•	0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	P_DCU	•	•	•	
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	PAM	•		•	0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	PCM	•		•	
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	RKE	•		•	0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	SRM				0
Focus Cabriolet	2. 0L	DURATEC-HE / I4	MY06.75	TCM				0
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	ABS	•	•	•	
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	ACM	•	•	•	0
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	CDP	•	•	•	0
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	D_DCU	•	•	•	•
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	EATC	•	•	•	
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	EPS	•	•	•	0
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	FACM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008.25 MY	FFH	•	•	•	•
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	FTCM	•	•	•	0
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	GEM	•	•	•	•
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	HCM	•	•	•	0
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	IC	•	•	•	•
Focus Cabriolet	2. OL	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	P_DCU	•	•	•	•
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	PAM	•	•	•	0
Focus Cabriolet	2. OL	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	PCM	•	•	•	•
Focus Cabriolet	2. OL	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	RCM	•	•	•	0
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	RKE	•	•	•	0
Focus Cabriolet	2. OL	Duratorq Turbo Diesel Common Rail Injection	2008. 25 MY	SRM	•	•	•	0
Focus Cabriolet	2. OL	Duratorq Turbo Diesel Common Rail Injection	MY06.75	ABS	•	•	•	•
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	ACM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	CDP	•	•	•	0
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	D_DCU	•	•	•	•
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	EATC	•	•	•	
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	EPS	•	•	•	0
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	FACM	•	•	•	0
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	FFH	•	•	•	•
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	FTCM	•	•	•	0
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	GDM	•	•	•	0
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	GEM	•	•	•	•
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	НСМ	•	•	•	0
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	IC	•	•	•	•
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	NAV	•	•	•	0
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	P_DCU	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	PAM	•	•	•	0
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	PCM	•	•	•	•
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	RKE	•	•	•	0
Focus Cabriolet	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY06.75	SRM	•	•	•	0
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.6L	BZ	2005 MY	ABS	•	•	•	
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.6L	BZ	2005 MY	D_DCU				
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.6L	BZ	2005 MY	EATC	•	•	•	•
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.6L	BZ	2005 MY	GEM				
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.6L	BZ	2005 MY	HCM				0
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.6L	BZ	2005 MY	IC				
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.6L	BZ	2005 MY	P DCU				
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.6L	BZ	2005 MY	PCM				
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.6L	BZ	2005 MY	RCM				0
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.6L	BZ	2005 MY	RL_DCU				
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.6L	BZ	2005 MY	RR_DCU				
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	2005 MY	ABS				
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	2005 MY	D_DCU			•	
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	2005 MY	EATC	•	•		•
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	2005 MY	EPS	•	•		0
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	2005 MY	GEM	•	•	•	
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	2005 MY	HCM				0
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	2005 MY	IC				•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	2005 MY	P_DCU		•		
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	2005 MY	PCM				
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	2005 MY	RCM		•		0
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	2005 MY	RL_DCU				
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	2005 MY	RR_DCU		•		
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	1.8L	DURATEC-HE / I4	2005 MY	TCM	•	•	•	0
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	DURATEC-HE / I4	2005 MY	ABS	•	•	•	•
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	DURATEC-HE / I4	2005 MY	D_DCU	•	•	•	•
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	DURATEC-HE / I4	2005 MY	EATC	•		•	•
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2.0L	DURATEC-HE / I4	2005 MY	EPS		•		0
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	DURATEC-HE / I4	2005 MY	GEM		•		
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	DURATEC-HE / I4	2005 MY	HCM		•		0
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	DURATEC-HE / I4	2005 MY	IC	•	•	•	
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	DURATEC-HE / I4	2005 MY	P_DCU	•	•	•	
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	DURATEC-HE / I4	2005 MY	PCM				
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	DURATEC-HE / I4	2005 MY	RCM				0
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	DURATEC-HE / I4	2005 MY	RL_DCU				
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	DURATEC-HE / I4	2005 MY	RR_DCU				
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	DURATEC-HE / I4	2005 MY	TCM				0
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2005 MY	ABS	•	•	•	
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2005 MY	D_DCU	•	•	•	•
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2005 MY	EATC	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2005 MY	EPS	•	•	•	0
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2005 MY	FACM	•	•	•	0
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2005 MY	GEM	•	•	•	•
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2005 MY	HCM	•	•	•	0
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2005 MY	IC	•	•	•	•
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2005 MY	P_DCU	•	•	•	•
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2005 MY	PCM	•	•	•	•
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2005 MY	RCM	•	•	•	0
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2005 MY	RL_DCU	•	•	•	•
Focus VIN = LFA / LVS / AFA / PE1 / FFJ	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2005 MY	RR_DCU	•	•	•	•
FORD GT	5. 4L	4V	2005 MY	ABS/TCS		•	•	
FORD GT	5. 4L	4V	2005 MY	GEM	•	•	•	
FORD GT	5. 4L	4V	2005 MY	IC	•	•		•
FORD GT	5. 4L	4V	2005 MY	PATS	•			
FORD GT	5. 4L	4V	2005 MY	PCM	•			
FORD GT	5. 4L	4V	2005 MY	RCM				

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
FORD GT	5. 4L	4V	2006 MY	ABS/TCS	•	•		
FORD GT	5. 4L	4V	2006 MY	GEM	•	•	•	
FORD GT	5. 4L	4V	2006 MY	IC	•	•	•	
FORD GT	5. 4L	4V	2006 MY	PATS	•	•	•	
FORD GT	5. 4L	4V	2006 MY	PCM	•	•	•	
FORD GT	5. 4L	4V	2006 MY	RCM	•	•	•	
Fusion	1.4L	DURATEC 16V	2002 MY	ABS/TCS		•		
Fusion	1.4L	DURATEC 16V	2002 MY	GEM	•	•	•	•
Fusion	1.4L	DURATEC 16V	2002 MY	IC	•	•		
Fusion	1.4L	DURATEC 16V	2002 MY	PCM	•	•	•	
Fusion	1.4L	DURATEC 16V	2002 MY	RCM	•	•	•	
Fusion	1.4L	DURATEC 16V	2002 MY	TCM	•	•	•	0
Fusion	1.4L	DURATEC 16V	2006 MY	ABS/TCS	•	•	•	•
Fusion	1.4L	DURATEC 16V	2006 MY	ACM		•		0
Fusion	1.4L	DURATEC 16V	2006 MY	EATC		•		
Fusion	1.4L	DURATEC 16V	2006 MY	GEM	•	•		
Fusion	1.4L	DURATEC 16V	2006 MY	IC	•	•	•	
Fusion	1.4L	DURATEC 16V	2006 MY	PCM	•	•	•	
Fusion	1.4L	DURATEC 16V	2006 MY	RCM	•	•	•	0
Fusion	1.4L	DURATEC 16V	2006 MY	SRM	•	•	•	0
Fusion	1.4L	DURATEC 16V	2006 MY	TCM	•		•	0
Fusion	1.4L	DURATEC 16V	2008.75 MY	ABS	•	•		0
Fusion	1.4L	DURATEC 16V	2008.75 MY	ACM	•	•		0
Fusion	1.4L	DURATEC 16V		BCMii	•	•		0
Fusion	1.4L	DURATEC 16V		FCDIM	•	•		0
Fusion	1.4L	DURATEC 16V	2008.75 MY	HVAC	•	•		0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fusion	1.4L	DURATEC 16V	2008.75 MY	IPC		•		
Fusion	1.4L	DURATEC 16V	2008.75 MY	PCM				\circ
Fusion	1.4L	DURATEC 16V	2008.75 MY	PSCM				0
Fusion	1.4L	DURATEC 16V	2008.75 MY	RCM				0
Fusion	1.4L	DURATEC 16V	2008.75 MY	RFA			•	0
Fusion	1.4L	DURATEC 16V	2008.75 MY	SRM		•	•	0
Fusion	1.4L	DURATEC 16V	2008. 75 MY	TCM		•	•	0
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	ABS/TCS	•	•	•	•
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	GEM	•	•	•	•
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	IC	•	•	•	•
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	PCM	•	•	•	•
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	RCM	•	•	•	
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	TCM	•	•	•	0
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	ABS/TCS	•	•	•	•
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	ACM	•	•	•	0
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	EATC	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	GEM	•	•	•	
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	IC	•	•	•	•
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	PCM	•	•	•	•
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	RCM	•	•	•	0
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	SRM	•	•	•	0
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	TCM	•	•	•	0
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	ABS	•	•	•	0
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	ACM	•	•	•	0
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	BCMii	•	•	•	0
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	FCDIM	•	•	•	0
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	HVAC	•	•	•	0
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	IPC	•	•	•	
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	PCM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008. 75 MY	PSCM	•	•	•	0
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	RCM	•	•	•	0
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	RFA	•	•	•	0
Fusion	1. 4L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	SRM	•	•	•	0
Fusion	1.6L	DURATEC 16V	2002 MY	ABS/TCS				
Fusion	1.6L	DURATEC 16V	2002 MY	GEM		•		•
Fusion	1.6L	DURATEC 16V	2002 MY	IC		•		
Fusion	1.6L	DURATEC 16V	2002 MY	PCM	•	•	•	•
Fusion	1.6L	DURATEC 16V	2002 MY	RCM	•	•	•	
Fusion	1.6L	DURATEC 16V	2002 MY	TCM	•	•	•	0
Fusion	1.6L	DURATEC 16V	2006 MY	ABS/TCS	•	•	•	•
Fusion	1.6L	DURATEC 16V	2006 MY	ACM	•	•	•	0
Fusion	1.6L	DURATEC 16V	2006 MY	EATC	•	•	•	•
Fusion	1.6L	DURATEC 16V	2006 MY	GEM	•	•	•	
Fusion	1. 6L	DURATEC 16V	2006 MY	IC	•	•	•	
Fusion	1.6L	DURATEC 16V	2006 MY	PCM	•	•	•	•
Fusion	1.6L	DURATEC 16V	2006 MY	RCM		•		0
Fusion	1. 6L	DURATEC 16V	2006 MY	SRM	•	•	•	0
Fusion	1. 6L	DURATEC 16V	2006 MY	TCM	•	•	•	0
Fusion	1. 6L	DURATEC VCT	2008.75 MY	ABS	•	•	•	0
Fusion	1. 6L	DURATEC VCT	2008.75 MY	ACM	•	•	•	0
Fusion	1. 6L	DURATEC VCT	2008.75 MY	BCMii			•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fusion	1.6L	DURATEC VCT	2008.75 MY	FCDIM		•		0
Fusion	1.6L	DURATEC VCT	2008.75 MY	HVAC		•		0
Fusion	1.6L	DURATEC VCT	2008.75 MY	IPC				
Fusion	1.6L	DURATEC VCT	2008.75 MY	PCM				0
Fusion	1.6L	DURATEC VCT	2008.75 MY	PSCM				0
Fusion	1.6L	DURATEC VCT	2008.75 MY	RCM				0
Fusion	1.6L	DURATEC VCT	2008.75 MY	RFA				0
Fusion	1.6L	DURATEC VCT	2008.75 MY	SRM				0
Fusion	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	ABS/TCS	•	•	•	•
Fusion	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	EPS	•	•	•	0
Fusion	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	GEM	•	•	•	•
Fusion	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	IC	•	•	•	•
Fusion	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	PCM	•	•	•	•
Fusion	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2002 MY	RCM	•	•	•	
Fusion	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	ABS/TCS	•	•	•	•
Fusion	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	ACM	•	•	•	0
Fusion	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	EATC	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fusion	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	EPS	•	•	•	0
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	GEM	•	•	•	
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	IC	•	•	•	
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	PCM	•	•	•	•
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	RCM	•	•	•	0
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2006 MY	SRM	•	•	•	0
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	ABS	•	•	•	0
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	ACM	•	•	•	0
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	BCMii	•	•	•	0
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	FCDIM	•	•	•	0
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	HVAC	•	•	•	0
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	IPC	•	•	•	
Fusion	1. 6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	PCM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	PSCM	•	•	•	0
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	RCM	•	•	•	0
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	RFA	•	•	•	0
Fusion	1.6L	Duratorq Turbo Diesel Common Rail Injection	2008.75 MY	SRM	•	•	•	0
Fusion	1 25L	DURATEC 16V	2002 MY	ABS/TCS				
Fusion	1_25L	DURATEC 16V	2002 MY	GEM	•	•		
Fusion	1_25L	DURATEC 16V	2002 MY	IC	•	•		
Fusion	1_25L	DURATEC 16V	2002 MY	PCM		•		
Fusion	1_25L	DURATEC 16V	2002 MY	RCM				
Fusion	1_25L	DURATEC 16V	2006 MY	ABS/TCS				
Fusion	1 25L	DURATEC 16V	2006 MY	ACM				0
Fusion	1_25L	DURATEC 16V	2006 MY	EATC				
Fusion	1_25L	DURATEC 16V	2006 MY	GEM				
Fusion	1_25L	DURATEC 16V	2006 MY	IC				
Fusion	1_25L	DURATEC 16V	2006 MY	PCM				
Fusion	1_25L	DURATEC 16V	2006 MY	RCM				0
Fusion	1_25L	DURATEC 16V	2006 MY	SRM		•		0
Fusion	1_25L	DURATEC 16V	2008. 75 MY	ABS		•	•	0
Fusion	1_25L	DURATEC 16V	2008.75 MY	ACM	•	•	•	0
Fusion	1_25L	DURATEC 16V	2008.75 MY	BCMii		•	•	0
Fusion	1_25L	DURATEC 16V	2008.75 MY	FCDIM		•	•	0
Fusion	1_25L	DURATEC 16V	2008. 75 MY	HVAC		•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
Fusion	1_25L	DURATEC 16V	2008.75 MY	IPC				
Fusion	1_25L	DURATEC 16V	2008.75 MY	PCM		•		0
Fusion	1_25L	DURATEC 16V	2008.75 MY	PSCM		•		0
Fusion	1 25L	DURATEC 16V	2008.75 MY	RCM		•		0
Fusion	1 25L	DURATEC 16V	2008.75 MY	RFA		•		0
Fusion	1_25L	DURATEC 16V	2008.75 MY	SRM		•		0
Fusion	2.3L	DURATEC-HE / I4	2006 MY	ABS		•		
Fusion	2.3L	DURATEC-HE / I4	2006 MY	ACM		•		0
Fusion	2.3L	DURATEC-HE / I4	2006 MY	EATC		•		
Fusion	2.3L	DURATEC-HE / I4	2006 MY	GEM		•		
Fusion	2.3L	DURATEC-HE / I4	2006 MY	IC		•		
Fusion	2.3L	DURATEC-HE / I4	2006 MY	OCSM		•	•	0
Fusion	2. 3L	DURATEC-HE / I4	2006 MY	PCM		•		
Fusion	2.3L	DURATEC-HE / I4	2006 MY	RCM		•		
Fusion	2. 3L	DURATEC-HE / I4	2006 MY	TCM		•		
Fusion	2.3L	DURATEC-HE / I4	2007 MY	4X4				
Fusion	2.3L	DURATEC-HE / I4	2007 MY	ABS		•		
Fusion	2.3L	DURATEC-HE / I4	2007 MY	ACM		•		0
Fusion	2.3L	DURATEC-HE / I4	2007 MY	EATC		•		
Fusion	2.3L	DURATEC-HE / I4	2007 MY	GEM		•		
Fusion	2. 3L	DURATEC-HE / I4	2007 MY	IC	•		•	
Fusion	2. 3L	DURATEC-HE / I4	2007 MY	OCSM	•		•	0
Fusion	2. 3L	DURATEC-HE / I4	2007 MY	PCM		•	•	
Fusion	2. 3L	DURATEC-HE / I4	2007 MY	RCM	•	•	•	
Fusion	2. 3L	DURATEC-HE / I4	2007 MY	SDARS	•	•	•	
Fusion	2. 3L	DURATEC-HE / I4	2007 MY	TCM	•	•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fusion	2. 3L	DURATEC-HE / I4	2008 MY	4X4	•	•		
Fusion	2.3L	DURATEC-HE / I4	2008 MY	ABS				
Fusion	2.3L	DURATEC-HE / I4	2008 MY	ACM				0
Fusion	2. 3L	DURATEC-HE / I4	2008 MY	APIM				0
Fusion	2. 3L	DURATEC-HE / I4	2008 MY	GEM/SJB		•		
Fusion	2. 3L	DURATEC-HE / I4	2008 MY	HVAC		•		
Fusion	2. 3L	DURATEC-HE / I4	2008 MY	IC		•		
Fusion	2. 3L	DURATEC-HE / I4	2008 MY	OCSM		•		0
Fusion	2. 3L	DURATEC-HE / I4	2008 MY	PAM		•		
Fusion	2. 3L	DURATEC-HE / I4	2008 MY	PCM		•		
Fusion	2. 3L	DURATEC-HE / I4	2008 MY	RCM		•		•
Fusion	2. 3L	DURATEC-HE / I4	2008 MY	SDARS		•	•	•
Fusion	2. 3L	DURATEC-HE / I4	2008 MY	TCM		•		
Fusion	2. 3L	DURATEC-HE / I4	2009 MY	4X4		•		•
Fusion	2. 3L	DURATEC-HE / I4	2009 MY	ABS				
Fusion	2. 3L	DURATEC-HE / I4	2009 MY	ACM		•		0
Fusion	2. 3L	DURATEC-HE / I4	2009 MY	APIM		•		0
Fusion	2. 3L	DURATEC-HE / I4	2009 MY	GEM/SJB		•	•	•
Fusion	2. 3L	DURATEC-HE / I4	2009 MY	HVAC		•		•
Fusion	2. 3L	DURATEC-HE / I4	2009 MY	IC		•		•
Fusion	2. 3L	DURATEC-HE / I4	2009 MY	OCSM		•		0
Fusion	2. 3L	DURATEC-HE / I4	2009 MY	PAM	•	•		•
Fusion	2. 3L	DURATEC-HE / I4	2009 MY	PCM	•	•	•	
Fusion	2. 3L	DURATEC-HE / I4	2009 MY	RCM	•	•	•	
Fusion	2. 3L	DURATEC-HE / I4	2009 MY	SDARS	•	•		•
Fusion	2. 3L	DURATEC-HE / I4	2009 MY	TCM		•		

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fusion	2.5L	DURATEC-HE / I4	2010 MY	4X4		•		
Fusion	2.5L	DURATEC-HE / I4	2010 MY	ABS		•		
Fusion	2.5L	DURATEC-HE / I4	2010 MY	ACM		•		0
Fusion	2.5L	DURATEC-HE / I4	2010 MY	APIM		•		0
Fusion	2.5L	DURATEC-HE / I4	2010 MY	DSP		•		0
Fusion	2.5L	DURATEC-HE / I4	2010 MY	FCIM		•		
Fusion	2.5L	DURATEC-HE / I4	2010 MY	FCIM		•		0
Fusion	2.5L	DURATEC-HE / I4	2010 MY	FDIM		•		
Fusion	2. 5L	DURATEC-HE / I4	2010 MY	GEM/SJB		•		
Fusion	2.5L	DURATEC-HE / I4	2010 MY	GPSM		•		0
Fusion	2.5L	DURATEC-HE / I4	2010 MY	HVAC		•		
Fusion	2. 5L	DURATEC-HE / I4	2010 MY	IPC		•		
Fusion	2.5L	DURATEC-HE / I4	2010 MY	OCSM		•		0
Fusion	2.5L	DURATEC-HE / I4	2010 MY	PAM		•		
Fusion	2.5L	DURATEC-HE / I4	2010 MY	PCM				
Fusion	2.5L	DURATEC-HE / I4	2010 MY	PSCM		•		0
Fusion	2.5L	DURATEC-HE / I4	2010 MY	RCM		•		0
Fusion	2.5L	DURATEC-HE / I4	2010 MY	SOD-L		•		
Fusion	2.5L	DURATEC-HE / I4	2010 MY	SOD-R		•		
Fusion	2.5L	HEV / ATKINSON 4V	2010 MY	4X4		•		
Fusion	2. 5L	HEV / ATKINSON 4V	2010 MY	ABS		•		
Fusion	2. 5L	HEV / ATKINSON 4V	2010 MY	ACCM#2	•	•		0
Fusion	2.5L	HEV / ATKINSON 4V	2010 MY	ACM	•	•	•	0
Fusion	2. 5L	HEV / ATKINSON 4V	2010 MY	APIM	•	•		0
Fusion	2. 5L	HEV / ATKINSON 4V	2010 MY	BECM	•	•		•
Fusion	2.5L	HEV / ATKINSON 4V	2010 MY	DCDC	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fusion	2. 5L	HEV / ATKINSON 4V	2010 MY	DSP	•	•		0
Fusion	2.5L	HEV / ATKINSON 4V	2010 MY	FCIM	•	•		•
Fusion	2.5L	HEV / ATKINSON 4V	2010 MY	FCIM	•	•		0
Fusion	2.5L	HEV / ATKINSON 4V	2010 MY	FDIM		•		
Fusion	2.5L	HEV / ATKINSON 4V	2010 MY	GEM/SJB	•	•		
Fusion	2.5L	HEV / ATKINSON 4V	2010 MY	GPSM	•	•		0
Fusion	2.5L	HEV / ATKINSON 4V	2010 MY	HVAC	•	•		
Fusion	2.5L	HEV / ATKINSON 4V	2010 MY	IPC	•	•		
Fusion	2.5L	HEV / ATKINSON 4V	2010 MY	OCSM	•	•		0
Fusion	2. 5L	HEV / ATKINSON 4V	2010 MY	PAM	•	•		•
Fusion	2. 5L	HEV / ATKINSON 4V	2010 MY	PCM	•	•	•	
Fusion	2. 5L	HEV / ATKINSON 4V	2010 MY	PSCM	•	•	•	0
Fusion	2. 5L	HEV / ATKINSON 4V	2010 MY	RCM	•	•	•	0
Fusion	2. 5L	HEV / ATKINSON 4V	2010 MY	SOD-L	•	•	•	•
Fusion	2. 5L	HEV / ATKINSON 4V	2010 MY	SOD-R	•	•		
Fusion	2. 5L	HEV / ATKINSON 4V	2010 MY	TCM	•	•	•	0
Fusion	3. 0L	4V	2006 MY	ABS	•	•	•	•
Fusion	3. 0L	4V	2006 MY	ACM	•	•	•	0
Fusion	3. 0L	4V	2006 MY	EATC	•	•	•	•
Fusion	3. 0L	4V	2006 MY	GEM	•	•	•	•
Fusion	3. 0L	4V	2006 MY	IC	•		•	
Fusion	3. 0L	4V	2006 MY	OCSM	•	•	•	0
Fusion	3. 0L	4V	2006 MY	PCM	•	•	•	•
Fusion	3. 0L	4V	2006 MY	RCM	•	•	•	
Fusion	3. 0L	4V	2006 MY	TCM	•	•	•	•
Fusion	3. 0L	4V	2007 MY	4X4	•	•		

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fusion	3. 0L	4V	2007 MY	ABS		•		
Fusion	3. 0L	4V	2007 MY	ACM		•		0
Fusion	3. 0L	4V	2007 MY	EATC		•		
Fusion	3. 0L	4V	2007 MY	GEM		•		
Fusion	3. 0L	4V	2007 MY	IC		•		
Fusion	3. 0L	4V	2007 MY	OCSM		•		0
Fusion	3. 0L	4V	2007 MY	PCM		•		
Fusion	3. 0L	4V	2007 MY	RCM		•		
Fusion	3. 0L	4V	2007 MY	SDARS		•		
Fusion	3. 0L	4V	2007 MY	TCM		•		
Fusion	3. 0L	4V	2008 MY	4X4		•		
Fusion	3. 0L	4V	2008 MY	ABS		•		
Fusion	3. 0L	4V	2008 MY	ACM		•		0
Fusion	3. 0L	4V	2008 MY	APIM		•		0
Fusion	3. 0L	4V	2008 MY	GEM/SJB		•		
Fusion	3. 0L	4V	2008 MY	HVAC		•		
Fusion	3. 0L	4V	2008 MY	IC		•		
Fusion	3. 0L	4V	2008 MY	OCSM		•		0
Fusion	3. 0L	4V	2008 MY	PAM		•		•
Fusion	3. 0L	4V	2008 MY	PCM		•		•
Fusion	3. 0L	4V	2008 MY	RCM		•		•
Fusion	3. 0L	4V	2008 MY	SDARS		•	•	
Fusion	3. 0L	4V	2008 MY	TCM	•	•	•	
Fusion	3. 0L	4V	2009 MY	4X4	•	•		•
Fusion	3. 0L	4V	2009 MY	ABS	•	•		
Fusion	3. 0L	4V	2009 MY	ACM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fusion	3. 0L	4V	2009 MY	APIM		•		0
Fusion	3. 0L	4V	2009 MY	GEM/SJB		•		•
Fusion	3. 0L	4V	2009 MY	HVAC		•		•
Fusion	3. 0L	4V	2009 MY	IC		•		
Fusion	3. 0L	4V	2009 MY	OCSM		•		0
Fusion	3. 0L	4V	2009 MY	PAM		•		
Fusion	3. 0L	4V	2009 MY	PCM		•		
Fusion	3. 0L	4V	2009 MY	RCM		•		•
Fusion	3. 0L	4V	2009 MY	SDARS		•		
Fusion	3. 0L	4V	2009 MY	TCM		•		
Fusion	3. 0L	4V	2010 MY	4X4		•		
Fusion	3. 0L	4V	2010 MY	ABS	•	•		
Fusion	3. 0L	4V	2010 MY	ACM		•		0
Fusion	3. 0L	4V	2010 MY	APIM		•		0
Fusion	3. 0L	4V	2010 MY	DSP				0
Fusion	3. 0L	4V	2010 MY	FCIM		•		
Fusion	3. 0L	4V	2010 MY	FCIM		•		0
Fusion	3. 0L	4V	2010 MY	FDIM		•		
Fusion	3. 0L	4V	2010 MY	GEM/SJB		•		
Fusion	3. 0L	4V	2010 MY	GPSM		•		0
Fusion	3. 0L	4V	2010 MY	HVAC		•		
Fusion	3. 0L	4V	2010 MY	IPC	•	•	•	
Fusion	3. 0L	4V	2010 MY	OCSM	•	•	•	0
Fusion	3. 0L	4V	2010 MY	PAM	•	•		•
Fusion	3. 0L	4V		PCM	•	•		•
Fusion	3. 0L	4V	2010 MY	PSCM	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Fusion	3. 0L	4V	2010 MY	RCM		•		0
Fusion	3. 0L	4V	2010 MY	SOD-L	•	•	•	•
Fusion	3. 0L	4V	2010 MY	SOD-R		•		
Fusion	3. 5L	4V	2010 MY	4X4		•	•	
Fusion	3. 5L	4V	2010 MY	ABS	•	•	•	
Fusion	3. 5L	4V	2010 MY	ACM	•	•	•	0
Fusion	3. 5L	4V	2010 MY	APIM		•		0
Fusion	3. 5L	4V	2010 MY	DSP	•	•	•	0
Fusion	3. 5L	4V	2010 MY	FCIM		•		
Fusion	3. 5L	4V	2010 MY	FCIM		•	•	0
Fusion	3. 5L	4V	2010 MY	FDIM	•	•	•	•
Fusion	3. 5L	4V	2010 MY	GEM/SJB	•	•	•	•
Fusion	3. 5L	4V	2010 MY	GPSM	•	•	•	0
Fusion	3. 5L	4V	2010 MY	HVAC		•		
Fusion	3. 5L	4V	2010 MY	IPC		•		
Fusion	3. 5L	4V	2010 MY	OCSM		•		0
Fusion	3. 5L	4V	2010 MY	PAM	•	•	•	
Fusion	3. 5L	4V	2010 MY	PCM	•	•	•	
Fusion	3. 5L	4V	2010 MY	RCM	•	•	•	0
Fusion	3. 5L	4V	2010 MY	SOD-L	•	•	•	•
Fusion	3. 5L	4V	2010 MY	SOD-R			•	
Fusion	3. 5L	4V	2010 MY	TCM	•	•		
Galaxy	1. 9L	EDC 1.9	2001 MY	ABS	•	•		0
Galaxy	1. 9L	EDC 1.9	2001 MY	СЈВ	•	•		0
Galaxy	1. 9L	EDC 1.9	2001 MY	IC	•	•		0
Galaxy	1. 9L	EDC 1.9	2001 MY	LHID	•	•		0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Galaxy	1.9L	EDC 1.9	2001 MY	MFSW		•		0
Galaxy	1.9L	EDC 1.9	2001 MY	PAM		•		0
Galaxy	1.9L	EDC 1.9	2001 MY	PATS		•		0
Galaxy	1.9L	EDC 1.9	2001 MY	PCM		•		0
Galaxy	1.9L	EDC 1.9	2001 MY	RADIO		•		0
Galaxy	1.9L	EDC 1.9	2001 MY	RCC		•		0
Galaxy	1.9L	EDC 1.9	2001 MY	RHID		•		0
Galaxy	1.9L	EDC 1.9	2001 MY	RNS		•		0
Galaxy	1.9L	EDC 1.9	Other	ABS		•		0
Galaxy	1.9L	EDC 1.9	Other	СЈВ		•		0
Galaxy	1.9L	EDC 1.9	0ther	PCM		•		
Galaxy	1.9L	EDC 1.9	Other	TCM	•	•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1995.5 MY	ABS		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1995.5 MY	СЈВ		•		0
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995.5 MY	PATS				0
Galaxy	2.0L	2.0 DOHC SFI (8V)	1995.5 MY	PCM		•		
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1995.5 MY	TCM		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1997 MY	ABS		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1997 MY	СЈВ		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1997 MY	PATS	•	•	•	0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1997 MY	PCM		•		
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1997 MY	TCM		•	•	0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1998 MY	ABS	•	•	•	0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1998 MY	СЈВ	•	•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1998 MY	PATS	•	•	•	0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1998 MY	PCM	•	•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1998 MY	TCM	•	•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1998.75 MY	ABS		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1998.75 MY	СЈВ		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1998.75 MY	PATS		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1998.75 MY	PCM		•		•
Galaxy	2. 0L	2.0 DOHC SFI (8V)	1998.75 MY	TCM		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	2000.75 MY	ABS		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	2000.75 MY	СЈВ		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	2000.75 MY	IC		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	2000.75 MY	LHID		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	2000.75 MY	MFSW		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	2000.75 MY	PAM		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	2000.75 MY	PATS		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	2000.75 MY	PCM		•		
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000.75 MY	RADIO				0
Galaxy	2.0L	2.0 DOHC SFI (8V)	2000.75 MY	RCC		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	2000.75 MY	RHID		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	2000.75 MY	RNS		•		0
Galaxy	2. 0L	2.0 DOHC SFI (8V)	2000.75 MY	TCM		•		0
Galaxy	2. 3L	DOHC SFI (16V)	1997 MY	ABS		•		0
Galaxy	2. 3L	DOHC SFI (16V)	1997 MY	СЈВ		•		0
Galaxy	2. 3L	DOHC SFI (16V)	1997 MY	PATS		•	•	0
Galaxy	2. 3L	DOHC SFI (16V)	1997 MY	PCM		•	•	•
Galaxy	2. 3L	DOHC SFI (16V)	1997 MY	TCM	•	•	•	0
Galaxy	2. 3L	DOHC SFI (16V)	1998 MY	ABS	•	•		0
Galaxy	2. 3L	DOHC SFI (16V)	1998 MY	СЈВ	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Galaxy	2. 3L	DOHC SFI (16V)	1998 MY	PATS		•		0
Galaxy	2. 3L	DOHC SFI (16V)	1998 MY	PCM		•		
Galaxy	2. 3L	DOHC SFI (16V)	1998 MY	TCM		•		0
Galaxy	2. 3L	DOHC SFI (16V)	1998.75 MY	ABS		•		0
Galaxy	2. 3L	DOHC SFI (16V)	1998.75 MY	СЈВ		•		0
Galaxy	2. 3L	DOHC SFI (16V)	1998.75 MY	PATS		•		0
Galaxy	2. 3L	DOHC SFI (16V)	1998.75 MY	PCM		•		
Galaxy	2. 3L	DOHC SFI (16V)	1998.75 MY	TCM		•		0
Galaxy	2. 3L	DOHC SFI (16V)	2000.75 MY	ABS		•		0
Galaxy	2.3L	DOHC SFI (16V)	2000.75 MY	СЈВ		•		0
Galaxy	2. 3L	DOHC SFI (16V)	2000.75 MY	IC		•		0
Galaxy	2. 3L	DOHC SFI (16V)	2000.75 MY	LHID		•		0
Galaxy	2.3L	DOHC SFI (16V)	2000.75 MY	MFSW		•		0
Galaxy	2. 3L	DOHC SFI (16V)	2000.75 MY	PAM		•		0
Galaxy	2.3L	DOHC SFI (16V)	2000.75 MY	PATS				0
Galaxy	2.3L	DOHC SFI (16V)	2000.75 MY	PCM		•		
Galaxy	2. 3L	DOHC SFI (16V)	2000.75 MY	RADIO		•		0
Galaxy	2. 3L	DOHC SFI (16V)	2000.75 MY	RCC		•		0
Galaxy	2.3L	DOHC SFI (16V)	2000.75 MY	RHID		•		0
Galaxy	2.3L	DOHC SFI (16V)	2000.75 MY	RNS		•		0
Galaxy	2. 3L	DOHC SFI (16V)	2000.75 MY	TCM		•		0
Galaxy	2.8L	2.8 CD-V6	2001 MY	ABS		•	•	0
Galaxy	2.8L	2.8 CD-V6	2001 MY	СЈВ	•	•	•	0
Galaxy	2. 8L	2.8 CD-V6	2001 MY	IC	•	•		0
Galaxy	2. 8L	2.8 CD-V6	2001 MY	LHID	•	•		0
Galaxy	2.8L	2.8 CD-V6	2001 MY	MFSW	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Galaxy	2.8L	2.8 CD-V6	2001 MY	PAM	•	•	•	0
Galaxy	2.8L	2.8 CD-V6	2001 MY	PATS		•		0
Galaxy	2.8L	2.8 CD-V6	2001 MY	PCM	•	•	•	0
Galaxy	2.8L	2.8 CD-V6	2001 MY	RADIO	•	•	•	0
Galaxy	2.8L	2.8 CD-V6	2001 MY	RCC	•	•	•	0
Galaxy	2.8L	2.8 CD-V6	2001 MY	RHID	•	•	•	0
Galaxy	2.8L	2.8 CD-V6	2001 MY	RNS	•		•	0
Galaxy	2.8L	2.8 CD-V6	Other	ABS	•		•	0
Galaxy	2.8L	2.8 CD-V6	Other	СЈВ	•		•	0
Galaxy	2.8L	2.8 CD-V6	Other	PCM				
Galaxy	2.8L	2.8 CD-V6	Other	TCM				0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	ABS	•	•	•	0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	ACM	•	•	•	0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	AHCM	•	•	•	0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	BCMii	•	•	•	•
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	CCMii	•	•	•	•
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	DDM	•	•	•	0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	HCM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	HVAC	•	•	•	0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	IPC	•	•	•	•
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	NAV	•	•	•	0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PAM	•	•	•	0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PBM	•	•	•	0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PCM	•	•	•	0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PDM	•	•	•	0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PSCM	•	•	•	0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	RCM	•	•	•	0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	RFA	•	•	•	0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	RGTM	•	•	•	0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	RHVAC	•	•	•	0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	SASM	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	SRM	•	•	•	0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	TRM	•	•	•	0
GALAXY\S-Max	1.8L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	VDM	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	ABS	•		•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	ACM	•		•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	AHCM	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	BCMii	•	•	•	•
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	CCMii	•	•	•	
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	DDM	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	HCM				0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	HVAC				0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	IPC				
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	NAV				0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	PAM				0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	PBM				0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	PCM		•		
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	PDM		•		0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	PSCM	•		•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	RCM	•		•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	RFA	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	RGTM	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	RHVAC	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	SASM	•	•	•	0

- This function is supported.
- O This function is not supported.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	SRM		•		0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	TRM	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2006. 5	VDM	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	ABS	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	ACM	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	AHCM	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	BCMii	•	•	•	
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	CMR	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010. 5 MY	DDM	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	DSM	•		•	
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	HCM	•		•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	HVAC	•		•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	IPC	•	•	•	•
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	PAM	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	PBM		•		0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	PCM	•		•	
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	PDM	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	RCM	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	RFA	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	RHVAC	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	SASM	•		•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	SOD-L	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	SOD-R	•	•	•	0
GALAXY\S-Max	2. 0L	DURATEC-HE / I4	2010.5 MY	SRM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	ABS	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	ACM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	АНСМ	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	BCMii	•	•	•	•
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	CCMii	•	•	•	•
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	DDM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	HCM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	HVAC	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	IPC	•	•	•	•
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	NAV	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PAM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PBM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PCM	•	•	•	•
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PDM	•	•	•	0

- This function is supported.
- O This function is not supported.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PSCM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	RCM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	RFA	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	RGTM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	RHVAC	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	SASM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	SRM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	TCM	•	•	•	
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	TRM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	VDM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010.5 MY	ABS	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010.5 MY	ACM	•	•	•	0

- This function is supported.
- O This function is not supported.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010. 5 MY	AHCM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010.5 MY	BCMii	•	•	•	•
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010. 5 MY	CMR	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010. 5 MY	DDM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010. 5 MY	DSM	•	•	•	
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010. 5 MY	HCM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010.5 MY	HVAC	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010.5 MY	IPC	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010.5 MY	PAM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010.5 MY	PBM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010.5 MY	PCM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010.5 MY	PDM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010.5 MY	PSCM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010.5 MY	RCM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010.5 MY	RFA	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010.5 MY	RHVAC	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010.5 MY	SASM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010. 5 MY	SOD-L	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010. 5 MY	SOD-R	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010. 5 MY	SRM	•	•	•	0
GALAXY\S-Max	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	2010. 5 MY	TCM	•	•	•	0
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010. 5 MY	ABS	•	•	•	0
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010.5 MY	ACM	•	•	•	0
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010. 5 MY	AHCM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010.5 MY	BCMii	•	•	•	•
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010.5 MY	CMR	•	•	•	0
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010. 5 MY	DDM	•	•	•	0
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010.5 MY	DSM	•	•	•	
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010.5 MY	HCM	•	•	•	0
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010.5 MY	HVAC	•	•	•	0
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010.5 MY	IPC	•	•	•	•
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010.5 MY	PAM	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010.5 MY	PBM	•	•	•	0
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010.5 MY	PCM	•	•	•	0
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010.5 MY	PDM	•	•	•	0
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010.5 MY	RCM	•	•	•	0
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010.5 MY	RFA	•	•	•	0
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010.5 MY	RHVAC	•	•	•	0
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010.5 MY	SASM	•	•	•	0
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010.5 MY	SOD-L	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010. 5 MY	SOD-R	•	•	•	0
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010. 5 MY	SRM	•	•	•	0
GALAXY\S-Max	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	2010.5 MY	TCM	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	ABS	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	ACM	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	AHCM	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	BCMii	•	•	•	•
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	CCMii	•	•	•	•
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	DDM	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	HCM	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	HVAC	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	IPC	•	•	•	•
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	NAV	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PAM	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PBM	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PCM	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PDM	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PSCM	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	RCM	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	RFA	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	RGTM	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	RHVAC	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	SASM	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	SRM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	TRM	•	•	•	0
GALAXY\S-Max	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	VDM	•	•	•	0
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006. 5	ABS		•		0
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006. 5	ACM		•		0
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	AHCM		•		0
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	BCMii		•		
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	CCMii		•		
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	DDM		•		0
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	HCM		•	•	0
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	HVAC		•	•	0
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	IPC		•		
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	NAV		•		0
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	PAM		•		0
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	PBM		•	•	0
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	PCM		•		
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	PDM		•	•	0
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	PSCM		•	•	0
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	RCM		•	•	0
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	RFA	•		•	0
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	RGTM		•		0
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	RHVAC		•	•	0
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	SASM	•	•	•	0
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	SRM		•	•	0
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	TCM		•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
GALAXY\S-Max	2.3L	DURATEC-HE / I4	2006. 5	TRM	•	•		0
GALAXY\S-Max	2. 3L	DURATEC-HE / I4	2006. 5	VDM	•	•	•	0
GALAXY\S-Max	2.5L	15	2006. 5	ABS	•	•	•	0
GALAXY\S-Max	2.5L	I5	2006. 5	ACM	•			0
GALAXY\S-Max	2.5L	15	2006. 5	AHCM	•	•	•	0
GALAXY\S-Max	2.5L	15	2006. 5	BCMii	•	•	•	•
GALAXY\S-Max	2.5L	I5	2006. 5	CCMii	•			
GALAXY\S-Max	2.5L	I5	2006. 5	DDM	•	•	•	0
GALAXY\S-Max	2.5L	I5	2006. 5	HCM	•	•	•	0
GALAXY\S-Max	2.5L	I5	2006. 5	HVAC	•			0
GALAXY\S-Max	2.5L	I5	2006. 5	IPC	•	•		•
GALAXY\S-Max	2.5L	I5	2006. 5	NAV	•	•		0
GALAXY\S-Max	2.5L	I5	2006. 5	PAM	•	•	•	0
GALAXY\S-Max	2.5L	I5	2006. 5	PBM	•	•	•	0
GALAXY\S-Max	2.5L	I5	2006. 5	PCM	•	•	•	0
GALAXY\S-Max	2.5L	I5	2006. 5	PDM	•			0
GALAXY\S-Max	2.5L	I5	2006. 5	PSCM	•			0
GALAXY\S-Max	2.5L	I5	2006. 5	RCM	•			0
GALAXY\S-Max	2.5L	I5	2006. 5	RFA	•	•	•	0
GALAXY\S-Max	2.5L	I5	2006. 5	RGTM	•	•	•	0
GALAXY\S-Max	2.5L	I5	2006. 5	RHVAC	•	•	•	0
GALAXY\S-Max	2.5L	I5	2006. 5	SASM	•	•	•	0
GALAXY\S-Max	2.5L	I5	2006. 5	SRM	•	•	•	0
GALAXY\S-Max	2.5L	I5	2006. 5	TRM	•	•	•	0
GALAXY\S-Max	2.5L	I5	2006. 5	VDM	•	•	•	0
Granada / Scorpio	2. 0L	2.0 DOHC SFI (8V)	1995. 25 MY	ABS/TCS	•	•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Granada / Scorpio	2. 0L	2.0 DOHC SFI (8V)	1995.25 MY	GEM	•	•		0
Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	1995.25 MY	PATS				0
Granada / Scorpio	2. 0L	2.0 DOHC SFI (8V)	1995.25 MY	PCM				
Granada / Scorpio	2.0L	2.0 DOHC SFI (8V)	1995.25 MY	RCM				0
Granada / Scorpio	2. 0L	2.0 DOHC SFI (8V)	1997 MY	ABS/TCS	•			
Granada / Scorpio	2. 0L	2.0 DOHC SFI (8V)	1997 MY	GEM				0
Granada / Scorpio	2. 0L	2.0 DOHC SFI (8V)	1997 MY	PATS				0
Granada / Scorpio	2. 0L	2.0 DOHC SFI (8V)	1997 MY	PCM	•	•		
Granada / Scorpio	2. 0L	2.0 DOHC SFI (8V)	1997 MY	RCM		•		0
Granada / Scorpio	2.0L	DOHC SFI (16V)	1995.25 MY	ABS/TCS				
Granada / Scorpio	2. 0L	DOHC SFI (16V)	1995.25 MY	GEM	•	•		0
Granada / Scorpio	2. 0L	DOHC SFI (16V)	1995.25 MY	PATS				0
Granada / Scorpio	2. 0L	DOHC SFI (16V)	1995. 25 MY	PATS		•	0	
Granada / Scorpio	2. 0L	DOHC SFI (16V)	1995. 25 MY	PCM		•		
Granada / Scorpio	2. 0L	DOHC SFI (16V)	1995. 25 MY	RCM		•		0
Granada / Scorpio	2. 0L	Other	1995 MY	ABS/TCS	•	•		
Granada / Scorpio	2. 0L	Other	1995 MY	GEM		•		0
Granada / Scorpio		Other	1995 MY	PATS		•		0
Granada / Scorpio		Other	1995 MY	PATS		•	0	
Granada / Scorpio	2. 0L	Other	1995 MY	PCM		•		
Granada / Scorpio		Other	1995 MY	RCM				0
Granada / Scorpio	2. 3L	DOHC SFI (16V)	1996.75 MY	ABS/TCS				
Granada / Scorpio	2.3L	DOHC SFI (16V)	1996.75 MY	GEM	•	•		0
Granada / Scorpio	2.3L	DOHC SFI (16V)	1996.75 MY	PATS	•	•		0
Granada / Scorpio	2.3L	DOHC SFI (16V)	1996.75 MY	PATS		•	0	
Granada / Scorpio	2.3L	DOHC SFI (16V)	1996.75 MY	PCM				

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Granada / Scorpio	2. 3L	DOHC SFI (16V)	1996.75 MY	PCM		•		0
Granada / Scorpio	2. 3L	DOHC SFI (16V)	1996.75 MY	RCM		•		0
Granada / Scorpio	2. 3L	DOHC SFI (16V)	1998 MY	ABS/TCS		•		
Granada / Scorpio	2. 3L	DOHC SFI (16V)	1998 MY	GEM		•		0
Granada / Scorpio	2.3L	DOHC SFI (16V)	1998 MY	PATS		•		0
Granada / Scorpio	2.3L	DOHC SFI (16V)	1998 MY	PATS			0	•
Granada / Scorpio	2.3L	DOHC SFI (16V)	1998 MY	PCM				
Granada / Scorpio	2.3L	DOHC SFI (16V)	1998 MY	PCM				0
Granada / Scorpio	2. 3L	DOHC SFI (16V)	1998 MY	RCM				0
Granada / Scorpio	2. 3L	DOHC SFI (16V)	1998.25 MY	ABS/TCS		•		
Granada / Scorpio	2.3L	DOHC SFI (16V)	1998.25 MY	GEM		•		0
Granada / Scorpio	2. 3L	DOHC SFI (16V)	1998.25 MY	PATS		•	0	
Granada / Scorpio	2.3L	DOHC SFI (16V)	1998.25 MY	PCM				
Granada / Scorpio	2. 3L	DOHC SFI (16V)	1998.25 MY	PCM				0
Granada / Scorpio	2.3L	DOHC SFI (16V)	1998.25 MY	RCM				0
Granada / Scorpio	2.5L	Other	0ther	ABS/TCS		•		•
Granada / Scorpio		Other	0ther	GEM				0
Granada / Scorpio	2.5L		0ther	PATS				0
Granada / Scorpio	2.5L	Other	0ther	PATS			0	
Granada / Scorpio	2.5L	Other	Other	PCM				
Granada / Scorpio	2.5L	Other	Other	RCM		•		0
Granada / Scorpio	2.9L	2.9 V6 24V	1991 5 MY	ABS/TCS		•		•
Granada / Scorpio	2.9L	2.9 V6 24V	1991 5 MY	GEM				0
Granada / Scorpio	2.9L	2.9 V6 24V	1991 5 MY	PATS	•	•	0	
Granada / Scorpio	2.9L	2.9 V6 24V	1991 5 MY	PCM		•		
Granada / Scorpio	2.9L	2.9 V6 24V	1991 5 MY	PCM		•		0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Granada / Scorpio	2. 9L	2.9 V6 24V	1991 5 MY	RCM	•	•	•	0
Granada / Scorpio	2. 9L	2.9 V6 24V	1993.75 MY	ABS/TCS		•	•	
Granada / Scorpio	2.9L	2.9 V6 24V	1993.75 MY	GEM		•		0
Granada / Scorpio	2.9L	2.9 V6 24V	1993.75 MY	PATS		•	0	
Granada / Scorpio	2.9L	2.9 V6 24V	1993.75 MY	PCM		•	•	
Granada / Scorpio	2.9L	2.9 V6 24V	1993.75 MY	PCM		•	•	0
Granada / Scorpio	2.9L	2.9 V6 24V	1993.75 MY	RCM		•		0
Granada / Scorpio	2.9L	2.9 V6 24V	1995 MY	ABS/TCS		•		
Granada / Scorpio	2.9L	2.9 V6 24V	1995 MY	GEM		•		0
Granada / Scorpio	2.9L	2.9 V6 24V	1995 MY	PATS		•	0	
Granada / Scorpio	2.9L	2.9 V6 24V	1995 MY	PCM		•	•	
Granada / Scorpio	2.9L	2.9 V6 24V	1995 MY	PCM		•		0
Granada / Scorpio	2.9L	2.9 V6 24V	1995 MY	RCM		•		0
Granada / Scorpio	2.9L	2.9 V6 24V	1995. 25 MY	ABS/TCS		•		
Granada / Scorpio	2.9L	2.9 V6 24V	1995.25 MY	GEM		•		0
Granada / Scorpio	2.9L	2.9 V6 24V	1995.25 MY	PATS		•	0	
Granada / Scorpio	2.9L	2.9 V6 24V	1995.25 MY	PCM		•		
Granada / Scorpio	2.9L	2.9 V6 24V	1995.25 MY	PCM		•		0
Granada / Scorpio	2.9L	2.9 V6 24V	1995. 25 MY	RCM		•		0
Granada / Scorpio	2.9L	2.9 V6 24V	1997 MY	ABS/TCS		•		
Granada / Scorpio	2.9L	2.9 V6 24V	1997 MY	GEM		•	•	0
Granada / Scorpio	2.9L	2.9 V6 24V	1997 MY	PATS		•	0	
Granada / Scorpio	2.9L	2.9 V6 24V	1997 MY	PCM		•		
Granada / Scorpio	2.9L	2.9 V6 24V	1997 MY	PCM		•		0
Granada / Scorpio	2.9L	2.9 V6 24V	1997 MY	RCM				0
Granada / Scorpio	2.9L	2.9 V6 24V	1998 MY	ABS/TCS	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Granada / Scorpio	2.9L	2.9 V6 24V	1998 MY	GEM	•	•		0
Granada / Scorpio	2.9L	2.9 V6 24V	1998 MY	PATS			0	
Granada / Scorpio	2.9L	2.9 V6 24V	1998 MY	PCM				
Granada / Scorpio	2.9L	2.9 V6 24V	1998 MY	PCM		•		0
Granada / Scorpio	2.9L	2.9 V6 24V	1998 MY	RCM				0
Granada / Scorpio	2.9L	2.9 V6 24V	1998.25 MY	ABS/TCS	•	•		
Granada / Scorpio	2.9L	2.9 V6 24V	1998.25 MY	GEM	•	•		0
Granada / Scorpio	2.9L	2.9 V6 24V	1998.25 MY	PATS	•	•	0	
Granada / Scorpio	2.9L	2.9 V6 24V	1998.25 MY	PCM	•	•		
Granada / Scorpio	2.9L	2.9 V6 24V	1998.25 MY	PCM	•	•		0
Granada / Scorpio	2.9L	2.9 V6 24V	1998.25 MY	RCM	•	•	•	0
Ka	1. 0L	HCS	1997.5 MY	ABS/TCS	•	•	•	•
Ka	1. 0L	HCS	1997.5 MY	CSM	•	•	•	0
Ka	1. 0L	HCS	1997.5 MY	PATS	•	•	•	0
Ka	1. 0L	HCS	1997.5 MY	PCM	•	•		
Ka	1. 0L	HCS	1999 MY	ABS/TCS	•	•	•	•
Ka	1. 0L	HCS	1999 MY	CSM	•	•	•	0
Ka	1. 0L	HCS	1999 MY	ECS	•	•	•	0
Ka	1. 0L	HCS	1999 MY	PCM	•	•	•	
Ka	1. 0L	Zetec Rocam	1999.75 MY	ABS/TCS	•	•		
Ka	1. 0L	Zetec Rocam	1999.75 MY	CSM	•	•		0
Ka	1. 0L	Zetec Rocam	1999.75 MY	PCM	•	•	•	
KA	1. 2L	DURATEC 8V	2009 MY	ABS	•	•	•	
KA	1. 2L	DURATEC 8V	2009 MY	BCMii	•	•		
KA	1. 2L	DURATEC 8V	2009 MY	EPS	•	•		0
KA	1.2L	DURATEC 8V	2009 MY	PAM	•	•		0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ка	1. 3L	DURATEC 8V	2000 MY	ABS/TCS		•		
Ka	1. 3L	DURATEC 8V	2000 MY	CSM		•		0
Ka	1. 3L	DURATEC 8V	2000 MY	ECS		•		0
Ka	1. 3L	DURATEC 8V	2000 MY	GEM		•		
Ka	1. 3L	DURATEC 8V	2000 MY	PCM		•		
KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	2009 MY	ABS	•	•	•	
KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	2009 MY	BCMii	•	•	•	
KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	2009 MY	EPS	•	•	•	0
KA	1. 3L	Duratorq-Turbo Diesel Common Rail Injection	2009 MY	PAM	•	•	•	0
Ка	1. 3L	Endura-E	1997 MY	ABS/TCS		•		
Ka	1. 3L	Endura-E	1997 MY	CSM		•		0
Ka	1.3L	Endura-E	1997 MY	PATS		•		0
Ka	1. 3L	Endura-E	1997 MY	PCM		•		
Ka	1.3L	Endura-E	1997.5 MY	ABS/TCS				
Ka	1.3L	Endura-E	1997.5 MY	CSM				0
Ka	1.3L	Endura-E	1997.5 MY	PATS				0
Ka	1.3L	Endura-E	1997.5 MY	PCM		•		
Ka	1. 3L	Endura-E	19985 MY	ABS/TCS	•	•		•
Ka	1. 3L	Endura-E	19985 MY	CSM		•		0
Ka	1. 3L	Endura-E	19985 MY	PATS				0
Ka	1. 3L	Endura-E	19985 MY	PCM		•		
Ka	1. 3L	Endura-E	1999 MY	ABS/TCS		•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ka	1. 3L	Endura-E	1999 MY	CSM	•	•		0
Ka	1.3L	Endura-E	1999 MY	ECS	•	•		0
Ka	1.3L	Endura-E	1999 MY	PCM	•	•		
Ka	1. 3L	Endura-E	2000 MY	ABS/TCS	•	•		
Ka	1.3L	Endura-E	2000 MY	CSM	•	•		0
Ka	1.3L	Endura-E	2000 MY	ECS	•	•		0
Ka	1.3L	Endura-E	2000 MY	GEM	•	•		
Ka	1.3L	Endura-E	2000 MY	PCM	•	•		
Ka	1.6L	DURATEC 8V	2000 MY	ABS/TCS	•	•		
Ka	1.6L	DURATEC 8V	2000 MY	CSM	•	•		0
Ka	1.6L	DURATEC 8V	2000 MY	ECS	•	•	•	0
Ka	1.6L	DURATEC 8V	2000 MY	GEM	•	•		
Ka	1.6L	DURATEC 8V	2000 MY	PCM	•	•		
Ka	1.6L	Zetec Rocam	2001.5 MY	ABS/TCS	•	•		
Ka	1.6L	Zetec Rocam	2001.5 MY	CSM	•	•		0
Ka	1.6L	Zetec Rocam	2001.5 MY	ECS		•		0
Ka	1.6L	Zetec Rocam	2001.5 MY	PCM	•	•		
MONDEO	1.6L	DURATEC VCT	MY07.25	ABS	•	•		0
MONDEO	1.6L	DURATEC VCT	MY07.25	ACM	•	•		0
MONDEO	1.6L	DURATEC VCT	MY07.25	AHCM	•	•		0
MONDEO	1.6L	DURATEC VCT	MY07.25	BCMii	•	•		
MONDEO	1.6L	DURATEC VCT	MY07.25	CCMii	•	•	•	•
MONDEO	1.6L	DURATEC VCT	MY07.25	CMR	•	•		0
MONDEO	1. 6L	DURATEC VCT	MY07.25	DDM	•	•	•	0
MONDEO	1. 6L	DURATEC VCT	MY07.25	DSM	•	•	•	•
MONDEO	1.6L	DURATEC VCT	MY07.25	HCM	•	•		0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MONDEO	1.6L	DURATEC VCT	MY07.25	HVAC		•		0
MONDEO	1.6L	DURATEC VCT	MY07.25	IPC		•		
MONDEO	1.6L	DURATEC VCT	MY07.25	PAM		•		0
MONDEO	1.6L	DURATEC VCT	MY07.25	PBM		•	•	0
MONDEO	1.6L	DURATEC VCT	MY07.25	PCM		•		0
MONDEO	1.6L	DURATEC VCT	MY07.25	PDM		•		0
MONDEO	1.6L	DURATEC VCT	MY07.25	PSCM		•	•	0
MONDEO	1.6L	DURATEC VCT	MY07.25	RCM		•	•	0
MONDEO	1.6L	DURATEC VCT	MY07.25	RFA		•		0
MONDEO	1.6L	DURATEC VCT	MY07.25	SASM	•	•	•	0
MONDEO	1.6L	DURATEC VCT	MY07.25	SRM		•	•	0
MONDEO	1.6L	DURATEC VCT	MY07.25	TRM			•	0
MONDEO	1.6L	DURATEC VCT	MY07.25	VDM		•	•	0
Mondeo	1.6L	Zetec	1993.5 MY	ABS		•	•	0
Mondeo	1.6L	Zetec	1993.5 MY	CSM		•		0
Mondeo	1.6L	Zetec	1993.5 MY	PATS		•	•	0
Mondeo	1.6L	Zetec	1995 MY	ABS		•	•	0
Mondeo	1.6L	Zetec	1995 MY	CSM		•	•	0
Mondeo	1.6L	Zetec	1995 MY	PATS		•	•	0
Mondeo	1.6L	Zetec	1997 MY	ABS		•	•	0
Mondeo	1.6L	Zetec	1997 MY	CSM	•		•	0
Mondeo	1.6L	Zetec	1997 MY	FFH		•		0
Mondeo	1.6L	Zetec	1997 MY	PATS		•	•	0
Mondeo	1.6L	Zetec	1997 MY	PCM	•	•	•	•
Mondeo	1.6L	Zetec	1998.75 MY	ABS	•	•	•	0
Mondeo	1.6L	Zetec	1998.75 MY	ABS/TCS		•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Mondeo	1.6L	Zetec	1998.75 MY	CSM		•		0
Mondeo	1.6L	Zetec	1998.75 MY	CSM		•	0	
Mondeo	1.6L	Zetec	1998.75 MY	FFH		•		0
Mondeo	1.6L	Zetec	1998.75 MY	PCM		•		
Mondeo	1.6L	Zetec	1999 MY	ABS		•		0
Mondeo	1.6L	Zetec	1999 MY	ABS/TCS		•		
Mondeo	1.6L	Zetec	1999 MY	CSM		•		0
Mondeo	1.6L	Zetec	1999 MY	CSM		•	0	
Mondeo	1.6L	Zetec	1999 MY	FFH		•		0
Mondeo	1.6L	Zetec	1999 MY	PCM		•		
Mondeo	1.8L	DURATEC-HE / I4	2001 MY	ABS		•		0
Mondeo	1.8L	DURATEC-HE / I4	2001 MY	ABS/TCS	•	•		
Mondeo	1.8L	DURATEC-HE / I4	2001 MY	ACM	•	•		0
Mondeo	1.8L	DURATEC-HE / I4	2001 MY	CDP		•		0
Mondeo	1.8L	DURATEC-HE / I4	2001 MY	CSM		•		0
Mondeo	1.8L	DURATEC-HE / I4	2001 MY	EATC		•		
Mondeo	1.8L	DURATEC-HE / I4	2001 MY	GDM		•		0
Mondeo	1.8L	DURATEC-HE / I4	2001 MY	GEM		•		
Mondeo	1.8L	DURATEC-HE / I4	2001 MY	HEC		•		
Mondeo	1.8L	DURATEC-HE / I4	2001 MY	LHID		•		
Mondeo	1.8L	DURATEC-HE / I4	2001 MY	NAV		•		0
Mondeo	1.8L	DURATEC-HE / I4	2001 MY	PCM	•	•	•	
Mondeo	1.8L	DURATEC-HE / I4	2001 MY	RCM	•	•	•	0
Mondeo	1.8L	DURATEC-HE / I4	2001 MY	RETM	•	•		0
Mondeo	1.8L	DURATEC-HE / I4	2001 MY	RHID	•	•		0
Mondeo	1.8L	DURATEC-HE / I4	2001 MY	SRM	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Mondeo	1.8L	DURATEC-SCi	2001 MY	ABS		•		0
Mondeo	1.8L	DURATEC-SCi	2001 MY	ABS/TCS		•		
Mondeo	1.8L	DURATEC-SCi	2001 MY	ACM		•		0
Mondeo	1.8L	DURATEC-SCi	2001 MY	CDP		•		0
Mondeo	1.8L	DURATEC-SCi	2001 MY	CSM		•		0
Mondeo	1.8L	DURATEC-SCi	2001 MY	EATC		•		
Mondeo	1.8L	DURATEC-SCi	2001 MY	GDM		•		0
Mondeo	1.8L	DURATEC-SCi	2001 MY	GEM		•		
Mondeo	1.8L	DURATEC-SCi	2001 MY	HEC				
Mondeo	1.8L	DURATEC-SCi	2001 MY	LHID		•		
Mondeo	1.8L	DURATEC-SCi	2001 MY	NAV		•		0
Mondeo	1.8L	DURATEC-SCi	2001 MY	PCM		•		0
Mondeo	1.8L	DURATEC-SCi	2001 MY	RCM				0
Mondeo	1.8L	DURATEC-SCi	2001 MY	RETM		•		0
Mondeo	1.8L	DURATEC-SCi	2001 MY	RHID		•		0
Mondeo	1.8L	DURATEC-SCi	2001 MY	SRM				0
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07. 25	ABS	•	•	•	0
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07. 25	ACM	•	•	•	0
MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	MY07. 25	AHCM	•	•	•	0
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07. 25	BCMii	•	•	•	•
MONDEO	1. 8L	Duratorq Turbo Diesel Common Rail Injection	MY07. 25	CCMii	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	CMR	•	•	•	0
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	DDM	•	•	•	0
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	DSM	•	•	•	•
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	НСМ	•	•	•	0
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	HVAC	•	•	•	0
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	IPC	•	•	•	•
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	PAM	•	•	•	0
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	PBM	•	•	•	0
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	PCM	•	•	•	•
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	PDM	•	•	•	0
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	PSCM	•	•	•	0
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	RCM	•	•	•	0
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	RFA	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	SASM	•	•	•	0
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	SRM	•	•	•	0
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	TRM	•	•	•	0
MONDEO	1.8L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	VDM	•	•	•	0
Mondeo	1.8L	Endura-DE		ABS	•	•		0
Mondeo	1.8L	Endura-DE		CSM	•	•		0
Mondeo	1.8L	Endura-DE		PATS	•	•	•	0
Mondeo	1.8L	Endura-DE	1997 MY	ABS	•	•	•	0
Mondeo	1.8L	Endura-DE	1997 MY	CSM				0
Mondeo	1.8L	Endura-DE	1997 MY	FFH				0
Mondeo	1.8L	Endura-DE	1997 MY	PATS				0
Mondeo	1.8L	Endura-DE	1997 MY	PCM				0
Mondeo	1.8L	Endura-DE	Other	ABS				0
Mondeo	1.8L	Endura-DE	Other	CSM				0
Mondeo	1.8L	Endura-DE	Other	PATS		•		0
Mondeo	1.8L	Zetec	1993.5 MY	ABS		•		0
Mondeo	1.8L	Zetec	1993.5 MY	CSM	•			0
Mondeo	1.8L	Zetec	1993.5 MY	PATS				0
Mondeo	1.8L	Zetec	1993.75 MY	ABS	•	•		0
Mondeo	1.8L	Zetec	1993.75 MY	CSM	•	•		0
Mondeo	1.8L	Zetec	1993.75 MY	PATS	•	•		0
Mondeo	1.8L	Zetec	1994.5 MY	ABS	•	•		0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
Mondeo	1.8L	Zetec	1994.5 MY	CSM		•	•	0
Mondeo	1.8L	Zetec	1994.5 MY	PATS	•	•	•	0
Mondeo	1.8L	Zetec	1995 MY	ABS				0
Mondeo	1.8L	Zetec	1995 MY	CSM				0
Mondeo		Zetec	1995 MY	PATS				0
Mondeo	1.8L	Zetec	1996 MY	ABS				0
Mondeo	1.8L	Zetec	1996 MY	CSM				0
Mondeo	1.8L	Zetec	1996 MY	PATS	•	•	•	0
Mondeo	1.8L	Zetec	1997 MY	ABS			•	0
Mondeo	1.8L	Zetec	1997 MY	CSM		•		0
Mondeo	1.8L	Zetec	1997 MY	FFH	•	•	•	0
Mondeo	1.8L	Zetec	1997 MY	PATS	•	•	•	0
Mondeo	1.8L	Zetec	1997 MY	PCM	•	•	•	•
Mondeo	1.8L	Zetec	1997 MY	PCM				0
Mondeo	1.8L	Zetec	1998 MY	ABS				0
Mondeo	1.8L	Zetec	1998 MY	ABS/TCS				
Mondeo	1.8L	Zetec	1998 MY	CSM		•	•	0
Mondeo	1.8L	Zetec	1998 MY	CSM	•	•	0	
Mondeo	1.8L	Zetec	1998 MY	FFH	•	•	•	0
Mondeo	1.8L	Zetec	1998 MY	PATS	•	•	0	•
Mondeo	1.8L	Zetec	1998 MY	PCM	•		•	•
Mondeo	1.8L	Zetec	1998.75 MY	ABS		•	•	0
Mondeo	1.8L	Zetec	1998.75 MY	ABS/TCS		•	•	
Mondeo	1.8L	Zetec	1998.75 MY	CSM	•	•	•	0
Mondeo	1.8L	Zetec	1998.75 MY	CSM	•	•	0	
Mondeo	1.8L	Zetec	1998.75 MY	FFH	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Mondeo	1.8L	Zetec	1998.75 MY	PCM	•	•	•	
Mondeo	1.8L	Zetec	19985 MY	ABS	•	•	•	0
Mondeo	1.8L	Zetec	19985 MY	ABS/TCS	•	•		
Mondeo	1.8L	Zetec	19985 MY	CSM		•		0
Mondeo	1.8L	Zetec	19985 MY	CSM	•	•	0	
Mondeo	1.8L	Zetec	19985 MY	FFH				0
Mondeo	1.8L	Zetec	19985 MY	PATS			0	
Mondeo	1.8L	Zetec	19985 MY	PCM	•			
Mondeo	1.8L	Zetec	1999 MY	ABS				0
Mondeo	1.8L	Zetec	1999 MY	ABS/TCS	•			
Mondeo	1.8L	Zetec	1999 MY	CSM	•			0
Mondeo	1.8L	Zetec	1999 MY	CSM			0	
Mondeo	1.8L	Zetec	1999 MY	FFH				0
Mondeo	1.8L	Zetec	1999 MY	PCM				
Mondeo	1.8L	Zetec	2000.25 MY	ABS				0
Mondeo	1.8L	Zetec	2000.25 MY	ABS/TCS	•			0
Mondeo	1.8L	Zetec	2000.25 MY	AFCM				0
Mondeo	1.8L	Zetec	2000.25 MY	CSM				0
Mondeo	1.8L	Zetec	2000.25 MY	PCM				
Mondeo	2. 0L	DURATEC-HE / I4	2001 MY	ABS				0
Mondeo	2.0L	DURATEC-HE / I4	2001 MY	ABS/TCS		•		•
Mondeo	2.0L	DURATEC-HE / I4	2001 MY	ACM				0
Mondeo	2.0L	DURATEC-HE / I4	2001 MY	CDP		•		0
Mondeo	2. 0L	DURATEC-HE / I4	2001 MY	CSM	•	•		0
Mondeo	2. 0L	DURATEC-HE / I4	2001 MY	EATC	•			
Mondeo	2. 0L	DURATEC-HE / I4	2001 MY	GDM				0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Mondeo	2. 0L	DURATEC-HE / I4	2001 MY	GEM		•		
Mondeo	2. 0L	DURATEC-HE / I4	2001 MY	HEC		•		
Mondeo	2. 0L	DURATEC-HE / I4	2001 MY	LHID		•		
Mondeo	2.0L	DURATEC-HE / I4	2001 MY	NAV		•		0
Mondeo	2. 0L	DURATEC-HE / I4	2001 MY	PCM		•		
Mondeo	2. 0L	DURATEC-HE / I4	2001 MY	RCM		•		0
Mondeo	2. 0L	DURATEC-HE / I4	2001 MY	RETM		•		0
Mondeo	2. 0L	DURATEC-HE / I4	2001 MY	RHID		•		0
Mondeo	2. 0L	DURATEC-HE / I4	2001 MY	SRM		•		0
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	ABS		•		0
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	ACM		•		0
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	AHCM		•		0
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	BCMii		•		
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	CCMii		•		
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	CMR		•		0
MONDEO	2.0L	DURATEC-HE / I4	MY07.25	DDM		•		0
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	DSM		•		
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	HCM		•		0
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	HVAC		•		0
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	IPC		•		•
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	PAM		•		0
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	PBM		•	•	0
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	PCM	•	•	•	
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	PDM	•	•	•	0
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	PSCM	•	•	•	0
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	RCM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	RFA		•		0
MONDEO	2. 0L	DURATEC-HE / I4	MY07.25	SASM		•		0
MONDEO	2.0L	DURATEC-HE / I4	MY07.25	SRM				0
MONDEO	2.0L	DURATEC-HE / I4	MY07.25	TRM				0
MONDEO	2.0L	DURATEC-HE / I4	MY07.25	VDM			•	0
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	ABS	•	•	•	0
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	ABS/TCS	•	•	•	•
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	ACM	•	•	•	0
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	CDP	•	•	•	0
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	CSM	•	•	•	0
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	EATC	•	•	•	•
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	FFH	•	•	•	•
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	GDM	•	•	•	0
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	GEM	•	•	•	•
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	HEC	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	ICU	•	•	•	0
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	LHID	•	•	•	•
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	NAV	•	•	•	0
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	PCM	•	•	•	•
Mondeo	2. OL	Duratorq Turbo Diesel Common Rail Injection	2001 MY	RCM	•	•	•	0
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	RETM	•	•	•	0
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	RHID	•	•	•	0
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	SRM	•	•	•	0
Mondeo	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	TCM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	ABS	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	ACM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	AHCM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	BCMii	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	CCMii	•	•	•	•
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	CMR	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	DDM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	DSM	•	•	•	•
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	НСМ	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	HVAC	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	IPC	•	•	•	•
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	PAM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	PBM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	PCM	•	•	•	•
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	PDM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	PSCM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	RCM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07. 25	RFA	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	SASM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	SRM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	TCM	•	•	•	
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	TRM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	VDM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07. 25	ABS	•	•	•	0
MONDEO	2. OL	Duratorq Turbo Diesel Common Rail Injection StgV	MY07. 25	ACM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07. 25	AHCM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07. 25	BCMii	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes		Active Test
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07. 25	CCMii	•	•	•	•
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07. 25	CMR	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07. 25	DDM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07. 25	DSM	•	•	•	•
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07. 25	НСМ	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07. 25	HVAC	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07. 25	IPC	•	•	•	•
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07. 25	PAM	•	•	•	0

- This function is supported.
- O This function is not supported.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07.25	PBM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07.25	PCM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07.25	PDM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07.25	PSCM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07.25	RCM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07.25	RFA	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07.25	SASM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07.25	SRM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	TCM	•	•	•	0
MONDEO	2. 0L	StgV Duratorq Turbo Diesel Common Rail Injection StgV	MY07.25	TRM	•	•	•	0
MONDEO	2. 0L	Duratorq Turbo Diesel Common Rail Injection StgV	MY07.25	VDM	•	•	•	0
Mondeo	2. 0L	DURATORQ DI	2001 MY	ABS	•	•	•	0
Mondeo	2. 0L	DURATORQ DI	2001 MY	ABS/TCS	•			
Mondeo	2. 0L	DURATORQ DI	2001 MY	ACM	•	•		0
Mondeo	2. 0L	DURATORQ_DI	2001 MY	CDP	•	•	•	0
Mondeo	2. 0L	DURATORQ_DI	2001 MY	CSM	•	•	•	0
Mondeo	2. 0L	DURATORQ DI	2001 MY	EATC	•	•		•
Mondeo	2. 0L	DURATORQ DI	2001 MY	FFH	•	•		•
Mondeo	2. 0L	DURATORQ DI	2001 MY	FIP	•			0
Mondeo	2. 0L	DURATORQ DI	2001 MY	GDM	•	•		0
Mondeo	2. 0L	DURATORQ_DI	2001 MY	GEM	•	•	•	•
Mondeo	2. 0L	DURATORQ_DI	2001 MY	HEC	•	•	•	•
Mondeo	2. 0L	DURATORQ DI	2001 MY	LHID	•	•		•
Mondeo	2. 0L	DURATORQ DI	2001 MY	NAV	•	•	•	0
Mondeo	2. 0L	DURATORQ_DI	2001 MY	PCM	•	•	•	•
Mondeo	2. 0L	DURATORQ_DI	2001 MY	RCM	•	•	•	0
Mondeo	2. 0L	DURATORQ_DI	2001 MY	RETM	•	•	•	0
Mondeo	2. 0L	DURATORQ_DI	2001 MY	RHID	•	•	•	0

- This function is supported.
- O This function is not supported.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Mondeo	2. 0L	DURATORQ_DI	2001 MY	SRM	•	•	•	0
MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	MY07.25	ABS	•	•	•	0
MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	MY07.25	ACM	•	•	•	0
MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	MY07.25	AHCM	•	•	•	0
MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	MY07.25	BCMii	•	•	•	•
MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	MY07.25	CCMii	•	•	•	•
MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	MY07.25	CMR	•	•	•	0
MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	MY07.25	DDM	•	•	•	0
MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	MY07.25	DSM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	MY07.25	HCM	•	•	•	0
MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	MY07.25	HVAC	•	•	•	0
MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	MY07.25	IPC	•	•	•	•
MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	MY07. 25	PAM	•	•	•	0
MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	MY07. 25	PBM	•	•	•	0
MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	MY07.25	PCM	•	•	•	0
MONDEO	2. OL	EcoBoost - Gas Turbocharged Direct Injection	MY07.25	PDM	•	•	•	0
MONDEO	2. 0L	EcoBoost - Gas Turbocharged Direct Injection	MY07.25	PSCM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MONDEO	0.01	EcoBoost - Gas	10/07 05	DCM				
MONDEO	2. 0L	Turbocharged Direct Injection	MY07. 25	RCM		_	_	0
		EcoBoost - Gas						
MONDEO	2. 0L	Turbocharged Direct	MY07.25	RFA	•	•	•	0
		Injection						
		EcoBoost - Gas						
MONDEO	2. 0L	Turbocharged Direct	MY07.25	SASM	•	•	•	0
		Injection						
		EcoBoost - Gas						
MONDEO	2. 0L	Turbocharged Direct	MY07.25	SRM		•		0
		Injection			<u> </u>			
MONDEO		EcoBoost - Gas	15707 05	(TD) (۱ ـ		
MONDEO	2. 0L	Turbocharged Direct	MY07.25	TRM	•	_	•	0
		Injection EcoBoost - Gas						
MONDEO	2. 0L	Turbocharged Direct	MY07.25	VDM			•	0
MONDEO	2. 01	Injection	W107.25	V DWI	•			O
Mondeo	2. OL	Zetec	1993.5 MY	ABS	•	•	•	0
Mondeo	2. 0L	Zetec	1993.5 MY	CSM	•	•	•	0
Mondeo	2. 0L	Zetec	1993.5 MY	PATS	•	•	•	0
Mondeo	2. 0L	Zetec	1993.75 MY	ABS	•	•	•	0
Mondeo	2. 0L	Zetec	1993.75 MY	CSM	•	•		0
Mondeo	2. 0L	Zetec	1993.75 MY	PATS	•	•	•	0
Mondeo	2. 0L	Zetec	1995 MY	ABS	•	•	•	0
Mondeo	2. 0L	Zetec	1995 MY	CSM				0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Mondeo	2. 0L	Zetec	1995 MY	PATS		•		0
Mondeo	2. 0L	Zetec	1996 MY	ABS		•	•	0
Mondeo	2. 0L	Zetec	1996 MY	CSM		•		0
Mondeo	2. 0L	Zetec	1996 MY	PATS		•	•	0
Mondeo	2. 0L	Zetec	1997 MY	ABS		•		0
Mondeo	2. 0L	Zetec	1997 MY	CSM		•		0
Mondeo	2. 0L	Zetec	1997 MY	FFH		•		0
Mondeo	2. 0L	Zetec	1997 MY	PATS		•	•	0
Mondeo	2. 0L	Zetec	1997 MY	PCM		•		
Mondeo	2. 0L	Zetec	1997 MY	PCM		•	•	0
Mondeo	2. 0L	Zetec	1998 MY	ABS		•	•	0
Mondeo	2. 0L	Zetec	1998 MY	ABS/TCS		•	•	
Mondeo	2. 0L	Zetec	1998 MY	CSM		•	•	0
Mondeo	2. 0L	Zetec	1998 MY	CSM		•	0	
Mondeo	2. 0L	Zetec	1998 MY	FFH		•	•	0
Mondeo	2. 0L	Zetec	1998 MY	PATS		•	0	
Mondeo	2. 0L	Zetec	1998 MY	PCM		•	•	
Mondeo	2. 0L	Zetec	1998 MY	PCM		•	•	0
Mondeo	2. 0L	Zetec	1998.75 MY	ABS		•	•	0
Mondeo	2. 0L	Zetec	1998.75 MY	ABS/TCS		•	•	•
Mondeo	2. 0L	Zetec	1998.75 MY	CSM	•		•	0
Mondeo	2. 0L	Zetec	1998.75 MY	CSM		•	0	
Mondeo	2. 0L	Zetec	1998.75 MY	FFH		•	•	0
Mondeo	2. 0L	Zetec	1998.75 MY	PATS	•	•	•	0
Mondeo	2. 0L	Zetec	1998.75 MY	PCM	•	•	•	•
Mondeo	2. 0L	Zetec	1998.75 MY	PCM	•	•	•	0

- This function is supported.
- O This function is not supported.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Mondeo	2. 0L	Zetec	19985 MY	ABS	•	•		0
Mondeo	2. 0L	Zetec	19985 MY	ABS/TCS		•		
Mondeo	2. 0L	Zetec	19985 MY	CSM		•		0
Mondeo	2. 0L	Zetec	19985 MY	CSM		•	0	
Mondeo	2. 0L	Zetec	19985 MY	FFH		•		0
Mondeo	2. 0L	Zetec	19985 MY	PATS		•	0	•
Mondeo	2. 0L	Zetec	19985 MY	PCM		•		
Mondeo	2. 0L	Zetec	1999 MY	ABS	•	•	•	0
Mondeo	2. 0L	Zetec	1999 MY	ABS/TCS		•		
Mondeo	2. 0L	Zetec	1999 MY	CSM	•			0
Mondeo	2. 0L	Zetec	1999 MY	CSM	•	•	0	
Mondeo	2. 0L	Zetec	1999 MY	FFH	•	•	•	0
Mondeo	2. 0L	Zetec	1999 MY	PCM	•	•	•	
Mondeo	2. 0L	Zetec	1999 MY	PCM	•	•	•	0
Mondeo	2. 0L	Zetec	2000.5 MY	ABS		•		0
Mondeo	2. 0L	Zetec	2000.5 MY	ABS/TCS	•			0
Mondeo	2. 0L	Zetec	2000.5 MY	CSM	•			0
Mondeo	2. 0L	Zetec	2000.5 MY	CSM	•	•	0	
Mondeo	2. 0L	Zetec	2000.5 MY	PCM	•	•	•	
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	ABS	•	•	•	0
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	ABS/TCS	•	•	•	•
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	ACM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	CDP	•	•	•	0
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	CSM	•	•	•	0
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	EATC	•	•	•	•
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	FFH	•	•	•	•
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	GDM	•	•	•	0
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	GEM	•	•	•	•
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	HEC	•	•	•	•
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	ICU	•	•	•	0
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	LHID	•	•	•	•
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	NAV	•	•	•	0
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	PCM	•	•	•	•
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	RCM	•	•	•	0
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	RETM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	RHID	•	•	•	0
Mondeo	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	SRM	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	ABS	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	ACM	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	AHCM	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	BCMii	•	•	•	•
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	CCMii	•	•	•	•
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	CMR	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	DDM	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	DSM	•	•	•	•
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	HCM	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	HVAC	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	IPC	•	•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	PAM	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	PBM	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	PCM	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	PDM	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	PSCM	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	RCM	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	RFA	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	SASM	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	SRM	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	TRM	•	•	•	0
MONDEO	2. 2L	Duratorq Turbo Diesel Common Rail Injection	MY07.25	VDM	•	•	•	0
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	ABS	•	•	•	0
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	ACM	•	•	•	0
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	AHCM	•	•	•	0
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	BCMii				

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	CCMii		•		
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	CMR		•		0
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	DDM		•		0
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	DSM		•		
MONDEO	2.3L	DURATEC-HE / I4	MY07.25	HCM		•		0
MONDEO	2.3L	DURATEC-HE / I4	MY07.25	HVAC		•		0
MONDEO	2.3L	DURATEC-HE / I4	MY07.25	IPC		•		
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	PAM		•		0
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	PBM		•		0
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	PCM		•		
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	PDM		•		0
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	PSCM		•		0
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	RCM		•		0
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	RFA		•		0
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	SASM		•		0
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	SRM		•		0
MONDEO	2.3L	DURATEC-HE / I4	MY07.25	TCM		•		
MONDEO	2.3L	DURATEC-HE / I4	MY07.25	TRM		•		0
MONDEO	2. 3L	DURATEC-HE / I4	MY07.25	VDM		•		0
Mondeo	2.5L	Duratec-VE	1994.75 MY	ABS		•		0
Mondeo	2. 5L	Duratec-VE	1994.75 MY	CSM		•		0
Mondeo	2.5L	Duratec-VE	1994.75 MY	PATS	•	•	•	0
Mondeo	2.5L	Duratec-VE	1995 MY	ABS	•	•	•	0
Mondeo	2. 5L	Duratec-VE	1995 MY	CSM	•	•		0
Mondeo	2. 5L	Duratec-VE	1995 MY	PATS	•	•		0
Mondeo	2.5L	Duratec-VE	1996 MY	ABS	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
Mondeo	2.5L	Duratec-VE	1996 MY	CSM				0
Mondeo	2. 5L	Duratec-VE	1996 MY	PATS		•		0
Mondeo	2.5L	Duratec-VE	1997 MY	ABS		•		0
Mondeo	2. 5L	Duratec-VE	1997 MY	CSM				\circ
Mondeo	2. 5L	Duratec-VE	1997 MY	FFH		•		0
Mondeo	2. 5L	Duratec-VE	1997 MY	PATS		•		0
Mondeo	2.5L	Duratec-VE	1997 MY	PCM		•		
Mondeo	2. 5L	Duratec-VE	1997 MY	PCM		•		0
Mondeo	2.5L	Duratec-VE	1998 MY	ABS		•		0
Mondeo	2.5L	Duratec-VE	1998 MY	ABS/TCS		•		
Mondeo	2. 5L	Duratec-VE	1998 MY	CSM		•		0
Mondeo	2.5L	Duratec-VE	1998 MY	CSM		•	0	
Mondeo	2.5L	Duratec-VE	1998 MY	FFH		•		0
Mondeo	2. 5L	Duratec-VE	1998 MY	PATS		•	0	
Mondeo	2. 5L	Duratec-VE	1998 MY	PCM				
Mondeo	2. 5L	Duratec-VE	1998 MY	PCM		•	•	0
Mondeo	2. 5L	Duratec-VE	19985 MY	ABS		•		0
Mondeo	2. 5L	Duratec-VE	19985 MY	ABS/TCS		•	•	
Mondeo	2. 5L	Duratec-VE	19985 MY	CSM		•		0
Mondeo	2. 5L	Duratec-VE	19985 MY	CSM		•	0	
Mondeo	2. 5L	Duratec-VE	19985 MY	FFH	•		•	0
Mondeo	2.5L	Duratec-VE	19985 MY	PATS		•	0	
Mondeo	2.5L	Duratec-VE	19985 MY	PCM	•	•		
Mondeo	2.5L	Duratec-VE	19985 MY	PCM	•	•	•	0
Mondeo	2.5L	Duratec-VE	1999 MY	ABS	•	•	•	0
Mondeo	2. 5L	Duratec-VE	1999 MY	ABS/TCS	•	•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Mondeo	2. 5L	Duratec-VE	1999 MY	CSM	•	•		0
Mondeo	2. 5L	Duratec-VE	1999 MY	CSM	•	•	0	
Mondeo	2. 5L	Duratec-VE	1999 MY	FFH	•	•		0
Mondeo	2.5L	Duratec-VE	1999 MY	PCM	•	•		
Mondeo	2. 5L	Duratec-VE	1999 MY	PCM	•	•		0
Mondeo	2. 5L	Duratec-VE	1999.75 MY	ABS	•	•		0
Mondeo	2. 5L	Duratec-VE	1999.75 MY	ABS/TCS	•	•		
Mondeo	2. 5L	Duratec-VE	1999.75 MY	CSM	•	•		0
Mondeo	2.5L	Duratec-VE	1999.75 MY	CSM	•	•	0	
Mondeo	2.5L	Duratec-VE	1999.75 MY	FFH	•	•		0
Mondeo	2. 5L	Duratec-VE	1999.75 MY	PCM	•	•		
Mondeo	2.5L	Duratec-VE	2000.5 MY	ABS	•	•		0
Mondeo	2.5L	Duratec-VE	2000.5 MY	ABS/TCS	•	•		0
Mondeo	2. 5L	Duratec-VE	2000.5 MY	CSM	•	•		0
Mondeo	2.5L	Duratec-VE	2000.5 MY	CSM	•	•	0	
Mondeo	2.5L	Duratec-VE	2000.5 MY	PCM		•		
Mondeo	2. 5L	Duratec-VE	2001 MY	ABS	•	•		0
Mondeo	2. 5L	Duratec-VE	2001 MY	ABS/TCS	•	•		
Mondeo	2. 5L	Duratec-VE	2001 MY	ACM	•	•		0
Mondeo	2. 5L	Duratec-VE	2001 MY	CDP	•	•		0
Mondeo	2.5L	Duratec-VE	2001 MY	CSM	•	•		0
Mondeo	2.5L	Duratec-VE	2001 MY	EATC	•	•	•	
Mondeo	2.5L	Duratec-VE	2001 MY	GDM	•	•	•	0
Mondeo	2. 5L	Duratec-VE	2001 MY	GEM	•	•		•
Mondeo	2. 5L	Duratec-VE	2001 MY	HEC	•	•		•
Mondeo	2.5L	Duratec-VE	2001 MY	LHID	•	•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Mondeo	2. 5L	Duratec-VE	2001 MY	NAV				0
Mondeo	2.5L	Duratec-VE	2001 MY	PCM		•		
Mondeo	2.5L	Duratec-VE	2001 MY	RCM		•		0
Mondeo	2.5L	Duratec-VE	2001 MY	RETM		•		0
Mondeo	2.5L	Duratec-VE	2001 MY	RHID		•		0
Mondeo	2.5L	Duratec-VE	2001 MY	SRM		•		0
Mondeo	2.5L	Duratec-VE	2001 MY	TCM		•		0
MONDEO	2.5L	15	MY07.25	ABS		•		0
MONDEO	2.5L	15	MY07.25	ACM		•		0
MONDEO	2.5L	15	MY07.25	AHCM				0
MONDEO	2.5L	15	MY07.25	BCMii		•		
MONDEO	2.5L	15	MY07.25	CCMii		•		
MONDEO	2.5L	15	MY07.25	CMR		•		0
MONDEO	2.5L	15	MY07.25	DDM		•		0
MONDEO	2.5L	15	MY07.25	DSM		•		
MONDEO	2.5L	15	MY07.25	HCM				0
MONDEO	2.5L	15	MY07.25	HVAC		•		0
MONDEO	2.5L	15	MY07.25	IPC		•		
MONDEO	2. 5L	15	MY07.25	PAM	•	•	•	0
MONDEO	2.5L	15	MY07.25	PBM		•		0
MONDEO	2.5L	15	MY07.25	PCM		•	•	0
MONDEO	2. 5L	I5	MY07.25	PDM			•	0
MONDEO	2. 5L	15	MY07.25	PSCM	•	•		0
MONDEO	2. 5L	I5	MY07.25	RCM	•	•	•	0
MONDEO	2. 5L	I5	MY07.25	RFA	•	•	•	0
MONDEO	2. 5L	15	MY07.25	SASM		•	•	0

- This function is supported.
- O This function is not supported.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
MONDEO	2.5L	I5	MY07.25	SRM	•	•	•	0
MONDEO	2.5L	I5	MY07.25	TRM		•	•	0
MONDEO	2.5L	I5	MY07.25	VDM		•		0
Mondeo	3. 0L	Duratec SE	2001 MY	ABS		•	•	0
Mondeo	3. 0L	Duratec SE	2001 MY	ABS/TCS		•	•	
Mondeo	3. OL	Duratec SE	2001 MY	ACM		•		0
Mondeo	3. 0L	Duratec SE	2001 MY	CDP		•		0
Mondeo	3. 0L	Duratec SE	2001 MY	CSM		•	•	0
Mondeo	3. 0L	Duratec SE	2001 MY	EATC		•	•	
Mondeo	3. 0L	Duratec SE	2001 MY	GDM	•		•	0
Mondeo	3. 0L	Duratec SE	2001 MY	GEM			•	
Mondeo	3. 0L	Duratec SE	2001 MY	HEC			•	
Mondeo	3. 0L	Duratec SE	2001 MY	LHID	•	•	•	•
Mondeo	3. 0L	Duratec SE	2001 MY	NAV		•	•	0
Mondeo	3. OL	Duratec SE	2001 MY	PCM		•		
Mondeo	3. 0L	Duratec SE	2001 MY	RCM	•		•	0
Mondeo	3. 0L	Duratec SE	2001 MY	RETM		•	•	0
Mondeo	3. 0L	Duratec SE	2001 MY	RHID		•	•	0
Mondeo	3. 0L	Duratec SE	2001 MY	SRM		•	•	0
Mondeo	3. 0L	Duratec-ST	2001 MY	ABS	•	•	•	0
Mondeo	3. OL	Duratec-ST	2001 MY	ABS/TCS	•	•	•	
Mondeo	3. OL	Duratec-ST	2001 MY	ACM	•	•	•	0
Mondeo	3. 0L	Duratec-ST	2001 MY	CDP			•	0
Mondeo	3. 0L	Duratec-ST	2001 MY	CSM	•	•	•	0
Mondeo	3. OL	Duratec-ST	2001 MY	EATC	•	•	•	•
Mondeo	3. OL	Duratec-ST	2001 MY	GDM	•	•	•	0

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Mondeo	3. 0L	Duratec-ST	2001 MY	GEM		•		
Mondeo	3. 0L	Duratec-ST	2001 MY	HEC		•	•	•
Mondeo	3. 0L	Duratec-ST	2001 MY	LHID		•		
Mondeo	3. 0L	Duratec-ST	2001 MY	NAV		•		0
Mondeo	3. 0L	Duratec-ST	2001 MY	PCM		•		
Mondeo	3. 0L	Duratec-ST	2001 MY	RCM		•		0
Mondeo	3. 0L	Duratec-ST	2001 MY	RETM		•		0
Mondeo	3. 0L	Duratec-ST	2001 MY	RHID		•		0
Mondeo	3. 0L	Duratec-ST	2001 MY	SRM		•		0
Puma	1.4L	Zetec-SE	19985 MY	ABS/TCS		•	•	
Puma	1. 4L	Zetec-SE	19985 MY	HEC		•	•	
Puma	1. 4L	Zetec-SE	19985 MY	PATS			•	0
Puma	1. 4L	Zetec-SE	19985 MY	PCM		•	•	•
Puma	1. 4L	Zetec-SE	1999.5 MY	ABS/TCS		•	•	•
Puma	1.4L	Zetec-SE	1999.5 MY	GEM		•		
Puma	1.4L	Zetec-SE	1999.5 MY	HEC		•	•	
Puma	1. 4L	Zetec-SE	1999.5 MY	PATS		•	•	0
Puma	1. 4L	Zetec-SE	1999.5 MY	PCM		•	•	
Puma	1.6L	Zetec-SE	2001 MY	ABS/TCS		•	•	•
Puma	1.6L	Zetec-SE	2001 MY	GEM		•	•	•
Puma	1.6L	Zetec-SE	2001 MY	HEC	•		•	
Puma	1. 6L	Zetec-SE	2001 MY	PATS		•		0
Puma	1. 6L	Zetec-SE	2001 MY	PCM		•	•	
Puma	1.7L	Zetec-SE	1997.5 MY	ABS/TCS	•	•	•	•
Puma	1. 7L	Zetec-SE	1997.5 MY	HEC	•	•	•	
Puma	1. 7L	Zetec-SE	1997.5 MY	PATS	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Puma	1.7L	Zetec-SE	1997.5 MY	PCM	•	•		
Puma	1.7L	Zetec-SE	1999.5 MY	ABS/TCS				
Puma	1.7L	Zetec-SE	1999.5 MY	GEM				
Puma	1.7L	Zetec-SE	1999.5 MY	HEC		•		
Puma	1.7L	Zetec-SE	1999.5 MY	PATS		•		0
Puma	1.7L	Zetec-SE	1999.5 MY	PCM	•	•		
Puma	1.7L	Zetec-SE	2001 MY	ABS/TCS	•	•		
Puma	1.7L	Zetec-SE	2001 MY	GEM	•	•		
Puma	1.7L	Zetec-SE	2001 MY	HEC	•	•		
Puma	1.7L	Zetec-SE	2001 MY	PATS		•		0
Puma	1.7L	Zetec-SE	2001 MY	PCM	•	•		
Ranger	2. 3L	DURATEC-HE / I4	2006 MY	4X4	•	•		
Ranger	2. 3L	DURATEC-HE / I4	2006 MY	ABS/TCS	•	•		
Ranger	2. 3L	DURATEC-HE / I4	2006 MY	GEM	•	•		
Ranger	2. 3L	DURATEC-HE / I4	2006 MY	IC	•	•		
Ranger	2. 3L	DURATEC-HE / I4	2006 MY	PCM		•		
Ranger	2. 3L	DURATEC-HE / I4	2006 MY	RCM	•	•		
Ranger	2. 3L	DURATEC-HE / I4	2009.5 MY	4X4	•	•	•	
Ranger	2. 3L	DURATEC-HE / I4	2009.5 MY	ABS/TCS	•	•		
Ranger	2. 3L	DURATEC-HE / I4	2009.5 MY	GEM	•	•	•	
Ranger	2. 3L	DURATEC-HE / I4	2009.5 MY	IC	•	•		
Ranger	2. 3L	DURATEC-HE / I4	2009.5 MY	PCM	•	•	•	
Ranger	2. 3L	DURATEC-HE / I4	2009.5 MY	RCM	•	•	•	
Ranger	3. 0L	I4 DSL Electronic	2005.5 MY	4X4	•	•		•
Ranger	3. 0L	I4 DSL Electronic	2005.5 MY	ABS/TCS	•	•		•
Ranger	3. 0L	I4 DSL Electronic	2005.5 MY	GEM	•	•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger	3. 0L	I4 DSL Electronic	2005.5 MY	IC		•		
Ranger	3. 0L	I4 DSL Electronic	2005. 5 MY	PCM		•	•	
Ranger	3. 0L	I4 DSL Electronic	2005. 5 MY	RCM		•		
Ranger / Courier / Mazda B Series /Bravo	4. 0L	V6 SOHC	2003 MY	ABS/TCS		•		
Ranger / Courier / Mazda B Series /Bravo	4. 0L	V6 SOHC	2003 MY	ES0F		•	•	
Ranger / Courier / Mazda B Series /Bravo	4. 0L	V6 SOHC	2003 MY	PCM		•	•	
Ranger / Mazda B Series / Courier			2004 MY	4X4	•	•	•	
Ranger / Mazda B Series / Courier			2004 MY	ABS/TCS		•	•	
Ranger / Mazda B Series / Courier			2004 MY	GEM		•		
Ranger / Mazda B Series / Courier			2004 MY	IC		•	•	0
Ranger / Mazda B Series / Courier			2004 MY	PCM				
Ranger / Mazda B Series / Courier			2004 MY	RCM		•	•	
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2004 MY	4X4		•	•	
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / 14	2004 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	GEM		•		
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2004 MY	IC		•		0
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2004 MY	PCM		•	•	
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2004 MY	RCM		•	•	
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2005 MY	4X4		•	•	
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2005 MY	ABS/TCS		•	•	
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2005 MY	GEM	•			
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2005 MY	IC	•	•	•	•
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2005 MY	PCM	•	•	•	
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2005 MY	RCM	•	•	•	•
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2005 MY	TPM	•	•	•	•
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2006 MY	4X4	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2006 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2006 MY	GEM		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2006 MY	IC		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2006 MY	PCM		•	•	
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2006 MY	RCM		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2007 MY	4X4	•	•	•	
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2007 MY	ABS/TCS		•	•	
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2007 MY	GEM		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2007 MY	IC		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2007 MY	OCSM		•	•	0
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2007 MY	PCM	•	•	•	
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2007 MY	RCM		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2007 MY	SDARS		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2008 MY	4X4		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2008 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2008 MY	GEM/SJB		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2008 MY	IC		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2008 MY	OCSM		•		0
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2008 MY	PCM		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2008 MY	RCM		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2008 MY	SDARS		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2009 MY	4X4		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2009 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2009 MY	GEM/SJB		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2009 MY	IC		•		
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2009 MY	OCSM		•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2009 MY	PCM	•	•		
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	RCM				
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2009 MY	SDARS				
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	4X4				
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	ABS		•		
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	GEM/SJB				
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	IC				
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	OCSM				0
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2010 MY	PCM	•	•		
Ranger / Mazda B Series / Courier	2.3L	DURATEC-HE / I4	2010 MY	RCM		•		0
Ranger / Mazda B Series / Courier	2. 3L	DURATEC-HE / I4	2010 MY	SDARS	•	•		
Ranger / Mazda B Series / Courier	2. 3L	OHC	1995 MY	ABS/TCS	•	•		0
Ranger / Mazda B Series / Courier	2. 3L	OHC	1995 MY	GEM	•	•		
Ranger / Mazda B Series / Courier	2. 3L	OHC	1995 MY	PCM	•	•		
Ranger / Mazda B Series / Courier	2. 3L	OHC	1995 MY	RAP	•	•		
Ranger / Mazda B Series / Courier	2. 3L	OHC	1996 MY	ABS/TCS	•	•		
Ranger / Mazda B Series / Courier	2. 3L	OHC	1996 MY	GEM	•	•		
Ranger / Mazda B Series / Courier	2.3L	OHC	1996 MY	IAB	•	•		
Ranger / Mazda B Series / Courier	2. 3L	OHC	1996 MY	PCM	•	•		
Ranger / Mazda B Series / Courier	2. 3L	OHC	1996 MY	RAP	•	•		
Ranger / Mazda B Series / Courier	2. 3L	OHC	1997 MY	ABS/TCS	•	•		
Ranger / Mazda B Series / Courier	2. 3L	OHC	1997 MY	GEM	•	•	•	
Ranger / Mazda B Series / Courier	2. 3L	OHC	1997 MY	IAB	•	•		
Ranger / Mazda B Series / Courier	2. 3L	OHC	1997 MY	PCM	•	•	•	
Ranger / Mazda B Series / Courier	2. 3L	OHC	1997 MY	RAP	•	•	•	
Ranger / Mazda B Series / Courier	2. 3L	Other	1996 MY	ABS/TCS	•	•		•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	2. 3L	Other	1996 MY	GEM		•	•	
Ranger / Mazda B Series / Courier	2. 3L	Other	1996 MY	PCM		•		
Ranger / Mazda B Series / Courier	2. 3L	Other	1997 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	2. 3L	Other	1997 MY	GEM		•	•	
Ranger / Mazda B Series / Courier	2. 3L	Other	1997 MY	PCM		•		
Ranger / Mazda B Series / Courier	2. 3L	Other	2001 MY	4X4		•		
Ranger / Mazda B Series / Courier	2. 3L	Other	2001 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	2. 3L	Other	2001 MY	GEM		•		
Ranger / Mazda B Series / Courier	2. 3L	Other	2001 MY	PATS		•	0	
Ranger / Mazda B Series / Courier	2. 3L	Other	2001 MY	PCM		•		
Ranger / Mazda B Series / Courier	2. 3L	Other	2001 MY	RAP		•		
Ranger / Mazda B Series / Courier	2. 3L	Other	2001 MY	RCM		•		
Ranger / Mazda B Series / Courier	2. 3L	Other	2002 MY	4X4		•		
Ranger / Mazda B Series / Courier	2. 3L	Other	2002 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	2. 3L	Other	2002 MY	GEM				
Ranger / Mazda B Series / Courier	2. 3L	Other	2002 MY	PCM		•		
Ranger / Mazda B Series / Courier	2. 3L	Other	2002 MY	RAP		•		
Ranger / Mazda B Series / Courier	2. 3L	Other	2002 MY	RCM		•		
Ranger / Mazda B Series / Courier	2. 3L	Other	2003 MY	4X4		•		
Ranger / Mazda B Series / Courier	2. 3L	Other	2003 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	2. 3L	Other	2003 MY	GEM		•	•	
Ranger / Mazda B Series / Courier	2. 3L	Other	2003 MY	PCM			•	
Ranger / Mazda B Series / Courier	2. 3L	Other	2003 MY	RAP	•	•	•	
Ranger / Mazda B Series / Courier	2. 3L	Other	2003 MY	RCM	•	•	•	•
Ranger / Mazda B Series / Courier	2. 5L	Other	1998 MY	ABS/TCS	•	•	•	•
Ranger / Mazda B Series / Courier	2. 5L	Other	1998 MY	GEM		•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	2.5L	0ther	1998 MY	IAB		•		
Ranger / Mazda B Series / Courier	2.5L	Other	1998 MY	PCM		•		
Ranger / Mazda B Series / Courier	2.5L	Other	1998 MY	RAP		•		
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	GEM		•		
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	PCM		•		
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	RAP		•		
Ranger / Mazda B Series / Courier	2.5L	Other	1999 MY	RCM		•		
Ranger / Mazda B Series / Courier	2.5L	Other	2000 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	2.5L	Other	2000 MY	GEM	•	•	•	
Ranger / Mazda B Series / Courier	2. 5L	Other	2000 MY	PCM	•	•	•	
Ranger / Mazda B Series / Courier	2. 5L	Other	2000 MY	RAP	•	•	•	
Ranger / Mazda B Series / Courier	2.5L	Other	2000 MY	RCM		•		
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	4X4		•		
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	GEM		•		
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	PATS		•	0	
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	PCM		•		
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	RAP		•		
Ranger / Mazda B Series / Courier	2.5L	Other	2001 MY	RCM		•		
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	4X4		•	•	
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	ABS/TCS	•	•	•	
Ranger / Mazda B Series / Courier	2.8L	0ther	2001 MY	GEM		•	•	
Ranger / Mazda B Series / Courier	2.8L	0ther	2001 MY	PATS		•	0	
Ranger / Mazda B Series / Courier	2.8L	0ther	2001 MY	PCM	•	•		
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	RAP	•	•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	2.8L	Other	2001 MY	RCM		•		
Ranger / Mazda B Series / Courier	3. 0L	FFV	1999 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	3. 0L	FFV	1999 MY	GEM		•		
Ranger / Mazda B Series / Courier	3. 0L	FFV	1999 MY	PATS				
Ranger / Mazda B Series / Courier	3. 0L	FFV	1999 MY	PCM		•		
Ranger / Mazda B Series / Courier	3. 0L	FFV	1999 MY	RAP		•		
Ranger / Mazda B Series / Courier	3. 0L	FFV	1999 MY	RCM		•		
Ranger / Mazda B Series / Courier	3. 0L	FFV	2000 MY	ABS/TCS		•	•	
Ranger / Mazda B Series / Courier	3. 0L	FFV	2000 MY	GEM		•	•	
Ranger / Mazda B Series / Courier	3. 0L	FFV	2000 MY	PATS	•		•	
Ranger / Mazda B Series / Courier	3. 0L	FFV	2000 MY	PCM			•	
Ranger / Mazda B Series / Courier	3. 0L	FFV	2000 MY	RAP			•	
Ranger / Mazda B Series / Courier	3. 0L	FFV	2000 MY	RCM		•	•	•
Ranger / Mazda B Series / Courier	3. 0L	Other	1995 MY	ABS/TCS		•	•	0
Ranger / Mazda B Series / Courier	3. 0L	Other	1995 MY	GEM		•	•	
Ranger / Mazda B Series / Courier	3. 0L	Other	1995 MY	PCM		•	•	
Ranger / Mazda B Series / Courier	3. 0L	Other	1995 MY	RAP			•	
Ranger / Mazda B Series / Courier	3. 0L	Other	1996 MY	ABS/TCS			•	
Ranger / Mazda B Series / Courier	3. 0L	Other	1996 MY	GEM		•	•	
Ranger / Mazda B Series / Courier	3. 0L	Other	1996 MY	IAB		•	•	
Ranger / Mazda B Series / Courier	3. 0L	Other	1996 MY	PCM		•	•	
Ranger / Mazda B Series / Courier	3. 0L	Other	1996 MY	RAP	•	•	•	•
Ranger / Mazda B Series / Courier	3. 0L	Other	1997 MY	ABS/TCS	•	•	•	•
Ranger / Mazda B Series / Courier	3. 0L	Other	1997 MY	GEM	•	•	•	•
Ranger / Mazda B Series / Courier	3. 0L	Other	1997 MY	IAB		•	•	•
Ranger / Mazda B Series / Courier	3. 0L	Other	1997 MY	PCM	•	•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	3. 0L	Other	1997 MY	RAP		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	1998 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	3. 0L	0ther	1998 MY	GEM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	1998 MY	IAB				
Ranger / Mazda B Series / Courier	3. 0L	Other	1998 MY	PCM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	1998 MY	RAP		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	1999 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	1999 MY	GEM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	1999 MY	PCM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	1999 MY	RAP				
Ranger / Mazda B Series / Courier	3. 0L	Other	1999 MY	RCM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2000 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2000 MY	GEM		•		
Ranger / Mazda B Series / Courier	3. 0L	0ther	2000 MY	PATS		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2000 MY	PCM				
Ranger / Mazda B Series / Courier	3. 0L	Other	2000 MY	RAP				
Ranger / Mazda B Series / Courier	3. 0L	Other	2000 MY	RCM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2001 MY	4X4		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2001 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2001 MY	GEM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2001 MY	PATS		•	0	
Ranger / Mazda B Series / Courier	3. 0L	Other	2001 MY	PCM				
Ranger / Mazda B Series / Courier	3. 0L	Other	2001 MY	RAP	•	•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2001 MY	RCM	•	•	•	
Ranger / Mazda B Series / Courier	3. 0L	Other	2002 MY	4X4	•	•	•	•
Ranger / Mazda B Series / Courier	3. 0L	Other	2002 MY	ABS/TCS		•		

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	3. 0L	Other	2002 MY	GEM		•	•	
Ranger / Mazda B Series / Courier	3. 0L	Other	2002 MY	PCM		•		
Ranger / Mazda B Series / Courier	3. 0L	0ther	2002 MY	RAP		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2002 MY	RCM				
Ranger / Mazda B Series / Courier	3. 0L	Other	2003 MY	4X4		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2003 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2003 MY	GEM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2003 MY	PCM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2003 MY	RAP		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2003 MY	RCM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2004 MY	4X4		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2004 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2004 MY	GEM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2004 MY	IC				\circ
Ranger / Mazda B Series / Courier	3. 0L	Other	2004 MY	PCM				
Ranger / Mazda B Series / Courier	3. 0L	Other	2004 MY	RCM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2005 MY	4X4		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2005 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2005 MY	GEM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2005 MY	IC		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2005 MY	PCM		•	•	
Ranger / Mazda B Series / Courier	3. 0L	Other	2005 MY	RCM	•		•	
Ranger / Mazda B Series / Courier	3. 0L	Other	2005 MY	TPM	•	•	•	
Ranger / Mazda B Series / Courier	3. 0L	Other	2006 MY	4X4	•	•	•	
Ranger / Mazda B Series / Courier	3. 0L	Other	2006 MY	ABS/TCS	•	•	•	
Ranger / Mazda B Series / Courier	3. 0L	Other	2006 MY	GEM		•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	3. 0L	Other	2006 MY	IC		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2006 MY	PCM		•		
Ranger / Mazda B Series / Courier	3. 0L	0ther	2006 MY	RCM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2007 MY	4X4		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2007 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2007 MY	GEM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2007 MY	IC		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2007 MY	OCSM		•		0
Ranger / Mazda B Series / Courier	3. 0L	Other	2007 MY	PCM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2007 MY	RCM		•	•	
Ranger / Mazda B Series / Courier	3. 0L	Other	2007 MY	SDARS		•	•	
Ranger / Mazda B Series / Courier	3. 0L	Other	2008 MY	4X4		•	•	
Ranger / Mazda B Series / Courier	3. 0L	Other	2008 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2008 MY	GEM/SJB		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2008 MY	IC		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2008 MY	OCSM		•	•	0
Ranger / Mazda B Series / Courier	3. 0L	Other	2008 MY	PCM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2008 MY	RCM		•		
Ranger / Mazda B Series / Courier	3. 0L	Other	2008 MY	SDARS		•		
Ranger / Mazda B Series / Courier	4.0L	Other	1995 MY	ABS/TCS		•		\circ
Ranger / Mazda B Series / Courier	4. 0L	Other	1995 MY	GEM		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	1995 MY	PCM		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	1995 MY	RAP		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	1996 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	1996 MY	GEM		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	1996 MY	IAB		•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	4. 0L	Other	1996 MY	PCM				
Ranger / Mazda B Series / Courier	4. 0L	Other	1996 MY	RAP		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	1997 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	1997 MY	GEM		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	1997 MY	IAB	•	•		
Ranger / Mazda B Series / Courier	4. 0L	Other	1997 MY	PCM		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	1997 MY	RAP		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	1998 MY	ABS/TCS	•	•	•	•
Ranger / Mazda B Series / Courier	4. 0L	Other	1998 MY	GEM	•	•		
Ranger / Mazda B Series / Courier	4. 0L	Other	1998 MY	IAB	•	•	•	
Ranger / Mazda B Series / Courier	4. 0L	Other	1998 MY	PCM	•	•	•	
Ranger / Mazda B Series / Courier	4. 0L	Other	1998 MY	RAP	•	•	•	
Ranger / Mazda B Series / Courier	4. 0L	Other	1999 MY	ABS/TCS	•	•	•	•
Ranger / Mazda B Series / Courier	4. 0L	Other	1999 MY	GEM		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	1999 MY	PATS		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	1999 MY	PCM	•	•		
Ranger / Mazda B Series / Courier	4. 0L	Other	1999 MY	RAP	•	•	•	
Ranger / Mazda B Series / Courier	4. 0L	Other	1999 MY	RCM	•			
Ranger / Mazda B Series / Courier	4. 0L	Other	2000 MY	ABS/TCS	•	•	•	•
Ranger / Mazda B Series / Courier	4. 0L	Other	2000 MY	GEM	•	•	•	•
Ranger / Mazda B Series / Courier	4. 0L	Other	2000 MY	PATS	•			
Ranger / Mazda B Series / Courier	4. 0L	Other	2000 MY	PCM	•	•	•	•
Ranger / Mazda B Series / Courier	4. 0L	Other	2000 MY	RAP	•	•		
Ranger / Mazda B Series / Courier	4. 0L	Other	2000 MY	RCM	•	•	•	•
Ranger / Mazda B Series / Courier	4. 0L	Other	2001 MY	4X4	•	•	•	•
Ranger / Mazda B Series / Courier	4. 0L	Other	2001 MY	ABS/TCS	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	4. 0L	Other	2001 MY	GEM		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	2001 MY	PATS		•	0	
Ranger / Mazda B Series / Courier	4. 0L	0ther	2001 MY	PCM		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	2001 MY	RAP		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	2001 MY	RCM		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	2002 MY	4X4		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	2002 MY	ABS/TCS		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	2002 MY	GEM		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	2002 MY	PCM		•		
Ranger / Mazda B Series / Courier	4. 0L	Other	2002 MY	RAP		•	•	
Ranger / Mazda B Series / Courier	4. 0L	Other	2002 MY	RCM	•	•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2003 MY	4X4		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2003 MY	ABS/TCS		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2003 MY	GEM		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2003 MY	PCM		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2003 MY	RAP	•	•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2003 MY	RCM		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2004 MY	4X4	•	•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2004 MY	ABS/TCS		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2004 MY	GEM		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2004 MY	IC		•	•	0
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2004 MY	PCM		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2004 MY	RCM		•		•
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2005 MY	4X4		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2005 MY	ABS/TCS	•	•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2005 MY	GEM		•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2005 MY	IC		•		
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2005 MY	PCM		•		
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2005 MY	RCM		•		
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2005 MY	TPM		•		
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2006 MY	4X4		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2006 MY	ABS/TCS		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2006 MY	GEM		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2006 MY	IC		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2006 MY	PCM		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2006 MY	RCM	•		•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2007 MY	4X4		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2007 MY	ABS/TCS		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2007 MY	GEM		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2007 MY	IC		•		
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2007 MY	OCSM		•		0
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2007 MY	PCM		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2007 MY	RCM		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2007 MY	SDARS		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2008 MY	4X4		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2008 MY	ABS/TCS		•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2008 MY	GEM/SJB	•	•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2008 MY	IC	•	•	•	
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2008 MY	OCSM		•	•	0
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2008 MY	PCM	•	•	•	•
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2008 MY	RCM	•	•	•	•
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2008 MY	SDARS		•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2009 MY	4X4	•			
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2009 MY	ABS/TCS				
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2009 MY	GEM/SJB				
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2009 MY	IC				
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2009 MY	OCSM				0
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2009 MY	PCM		•		
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2009 MY	RCM		•		
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2009 MY	SDARS		•		
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2010 MY	4X4		•		
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2010 MY	ABS		•		
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2010 MY	GEM/SJB		•		
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2010 MY	IC		•		
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2010 MY	OCSM		•		0
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2010 MY	PCM				
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2010 MY	RCM				\circ
Ranger / Mazda B Series / Courier	4. 0L	V6 SOHC	2010 MY	SDARS				
Street Ka	1.6L	DURATEC 8V	2003.5 MY	ABS/TCS		•		
Street Ka	1.6L	DURATEC 8V	2003.5 MY	CSM		•		0
Street Ka	1.6L	DURATEC 8V	2003.5 MY	GEM				
Street Ka	1.6L	DURATEC 8V	2003.5 MY	PCM		•		
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1995 MY	ABS		•		0
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1995 MY	ABS/TCS		•	•	
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1995 MY	CSM	•	•		0
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1995 MY	PATS		•	0	
Transit Connect	2. 0L	2. 0 DOHC SFI (8V)	1995 MY	PCM				
Transit Connect	2. 0L	2. 0 DOHC SFI (8V)	1996 MY	ABS		•		0

- This function is supported.
- O This function is not supported.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1996 MY	ABS/TCS	•	•		
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1996 MY	CSM		•		0
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1996 MY	PCM		•		
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1997 MY	ABS		•		0
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1997 MY	ABS/TCS		•		
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1997 MY	CSM		•		0
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1997 MY	PATS		•	0	
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1997 MY	PCM		•		
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1997.5 MY	ABS		•		0
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1997.5 MY	ABS/TCS		•		
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1997.5 MY	CSM	•	•	•	0
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1997.5 MY	PCM		•	•	
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1998 MY	ABS	•	•	•	0
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1998 MY	ABS/TCS		•		
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1998 MY	CSM		•		0
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1998 MY	PCM		•		
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	19985 MY	ABS		•		0
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	19985 MY	ABS/TCS		•	•	
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	19985 MY	CSM		•		0
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	19985 MY	PCM		•	•	
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1999.5 MY	ABS		•		0
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1999.5 MY	ABS/TCS	•	•	•	
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1999.5 MY	AFCM	•	•	•	0
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1999.5 MY	CSM	•	•	•	0
Transit Connect	2. 0L	2.0 DOHC SFI (8V)	1999.5 MY	PCM	•	•		•
Transit Connect	2. 0L	DURATEC-HE / I4	2010 MY	ABS	•	•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Transit Connect	2. 0L	DURATEC-HE / I4	2010 MY	ACM		•		0
Transit Connect	2. 0L	DURATEC-HE / I4	2010 MY	GEM/SJB		•		
Transit Connect	2. 0L	DURATEC-HE / I4	2010 MY	IC	•		•	
Transit Connect	2. 0L	DURATEC-HE / I4	2010 MY	OCSM	•			0
Transit Connect	2. 0L	DURATEC-HE / I4	2010 MY	PAM	•	•	•	
Transit Connect	2. 0L	DURATEC-HE / I4	2010 MY	PCM	•	•	•	
Transit Connect	2. 0L	DURATEC-HE / I4	2010 MY	RCM	•		•	0
Transit Connect	2. 0L	DURATEC-HE / I4	2010 MY	SRM	•		•	0
Transit Connect	2. 0L	DURATEC-HE / I4	2010 MY	VSM	•		•	
Transit Connect	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	ABS/TCS	•	•	•	•
Transit Connect	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	CSM	•	•	•	•
Transit Connect	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	CSM	•	•	•	0
Transit Connect	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	FFH	•	•	•	•
Transit Connect	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	HEC	•	•	•	•
Transit Connect	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	ICU	•	•	•	0
Transit Connect	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	PAM	•	•	•	0
Transit Connect	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	PCM	•	•	•	•

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Transit Connect	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	RASM	•	•	•	•
Transit Connect	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	RCM	•	•	•	0
Transit Connect	2. 0L	Duratorq Turbo Diesel Common Rail Injection	2001 MY	TCM	•	•	•	•
Transit Connect	2. 0L	DURATORQ_DI	2001 MY	ABS/TCS		•		
Transit Connect	2. 0L	DURATORQ_DI	2001 MY	CSM		•		
Transit Connect	2. OL	DURATORQ DI	2001 MY	CSM				0
Transit Connect	2. 0L	DURATORQ DI	2001 MY	FFH		•		
Transit Connect	2. 0L	DURATORQ_DI	2001 MY	FIP		•		0
Transit Connect	2. 0L	DURATORQ_DI	2001 MY	HEC		•		
Transit Connect	2. 0L	DURATORQ_DI	2001 MY	PAM		•		
Transit Connect	2. 0L	DURATORQ_DI	2001 MY	PCM		•		
Transit Connect	2. OL	DURATORQ DI	2001 MY	RASM				
Transit Connect	2. 0L	DURATORQ DI	2001 MY	RCM		•		0
Transit Connect	2. 0L	DURATORQ_DI	2001 MY	TCM		•		
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	ABS	•	•	•	0
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	ABS/TCS	•	•	•	•
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	ACM	•	•	•	0
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	BCMii	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	CSM	•	•	•	0
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	FFH	•	•	•	•
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	IPC	•	•	•	•
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PAM	•	•	•	0
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PCM	•	•	•	•
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	RCM	•	•	•	0
Transit Connect	2. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	SRM	•	•	•	0
Transit Connect	2. 3L	DOHC SFI (16V)	2001 MY	ABS/TCS	•	•		•
Transit Connect	2. 3L	DOHC SFI (16V)	2001 MY	CSM	•	•		•
Transit Connect	2. 3L	DOHC SFI (16V)	2001 MY	CSM	•	•	•	0
Transit Connect	2. 3L	DOHC SFI (16V)	2001 MY	HEC	•	•	•	•
Transit Connect	2. 3L	DOHC SFI (16V)	2001 MY	PAM	•	•	•	0
Transit Connect	2. 3L	DOHC SFI (16V)	2001 MY	PCM	•	•	•	
Transit Connect	2. 3L	DOHC SFI (16V)	2001 MY	RASM				
Transit Connect	2. 3L	DOHC SFI (16V)	2001 MY	RCM	•	•	•	0
Transit Connect	2. 3L	DURATEC-HE / I4	2006. 5	ABS	•	•	•	0
Transit Connect	2. 3L	DURATEC-HE / I4	2006. 5	ABS/TCS	•	•		
Transit Connect	2. 3L	DURATEC-HE / I4	2006. 5	ACM	•	•	•	0
Transit Connect	2. 3L	DURATEC-HE / I4	2006. 5	BCMii				

- This function is supported.
- O This function is not supported.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Transit Connect	2. 3L	DURATEC-HE / I4	2006. 5	CSM	•	•	•	0
Transit Connect	2. 3L	DURATEC-HE / I4	2006. 5	FFH		•		
Transit Connect	2. 3L	DURATEC-HE / I4	2006. 5	IPC	•	•	•	•
Transit Connect	2. 3L	DURATEC-HE / I4	2006. 5	PAM	•	•	•	0
Transit Connect	2. 3L	DURATEC-HE / I4	2006. 5	PCM	•	•	•	•
Transit Connect	2. 3L	DURATEC-HE / I4	2006. 5	RCM	•	•	•	0
Transit Connect	2. 3L	DURATEC-HE / I4	2006. 5	SRM	•	•	•	0
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2000 MY	ABS/TCS	•	•	•	•
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2000 MY	CSM	•	•	•	•
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2000 MY	CSM	•	•	•	0
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2000 MY	FFH	•	•	•	•
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2000 MY	HEC	•	•	•	•
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2000 MY	ICU	•	•	•	0
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2000 MY	PAM	•	•	•	•
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2000 MY	PCM	•	•	•	•
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2000 MY	RCM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	ABS	•	•	•	0
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	ABS/TCS	•	•	•	•
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	ACM	•	•	•	0
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	BCMii	•	•	•	
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	CSM	•	•	•	0
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	FFH	•	•	•	•
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	IPC	•	•	•	•
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PAM	•	•	•	0
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PCM	•	•	•	•
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	RCM	•	•	•	0
Transit Connect	2. 4L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	SRM	•	•	•	0
Transit Connect	2. 4L	DURATORQ DI	2000 MY	ABS/TCS	•	•		•
Transit Connect	2.4L	DURATORQ_DI	2000 MY	CSM	•	•		•
Transit Connect	2.4L	DURATORQ_DI	2000 MY	CSM	•	•	•	0
Transit Connect	2.4L	DURATORQ_DI	2000 MY	FFH	•	•	•	

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Transit Connect	2.4L	DURATORQ_DI	2000 MY	FIP		•		0
Transit Connect	2.4L	DURATORQ_DI	2000 MY	HEC			•	
Transit Connect	2.4L	DURATORQ_DI	2000 MY	PAM			•	
Transit Connect	2.4L	DURATORQ DI	2000 MY	PCM				
Transit Connect	2.4L	DURATORQ DI	2000 MY	PCM			•	0
Transit Connect	2.4L	DURATORQ_DI	2000 MY	RASM				
Transit Connect	2.4L	DURATORQ_DI	2000 MY	RCM				0
Transit Connect	2.4L	DURATORQ_DI	2000 MY	TCM				
Transit Connect	2. 5L	2.5 turbo diesel engines with EPIC	Other	ABS	•	•	•	0
Transit Connect	2. 5L	2.5 turbo diesel engines with EPIC	Other	ABS/TCS	•	•	•	•
Transit Connect	2. 5L	2.5 turbo diesel engines with EPIC	Other	CSM	•	•	•	0
Transit Connect	2. 5L	2.5 turbo diesel engines with EPIC	Other	PCM	•	•	•	0
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	ABS	•	•	•	0
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	ABS/TCS	•	•	•	•
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	ACM	•	•	•	0
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	BCMii	•	•	•	
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	CSM	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	FFH	•	•	•	•
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	IPC	•	•	•	•
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PAM	•	•	•	0
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	PCM	•	•	•	•
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	RCM	•	•	•	0
Transit Connect	3. 2L	Duratorq Turbo Diesel Common Rail Injection	2006. 5	SRM	•	•	•	0
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002. 5 MY	ABS/TCS	•	•	•	•
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002. 5 MY	CSM	•	•	•	•
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002. 5 MY	ECS	•	•	•	0
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002. 5 MY	FFH	•	•	•	•
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002. 5 MY	HEC	•	•	•	•
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002. 5 MY	ICU	•	•	•	0
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002. 5 MY	PAM	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2002.5 MY	PCM	•	•	•	•
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007 MY	ABS	•	•	•	•
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007 MY	ABS/TCS	•	•	•	•
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007 MY	ACM	•	•	•	0
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007 MY	ECS	•	•	•	0
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007 MY	FFH	•	•	•	•
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007 MY	IC	•	•	•	•
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007 MY	PAM	•	•	•	•
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2007 MY	PCM	•	•	•	•
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2009.5 MY	ABS	•	•	•	
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2009.5 MY	ABS	•	•	•	0
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2009.5 MY	ACM	•	•	•	0
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2009.5 MY	FFH	•	•	•	0

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2009. 5 MY	GEM	•	•	•	•
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2009.5 MY	IC	•	•	•	
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2009.5 MY	PAM	•	•	•	•
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2009.5 MY	PCM	•	•	•	•
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2009.5 MY	RCM	•	•	•	0
Transit Connect / Tourneo_Connect	1.8L	Duratorq Turbo Diesel Common Rail Injection	2009. 5 MY	SRM	•	•	•	0
Transit Connect / Tourneo_Connect	1.8L	Endura DI	2002. 5 MY	ABS/TCS		•		
Transit Connect / Tourneo_Connect	1.8L	Endura DI	2002.5 MY	CSM		•		
Transit Connect / Tourneo Connect	1.8L	Endura DI	2002.5 MY	ECS				0
Transit Connect / Tourneo_Connect	1.8L	Endura DI	2002.5 MY	FFH				
Transit Connect / Tourneo_Connect	1.8L	Endura DI	2002.5 MY	FIP				0
Transit Connect / Tourneo_Connect	1.8L	Endura DI	2002.5 MY	HEC		•	•	
Transit Connect / Tourneo_Connect	1.8L	Endura DI	2002.5 MY	PAM				
Transit Connect / Tourneo_Connect	1.8L	Endura DI	2002.5 MY	PCM				
Transit Connect / Tourneo Connect	1.8L	Zetec	2002.5 MY	ABS/TCS				
Transit Connect / Tourneo_Connect	1.8L	Zetec	2002.5 MY	CSM		•		
Transit Connect / Tourneo_Connect	1.8L	Zetec	2002.5 MY	ECS				0
Transit Connect / Tourneo_Connect	1.8L	Zetec	2002.5 MY	FFH				
Transit Connect / Tourneo_Connect	1.8L	Zetec	2002.5 MY	HEC				
Transit Connect / Tourneo_Connect	1.8L	Zetec	2002.5 MY	PAM	•	•		

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Transit Connect / Tourneo_Connect	1.8L	Zetec	2002.5 MY	PCM		•		
Windstar	3. 0L	V6 OHV	1995 MY	ABS/TCS				
Windstar	3. 0L	V6 OHV	1995 MY	ABS/TCS				0
Windstar	3. 0L	V6 OHV	1995 MY	GEM		•		
Windstar	3. 0L	V6 OHV	1995 MY	PCM		•		•
Windstar	3. 0L	V6 OHV	1995.5 MY	PCM		•		•
Windstar	3. 0L	V6 OHV	1996 MY	ABS/TCS		•		•
Windstar	3. 0L	V6 OHV	1996 MY	ABS/TCS		•	•	0
Windstar	3. 0L	V6 OHV	1996 MY	GEM		•		
Windstar	3. 0L	V6 OHV	1996 MY	IAB	•		•	
Windstar	3. 0L	V6 OHV	1996 MY	PCM			•	
Windstar	3. 0L	V6 OHV	1997 MY	ABS/TCS			•	
Windstar	3. 0L	V6 OHV	1997 MY	ABS/TCS	•	•	•	0
Windstar	3. 0L	V6 OHV	1997 MY	GEM	•	•	•	•
Windstar	3. 0L	V6 OHV	1997 MY	IAB		•		
Windstar	3. 0L	V6 OHV	1997 MY	PCM		•	•	•
Windstar	3. 0L	V6 OHV	1998 MY	ABS/TCS		•	•	
Windstar	3. 0L	V6 OHV	1998 MY	ABS/TCS			•	0
Windstar	3. 0L	V6 OHV	1998 MY	GEM	•	•	•	•
Windstar	3. 0L	V6 OHV	1998 MY	IAB		•	•	•
Windstar	3. 0L	V6 OHV	1998 MY	PCM	•		•	
Windstar	3. 0L	V6 OHV	1998 MY	RAP	•	•		•
Windstar	3. 0L	V6 OHV	1999 MY	ABS/TCS	•	•		•
Windstar	3. 0L	V6 OHV	1999 MY	DDM	•	•	•	
Windstar	3. 0L	V6 OHV	1999 MY	FEM	•	•	•	•
Windstar	3. 0L	V6 OHV	1999 MY	IC	•	•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Windstar	3. 0L	V6 OHV	1999 MY	MC	•	•		
Windstar	3. 0L	V6 OHV	1999 MY	NGSC	•	•		0
Windstar	3. 0L	V6 OHV	1999 MY	PAM	•	•		
Windstar	3. 0L	V6 OHV	1999 MY	PCM		•		
Windstar	3. 0L	V6 OHV	1999 MY	RCM	•	•		•
Windstar	3. 0L	V6 OHV	1999 MY	REM	•	•	•	•
Windstar	3.8L	V6 OHV	1995 MY	ABS/TCS	•	•	•	•
Windstar	3.8L	V6 OHV	1995 MY	ABS/TCS	•	•	•	0
Windstar	3.8L	V6 OHV	1995 MY	GEM	•	•		
Windstar	3.8L	V6 OHV	1995 MY	PCM	•	•	•	
Windstar	3.8L	V6 OHV	1996 MY	ABS/TCS	•	•	•	
Windstar	3.8L	V6 OHV	1996 MY	ABS/TCS	•	•	•	0
Windstar	3.8L	V6 OHV	1996 MY	GEM	•	•	•	•
Windstar	3.8L	V6 OHV	1996 MY	IAB		•		
Windstar	3.8L	V6 OHV	1996 MY	PCM		•		
Windstar	3.8L	V6 OHV	1997 MY	ABS/TCS	•	•		
Windstar	3.8L	V6 OHV	1997 MY	ABS/TCS	•	•	•	0
Windstar	3.8L	V6 OHV	1997 MY	GEM	•	•	•	•
Windstar	3.8L	V6 OHV	1997 MY	IAB	•	•	•	•
Windstar	3.8L	V6 OHV	1997 MY	PCM	•	•	•	•
Windstar	3.8L	V6 OHV	1998 MY	ABS/TCS	•	•	•	
Windstar	3.8L	V6 OHV	1998 MY	ABS/TCS	•	•		0
Windstar	3.8L	V6 OHV	1998 MY	GEM	•	•	•	
Windstar	3.8L	V6 OHV	1998 MY	IAB	•	•	•	•
Windstar	3.8L	V6 OHV	1998 MY	PCM	•	•		•
Windstar	3.8L	V6 OHV	1998 MY	RAP	•	•	•	

- This function is supported.
- O This function is not supported.
- imes This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Windstar	3.8L	V6 OHV	1999 MY	ABS/TCS		•		
Windstar	3. 8L	V6 OHV	1999 MY	DDM		•	•	
Windstar	3. 8L	V6 OHV	1999 MY	FEM		•	•	
Windstar	3. 8L	V6 OHV	1999 MY	IC	•		•	
Windstar	3. 8L	V6 OHV	1999 MY	LPSDM		•	•	
Windstar	3. 8L	V6 OHV	1999 MY	MC		•	•	•
Windstar	3. 8L	V6 OHV	1999 MY	NGSC			•	0
Windstar	3. 8L	V6 OHV	1999 MY	PAM		•	•	
Windstar	3. 8L	V6 OHV	1999 MY	PCM	•	•	•	
Windstar	3. 8L	V6 OHV	1999 MY	RCM	•		•	
Windstar	3. 8L	V6 OHV	1999 MY	REM	•	•	•	•
Windstar	3. 8L	V6 OHV	1999 MY	RPSDM	•	•	•	•
Windstar	3. 8L	V6 OHV	2000 MY	ABS/TCS	•	•	•	•
Windstar	3. 8L	V6 OHV	2000 MY	DDM		•	•	
Windstar	3. 8L	V6 OHV	2000 MY	DSM	•	•	•	
Windstar	3. 8L	V6 OHV	2000 MY	FEM	•		•	
Windstar	3. 8L	V6 OHV	2000 MY	IC			•	
Windstar	3. 8L	V6 OHV	2000 MY	LPSDM	•	•	•	•
Windstar	3. 8L	V6 OHV	2000 MY	MC	•	•	•	•
Windstar	3. 8L	V6 OHV	2000 MY	NGSC		•	•	0
Windstar	3. 8L	V6 OHV	2000 MY	PAM	•	•	•	
Windstar	3.8L	V6 OHV	2000 MY	PCM	•	•	•	•
Windstar	3.8L	V6 OHV	2000 MY	RCM	•	•	•	•
Windstar	3.8L	V6 OHV	2000 MY	REM	•	•	•	•
Windstar	3.8L	V6 OHV	2000 MY	RPSDM	•	•	•	•
Windstar	3.8L	V6 OHV	2002 MY	ABS/TCS	•	•	•	•

- This function is supported.
- O This function is not supported.
- * This function may be supported, which depends on the actual condition of the vehicle.

Vehicle	Capacity	EngineType	Year	Module	Read Codes	Erase Codes	Live Data	Active Test
Windstar	3.8L	V6 OHV	2002 MY	DDM		•		
Windstar	3.8L	V6 OHV	2002 MY	DSM		•		•
Windstar	3.8L	V6 OHV	2002 MY	FEM		•		•
Windstar	3.8L	V6 OHV	2002 MY	IC		•		
Windstar	3.8L	V6 OHV	2002 MY	LPSDM		•		
Windstar	3.8L	V6 OHV	2002 MY	MC		•		
Windstar	3.8L	V6 OHV	2002 MY	NGSC		•		0
Windstar	3.8L	V6 OHV	2002 MY	PAM		•		•
Windstar	3.8L	V6 OHV	2002 MY	PCM		•		
Windstar	3.8L	V6 OHV	2002 MY	RCM		•	•	•
Windstar	3.8L	V6 OHV	2002 MY	REM		•	•	•
Windstar	3.8L	V6 OHV	2002 MY	RPSDM		•	•	
Windstar	3.8L	V6 OHV	2003 MY	ABS/TCS		•	•	•
Windstar	3.8L	V6 OHV	2003 MY	DDM		•	•	•
Windstar	3.8L	V6 OHV	2003 MY	DSM		•	•	
Windstar	3.8L	V6 OHV	2003 MY	FEM		•	•	•
Windstar	3.8L	V6 OHV	2003 MY	IC		•	•	
Windstar	3.8L	V6 OHV	2003 MY	LPSDM		•	•	•
Windstar	3.8L	V6 OHV	2003 MY	MC		•	•	•
Windstar	3.8L	V6 OHV	2003 MY	NGSC		•	•	0
Windstar	3.8L	V6 OHV	2003 MY	PAM	•	•	•	•
Windstar	3.8L	V6 OHV	2003 MY	PCM		•		•
Windstar	3.8L	V6 OHV	2003 MY	RCM		•	•	•
Windstar	3.8L	V6 OHV	2003 MY	REM	•	•	•	•
Windstar	3.8L	V6 OHV	2003 MY	RPSDM	•	•	•	•