MaxiDas_Maybach_V7.50 Function List

NOTES:

- This function is supported.

O This function is not supported.

 \blacktriangle This function is the new feature in this version.

* This function may be supported, which depends on the actual condition of the vehicle.

| Model year | Model Series | Control Unit Groups | System Name | DiagName | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame | Active Test | Special Function |
|------------------|-----------------|---------------------|--|-----------|--------------|---------------|-----------------|----------------|--------------|-----------------|----------------|-----------------------------|
| Up to | 240 | Drive | ETC-Electronic transmission control | EGS52 | | | • | | | | • | |
| Up to | 240 | Drive | ESM-Electronic selector module | EWM220 | | | • | • | | * | • | |
| Up to | 240 | Drive | SGR-Radar sensors control unit | RDU240 | | | | | | | 0 | |
| Up to | 240 | Drive | DTR-Distronic | ART220 | | | • | • | | * | 0 | 0005 |
| Up to | 240 | Drive | DTR-Distronic | ARS200 | | | | | | | 0 | 0005 |
| Up to | 240 | Drive | ME-SFI 2.7.1-Motor electronics 2.7.1 | MME275 | | • | • | | | • | • | 0004 |
| Up to | 240 | Chassis | SBC-Sensotronic Brake Control | EHB_ASG | | | • | | | 0 | 0 | 0006 0007 0008 |
| Up to 08/2006 | 240 | Chassis | SBC-Right Sensotronic Brake Control | EHB_ASG2 | • | • | • | • | • | 0 | | 0006 0007 0008 0038 0039 |
| Up to | 240 | Chassis | ESP-Electronic stability program | EHB_FSG | | | | | | | | 0014 |
| Up to | 240 | Chassis | AIRmatic | SLF211 | ● | | • | | | 0 | * | |
| Up to | 240 | Chassis | TPC-Tire pressure monitor | RDK211 | | | | | | | | |
| Up to | 240 | Body | CGW-Central gateway | ZGW240 | | | • | | | 0 | 0 | 0016 0017 0018 |
| Up to | 240 | Body | EZS-Electronic ignition switch | EZS240 | | | • | | | • | | |
| Up to | 240 | Body | AB-Airbag | ARMADA | | | • | • | | • | 0 | 0003 0010 0041 |
| Up to | 240 | Body | WSS-Weight sensing system | WSS171 | | | | | | 0 | 0 | |
| Up to | 240 | Body | BNS-Vehicle power supply control module | BNS240 | ● | | • | | | 0 | 0 | |
| Up to 08/2006 | 240 | Body | Dr-side SAM-Driver signal acquisition and actuation module | SAMF240 | • | • | • | • | • | 0 | • | |
| Up to 08/2006 | 240 | Body | Pass-side SAM-Passenger-side signal acquisition and actuation module | SAMB240 | • | • | • | • | • | 0 | • | |
| Up to 08/2006 | 240 | Body | Rear SAM 1-Rear signal acquisition and actuation module1 | SAM_H1240 | • | • | • | • | • | 0 | • | |
| Up to 08/2006 | 240 | Body | Rear SAM 2-Rear signal acquisition and actuation module2 | SAM_H2240 | • | • | • | • | • | 0 | • | |
| Up to 08/2006 | 240 | Body | MSS-Special vehicle multifunction control module | MSS240 | • | • | • | • | • | 0 | • | 0003 |
| Up to | 240 | Body | VBF (Front control panel)-Front control | VBF240 | ● | • | • | • | • | 0 | • | |
| Up to | 240 | Body | HBF (Rear control panel)-Rear control | HBF240 | | | • | | | 0 | • | |
| Up to | 240 | Body | BCG-Remote control(Rear control field) | BCG240 | | | • | • | | 0 | • | 0003 |
| Up to | 240 | Body | OCP-Overhead control panel | DBE240 | | | • | | | 0 | • | |
| Up to | 240 | Body | CRN-Center roof node | DKM240 | • | | 0 | • | | | • | |
| Up to | 240 | Body | PSE-Pneumatic system equipment | PSE240 | | | • | • | | 0 | • | |
| Up to 08/2006 | 240 | Body | HRA-Automatic headlamp range adjustment and headlamp control | ALWR211 | • | • | • | • | • | 0 | • | 0005 0009 |

FAutel[®]

MaxiDas_Maybach_V7.50 Function List

NOTES:

- This function is supported.
- O This function is not supported.

 \blacktriangle This function is the new feature in this version.

X This function may be supported, which depends on the actual condition of the vehicle.

| Model year | Model Series | Control Unit Groups | System Name | DiagName | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame | Active Test | Special Function |
|------------------|-----------------|-------------------------------|---|-----------|--------------|---------------|-----------------|----------------|--------------|-----------------|----------------|---------------------|
| Up to | 240 | Body | System diagnosis(CAN) | SD240 | | • | • | | | | | |
| Up to | 240 | Information and | PTS-Parktronic system | PTS211 | | • | • | • | | | • | |
| Up to | 240 | Information and | SCM [MRM]-Steering column module | MRM211 | | | • | | | | | 0005 |
| Up to | 240 | Information and | ICM-Instrument cluster | KI240 | | • | • | • | • | 0 | • | |
| Up to 08/2006 | 240 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio | XAGW | • | • | • | • | • | • | | 0003 |
| Up to | 240 | Information and | CTEL-Telecommunication for telematics | XCP | | | • | | | | 0 | |
| Up to 08/2006 | 240 | Information and communication | Telephone adapter for portable CTEL- Telecommunication for telematics services | ХСРТА | • | • | • | • | • | • | | |
| Up to | 240 | Information and | AUDIO | XHU | • | | • | | | • | • | 0003 |
| Up to | 240 | Information and | COMAND or AUDIO | XHUJP | | | 0 | | | | | |
| Up to | 240 | Information and | NAVI-Navigation system | XNAVIH | • | • | 0 | • | • | • | | |
| Up to | 240 | Information and | VCS-Voice control system | XSBS | | | 0 | | | | | |
| Up to | 240 | Information and | TV-TV tuner | XTV | | • | 0 | • | • | • | • | |
| Up to | 240 | Information and | TV-TV tuner(AGW) | TV211 | | | • | | | | | |
| Up to | 240 | Information and | SOUND-Bose sound system | XSND | • | | 0 | • | • | • | | |
| Up to 08/2006 | 240 | Information and communication | CTEL-Mobile phone adapter with universal interface | XUHI | • | • | • | • | • | • | 0 | |
| Up to | 240 | Information and | AVC-Audio video controller | XAVC | | | 0 | • | | | • | |
| Up to | 240 | Information and | TV-TV tuner(REAR) | XFTV | | | 0 | | | | | |
| Up to | 240 | Information and | TV-TV tuner (rear) | FTV_240 | | | • | • | • | | | |
| Up to | 240 | Information and | CDC-CD changer(REAR) | XFCDC | | | 0 | | | | 0 | |
| Up to | 240 | Information and | KTL-Left headphone transmitter | XRFTL | • | | 0 | • | • | 0 | | |
| Up to | 240 | Information and | KTR-Right headphone transmitter | XRFTR | | | 0 | | | 0 | | |
| Up to | 240 | Information and | GPS box | XGPSBOX | • | | 0 | • | • | • | 0 | |
| Up to | 240 | Information and | TELE AID-Control unit | XLCT | | | • | • | • | • | 0 | |
| Up to | 240 | Seats and doors | ESA-FL-Electric seat adjustment front left | SSGVL240 | | | • | | • | 0 | • | |
| Up to | 240 | Seats and doors | ESA-FR-Electric seat adjustment front | SSGVR240 | | | • | | | 0 | * | |
| Up to | 240 | Seats and doors | ESA-LR-Left rear electrical seat | SSGHL240 | • | | • | | • | 0 | | |
| Up to | 240 | Seats and doors | ESA-RR-Right rear electrical seat | SSGHR240 | | | 0 | | | | | |
| Up to | 240 | Seats and doors | OSB-FL-Multicontour backrest front left | MMKLVL240 | • | | • | | | 0 | • | |
| Up to | 240 | Seats and doors | OSB-FR-Multicontour backrest front right | MMKLVR240 | | | 0 | | | 0 | | |
| Up to | 240 | Seats and doors | MKL-HL-Rear left multicontour backrest | MMKLHL240 | • | | • | | • | 0 | • | |
| Up to | 240 | Seats and doors | MKL-HR-Rear right multicontour backrest | MMKLHR240 | | | | | | 0 | • | |

MaxiDas_Maybach_V7.50 Function List

NOTES:

• This function is supported.

O This function is not supported.

 \blacktriangle This function is the new feature in this version.

X This function may be supported, which depends on the actual condition of the vehicle.

| Model year | Model Series | Control Unit Groups | System Name | DiagName | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame | Active Test | Special Function |
|------------------|-----------------|---------------------|--|-----------|--------------|---------------|-----------------|----------------|--------------|-----------------|----------------|-----------------------------|
| Up to | 240 | Seats and doors | DCM-FL-Door control module front left | TSGVL240 | | • | • | | • | 0 | • | |
| Up to | 240 | Seats and doors | DCM-FR-Door control module front right | TSGVR240 | | | • | | • | 0 | • | |
| Up to | 240 | Seats and doors | DCM-RL-Door control module rear left | TSGHL240 | | • | • | | • | 0 | • | |
| Up to | 240 | Seats and doors | DCM-RR-Door control module rear right | TSGHR240 | | | • | | • | 0 | • | |
| Up to | 240 | Seats and doors | PWC-Partition wall control module | TWS240 | | • | • | | • | 0 | | |
| Up to | 240 | Seats and doors | LDCA-Electric left door closing assist | TZL240 | | | • | | | | 0 | |
| Up to | 240 | Seats and doors | RDCA-Electric right door closing assist | TZR240 | | • | • | | • | | 0 | |
| Up to | 240 | Seats and doors | TLC-Trunk lid control | HFS211 | | | • | | • | | • | |
| Up to | 240 | Air conditioning | AAC-Automatic air conditioning | KLA240 | | • | • | | • | 0 | • | 0003 |
| Up to | 240 | Air conditioning | REAR AC-Rear air conditioning | FKLA240 | | | • | | • | 0 | • | |
| Up to | 240 | Air conditioning | STH-Stationary heater | STH211 | | • | • | • | • | • | • | |
| Up to | 240 | Air conditioning | HSW-Heated steering wheel | LRK_211 | | | • | • | • | | • | 0003 0005 |
| As of | 240 | Drive | ETC-Electronic transmission control | EGS52 | | • | • | • | • | | • | |
| As of | 240 | Drive | ETC-Electronic transmission control | EGS53 | | | • | • | • | | • | |
| As of | 240 | Drive | ESM-Electronic selector module | EWM220 | | • | • | • | • | * | • | |
| As of | 240 | Drive | SGR-Radar sensors control unit | RDU240 | | | • | | • | | 0 | |
| As of | 240 | Drive | DTR-Distronic | ARS200 | | • | • | • | • | • | 0 | 0005 |
| As of | 240 | Drive | ME 2.7.2-Motor electronics 2.7.2 | ME272 | | • | • | • | • | | | 0004 |
| As of | 240 | Drive | ME 2.7.2-Motor electronics 2.7.2 | ME272AMG | | • | • | • | • | | | 0004 |
| As of | 240 | Drive | FSCU-Fuel pump | FSCM221 | | • | • | • | 0 | | | |
| As of | 240 | Chassis | SBC-Sensotronic Brake Control | EHB_ASG | | • | • | • | • | 0 | 0 | 0006 0007 0008 |
| As of 09/2006 | 240 | Chassis | SBC-Right Sensotronic Brake Control | EHB_ASG2 | • | • | • | • | • | 0 | | 0006 0007 0008 0038 0039 |
| As of | 240 | Chassis | ESP-Electronic stability program | EHB_FSG | | • | • | • | • | • | • | 0014 |
| As of | 240 | Chassis | AIRmatic | SLF211 | | • | • | • | • | 0 | * | |
| As of | 240 | Chassis | TPC-Tire pressure monitor | RDK211 | | • | • | • | • | | • | |
| As of | 240 | Body | CGW-Central gateway | ZGW240 | | | • | | • | 0 | 0 | 0016 0017 0018 |
| As of | 240 | Body | EZS-Electronic ignition switch | EZS240 | | | • | | • | • | | |
| As of | 240 | Body | AB-Airbag | ARCADE164 | | | • | | • | | | |
| As of | 240 | Body | WSS-Weight sensing system | WSS171 | • | • | • | • | • | 0 | 0 | |
| As of | 240 | Body | BNS-Vehicle power supply control module | BNS240 | | | | | • | 0 | 0 | |
| As of 09/2006 | 240 | Body | Dr-side SAM-Driver signal acquisition and actuation module | SAMF240 | • | • | • | • | • | 0 | • | |

MaxiDas_Maybach_V7.50 Function List

NOTES:

- This function is supported.
- O This function is not supported.

 \blacktriangle This function is the new feature in this version.

* This function may be supported, which depends on the actual condition of the vehicle.

| Model year | Model Series | Control Unit Groups | System Name | DiagName | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame | Active Test | Special Function |
|------------------|-----------------|-------------------------------|---|-----------|--------------|---------------|-----------------|----------------|--------------|-----------------|----------------|---------------------|
| As of 09/2006 | 240 | Body | Pass-side SAM-Passenger-side signal acquisition and actuation module | SAMB240 | • | • | • | • | • | 0 | • | |
| As of 09/2006 | 240 | Body | Rear SAM 1-Rear signal acquisition and actuation module1 | SAM_H1240 | • | • | • | • | • | 0 | • | |
| As of 09/2006 | 240 | Body | Rear SAM 2-Rear signal acquisition and actuation module2 | SAM_H2240 | • | • | • | • | • | 0 | • | |
| As of 09/2006 | 240 | Body | MSS-Special vehicle multifunction control module | MSS240 | • | • | • | • | • | 0 | • | 0003 |
| As of | 240 | Body | VBF (Front control panel)-Front control | VBF240 | | | • | | | 0 | • | |
| As of | 240 | Body | HBF (Rear control panel)-Rear control | HBF240 | | | • | • | • | 0 | • | |
| As of | 240 | Body | BCG-Remote control(Rear control field) | BCG240 | | | • | | | 0 | • | 0003 |
| As of | 240 | Body | OCP-Overhead control panel | DBE240 | | | • | • | • | 0 | • | |
| As of | 240 | Body | CRN-Center roof node | DKM240 | | | 0 | | | • | • | |
| As of | 240 | Body | PSE-Pneumatic system equipment | PSE240 | | | • | • | • | 0 | • | |
| As of 09/2006 | 240 | Body | HRA-Automatic headlamp range adjustment and headlamp control | ALWR211 | • | • | • | • | • | 0 | • | 0005 0009 |
| As of | 240 | Body | System diagnosis(CAN) | SD240 | | | • | • | • | • | | |
| As of | 240 | Information and | PTS-Parktronic system | PTS211 | | | • | • | | • | • | |
| As of | 240 | Information and | SCM [MRM]-Steering column module | MRM211 | | | • | • | • | • | • | 0005 |
| As of | 240 | Information and | ICM-Instrument cluster | KI240 | | | • | • | | 0 | • | |
| As of 09/2006 | 240 | Information and communication | AGW-Audio gateway (MOST network management, diagnosis gateway, radio | XAGW | • | • | • | • | • | • | | 0003 |
| As of | 240 | Information and | CTEL-Telecommunication for telematics | ХСР | | | • | | | | 0 | |
| As of 09/2006 | 240 | Information and communication | Telephone adapter for portable CTEL- Telecommunication for telematics services | ХСРТА | • | • | • | • | • | • | | |
| As of | 240 | Information and | AUDIO | XHU | | | • | • | | • | • | 0003 |
| As of | 240 | Information and | COMAND or AUDIO | XHUJP | • | • | 0 | • | • | • | • | |
| As of | 240 | Information and | NAVI-Navigation system | XNAVIH | | | 0 | | | • | | |
| As of | 240 | Information and | VCS-Voice control system | XSBS | | | 0 | • | | • | | |
| As of | 240 | Information and | TV-TV tuner | XTV | | | 0 | | • | • | • | |
| As of | 240 | Information and | TV-TV tuner(AGW) | TV211 | | | | • | | • | | |
| As of | 240 | Information and | SOUND-Bose sound system | XSND | | | 0 | | | | | |
| As of 09/2006 | 240 | Information and communication | CTEL-Mobile phone adapter with universal interface | XUHI | • | • | • | • | • | • | 0 | |
| As of | 240 | Information and | AVC-Audio video controller | XAVC | | | 0 | | | | • | |
| As of | 240 | Information and | TV-TV tuner(REAR) | XFTV | • | • | 0 | | | • | | |

MaxiDas_Maybach_V7.50 Function List

NOTES:

- This function is supported.
- O This function is not supported.

 \blacktriangle This function is the new feature in this version.

X This function may be supported, which depends on the actual condition of the vehicle.

| Model year | Model Series | Control Unit Groups | System Name | DiagName | Ecu Info. | Read Codes | Event Memory | Erase Codes | Live Data | Freeze Frame | Active Test | Special Function |
|------------|-----------------|---------------------|--|-----------|--------------|---------------|-----------------|----------------|--------------|-----------------|----------------|---------------------|
| As of | 240 | Information and | TV-TV tuner (rear) | FTV_240 | | | | • | • | • | | |
| As of | 240 | Information and | CDC-CD changer(REAR) | XFCDC | • | | 0 | • | • | • | 0 | |
| As of | 240 | Information and | KTL-Left headphone transmitter | XRFTL | | | 0 | | • | 0 | | |
| As of | 240 | Information and | KTR-Right headphone transmitter | XRFTR | • | | 0 | • | • | 0 | | |
| As of | 240 | Information and | GPS box | XGPSBOX | | | 0 | | | • | 0 | |
| As of | 240 | Information and | TELE AID-Control unit | XLCT | • | • | • | • | • | • | 0 | |
| As of | 240 | Seats and doors | ESA-FL-Electric seat adjustment front left | SSGVL240 | | | | • | • | 0 | • | |
| As of | 240 | Seats and doors | ESA-FR-Electric seat adjustment front | SSGVR240 | | | • | • | • | 0 | * | |
| As of | 240 | Seats and doors | ESA-LR-Left rear electrical seat | SSGHL240 | | | | | • | 0 | • | |
| As of | 240 | Seats and doors | ESA-RR-Right rear electrical seat | SSGHR240 | • | | 0 | • | • | • | • | |
| As of | 240 | Seats and doors | OSB-FL-Multicontour backrest front left | MMKLVL240 | | | | | | 0 | | |
| As of | 240 | Seats and doors | OSB-FR-Multicontour backrest front right | MMKLVR240 | | | 0 | • | • | 0 | | |
| As of | 240 | Seats and doors | MKL-HL-Rear left multicontour backrest | MMKLHL240 | | | | • | • | 0 | • | |
| As of | 240 | Seats and doors | MKL-HR-Rear right multicontour backrest | MMKLHR240 | | | • | • | • | 0 | ● | |
| As of | 240 | Seats and doors | DCM-FL-Door control module front left | TSGVL240 | | | | | | 0 | | |
| As of | 240 | Seats and doors | DCM-FR-Door control module front right | TSGVR240 | • | | • | • | • | 0 | • | |
| As of | 240 | Seats and doors | DCM-RL-Door control module rear left | TSGHL240 | | | | | | 0 | | |
| As of | 240 | Seats and doors | DCM-RR-Door control module rear right | TSGHR240 | • | | • | • | • | 0 | • | |
| As of | 240 | Seats and doors | PWC-Partition wall control module | TWS240 | | | • | | • | 0 | | |
| As of | 240 | Seats and doors | LDCA-Electric left door closing assist | TZL240 | • | • | • | • | • | • | 0 | |
| As of | 240 | Seats and doors | RDCA-Electric right door closing assist | TZR240 | | | | | | • | 0 | |
| As of | 240 | Seats and doors | TLC-Trunk lid control | HFS211 | | | • | | • | • | | |
| As of | 240 | Air conditioning | AAC-Automatic air conditioning | KLA240 | | | | • | • | 0 | | 0003 |
| As of | 240 | Air conditioning | REAR AC-Rear air conditioning | FKLA240 | • | | • | | • | 0 | • | |
| As of | 240 | Air conditioning | STH-Stationary heater | STH211 | | | • | • | • | • | • | |
| As of | 240 | Air conditioning | HSW-Heated steering wheel | LRK_211 | • | | | | • | | • | 0003 0005 |

Special_Function

-Autel

| | · • | | Ι |
|-------|---|-------|---|
| index | Specil Function Name | index | Specil Function Name |
| 0001 | ASSYST Setting | 0023 | Teach-in process after replacement of component Diesel particulate filter |
| 0002 | Service Reset | 0024 | Teaching in the diesel particulate filter after replacing the engine control unit |
| 0003 | Read coding and change if necessary. | 0025 | Activate fuel pump |
| 0004 | Variant coding | 0026 | Rapid teach-in of zero quantity calibration values |
| 0005 | Initial startup | 0027 | Initial startup of control unit EZS |
| 0006 | Deactivate system | 0028 | Initial startup of control unit ESL |
| 0007 | Activate system | 0029 | Disable key or key track |
| 0008 | Customer complaints (without fault codes) | 0030 | Once again authorize key or key track.// (DEF@KL15) |
| 0009 | Control unit adaptations | 0031 | Once again authorize key or key track.// (!(DEF@KL15)) |
| 0010 | Chassis number | 0032 | Program replacement keys |
| 0011 | Sliding/tilting roof | 0033 | Activate control module N73 (EIS [EZS] control unit). |
| 0012 | Calibration of the torque sensor | 0034 | Activate control module $\mathrm{N26}/\mathrm{5}$ (Electric steering lock control module) |
| 0013 | Learning of the throttle valve stop | 0035 | Key assignment or key track assignment to a memory block number |
| 0014 | Road test | 0036 | Writing of the VIN |
| 0015 | Tire pressure loss warner (Activating) | 0037 | Telematic service 'Remote door unlocking' (TELE AID) |
| 0016 | Vehicle data | 0038 | Brake counter update and recalculate lifetime |
| 0017 | Modification year or model year | 0039 | Replace hydraulic brake system fluid./Bleed brake system. |
| 0018 | All codes | 0040 | Zero point variation steering angle and lateral acceleration sensor |
| 0019 | Replace component Diesel particulate filter | 0041 | Steering variant |
| 0020 | Reprogram diesel particulate filter in control unit N3/9 (CDI control unit) | 0042 | Pneumatic tests |
| 0021 | Teach in component Y94 (Quantity control valve) | 0043 | Initial test/ Oil condition check/ Oil level check |
| 0022 | Teaching in the diesel particulate filter after replacing the engine control unit | 0044 | Diagnosis routines |
| 0045 | Calibration of compnent B24/12(ABC lateral acceleration sensor) | 0052 | Load adjustment |
| 0046 | Calibration of the plunger travel sensors | 0056 | Pneumatic test of component A9/1 (AIRmatic compressor unit) |
| 0047 | Erase zero point offset error of component N49 (Steering angle sensor) | 0057 | Pneumatic test of component A9/ly1 (AIRmatic pressure release valve) |
| 0048 | Initial startup with automatic takeover of settings of previous control unit | 0058 | Replacement of control module N80(Steering column module) |
| 0049 | Initial startup with manual settings input for new control unit/Level calibration | 0059 | Reset compressor operating time |
| 0050 | Initializing:Rain sensor,Steering column module | 0060 | Reset of calibration |
| 0051 | Level calibration | | |