

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C30	2009	TCM	MPS6	●	●	●	●	●	○		
C30	2009	ECM	D5244T9	●	●	●	●	●	●		
C30	2009	ECM	D5244T8	●	●	●	●	●	●		
C30	2009	ECM	D5244T13	●	●	●	●	●	●		
C30	2009	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
C30	2009	ADM	D4204T	●	●	●	●	●	○		
C30	2009	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
C30	2009	ADM	D4164T	●	●	●	●	●	○		
C30	2009	ECM	D4164T	●	●	●	●	●	●	69, 141	
C30	2009	ECM	B5254T7	●	●	●	●	●	●	74	
C30	2009	ECM	B5244S4	●	●	●	●	●	●	9	
C30	2009	ECM	B4204S3	●	●	●	●	●	●	9	
C30	2009	ECM	B4184S8	●	●	●	●	●	●	9	
C30	2009	ECM	B4184S11	●	●	●	●	●	●	9	
C30	2009	ECM	B4164S3	●	●	●	●	●	●	9	
C30	2009	TCM	AW55-50/51SN	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
C30	2009	AEM		●	●	●	●	●	●	146	
C30	2009	KVM		●	●	●	●	●	●	147	
C30	2009	RDAR		●	●	●	●	●	○		
C30	2009	PHM		●	●	●	●	●	○		
C30	2009	CPM		●	●	●	●	●	●		
C30	2009	AUD		●	●	●	●	○	○		
C30	2009	BPM		●	●	●	●	●	○		
C30	2009	PAM		●	●	●	●	●	○		
C30	2009	SRS		●	●	●	●	●	○	95	
C30	2009	DDM		●	●	●	●	●	●	149, 150	
C30	2009	PDM		●	●	●	●	●	●	149, 150	
C30	2009	AUU		●	●	●	●	●	○		
C30	2009	BCM		●	●	●	●	●	○	146, 111	
C30	2009	CCM		●	●	●	●	○	○	30, 113, 152, 32, 153	
C30	2009	SWM		●	●	●	●	●	○		
C30	2009	TRM		●	●	●	●	●	○		
C30	2009	EPS		●	●	●	●	●	○		
C30	2009	IAM		●	●	●	●	●	●		
C30	2009	PSL		●	●	●	●	●	●	145	
C30	2009	PSR		●	●	●	●	●	●	145	
C30	2009	CEM		●	●	●	●	●	●	154, 156, 94, 158, 35, 95, 159, 160, 162	
C30	2009	DIM		●	●	●	●	●	●	48, 161, 46, 165, 118, 51	

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C30	2009	ICM		●	●	●	●	●	●	166, 167, 168	
C30	2009	MMM		●	●	●	●	○	○		
C30	2008	TCM	MPS6	●	●	●	●	●	○		
C30	2008	ECM	D5244T9	●	●	●	●	●	●		
C30	2008	ECM	D5244T8	●	●	●	●	●	●		
C30	2008	ECM	D5244T13	●	●	●	●	●	●		
C30	2008	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
C30	2008	ADM	D4204T	●	●	●	●	●	○		
C30	2008	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
C30	2008	ADM	D4164T	●	●	●	●	●	○		
C30	2008	ECM	D4164T	●	●	●	●	●	●	69, 141	
C30	2008	ECM	B5254T7	●	●	●	●	●	●	74	
C30	2008	ECM	B5244S4	●	●	●	●	●	●	9	
C30	2008	ECM	B4204S3	●	●	●	●	●	●	9	
C30	2008	ECM	B4184S8	●	●	●	●	●	●	9	
C30	2008	ECM	B4184S11	●	●	●	●	●	●	9	
C30	2008	ECM	B4164S3	●	●	●	●	●	●	9	
C30	2008	TCM	AW55-50/51SN	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
C30	2008	BCM		●	●	●	●	●	○	146, 111	
C30	2008	KVM		●	●	●	●	●	●	147	
C30	2008	RDAR		●	●	●	●	●	○		
C30	2008	CPM		●	●	●	●	●	●		
C30	2008	AUD		●	●	●	●	○	○		
C30	2008	PAM		●	●	●	●	●	○		
C30	2008	SRS		●	●	●	●	●	○	95	
C30	2008	DDM		●	●	●	●	●	●	149, 150	
C30	2008	PDM		●	●	●	●	●	●	149, 150	
C30	2008	PSL		●	●	●	●	●	●	145	
C30	2008	PSR		●	●	●	●	●	●	145	
C30	2008	AUU		●	●	●	●	●	○		
C30	2008	CCM		●	●	●	●	●	○	30, 113, 152, 32, 153	
C30	2008	PHM		●	●	●	●	●	○		
C30	2008	CEM		●	●	●	●	●	●	154, 156, 94, 158, 159, 160, 35, 162, 95	
C30	2008	DIM		●	●	●	●	●	●	48, 161, 46, 165, 118, 51	
C30	2008	SWM		●	●	●	●	●	○		
C30	2008	TRM		●	●	●	●	●	○		
C30	2008	EPS		●	●	●	●	●	○		
C30	2008	IAM		●	●	●	●	●	●		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C30	2008	ICM		●	●	●	●	●	●	166, 167, 168	
C30	2008	MMM		●	●	●	●	○	○		
C30	2007	ECM	D5244T9	●	●	●	●	●	●		
C30	2007	ECM	D5244T8	●	●	●	●	●	●		
C30	2007	ADM	D4204T	●	●	●	●	●	○		
C30	2007	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
C30	2007	ADM	D4164T	●	●	●	●	●	○		
C30	2007	ECM	D4164T	●	●	●	●	●	●	69, 141, 169	
C30	2007	ECM	B5254T3	●	●	●	●	●	●	74	
C30	2007	ECM	B5244S4	●	●	●	●	●	●	9	
C30	2007	ECM	B4204S3	●	●	●	●	●	●	9	
C30	2007	ECM	B4184S8	●	●	●	●	●	●	9	
C30	2007	ECM	B4184S11	●	●	●	●	●	●	9	
C30	2007	ECM	B4164S3	●	●	●	●	●	●	9	
C30	2007	TCM	AW55-50/51SN	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
C30	2007	DIM		●	●	●	●	●	●	48, 161, 46, 165, 118	
C30	2007	GPS		●	●	●	●	●	○		
C30	2007	BCM		●	●	●	●	●	○	146, 111	
C30	2007	TMC		●	●	●	●	●	○		
C30	2007	SWM		●	●	●	●	●	○		
C30	2007	KVM		●	●	●	●	●	●	147	
C30	2007	PHM		●	●	●	●	●	○		
C30	2007	CEM		●	●	●	●	●	●	154, 156, 94, 158, 159, 160, 162, 95	
C30	2007	MMM		●	●	●	●	○	○		
C30	2007	RDAR		●	●	●	●	●	○		
C30	2007	CPM		●	●	●	●	●	●		
C30	2007	IAM		●	●	●	●	●	●		
C30	2007	AUD		●	●	●	●	○	○		
C30	2007	PAM		●	●	●	●	●	○		
C30	2007	SRS		●	●	●	●	●	○	95	
C30	2007	DDM		●	●	●	●	●	●	149, 150	
C30	2007	PDM		●	●	●	●	●	●	149, 150	
C30	2007	PSL		●	●	●	●	●	●	145	
C30	2007	PSR		●	●	●	●	●	●	145	
C30	2007	CCM		●	●	●	●	●	○	30, 113, 152, 32, 153	
C30	2007	TRM		●	●	●	●	●	○		
C30	2007	ICM		●	●	●	●	●	●	166, 167	
C30	2007	EPS		●	●	●	●	●	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
 - This function is not supported.
 - ▲ This function is the new feature in this version.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
- As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 (06-)	2009	TCM	MPS6	●	●	●	●	●	○		
C70 (06-)	2009	ECM	D5244T9	●	●	●	●	●	●		
C70 (06-)	2009	ECM	D5244T8	●	●	●	●	●	●		
C70 (06-)	2009	ECM	D5244T13	●	●	●	●	●	●		
C70 (06-)	2009	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
C70 (06-)	2009	ADM	D4204T	●	●	●	●	●	○		
C70 (06-)	2009	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
C70 (06-)	2009	ECM	B5254T7	●	●	●	●	●	●	74	
C70 (06-)	2009	ECM	B5244S5	●	●	●	●	●	●	9	
C70 (06-)	2009	ECM	B5244S4	●	●	●	●	●	●	9	
C70 (06-)	2009	TCM	AW55-50/51SN	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
C70 (06-)	2009	AEM		●	●	●	●	●	●	146	
C70 (06-)	2009	KVM		●	●	●	●	●	●	147	
C70 (06-)	2009	RDAR		●	●	●	●	●	○		
C70 (06-)	2009	PHM		●	●	●	●	●	○		
C70 (06-)	2009	CPM		●	●	●	●	●	●		
C70 (06-)	2009	AUD		●	●	●	●	○	○		
C70 (06-)	2009	BPM		●	●	●	●	●	○		
C70 (06-)	2009	PAM		●	●	●	●	●	○		
C70 (06-)	2009	SRS		●	●	●	●	●	○	95	
C70 (06-)	2009	DDM		●	●	●	●	●	●	149, 150	
C70 (06-)	2009	PDM		●	●	●	●	●	●	149, 150	
C70 (06-)	2009	AUU		●	●	●	●	●	○		
C70 (06-)	2009	BCM		●	●	●	●	●	○	146, 111	
C70 (06-)	2009	CCM		●	●	●	●	○	○	30, 113, 152, 32, 153	
C70 (06-)	2009	CRM		●	●	●	●	●	○	174, 176	
C70 (06-)	2009	SWM		●	●	●	●	●	○		
C70 (06-)	2009	TRM		●	●	●	●	●	○		
C70 (06-)	2009	EPS		●	●	●	●	●	○		
C70 (06-)	2009	SUB		●	●	●	●	○	○		
C70 (06-)	2009	IAM		●	●	●	●	●	●		
C70 (06-)	2009	PSL		●	●	●	●	●	●	145	
C70 (06-)	2009	PSR		●	●	●	●	●	●	145	
C70 (06-)	2009	CEM		●	●	●	●	●	●	154, 156, 94, 158, 159, 160, 35, 162, 95	
C70 (06-)	2009	DIM		●	●	●	●	●	●	48, 161, 118, 46, 165, 51	
C70 (06-)	2009	ICM		●	●	●	●	●	●	166, 167, 168	
C70 (06-)	2009	MMM		●	●	●	●	○	○	159	
C70 (06-)	2008	ECM	D5244T9	●	●	●	●	●	●		

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
 - This function is not supported.
 - ▲ This function is the new feature in this version.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
- As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 (06-)	2008	ECM	D5244T8	●	●	●	●	●	●		
C70 (06-)	2008	ECM	D5244T13	●	●	●	●	●	●	94	
C70 (06-)	2008	ADM	D4204T	●	●	●	●	●	○		
C70 (06-)	2008	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
C70 (06-)	2008	ECM	B5254T7	●	●	●	●	●	●	74	
C70 (06-)	2008	ECM	B5244S5	●	●	●	●	●	●	9	
C70 (06-)	2008	ECM	B5244S4	●	●	●	●	●	●	9	
C70 (06-)	2008	TCM	AW55-50/51SN	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
C70 (06-)	2008	BCM		●	●	●	●	●	○	146, 111	
C70 (06-)	2008	AEM		●	●	●	●	●	●	146	
C70 (06-)	2008	KVM		●	●	●	●	●	●	147	
C70 (06-)	2008	RDAR		●	●	●	●	●	○		
C70 (06-)	2008	CPM		●	●	●	●	●	●		
C70 (06-)	2008	AUD		●	●	●	●	○	○		
C70 (06-)	2008	PAM		●	●	●	●	●	○		
C70 (06-)	2008	SRS		●	●	●	●	●	○	95	
C70 (06-)	2008	DDM		●	●	●	●	●	●	149, 150	
C70 (06-)	2008	PDM		●	●	●	●	●	●	149, 150	
C70 (06-)	2008	PSL		●	●	●	●	●	●	145	
C70 (06-)	2008	PSR		●	●	●	●	●	●	145	
C70 (06-)	2008	AUU		●	●	●	●	●	○		
C70 (06-)	2008	CCM		●	●	●	●	●	○	30, 113, 152, 32, 153	
C70 (06-)	2008	PHM		●	●	●	●	●	○		
C70 (06-)	2008	CRM		●	●	●	●	●	○	174, 176	
C70 (06-)	2008	CEM		●	●	●	●	●	●	154, 156, 94, 158, 159, 160, 35, 162, 95	
C70 (06-)	2008	DIM		●	●	●	●	●	●	48, 161, 118, 46, 165, 51	
C70 (06-)	2008	SWM		●	●	●	●	●	○		
C70 (06-)	2008	TRM		●	●	●	●	●	○		
C70 (06-)	2008	EPS		●	●	●	●	●	○		
C70 (06-)	2008	SUB		●	●	●	●	○	○		
C70 (06-)	2008	IAM		●	●	●	●	●	●		
C70 (06-)	2008	ICM		●	●	●	●	●	●	166, 167, 168	
C70 (06-)	2008	MMM		●	●	●	●	○	○		
C70 (06-)	2007	ECM	D5244T9	●	●	●	●	●	●		
C70 (06-)	2007	ECM	D5244T8	●	●	●	●	●	●		
C70 (06-)	2007	ECM	B5254T3	●	●	●	●	●	●	74	
C70 (06-)	2007	ECM	B5244S5	●	●	●	●	●	●	9	
C70 (06-)	2007	ECM	B5244S4	●	●	●	●	●	●	9	

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
 - This function is not supported.
 - ▲ This function is the new feature in this version.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
- As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 (06-)	2007	TCM	AW55-50/51SN	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
C70 (06-)	2007	DIM		●	●	●	●	●	●	48, 161, 46, 165	
C70 (06-)	2007	GPS		●	●	●	●	●	○		
C70 (06-)	2007	BCM		●	●	●	●	●	○	146, 111	
C70 (06-)	2007	TMC		●	●	●	●	●	○		
C70 (06-)	2007	SWM		●	●	●	●	●	○		
C70 (06-)	2007	KVM		●	●	●	●	●	●	147	
C70 (06-)	2007	AEM		●	●	●	●	●	●	146	
C70 (06-)	2007	PHM		●	●	●	●	●	○		
C70 (06-)	2007	TRM		●	●	●	●	●	○		
C70 (06-)	2007	CEM		●	●	●	●	●	●	154, 156, 94, 158, 159, 160, 162, 95	
C70 (06-)	2007	MMM		●	●	●	●	○	○		
C70 (06-)	2007	RDAR		●	●	●	●	●	○		
C70 (06-)	2007	CPM		●	●	●	●	●	●		
C70 (06-)	2007	SUB		●	●	●	●	○	○		
C70 (06-)	2007	IAM		●	●	●	●	●	●		
C70 (06-)	2007	AUD		●	●	●	●	○	○		
C70 (06-)	2007	PAM		●	●	●	●	●	○		
C70 (06-)	2007	SRS		●	●	●	●	●	○	95	
C70 (06-)	2007	DDM		●	●	●	●	●	●	149, 150	
C70 (06-)	2007	PDM		●	●	●	●	●	●	149, 150	
C70 (06-)	2007	PSL		●	●	●	●	●	●	145	
C70 (06-)	2007	PSR		●	●	●	●	●	●	145	
C70 (06-)	2007	CCM		●	●	●	●	●	○	30, 113, 152, 32, 153	
C70 (06-)	2007	CRM		●	●	●	●	●	○	174, 176	
C70 (06-)	2007	ICM		●	●	●	●	●	●	166, 167	
C70 (06-)	2007	EPS		●	●	●	●	●	○		
C70 (06-)	2006	ECM	B5254T3	●	●	●	●	●	●	74	
C70 (06-)	2006	ECM	B5244S5	●	●	●	●	●	●	9	
C70 (06-)	2006	ECM	B5244S4	●	●	●	●	●	●	9	
C70 (06-)	2006	TCM	AW55-50/51SN	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
C70 (06-)	2006	DIM		●	●	●	●	●	●	48, 161, 46, 165	
C70 (06-)	2006	GPS		●	●	●	●	●	○		
C70 (06-)	2006	BCM		●	●	●	●	●	○	146, 111	
C70 (06-)	2006	TMC		●	●	●	●	●	○		
C70 (06-)	2006	SWM		●	●	●	●	●	○		
C70 (06-)	2006	KVM		●	●	●	●	●	●	147	
C70 (06-)	2006	AEM		●	●	●	●	●	●	146	

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
 - This function is not supported.
 - ▲ This function is the new feature in this version.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
- As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 (06-)	2006	ICM		●	●	●	●	●	●	166	
C70 (06-)	2006	IAM		●	●	●	●	●	●		
C70 (06-)	2006	AUD		●	●	●	●	○	○		
C70 (06-)	2006	PHM		●	●	●	●	●	○		
C70 (06-)	2006	TRM		●	●	●	●	●	○		
C70 (06-)	2006	PSL		●	●	●	●	●	●	145	
C70 (06-)	2006	CEM		●	●	●	●	●	●	154, 156, 94, 158, 159, 160, 162, 95	
C70 (06-)	2006	MMM		●	●	●	●	○	○		
C70 (06-)	2006	CPM		●	●	●	●	●	●		
C70 (06-)	2006	SUB		●	●	●	●	○	○		
C70 (06-)	2006	PSR		●	●	●	●	●	●	145	
C70 (06-)	2006	DDM		●	●	●	●	●	●	149	
C70 (06-)	2006	PDM		●	●	●	●	●	●	149	
C70 (06-)	2006	CCM		●	●	●	●	●	○	30, 113, 152, 32, 153	
C70 (06-)	2006	PAM		●	●	●	●	●	○		
C70 (06-)	2006	SRS		●	●	●	●	●	○	95	
C70 (06-)	2006	CRM		●	●	●	●	●	○	174, 176	
C70 (06-)	2006	EPS		●	●	●	●	●	○		
C70 Conv	2005	Petrol	B5204T4	●	●	●	●	●	●	1, 2, 3, 50	
C70 Conv	2005	Petrol	B5234T9	●	●	●	●	●	●	1, 2, 3, 50	
C70 Conv	2005	Petrol	B5244T7	●	●	●	●	●	●	1, 2, 3, 50	
C70 Conv	2005	Combined instrument	Combined instrument	●	●	●	○	●	●	72, 73, 37, 32	
C70 Conv	2005	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
C70 Conv	2005	RTI	RTI	●	●	●	○	●	●		
C70 Conv	2005	TCM	AW55-50/51SN	●	●	●	○	●	●	10, 11	
C70 Conv	2005	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
C70 Conv	2005	Cab control system	Cab control system	●	●	●	○	●	○		
C70 Conv	2005	CCM	CCM	●	●	●	○	●	○		
C70 Conv	2005	CPM	CPM	●	●	●	○	●	○		
C70 Conv	2005	Power seat module, left	Power seat module, left	●	●	●	○	●	●		
C70 Conv	2005	Power seat module, right	Power seat module,	●	●	●	○	●	●		
C70 Conv	2005	Rollover protection	Rollover protection	●	●	●	○	●	●		
C70 Conv	2005	SRS	SRS	●	●	●	○	●	○		
C70 Conv	2004	Petrol	B5204T4	●	●	●	●	●	●	1, 2, 3, 50	
C70 Conv	2004	Petrol	B5234T9	●	●	●	●	●	●	1, 2, 3, 50	
C70 Conv	2004	Petrol	B5244T7	●	●	●	●	●	●	1, 2, 3, 50	
C70 Conv	2004	Combined instrument	Combined instrument	●	●	●	○	●	●	72, 73, 37, 32	
C70 Conv	2004	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 Conv	2004	RTI	RTI	●	●	●	○	●	●		
C70 Conv	2004	TCM	AW55-50/51SN	●	●	●	○	●	●	10, 11	
C70 Conv	2004	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
C70 Conv	2004	Cab control system	Cab control system	●	●	●	○	●	○		
C70 Conv	2004	CCM	CCM	●	●	●	○	●	○		
C70 Conv	2004	CPM	CPM	●	●	●	○	●	○		
C70 Conv	2004	Power seat module, left	Power seat module, left	●	●	●	○	●	●		
C70 Conv	2004	Power seat module, right	Power seat module,	●	●	●	○	●	●		
C70 Conv	2004	Rollover protection	Rollover protection	●	●	●	○	●	●		
C70 Conv	2004	SRS	SRS	●	●	●	○	●	○		
C70 Conv	2003	Petrol	B5204T4	●	●	●	●	●	●	1, 2, 3, 50	
C70 Conv	2003	Petrol	B5234T9	●	●	●	●	●	●	1, 2, 3, 50	
C70 Conv	2003	Petrol	B5244T7	●	●	●	●	●	●	1, 2, 3, 50	
C70 Conv	2003	Combined instrument	Combined instrument	●	●	●	○	●	●	72, 73, 37, 32	
C70 Conv	2003	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
C70 Conv	2003	RTI	RTI	●	●	●	○	●	●		
C70 Conv	2003	TCM	AW55-50/51SN	●	●	●	○	●	●	10, 11	
C70 Conv	2003	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
C70 Conv	2003	Cab control system	Cab control system	●	●	●	○	●	○		
C70 Conv	2003	CCM	CCM	●	●	●	○	●	○		
C70 Conv	2003	CPM	CPM	●	●	●	○	●	○		
C70 Conv	2003	Power seat module, left	Power seat module, left	●	●	●	○	●	●		
C70 Conv	2003	Power seat module, right	Power seat module,	●	●	●	○	●	●		
C70 Conv	2003	Rollover protection	Rollover protection	●	●	●	○	●	●		
C70 Conv	2003	SRS	SRS	●	●	●	○	●	○		
C70 Conv	2002	Petrol	B5204T4	●	●	●	●	●	●	50	Elec. Ident.
C70 Conv	2002	Petrol	B5234T3	●	●	●	●	●	●	50	Elec. Ident.
C70 Conv	2002	Petrol	B5244T	●	●	●	●	●	●	50	Elec. Ident.
C70 Conv	2002	Combined instrument	Combined instrument	●	●	●	○	●	●	72, 73, 37, 32	
C70 Conv	2002	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
C70 Conv	2002	RTI	RTI	●	●	●	○	●	●		
C70 Conv	2002	TCM	AW55-50/51SN	●	●	●	○	●	●	10, 11	
C70 Conv	2002	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
C70 Conv	2002	Cab control system	Cab control system	●	●	●	○	●	○		
C70 Conv	2002	CCM	CCM	●	●	●	○	●	○		
C70 Conv	2002	CPM	CPM	●	●	●	○	●	○		
C70 Conv	2002	Power seat module, left	Power seat module, left	●	●	●	○	●	●		
C70 Conv	2002	Power seat module, right	Power seat module,	●	●	●	○	●	●		
C70 Conv	2002	Rollover protection	Rollover protection	●	●	●	○	●	●		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 Conv	2002	SRS	SRS	●	●	●	○	●	○		
C70 Conv	2001	Petrol	B5204T4	●	●	●	●	●	●	50	Elec. Ident.
C70 Conv	2001	Petrol	B5234T3	●	●	●	●	●	●	50	Elec. Ident.
C70 Conv	2001	Petrol	B5244T	●	●	●	●	●	●	50	Elec. Ident.
C70 Conv	2001	Combined instrument	Combined instrument	●	●	●	○	●	●	72, 73, 37, 32	
C70 Conv	2001	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
C70 Conv	2001	RTI	RTI	●	●	●	○	●	●		
C70 Conv	2001	TCM	AW55-50/51SN	●	●	●	○	●	●	10, 11	
C70 Conv	2001	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
C70 Conv	2001	Cab control system	Cab control system	●	●	●	○	●	○		
C70 Conv	2001	CCM	CCM	●	●	●	○	●	○		
C70 Conv	2001	CPM	CPM	●	●	●	○	●	○		
C70 Conv	2001	Power seat module, left	Power seat module, left	●	●	●	○	●	●		
C70 Conv	2001	Power seat module, right	Power seat module,	●	●	●	○	●	●		
C70 Conv	2001	Rollover protection	Rollover protection	●	●	●	○	●	●		
C70 Conv	2001	SRS	SRS	●	●	●	○	●	○		
C70 Conv	2000	Petrol	B5204T3	●	●	●	●	●	●	1, 50	Elec. Ident.
C70 Conv	2000	Petrol	B5204T4	●	●	●	●	●	●	1, 50	Elec. Ident.
C70 Conv	2000	Petrol	B5234T3	●	●	●	●	●	●	1, 50	Elec. Ident.
C70 Conv	2000	Petrol	B5244S	●	●	●	○	●	●	88, 6, 89	Extend DTC;Elec. Ident.
C70 Conv	2000	Petrol	B5244T	●	●	●	●	●	●	1, 50	Elec. Ident.
C70 Conv	2000	Combined instrument	Combined instrument	●	●	●	○	●	●	72, 73, 37, 32	
C70 Conv	2000	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
C70 Conv	2000	RTI	RTI	●	●	●	○	●	●		
C70 Conv	2000	TCM	AW50-42	●	●	●	○	●	●	10, 11	
C70 Conv	2000	TCM	AW55-50/51SN	●	●	●	○	●	●	10, 11	
C70 Conv	2000	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
C70 Conv	2000	Cab control system	Cab control system	●	●	●	○	●	○		
C70 Conv	2000	CCM	CCM	●	●	●	○	●	○		
C70 Conv	2000	CPM	CPM	●	●	●	○	●	○		
C70 Conv	2000	Power seat module, left	Power seat module, left	●	●	●	○	●	●		
C70 Conv	2000	Power seat module, right	Power seat module,	●	●	●	○	●	●		
C70 Conv	2000	Rollover protection	Rollover protection	●	●	●	○	●	●		
C70 Conv	2000	SRS	SRS	●	●	●	○	●	○		
C70 Conv	1999	Petrol	B5204T3	●	●	●	●	●	●	1, 50	Elec. Ident.
C70 Conv	1999	Petrol	B5204T4	●	●	●	●	●	●	1, 50	Elec. Ident.
C70 Conv	1999	Petrol	B5234T3	●	●	●	●	●	●	1, 50	Elec. Ident.
C70 Conv	1999	Petrol	B5254T	●	●	●	●	●	●	1, 93	Elec. Ident.

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 Conv	1999	Combined instrument	Combined instrument	●	●	●	○	●	●	72, 73, 37, 32	
C70 Conv	1999	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
C70 Conv	1999	RTI	RTI	●	●	●	○	●	●		
C70 Conv	1999	TCM	AW50-42	●	●	●	○	●	●		
C70 Conv	1999	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
C70 Conv	1999	Cab control system	Cab control system	●	●	●	○	●	○		
C70 Conv	1999	CCM	CCM	●	●	●	○	●	○		
C70 Conv	1999	CPM	CPM	●	●	●	○	●	○		
C70 Conv	1999	Power seat module, left	Power seat module, left	●	●	●	○	●	●		
C70 Conv	1999	Power seat module, right	Power seat module,	●	●	●	○	●	●		
C70 Conv	1999	Rollover protection	Rollover protection	●	●	●	○	●	●		
C70 Conv	1999	SRS	SRS	●	●	●	○	●	○		
C70 Coupe	2002	Petrol	B5204T4	●	●	●	●	●	●	50	Elec. Ident.
C70 Coupe	2002	Petrol	B5234T3	●	●	●	●	●	●	50	Elec. Ident.
C70 Coupe	2002	Petrol	B5244T	●	●	●	●	●	●	50	Elec. Ident.
C70 Coupe	2002	Combined instrument	Combined instrument	●	●	●	○	●	●	72, 73, 37, 32	
C70 Coupe	2002	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
C70 Coupe	2002	RTI	RTI	●	●	●	○	●	●		
C70 Coupe	2002	TCM	AW55-50/51SN	●	●	●	○	●	●	10, 11	
C70 Coupe	2002	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
C70 Coupe	2002	CCM	CCM	●	●	●	○	●	○		
C70 Coupe	2002	CPM	CPM	●	●	●	○	●	○		
C70 Coupe	2002	Power seat module, left	Power seat module, left	●	●	●	○	●	●		
C70 Coupe	2002	Power seat module, right	Power seat module,	●	●	●	○	●	●		
C70 Coupe	2002	SRS	SRS	●	●	●	○	●	○		
C70 Coupe	2001	Petrol	B5204T4	●	●	●	●	●	●	50	Elec. Ident.
C70 Coupe	2001	Petrol	B5234T3	●	●	●	●	●	●	50	Elec. Ident.
C70 Coupe	2001	Petrol	B5244T	●	●	●	●	●	●	50	Elec. Ident.
C70 Coupe	2001	Combined instrument	Combined instrument	●	●	●	○	●	●	72, 73, 37, 32	
C70 Coupe	2001	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
C70 Coupe	2001	RTI	RTI	●	●	●	○	●	●		
C70 Coupe	2001	TCM	AW55-50/51SN	●	●	●	○	●	●	10, 11	
C70 Coupe	2001	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
C70 Coupe	2001	CCM	CCM	●	●	●	○	●	○		
C70 Coupe	2001	CPM	CPM	●	●	●	○	●	○		
C70 Coupe	2001	Power seat module, left	Power seat module, left	●	●	●	○	●	●		
C70 Coupe	2001	Power seat module, right	Power seat module,	●	●	●	○	●	●		
C70 Coupe	2001	SRS	SRS	●	●	●	○	●	○		
C70 Coupe	2000	Petrol	B5204T3	●	●	●	●	●	●	1, 50	Elec. Ident.

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
 - This function is not supported.
 - ▲ This function is the new feature in this version.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
- As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
C70 Coupe	2000	Petrol	B5204T4	●	●	●	●	●	●	1, 50	Elec. Ident.
C70 Coupe	2000	Petrol	B5234T3	●	●	●	●	●	●	1, 50	Elec. Ident.
C70 Coupe	2000	Petrol	B5244S	●	●	●	○	●	●	88, 6, 89	Extend DTC;Elec. Ident.
C70 Coupe	2000	Petrol	B5244T	●	●	●	●	●	●	1, 50	Elec. Ident.
C70 Coupe	2000	Combined instrument	Combined instrument	●	●	●	○	●	●	72, 73, 37, 32	
C70 Coupe	2000	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
C70 Coupe	2000	RTI	RTI	●	●	●	○	●	●		
C70 Coupe	2000	TCM	AW50-42	●	●	●	○	●	●	10, 11	
C70 Coupe	2000	TCM	AW55-50/51SN	●	●	●	○	●	●	10, 11	
C70 Coupe	2000	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
C70 Coupe	2000	CCM	CCM	●	●	●	○	●	○		
C70 Coupe	2000	CPM	CPM	●	●	●	○	●	○		
C70 Coupe	2000	Power seat module, left	Power seat module, left	●	●	●	○	●	●		
C70 Coupe	2000	Power seat module, right	Power seat module,	●	●	●	○	●	●		
C70 Coupe	2000	SRS	SRS	●	●	●	○	●	○		
C70 Coupe	1999	Petrol	B5204T3	●	●	●	●	●	●	1, 50	Elec. Ident.
C70 Coupe	1999	Petrol	B5204T4	●	●	●	●	●	●	1, 93	Elec. Ident.
C70 Coupe	1999	Petrol	B5234T3	●	●	●	●	●	●	1, 50	Elec. Ident.
C70 Coupe	1999	Petrol	B5254S DENSO	●	●	●	○	●	●	88, 6, 89	Extend DTC;Elec. Ident.
C70 Coupe	1999	Petrol	B5254T	●	●	●	●	●	●	1, 93	Elec. Ident.
C70 Coupe	1999	Combined instrument	Combined instrument	●	●	●	○	●	●	72, 73, 37, 32	
C70 Coupe	1999	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
C70 Coupe	1999	RTI	RTI	●	●	●	○	●	●		
C70 Coupe	1999	TCM	AW50-42	●	●	●	○	●	●		
C70 Coupe	1999	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
C70 Coupe	1999	CCM	CCM	●	●	●	○	●	○		
C70 Coupe	1999	CPM	CPM	●	●	●	○	●	○		
C70 Coupe	1999	Power seat module, left	Power seat module, left	●	●	●	○	●	●		
C70 Coupe	1999	Power seat module, right	Power seat module,	●	●	●	○	●	●		
C70 Coupe	1999	SRS	SRS	●	●	●	○	●	○		
S40 (04-)	2009	TCM	MPS6	●	●	●	●	●	○		
S40 (04-)	2009	DEM	M66 AWD	●	●	●	●	●	○		
S40 (04-)	2009	ECM	D5244T9	●	●	●	●	●	●		
S40 (04-)	2009	ECM	D5244T8	●	●	●	●	●	●		
S40 (04-)	2009	ECM	D5244T13	●	●	●	●	●	●		
S40 (04-)	2009	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
S40 (04-)	2009	ADM	D4204T	●	●	●	●	●	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
 - This function is not supported.
 - ▲ This function is the new feature in this version.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
- As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (04-)	2009	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
S40 (04-)	2009	ADM	D4164T	●	●	●	●	●	○		
S40 (04-)	2009	ECM	D4164T	●	●	●	●	●	●	69, 141	
S40 (04-)	2009	ECM	B5254T7	●	●	●	●	●	●	74	
S40 (04-)	2009	ECM	B5244S7	●	●	●	●	●	●	9	
S40 (04-)	2009	ECM	B5244S5	●	●	●	●	●	●	9	
S40 (04-)	2009	ECM	B5244S4	●	●	●	●	●	●	9	
S40 (04-)	2009	ECM	B4204S3	●	●	●	●	●	●	9	
S40 (04-)	2009	ECM	B4184S8	●	●	●	●	●	●	9	
S40 (04-)	2009	ECM	B4184S11	●	●	●	●	●	●	9	
S40 (04-)	2009	ECM	B4164S3	●	●	●	●	●	●	9	
S40 (04-)	2009	TCM	AW55-50/51SN	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
S40 (04-)	2009	DEM	AW50/51 AWD	●	●	●	●	●	○		
S40 (04-)	2009	TCM	AW50/51 AWD	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
S40 (04-)	2009	PSM		●	●	●	●	●	●	145	
S40 (04-)	2009	AEM		●	●	●	●	●	●	146	
S40 (04-)	2009	KVM		●	●	●	●	●	●	147	
S40 (04-)	2009	RDAR		●	●	●	●	●	○		
S40 (04-)	2009	PHM		●	●	●	●	●	○		
S40 (04-)	2009	CPM		●	●	●	●	●	●		
S40 (04-)	2009	AUD		●	●	●	●	○	○		
S40 (04-)	2009	BPM		●	●	●	●	●	○		
S40 (04-)	2009	PAM		●	●	●	●	●	○		
S40 (04-)	2009	SRS		●	●	●	●	●	○	95	
S40 (04-)	2009	DDM		●	●	●	●	●	●	149, 150	
S40 (04-)	2009	PDM		●	●	●	●	●	●	149, 150	
S40 (04-)	2009	AUU		●	●	●	●	●	○		
S40 (04-)	2009	HCM		●	●	●	●	●	○	23	
S40 (04-)	2009	BCM		●	●	●	●	●	○	146, 111	
S40 (04-)	2009	CCM		●	●	●	●	○	○	30, 113, 152, 32, 153	
S40 (04-)	2009	SWM		●	●	●	●	●	○		
S40 (04-)	2009	TRM		●	●	●	●	●	○		
S40 (04-)	2009	EPS		●	●	●	●	●	○		
S40 (04-)	2009	IAM		●	●	●	●	●	●		
S40 (04-)	2009	CEM		●	●	●	●	●	●	154, 156, 94, 158, 159, 160, 35, 162, 95	
S40 (04-)	2009	DIM		●	●	●	●	●	●	48, 161, 118, 46, 165, 51	
S40 (04-)	2009	ICM		●	●	●	●	●	●	166, 167, 168	
S40 (04-)	2009	MMM		●	●	●	●	○	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (04-)	2008	TCM	MPS6	●	●	●	●	●	○		
S40 (04-)	2008	DEM	M66 AWD	●	●	●	●	●	○		
S40 (04-)	2008	ECM	D5244T9	●	●	●	●	●	●		
S40 (04-)	2008	ECM	D5244T8	●	●	●	●	●	●		
S40 (04-)	2008	ECM	D5244T13	●	●	●	●	●	●		
S40 (04-)	2008	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
S40 (04-)	2008	ADM	D4204T	●	●	●	●	●	○		
S40 (04-)	2008	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
S40 (04-)	2008	ADM	D4164T	●	●	●	●	●	○		
S40 (04-)	2008	ECM	D4164T	●	●	●	●	●	●	69, 141	
S40 (04-)	2008	ECM	B5254T7	●	●	●	●	●	●	74	
S40 (04-)	2008	ECM	B5254T3	●	●	●	●	●	●	74	
S40 (04-)	2008	ECM	B5244S7	●	●	●	●	●	●	9	
S40 (04-)	2008	ECM	B5244S5	●	●	●	●	●	●	9	
S40 (04-)	2008	ECM	B5244S4	●	●	●	●	●	●	9	
S40 (04-)	2008	ECM	B4204S3	●	●	●	●	●	●	9	
S40 (04-)	2008	ECM	B4184S8	●	●	●	●	●	●	9	
S40 (04-)	2008	ECM	B4184S11	●	●	●	●	●	●	9	
S40 (04-)	2008	ECM	B4164S3	●	●	●	●	●	●	9	
S40 (04-)	2008	TCM	AW55-50/51SN	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
S40 (04-)	2008	DEM	AW50/51 AWD	●	●	●	●	●	○		
S40 (04-)	2008	TCM	AW50/51 AWD	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
S40 (04-)	2008	BCM		●	●	●	●	●	○	146, 111	
S40 (04-)	2008	PSM		●	●	●	●	●	●	145	
S40 (04-)	2008	AEM		●	●	●	●	●	●	146	
S40 (04-)	2008	KVM		●	●	●	●	●	●	147	
S40 (04-)	2008	RDAR		●	●	●	●	●	○		
S40 (04-)	2008	CPM		●	●	●	●	●	●		
S40 (04-)	2008	AUD		●	●	●	●	○	○		
S40 (04-)	2008	PAM		●	●	●	●	●	○		
S40 (04-)	2008	SRS		●	●	●	●	●	○	95	
S40 (04-)	2008	DDM		●	●	●	●	●	●	149, 150	
S40 (04-)	2008	PDM		●	●	●	●	●	●	149, 150	
S40 (04-)	2008	AUU		●	●	●	●	●	○		
S40 (04-)	2008	HCM		●	●	●	●	●	○	23	
S40 (04-)	2008	CCM		●	●	●	●	●	○	30, 113, 152, 32, 153	
S40 (04-)	2008	PHM		●	●	●	●	●	○		
S40 (04-)	2008	CEM		●	●	●	●	●	●	154, 156, 94, 158, 159, 160, 35, 162, 95	

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (04-)	2008	DIM		●	●	●	●	●	●	48, 161, 118, 46, 165, 51	
S40 (04-)	2008	SWM		●	●	●	●	●	○		
S40 (04-)	2008	TRM		●	●	●	●	●	○		
S40 (04-)	2008	EPS		●	●	●	●	●	○		
S40 (04-)	2008	IAM		●	●	●	●	●	●		
S40 (04-)	2008	ICM		●	●	●	●	●	●	166, 167, 168	
S40 (04-)	2008	MMM		●	●	●	●	○	○		
S40 (04-)	2007	DEM	M66 AWD	●	●	●	●	●	○		
S40 (04-)	2007	ECM	D5244T9	●	●	●	●	●	●		
S40 (04-)	2007	ECM	D5244T8	●	●	●	●	●	●		
S40 (04-)	2007	ADM	D4204T	●	●	●	●	●	○		
S40 (04-)	2007	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
S40 (04-)	2007	ADM	D4164T	●	●	●	●	●	○		
S40 (04-)	2007	ECM	D4164T	●	●	●	●	●	●	69, 141, 169	
S40 (04-)	2007	ECM	B5254T3	●	●	●	●	●	●	74	
S40 (04-)	2007	ECM	B5244S7	●	●	●	●	●	●	9	
S40 (04-)	2007	ECM	B5244S5	●	●	●	●	●	●	9	
S40 (04-)	2007	ECM	B5244S4	●	●	●	●	●	●	9	
S40 (04-)	2007	ECM	B4204S3	●	●	●	●	●	●	9	
S40 (04-)	2007	ECM	B4184S8	●	●	●	●	●	●	9	
S40 (04-)	2007	ECM	B4184S11	●	●	●	●	●	●	9	
S40 (04-)	2007	ECM	B4164S3	●	●	●	●	●	●	9	
S40 (04-)	2007	TCM	AW55-50/51SN	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
S40 (04-)	2007	DEM	AW50/51 AWD	●	●	●	●	●	○		
S40 (04-)	2007	TCM	AW50/51 AWD	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
S40 (04-)	2007	GPS		●	●	●	●	●	○		
S40 (04-)	2007	BCM		●	●	●	●	●	○	146, 111	
S40 (04-)	2007	PSM		●	●	●	●	●	●	145	
S40 (04-)	2007	TMC		●	●	●	●	●	○		
S40 (04-)	2007	SWM		●	●	●	●	●	○		
S40 (04-)	2007	KVM		●	●	●	●	●	●	147	
S40 (04-)	2007	AEM		●	●	●	●	●	●	146	
S40 (04-)	2007	PHM		●	●	●	●	●	○		
S40 (04-)	2007	TRM		●	●	●	●	●	○		
S40 (04-)	2007	CEM		●	●	●	●	●	●	154, 156, 94, 158, 159, 160, 162, 95	
S40 (04-)	2007	MMM		●	●	●	●	○	○		
S40 (04-)	2007	RDAR		●	●	●	●	●	○		
S40 (04-)	2007	CPM		●	●	●	●	●	●		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (04-)	2007	IAM		●	●	●	●	●	●		
S40 (04-)	2007	AUD		●	●	●	●	○	○		
S40 (04-)	2007	PAM		●	●	●	●	●	○		
S40 (04-)	2007	DDM		●	●	●	●	●	●	149, 150	
S40 (04-)	2007	PDM		●	●	●	●	●	●	149, 150	
S40 (04-)	2007	SRS		●	●	●	●	●	○	95	
S40 (04-)	2007	CCM		●	●	●	●	●	○	30, 113, 152, 32, 153	
S40 (04-)	2007	DIM		●	●	●	●	●	●	48, 161, 118, 46, 165	
S40 (04-)	2007	ICM		●	●	●	●	●	●	166, 167	
S40 (04-)	2007	EPS		●	●	●	●	●	○		
S40 (04-)	2006	DEM	M66 AWD	●	●	●	●	●	○		
S40 (04-)	2006	ECM	D5244T8	●	●	●	●	●	●		
S40 (04-)	2006	ADM	D4204T2	●	●	●	●	●	○		
S40 (04-)	2006	ECM	D4204T2	●	●	●	●	●	●	71, 9, 141, 69	
S40 (04-)	2006	ADM	D4204T	●	●	●	●	●	○		
S40 (04-)	2006	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
S40 (04-)	2006	ADM	D4164T	●	●	●	●	●	○		
S40 (04-)	2006	ECM	D4164T	●	●	●	●	●	●	69, 141, 169	
S40 (04-)	2006	ECM	B5254T3	●	●	●	●	●	●	74	
S40 (04-)	2006	ECM	B5244S7	●	●	●	●	●	●	9	
S40 (04-)	2006	ECM	B5244S5	●	●	●	●	●	●	9	
S40 (04-)	2006	ECM	B5244S4	●	●	●	●	●	●	9	
S40 (04-)	2006	ECM	B4184S8	●	●	●	●	●	●	9	
S40 (04-)	2006	ECM	B4184S11	●	●	●	●	●	●	9	
S40 (04-)	2006	ECM	B4164S3	●	●	●	●	●	●	9	
S40 (04-)	2006	TCM	AW55-50/51SN	●	●	●	●	●	●	170, 111, 82, 140, 4, 100, 1	
S40 (04-)	2006	DEM	AW50/51 AWD	●	●	●	●	●	○		
S40 (04-)	2006	TCM	AW50/51 AWD	●	●	●	●	●	●	170, 111, 82, 140, 4, 100, 1	
S40 (04-)	2006	DIM		●	●	●	●	●	●	48, 161, 46, 165	
S40 (04-)	2006	GPS		●	●	●	●	●	○		
S40 (04-)	2006	DDM		●	●	●	●	●	●	149, 150	
S40 (04-)	2006	PDM		●	●	●	●	●	●	149, 150	
S40 (04-)	2006	BCM		●	●	●	●	●	○	146, 111	
S40 (04-)	2006	PSM		●	●	●	●	●	●	145	
S40 (04-)	2006	TMC		●	●	●	●	●	○		
S40 (04-)	2006	SWM		●	●	●	●	●	○		
S40 (04-)	2006	KVM		●	●	●	●	●	●	147	
S40 (04-)	2006	AEM		●	●	●	●	●	●	146	
S40 (04-)	2006	ICM		●	●	●	●	●	●	166	

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (04-)	2006	IAM		●	●	●	●	●	●		
S40 (04-)	2006	PHM		●	●	●	●	●	○		
S40 (04-)	2006	TRM		●	●	●	●	●	○		
S40 (04-)	2006	PAM		●	●	●	●	●	○		
S40 (04-)	2006	CEM		●	●	●	●	●	●	154, 156, 94, 158, 159, 160, 162, 95	
S40 (04-)	2006	MMM		●	●	●	●	○	○		
S40 (04-)	2006	CPM		●	●	●	●	●	●		
S40 (04-)	2006	CCM		●	●	●	●	●	○	30, 113, 152, 32, 153	
S40 (04-)	2006	AUD		●	●	●	●	○	○		
S40 (04-)	2006	SRS		●	●	●	●	●	○	95	
S40 (04-)	2006	EPS		●	●	●	●	●	○		
S40 (-04)	2004	Petrol	B4164S2	●	●	●	○	●	●	113, 1	
S40 (-04)	2004	Petrol	B4184S10	●	●	●	○	●	●	113, 1	
S40 (-04)	2004	Petrol	B4184S2	●	●	●	○	●	●	113, 1	
S40 (-04)	2004	Petrol	B4184S3	●	●	●	○	●	●	113, 1	
S40 (-04)	2004	Petrol	B4184S9	●	●	●	○	●	●	113, 1	
S40 (-04)	2004	Petrol	B4184SJ	●	●	●	○	●	●	117	
S40 (-04)	2004	Petrol	B4204S2	●	●	●	○	●	●	113, 1	
S40 (-04)	2004	Petrol	B4204T3	●	●	●	○	●	●	118, 1	
S40 (-04)	2004	Diesel	D4192T3 (Anti-spin	●	●	●	○	●	○		
S40 (-04)	2004	Diesel	D4192T4 (Anti-spin	●	●	●	○	●	○		
S40 (-04)	2004	Anti-spin system	Anti-spin system	●	●	●	○	●	○		
S40 (-04)	2004	DIM	DIM	●	●	●	○	●	●	121, 122, 81, 125, 126	
S40 (-04)	2004	Gas discharge light	Gas discharge light	●	●	●	○	●	●		
S40 (-04)	2004	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
S40 (-04)	2004	TCM	AW55-50/51SN	●	●	●	○	●	●	130, 131	
S40 (-04)	2004	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
S40 (-04)	2004	CCM	CCM	●	●	●	○	●	○	132, 133, 81	
S40 (-04)	2004	CPM	CPM	●	●	●	○	●	○	21	
S40 (-04)	2004	SRS	SRS	●	●	●	○	●	○		
S40 (-04)	2003	Petrol	B4164S2	●	●	●	○	●	●	113, 1	
S40 (-04)	2003	Petrol	B4184S10	●	●	●	○	●	●	113, 1	
S40 (-04)	2003	Petrol	B4184S2	●	●	●	○	●	●	113, 1	
S40 (-04)	2003	Petrol	B4184S3	●	●	●	○	●	●	113, 1	
S40 (-04)	2003	Petrol	B4184S9	●	●	●	○	●	●	113, 1	
S40 (-04)	2003	Petrol	B4184SJ	●	●	●	○	●	●	117	
S40 (-04)	2003	Petrol	B4204S2	●	●	●	○	●	●	113, 1	
S40 (-04)	2003	Petrol	B4204T3	●	●	●	○	●	●	118, 1	

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
 - This function is not supported.
 - ▲ This function is the new feature in this version.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
- As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40(-04)	2003	Petrol	B4204T5	●	●	●	○	●	●	118, 1	
S40(-04)	2003	Diesel	D4192T3(Anti-spin	●	●	●	○	●	○		
S40(-04)	2003	Diesel	D4192T4(Anti-spin	●	●	●	○	●	○		
S40(-04)	2003	Anti-spin system	Anti-spin system	●	●	●	○	●	○		
S40(-04)	2003	DIM	DIM	●	●	●	○	●	●	121, 122, 81, 125, 126	
S40(-04)	2003	Gas discharge light	Gas discharge light	●	●	●	○	●	●		
S40(-04)	2003	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
S40(-04)	2003	TCM	AW55-50/51SN	●	●	●	○	●	●	130, 131	
S40(-04)	2003	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
S40(-04)	2003	CCM	CCM	●	●	●	○	●	●	132, 133, 81	
S40(-04)	2003	CPM	CPM	●	●	●	○	●	○	21	
S40(-04)	2003	SRS	SRS	●	●	●	○	●	○		
S40(-04)	2002	Petrol	B4164S2	●	●	●	○	●	●	113, 1	
S40(-04)	2002	Petrol	B4184S10	●	●	●	○	●	●	113, 1	
S40(-04)	2002	Petrol	B4184S2	●	●	●	○	●	●	113, 1	
S40(-04)	2002	Petrol	B4184S3	●	●	●	○	●	●	113, 1	
S40(-04)	2002	Petrol	B4184S9	●	●	●	○	●	●	113, 1	
S40(-04)	2002	Petrol	B4184SJ	●	●	●	○	●	●	117	
S40(-04)	2002	Petrol	B4204S2	●	●	●	○	●	●	113, 1	
S40(-04)	2002	Petrol	B4204T3	●	●	●	○	●	●	118, 1	
S40(-04)	2002	Petrol	B4204T5	●	●	●	○	●	●	118, 1	
S40(-04)	2002	Diesel	D4192T3(Anti-spin	●	●	●	○	●	○		
S40(-04)	2002	Diesel	D4192T4(Anti-spin	●	●	●	○	●	○		
S40(-04)	2002	Anti-spin system	Anti-spin system	●	●	●	○	●	○		
S40(-04)	2002	DIM	DIM	●	●	●	○	●	●	121, 122, 81, 125, 126	
S40(-04)	2002	Gas discharge light	Gas discharge light	●	●	●	○	●	●		
S40(-04)	2002	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
S40(-04)	2002	TCM	AW55-50/51SN	●	●	●	○	●	●	130, 131	
S40(-04)	2002	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
S40(-04)	2002	CCM	CCM	●	●	●	○	●	●	132, 133, 81	
S40(-04)	2002	CPM	CPM	●	●	●	○	●	○	21	
S40(-04)	2002	SRS	SRS	●	●	●	○	●	○		
S40(-04)	2001	Petrol	B4164S2	●	●	●	○	●	●	113, 1	
S40(-04)	2001	Petrol	B4184S10	●	●	●	○	●	●	113, 1	
S40(-04)	2001	Petrol	B4184S2	●	●	●	○	●	●	113, 1	
S40(-04)	2001	Petrol	B4184S3	●	●	●	○	●	●	113, 1	
S40(-04)	2001	Petrol	B4184S9	●	●	●	○	●	●	113, 1	
S40(-04)	2001	Petrol	B4184SJ	●	●	●	○	●	●	117	
S40(-04)	2001	Petrol	B4184SM	●	●	●	○	●	●	134, 135	

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
 - This function is not supported.
 - ▲ This function is the new feature in this version.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
- As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40(-04)	2001	Petrol	B4204S2	●	●	●	○	●	●	113, 1	
S40(-04)	2001	Petrol	B4204T3	●	●	●	○	●	●	118, 1	
S40(-04)	2001	Petrol	B4204T5	●	●	●	○	●	●	118, 1	
S40(-04)	2001	Diesel	D4192T3(Anti-spin	●	●	●	○	●	○		
S40(-04)	2001	Diesel	D4192T4(Anti-spin	●	●	●	○	●	○		
S40(-04)	2001	Anti-spin system	Anti-spin system	●	●	●	○	●	○		
S40(-04)	2001	DIM	DIM	●	●	●	○	●	●	121, 122, 81, 125, 126	
S40(-04)	2001	Gas discharge light	Gas discharge light	●	●	●	○	●	●		
S40(-04)	2001	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
S40(-04)	2001	TCM	AW55-50/51SN	●	●	●	○	●	●	130, 131	
S40(-04)	2001	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
S40(-04)	2001	CCM	CCM	●	●	●	○	●	●	132, 133, 81	
S40(-04)	2001	CPM	CPM	●	●	●	○	●	○	21	
S40(-04)	2001	SRS	SRS	●	●	●	○	●	○		
S40(-04)	2000	Petrol	B4164S2	●	●	●	○	●	●		
S40(-04)	2000	Petrol	B4184S2	●	●	●	○	●	●		
S40(-04)	2000	Petrol	B4184S3	●	●	●	○	●	●		
S40(-04)	2000	Petrol	B4184SM	●	●	●	○	●	●	134, 135	
S40(-04)	2000	Petrol	B4194T2	●	●	●	○	●	●		
S40(-04)	2000	Petrol	B4204S2	●	●	●	○	●	●		
S40(-04)	2000	Petrol	B4204T2	●	●	●	○	●	●		
S40(-04)	2000	Diesel	D4192T2(Anti-spin	●	●	●	○	●	○		
S40(-04)	2000	Anti-spin system	Anti-spin system	●	●	●	○	●	○		
S40(-04)	2000	DIM	DIM	●	●	●	○	●	●	121, 122, 81, 125, 126	
S40(-04)	2000	Lock and alarm	Lock and alarm	●	●	●	○	●	○	80, 81, 40	
S40(-04)	2000	TCM	AW50-42	●	●	●	○	●	●		
S40(-04)	2000	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
S40(-04)	2000	CCM	CCM	●	●	●	○	●	○		
S40(-04)	2000	CPM	CPM	●	●	●	○	●	○	21	
S40(-04)	2000	SRS	SRS	●	●	●	○	○	○		
S40(-04)	1999	Petrol	B4164S(Anti-spin	●	●	●	○	●	○		
S40(-04)	1999	Petrol	B4184S(Anti-spin	●	●	●	○	●	○		
S40(-04)	1999	Petrol	B4184SM	●	●	●	○	●	●	134, 135	
S40(-04)	1999	Petrol	B4194T	●	●	●	○	●	●	113	
S40(-04)	1999	Petrol	B4204S(Anti-spin	●	●	●	○	●	○		
S40(-04)	1999	Petrol	B4204T	●	●	●	○	●	●	113	
S40(-04)	1999	Diesel	D4192T(Anti-spin	●	●	●	○	●	○		
S40(-04)	1999	Diesel	D4192T2(Anti-spin	●	●	●	○	●	○		
S40(-04)	1999	Anti-spin system	Anti-spin system	●	●	●	○	●	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
 - This function is not supported.
 - ▲ This function is the new feature in this version.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
- As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40(-04)	1999	DIM	DIM	●	●	●	○	●	●	125, 126	
S40(-04)	1999	Lock and alarm	Lock and alarm	●	●	●	○	●	●	139	
S40(-04)	1999	TCM	AW50-42	●	●	●	○	●	●		
S40(-04)	1999	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
S40(-04)	1999	CCM	CCM	●	●	●	○	●	○		
S40(-04)	1999	CPM	CPM	●	●	●	○	●	○	21	
S40(-04)	1999	SRS	SRS	●	●	●	○	○	○		
S40(04-)	2005	CEM	CEM	●	●	●	●	●	●	110, 27, 29, 31	
S40(04-)	2005	Petrol	B4164S3	●	●	●	●	●	●		
S40(04-)	2005	Petrol	B4184S11	●	●	●	●	●	●		
S40(04-)	2005	Petrol	B5244S4	●	●	●	●	●	●	88, 6, 95	
S40(04-)	2005	Petrol	B5244S5	●	●	●	●	●	●	88, 6, 95	
S40(04-)	2005	Petrol	B5254T3	●	●	●	●	●	●	1, 2, 3, 4, 5, 6	
S40(04-)	2005	Diesel	D4164T	●	●	●	○	●	●	96, 97, 98, 99	
S40(04-)	2005	Diesel	D4204T	●	●	●	●	●	●	96, 100, 99, 97	
S40(04-)	2005	Diesel	D4204T2	●	●	●	●	●	●	96, 100, 99, 97	
S40(04-)	2005	AFM	AFM	●	●	●	●	●	○		
S40(04-)	2005	AEM	AEM	●	●	●	●	●	●		
S40(04-)	2005	AUD	AUD	●	●	●	●	○	○		
S40(04-)	2005	DEM	DEM	●	●	●	●	●	○		
S40(04-)	2005	DIM	DIM	●	●	●	●	●	●	103, 35, 37, 104	
S40(04-)	2005	ICM	ICM	●	●	●	●	●	●		
S40(04-)	2005	IAM	IAM	●	●	●	●	●	●		
S40(04-)	2005	KVM	KVM	●	●	●	●	●	●		
S40(04-)	2005	MPM	MPM	●	●	●	●	●	●		
S40(04-)	2005	MMM	MMM	●	●	●	●	●	●		
S40(04-)	2005	PAM	PAM	●	●	●	●	●	○		
S40(04-)	2005	PHM	PHM	●	●	●	●	●	○		
S40(04-)	2005	SWM	SWM	●	●	●	○	●	○		
S40(04-)	2005	SUB	SUB	●	●	●	●	○	○		
S40(04-)	2005	TMC	TMC	●	●	●	●	●	○		
S40(04-)	2005	TCM	AW50/51AWD	●	●	●	●	●	●		
S40(04-)	2005	TCM	AW55-50/51SN	●	●	●	●	●	●		
S40(04-)	2005	ABS/BCM	ABS/BCM	●	●	●	●	●	●		
S40(04-)	2005	EPS	EPS	●	●	●	○	●	○		
S40(04-)	2005	CCM	CCM	●	●	●	●	●	○	44	
S40(04-)	2005	DDM	DDM	●	●	●	○	●	●	46	
S40(04-)	2005	PDM	PDM	●	●	●	○	●	●	46	
S40(04-)	2005	PSM	PSM	●	●	●	●	●	●	109	

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40 (04-)	2005	SRS	SRS	●	●	●	●	●	○		
S40 (04-)	2005	TRM	TRM	●	●	●	●	●	○		
S40 (04-)	2005	GPS	GPS	●	●	●	●	●	○		
S40 (04-)	2004	CEM	CEM	●	●	●	○	●	●	110, 27	
S40 (04-)	2004	EPS	EPS	●	●	●	○	●	○		
S40 (04-)	2004	Petrol	B5244S4	●	●	●	●	●	●	88, 6, 95	
S40 (04-)	2004	Petrol	B5244S5	●	●	●	●	●	●	88, 6, 95	
S40 (04-)	2004	Petrol	B5254T3	●	●	●	●	●	●	1, 2, 3, 4, 5, 6	
S40 (04-)	2004	Diesel	D4204T	●	●	●	●	●	●	96, 100, 97	
S40 (04-)	2004	Diesel	D4204T2	●	●	●	●	●	●	96, 100, 97	
S40 (04-)	2004	AFM	AFM	●	●	●	●	●	○		
S40 (04-)	2004	AEM	AEM	●	●	●	●	●	●		
S40 (04-)	2004	AUD	AUD	●	●	●	●	○	○		
S40 (04-)	2004	DIM	DIM	●	●	●	●	●	●	103, 35, 37, 104	
S40 (04-)	2004	ICM	ICM	●	●	●	●	●	●		
S40 (04-)	2004	MPM	MPM	●	●	●	●	●	●		
S40 (04-)	2004	MMM	MMM	●	●	●	●	●	●		
S40 (04-)	2004	PHM	PHM	●	●	●	●	●	○		
S40 (04-)	2004	SWM	SWM	●	●	●	○	●	○		
S40 (04-)	2004	SUB	SUB	●	●	●	●	○	○		
S40 (04-)	2004	TMC	TMC	●	●	●	●	●	○		
S40 (04-)	2004	TCM	AW55-50/51SN	●	●	●	●	●	●		
S40 (04-)	2004	ABS/BCM	ABS/BCM	●	●	●	●	●	●		
S40 (04-)	2004	CCM	CCM	●	●	●	●	●	○	44	
S40 (04-)	2004	DDM	DDM	●	●	●	○	●	●	46, 109	
S40 (04-)	2004	PDM	PDM	●	●	●	○	●	●	46	
S40 (04-)	2004	PSM	PSM	●	●	●	●	●	●	109	
S40 (04-)	2004	SRS	SRS	●	●	●	●	●	○		
S40 (04-)	2004	TRM	TRM	●	●	●	●	●	○		
S40 (04-)	2004	GPS	GPS	●	●	●	●	●	○		
S60	2005	CEM	CEM	●	●	●	●	●	●	27, 28, 150, 151, 29, 30, 31, 32	
S60	2005	Petrol	B5204T5	●	●	●	●	●	●	2, 3, 4, 5	
S60	2005	Petrol	B5244S	●	●	●	●	●	●	88, 6	
S60	2005	Petrol	B5244S2	●	●	●	●	●	●		
S60	2005	Petrol	B5244SG	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60	2005	Petrol	B5244SG2	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC
S60	2005	Petrol	B5244T4	●	●	●	●	●	●	1, 2, 3, 4, 5	
S60	2005	Petrol	B5244T5	●	●	●	●	●	●	1, 2, 3, 4, 5, 6	
S60	2005	Petrol	B5254T2	●	●	●	●	●	●	1, 2, 3, 4, 5, 6	
S60	2005	Petrol	B5254T4	●	●	●	●	●	●	1, 2, 3, 4, 5, 6	
S60	2005	Diesel	D5244T	●	●	●	○	●	●	7	
S60	2005	Diesel	D5244T2	●	●	●	○	●	●	7	
S60	2005	Diesel	D5244T3	●	●	●	○	●	●	7	
S60	2005	AEM	AEM	●	●	●	●	●	●		
S60	2005	AUM	AUM	●	●	●	●	●	○		
S60	2005	DIM	DIM	●	●	●	●	●	●	33, 35, 36, 37	
S60	2005	PHM	PHM	●	●	●	●	●	○		
S60	2005	REM	REM	●	●	●	●	●	●	39, 40	
S60	2005	RTI	RTI	●	●	●	●	○	○		
S60	2005	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24, 25	
S60	2005	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
S60	2005	TCM	AW55-50/51SN	●	●	●	●	●	●	10, 11	
S60	2005	ABS/BCM	ABS/BCM	●	●	●	●	●	●	62, 63	
S60	2005	SAS	SAS	●	●	●	●	●	○		
S60	2005	SUM	SUM	●	●	●	●	●	○		
S60	2005	CCM	CCM	●	●	●	●	●	○	43, 44	
S60	2005	DDM	DDM	●	●	●	●	●	●	46, 47, 48	
S60	2005	PDM	PDM	●	●	●	●	●	●	46, 47	
S60	2005	PSM	PSM	●	●	●	●	●	●	48	
S60	2005	SRS	SRS	●	●	●	●	●	○		
S60	2005	DEM	DEM	●	●	●	●	●	○		
S60	2005	DEM	DEM	●	●	●	●	●	○		
S60	2004	CEM	CEM	●	●	●	●	●	●	27, 51, 40, 30, 32	
S60	2004	Petrol	B5204T5	●	●	●	●	●	●	1, 2, 3, 4, 50	
S60	2004	Petrol	B5234T3	●	●	●	●	●	●	1, 2, 3, 4, 50	
S60	2004	Petrol	B5234T7	●	●	●	●	●	●	1, 2, 3, 4, 50	
S60	2004	Petrol	B5244S	●	●	●	●	●	●	88, 6	
S60	2004	Petrol	B5244S2	●	●	●	●	●	●	6	
S60	2004	Petrol	B5244SG	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60	2004	Petrol	B5244SG2	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC
S60	2004	Petrol	B5254T2	●	●	●	●	●	●	1, 2, 3, 4, 50	
S60	2004	Petrol	B5254T4	●	●	●	●	●	●	1, 2, 3, 4, 5, 50	
S60	2004	Diesel	D5244T	●	●	●	○	●	●	7	
S60	2004	Diesel	D5244T2	●	●	●	○	●	●	7	
S60	2004	AEM	AEM	●	●	●	●	●	●		
S60	2004	AUM	AUM	●	●	●	●	●	○		
S60	2004	DIM	DIM	●	●	●	●	●	●	33, 35, 53, 37	
S60	2004	PHM	PHM	●	●	●	●	●	○		
S60	2004	REM	REM	●	●	●	●	●	●	55	
S60	2004	RTI	RTI	●	●	●	●	○	○		
S60	2004	SWM	SWM	●	●	●	●	●	○		
S60	2004	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24	
S60	2004	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
S60	2004	TCM	AW55-50/51SN	●	●	●	●	●	●	10, 11	
S60	2004	DEM	DEM	●	●	●	○	●	○		
S60	2004	DEM	DEM	●	●	●	○	●	○		
S60	2004	ABS/BCM	ABS/BCM	●	●	●	●	●	●	62, 63	
S60	2004	SAS	SAS	●	●	●	○	●	○		
S60	2004	SUM	SUM	●	●	●	●	●	○		
S60	2004	CCM	CCM	●	●	●	●	●	○	41, 56, 56, 58	
S60	2004	DDM	DDM	●	●	●	●	●	●	47, 48, 59	
S60	2004	PDM	PDM	●	●	●	●	●	●	47, 59	
S60	2004	PSM	PSM	●	●	●	●	●	●	48, 60	
S60	2004	SRS	SRS	●	●	●	●	●	○		
S60	2003	CEM	CEM	●	●	●	●	●	●	27, 51, 40, 30, 32	
S60	2003	Petrol	B5204T5	●	●	●	●	●	●	1, 2, 3, 4, 50	
S60	2003	Petrol	B5234T3	●	●	●	●	●	●	1, 2, 3, 4, 50	
S60	2003	Petrol	B5234T7	●	●	●	●	●	●	1, 2, 3, 4, 50	
S60	2003	Petrol	B5244S	●	●	●	●	●	●	88, 6	
S60	2003	Petrol	B5244S2	●	●	●	●	●	●		
S60	2003	Petrol	B5244SG	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC
S60	2003	Petrol	B5244SG2	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC

As for special function please refer to the special function table.

[illegible]

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60	2001	TCM	AW55-50/51SN	●	●	●	●	●	●	10, 11	
S60	2001	ABS/BCM	ABS/BCM	●	●	●	●	●	●		
S60	2001	SAS	SAS	●	●	●	○	●	○		
S60	2001	CCM	CCM	●	●	●	●	●	○	41, 56, 56, 58	
S60	2001	DDM	DDM	●	●	●	●	●	●	47, 59	
S60	2001	PDM	PDM	●	●	●	●	●	●	47, 59	
S60	2001	PSM	PSM	●	●	●	●	●	●	48, 60	
S60	2001	SRS	SRS	●	●	●	●	●	○		
S60	2009	TCM	TF-80SC	●	●	●	●	●	●	81, 82, 83, 84, 85	
S60	2009	DEM	M66 AWD	●	●	●	●	●	○		
S60	2009	DEM	M58	●	●	●	●	●	○		
S60	2009	ECM	D5244T7	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
S60	2009	ECM	D5244T5	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
S60	2009	ECM	D5244T4	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
S60	2009	ECM	B5254T2	●	●	●	●	●	●	74	
S60	2009	ECM	B5244T5	●	●	●	●	●	●	74	
S60	2009	ECM	B5244S2	●	●	●	●	●	●		
S60	2009	ECM	B5244S	●	●	●	●	●	●		
S60	2009	ECM	B5204T5	●	●	●	●	●	●	74	
S60	2009	TCM	AW55-50/51SN	●	●	●	●	●	●	100, 101, 102, 103, 125	
S60	2009	DEM	AW50/51 AWD	●	●	●	●	●	○		
S60	2009	TCM	AW50/51 AWD	●	●	●	●	●	●	100, 101, 102, 103, 125	
S60	2009	AUM		●	●	●	●	●	○		
S60	2009	BCM		●	●	●	●	●	●	86, 87	
S60	2009	SRS		●	●	●	●	●	○	95	
S60	2009	PSM		●	●	●	●	●	●	107	
S60	2009	DDM		●	●	●	●	●	●	107, 108	
S60	2009	PDM		●	●	●	●	●	●	108	
S60	2009	SUM		●	●	●	●	●	●		
S60	2009	AEM		●	●	●	●	●	●		
S60	2009	REM		●	●	●	●	●	●		
S60	2009	CPM		●	○	○	○	●	○	111, 112	
S60	2009	RTI		●	●	●	●	○	○		
S60	2009	SAS		●	●	●	●	●	○		
S60	2009	HCM		●	●	●	●	●	○		
S60	2009	CCM		●	●	●	●	●	○	30, 113, 114, 29, 32, 115	
S60	2009	DIM		●	●	●	●	●	●	116, 117, 28, 46, 47, 118	
S60	2009	UEM		●	●	●	●	●	●		
S60	2009	PHM		●	●	●	●	●	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60	2009	CEM		●	●	●	●	●	●	91, 92, 94, 95, 96	
S60	2008	TCM	TF-80SC	●	●	●	●	●	●	81, 82, 83, 84, 85	
S60	2008	DEM	M66 AWD	●	●	●	●	●	○		
S60	2008	DEM	M58	●	●	●	●	●	○		
S60	2008	ECM	D5244T7	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
S60	2008	ECM	D5244T5	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
S60	2008	ECM	D5244T4	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
S60	2008	ECM	B5254T2	●	●	●	●	●	●	74	
S60	2008	ECM	B5244T5	●	●	●	●	●	●	74	
S60	2008	ETM	B5244SG	●	○	○	○	●	○		
S60	2008	ECM	B5244SG	●	●	●	●	●	●		
S60	2008	ECM	B5244S2	●	●	●	●	●	●		
S60	2008	ECM	B5244S	●	●	●	●	●	●		
S60	2008	ECM	B5204T5	●	●	●	●	●	●	74	
S60	2008	TCM	AW55-50/51SN	●	●	●	●	●	●	100, 101, 102, 103, 125	
S60	2008	DEM	AW50/51 AWD	●	●	●	●	●	○		
S60	2008	TCM	AW50/51 AWD	●	●	●	●	●	●	100, 101, 102, 103, 125	
S60	2008	AUM		●	●	●	●	●	○		
S60	2008	BCM		●	●	●	●	●	●	86, 87	
S60	2008	SRS		●	●	●	●	●	○	95	
S60	2008	PSM		●	●	●	●	●	●	107	
S60	2008	DDM		●	●	●	●	●	●	107, 108	
S60	2008	PDM		●	●	●	●	●	●	108	
S60	2008	SUM		●	●	●	●	●	●		
S60	2008	AEM		●	●	●	●	●	●		
S60	2008	PHM		●	●	●	●	●	○		
S60	2008	REM		●	●	●	●	●	●		
S60	2008	CPM		●	○	○	○	●	○	111, 112	
S60	2008	CEM		●	●	●	●	●	●	91, 92, 94, 95, 96	
S60	2008	HCM		●	●	●	●	●	○		
S60	2008	RTI		●	●	●	●	○	○		
S60	2008	SAS		●	●	●	●	●	○		
S60	2008	CCM		●	●	●	●	●	○	30, 113, 114, 29, 32, 115	
S60	2008	DIM		●	●	●	●	●	●	116, 117, 28, 46, 47, 118	
S60	2008	UEM		●	●	●	●	●	●		
S60	2007	DEM	TF-80SC AWD	●	●	●	●	●	○		
S60	2007	DEM	M66 AWD	●	●	●	●	●	○		
S60	2007	DEM	M58	●	●	●	●	●	○		
S60	2007	ECM	D5244T7	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60	2007	TCM	TF-80SC	●	●	●	●	●	●	81, 82, 83, 84, 85	
S60	2007	ECM	D5244T5	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
S60	2007	TCM	TF-80SC	●	●	●	●	●	●	81, 82, 83, 84, 85	
S60	2007	ECM	D5244T4	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
S60	2007	TCM	TF-80SC AWD	●	●	●	●	●	●	81, 82, 83, 84, 85	
S60	2007	ECM	B5254T4	●	●	●	●	●	●	74	
S60	2007	ECM	B5254T2	●	●	●	●	●	●	74	
S60	2007	ECM	B5244T5	●	●	●	●	●	●	74	
S60	2007	ETM	B5244SG	●	○	○	○	●	○		
S60	2007	ECM	B5244SG	●	●	●	●	●	●		
S60	2007	ECM	B5244S2	●	●	●	●	●	●		
S60	2007	ECM	B5244S	●	●	●	●	●	●		
S60	2007	ECM	B5204T5	●	●	●	●	●	●	74	
S60	2007	TCM	AW55-50/51SN	●	●	●	●	●	●	100, 101, 102, 103, 125	
S60	2007	DEM	AW50/51 AWD	●	●	●	●	●	○		
S60	2007	TCM	AW50/51 AWD	●	●	●	●	●	●	100, 101, 102, 103, 125	
S60	2007	AUM		●	●	●	●	●	○		
S60	2007	BCM		●	●	●	●	●	●	86, 87	
S60	2007	SRS		●	●	●	●	●	○	95	
S60	2007	PSM		●	●	●	●	●	●	107	
S60	2007	DDM		●	●	●	●	●	●	107, 108	
S60	2007	PDM		●	●	●	●	●	●	108	
S60	2007	SUM		●	●	●	●	●	●		
S60	2007	AEM		●	●	●	●	●	●		
S60	2007	PHM		●	●	●	●	●	○		
S60	2007	REM		●	●	●	●	●	●		
S60	2007	CPM		●	○	○	○	●	○	111, 112	
S60	2007	CEM		●	●	●	●	●	●	91, 92, 94, 95, 96	
S60	2007	HCM		●	●	●	●	●	○		
S60	2007	CCM		●	●	●	●	●	○	30, 113, 114, 29, 32, 115	
S60	2007	RTI		●	●	●	●	○	○		
S60	2007	SAS		●	●	●	●	●	○		
S60	2007	DIM		●	●	●	●	●	●	116, 117, 28, 46, 47	
S60	2007	UEM		●	●	●	●	●	●		
S60	2006	DEM	TF-80SC AWD	●	●	●	●	●	○		
S60	2006	DEM	M66 AWD	●	●	●	●	●	○		
S60	2006	DEM	M58	●	●	●	●	●	○		
S60	2006	ECM	D5244T7	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
S60	2006	ECM	D5244T6	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S60	2006	TCM	TF-80SC	●	●	●	●	●	●	81, 82, 83, 84, 85	
S60	2006	ECM	D5244T5	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
S60	2006	TCM	TF-80SC	●	●	●	●	●	●	81, 82, 83, 84, 85	
S60	2006	ECM	D5244T4	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
S60	2006	ECM	D5244T2	●	●	●	●	●	●		
S60	2006	ECM	D5244T	●	●	●	●	●	●		
S60	2006	TCM	TF-80SC AWD	●	●	●	●	●	●	81, 82, 83, 84, 85	
S60	2006	ECM	B5254T4	●	●	●	●	●	●	74	
S60	2006	ECM	B5254T2	●	●	●	●	●	●	74	
S60	2006	ECM	B5244T5	●	●	●	●	●	●	74	
S60	2006	ECM	B5244T4	●	●	●	●	●	●	74	
S60	2006	ETM	B5244SG	●	○	○	○	●	○		
S60	2006	ECM	B5244SG	●	●	●	●	●	●		
S60	2006	ECM	B5244S6	●	●	●	●	●	●		
S60	2006	ECM	B5244S2	●	●	●	●	●	●		
S60	2006	ECM	B5244S	●	●	●	●	●	●		
S60	2006	ECM	B5204T5	●	●	●	●	●	●	74	
S60	2006	TCM	AW55-50/51SN	●	●	●	●	●	●	100, 101, 102, 103, 125	
S60	2006	DEM	AW50/51 AWD	●	●	●	●	●	○		
S60	2006	TCM	AW50/51 AWD	●	●	●	●	●	●	100, 101, 102, 103, 125	
S60	2006	REM		●	●	●	●	●	●		
S60	2006	AUM		●	●	●	●	●	○		
S60	2006	BCM		●	●	●	●	●	●	86, 87	
S60	2006	SRS		●	●	●	●	●	○	95	
S60	2006	PSM		●	●	●	●	●	●	107	
S60	2006	DDM		●	●	●	●	●	●	107, 108	
S60	2006	PDM		●	●	●	●	●	●	108	
S60	2006	SUM		●	●	●	●	●	●		
S60	2006	AEM		●	●	●	●	●	●		
S60	2006	PHM		●	●	●	●	●	○		
S60	2006	DIM		●	●	●	●	●	●	116, 117, 28, 46, 47	
S60	2006	CPM		●	○	○	○	●	○	111, 112	
S60	2006	UEM		●	●	●	●	●	●	119, 120, 128, 122, 123, 12	
S60	2006	CEM		●	●	●	●	●	●	91, 92, 94, 95	
S60	2006	CCM		●	●	●	●	●	○	30, 113, 114, 29, 32, 115	
S60	2006	RTI		●	●	●	●	○	○		
S60	2006	SAS		●	●	●	●	●	○		
S70	2000	Petrol	B5204T3	●	●	●	●	●	●	1, 50	Elec. Ident.
S70	2000	Petrol	B5204T4	●	●	●	●	●	●	1, 50	Elec. Ident.

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
 - This function is not supported.
 - ▲ This function is the new feature in this version.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
- As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S70	2000	Petrol	B5234T3	●	●	●	●	●	●	1, 50	Elec. Ident.
S70	2000	Petrol	B5234T7	●	●	●	●	●	●	1, 50	Elec. Ident.
S70	2000	Petrol	B5244S	●	●	●	○	●	●	88, 6, 89	Extend DTC; Elec. Ident.
S70	2000	Petrol	B5244S2	●	●	●	○	●	●	88, 6, 89	Extend DTC; Elec. Ident.
S70	2000	Petrol	B5244SG	●	●	●	○	●	○		Elec. Ident.
S70	2000	Petrol	B5244SG2	●	●	●	○	●	○		Elec. Ident.
S70	2000	Petrol	B5244T	●	●	●	●	●	●	1, 50	Elec. Ident.
S70	2000	Diesel	D5252T MSA 15.8	●	○	○	○	●	●	91, 92	
S70	2000	Combined instrument	Combined instrument	●	●	●	○	●	●	72, 73, 37, 32	
S70	2000	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
S70	2000	RTI	RTI	●	●	●	○	●	●		
S70	2000	TCM	AW42AWD	●	●	●	○	●	●	10, 11	
S70	2000	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
S70	2000	TCM	AW50-42	●	●	●	○	●	●	10, 11	
S70	2000	TCM	AW55-50/51SN	●	●	●	●	●	●	10, 11	
S70	2000	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
S70	2000	CCM	CCM	●	●	●	○	●	○		
S70	2000	CPM	CPM	●	●	●	○	●	○		
S70	2000	Power seat module, left	Power seat module, left	●	●	●	○	●	●		
S70	2000	Power seat module, right	Power seat module,	●	●	●	○	●	●		
S70	2000	SRS	SRS	●	●	●	○	●	○		
S70	1999	Petrol	B5204T3	●	●	●	●	●	●	1, 50	Elec. Ident.
S70	1999	Petrol	B5204T4	●	●	●	●	●	●	1, 93	Elec. Ident.
S70	1999	Petrol	B5234T3	●	●	●	●	●	●	1, 93	Elec. Ident.
S70	1999	Petrol	B5234T7	●	●	●	●	●	●	1, 93	Elec. Ident.
S70	1999	Petrol	B5254S DENSO	●	●	●	○	●	●	88, 6, 89	Extend DTC; Elec. Ident.
S70	1999	Petrol	B5254T	●	●	●	●	●	●	1, 93	Elec. Ident.
S70	1999	Diesel	D5252T MSA 15.8	●	○	○	○	●	●	91, 92	
S70	1999	Combined instrument	Combined instrument	●	●	●	○	●	●	72, 73, 37, 32	
S70	1999	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
S70	1999	RTI	RTI	●	●	●	○	●	●		
S70	1999	TCM	AW42AWD	●	●	●	○	●	●	10, 11	
S70	1999	TCM	AW50-42	●	●	●	○	●	●		
S70	1999	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
S70	1999	CCM	CCM	●	●	●	○	●	○		
S70	1999	CPM	CPM	●	●	●	○	●	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S70	1999	Power seat module, left	Power seat module, left	●	●	●	○	●	●		
S70	1999	Power seat module, right	Power seat module,	●	●	●	○	●	●		
S70	1999	SRS	SRS	●	●	●	○	●	○		
S80	2005	Petrol	B5204T5	●	●	●	●	●	●	2, 3, 4, 5	
S80	2005	Petrol	B5244S	●	●	●	●	●	●	88, 6	
S80	2005	Petrol	B5244S2	●	●	●	●	●	●		
S80	2005	Petrol	B5244SG	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC
S80	2005	Petrol	B5244SG2	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC
S80	2005	Petrol	B5244T4	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80	2005	Petrol	B5254T2	●	●	●	●	●	●	1, 2, 3, 4, 5, 6	
S80	2005	Petrol	B6294S2	●	●	●	●	●	●	2, 3, 4, 5	
S80	2005	Petrol	B6294T	●	●	●	●	●	●	1, 2, 3, 4, 5, 6	
S80	2005	Diesel	D5244T	●	●	●	○	●	●	7	
S80	2005	Diesel	D5244T2	●	●	●	○	●	●	7	
S80	2005	AEM	AEM	●	●	●	●	●	●		
S80	2005	AUM	AUM	●	●	●	●	●	○		
S80	2005	DIM	DIM	●	●	●	●	●	●	33, 35, 36, 37	
S80	2005	PHM	PHM	●	●	●	●	●	○		
S80	2005	REM	REM	●	●	●	●	●	●	39, 40	
S80	2005	RTI	RTI	●	●	●	●	○	○		
S80	2005	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24, 25	
S80	2005	TCM	4T65EV	●	●	●	●	●	●	10, 11	
S80	2005	TCM	4T65EV-GT	●	●	●	●	●	●	10, 11	
S80	2005	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
S80	2005	TCM	AW55-50/51SN	●	●	●	●	●	●	10, 11	
S80	2005	ABS/BCM	ABS/BCM	●	●	●	●	●	●	62, 63	
S80	2005	SAS	SAS	●	●	●	●	●	○		
S80	2005	SUM	SUM	●	●	●	●	●	○		
S80	2005	CCM	CCM	●	●	●	●	●	○	43, 44	
S80	2005	DDM	DDM	●	●	●	●	●	●	46, 47, 48	
S80	2005	PDM	PDM	●	●	●	●	●	●	46	
S80	2005	PSM	PSM	●	●	●	●	●	●	48	
S80	2005	SRS	SRS	●	●	●	●	●	○		
S80	2005	CEM	CEM	●	●	●	●	●	●	27, 28, 150, 151, 29, 30, 31, 32	

● This function is supported. ▲ This function is the new feature in this version.
 ○ This function is not supported. ※ This function may be supported, which depends on the actual condition of the vehicle.
 As for special function please refer to the special function table.

[illegible]

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80	2003	Petrol	B5234T7	●	●	●	●	●	●	1, 2, 3, 4, 50	
S80	2003	Petrol	B5244S	●	●	●	●	●	●	6	
S80	2003	Petrol	B5244S2	●	●	●	●	●	●		
S80	2003	Petrol	B5244SG	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC
S80	2003	Petrol	B5244SG2	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC
S80	2003	Petrol	B5244T3	●	●	●	●	●	●	1, 2, 3, 4, 50	
S80	2003	Petrol	B6294S2	●	●	●	●	●	●	1, 2, 3, 4, 50	
S80	2003	Petrol	B6294T	●	●	●	●	●	●	1, 2, 3, 4, 50	
S80	2003	Diesel	D5244T	●	●	●	○	●	●	7	
S80	2003	Diesel	D5244T2	●	●	●	○	●	●	7	
S80	2003	AEM	AEM	●	●	●	●	●	●		
S80	2003	AUM	AUM	●	●	●	●	●	○		
S80	2003	DIM	DIM	●	●	●	●	●	●	33, 35, 53, 37	
S80	2003	PHM	PHM	●	●	●	●	●	○		
S80	2003	REM	REM	●	●	●	●	●	●	55	
S80	2003	RTI	RTI	●	●	●	●	○	○		
S80	2003	SWM	SWM	●	●	●	●	●	○		
S80	2003	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24	
S80	2003	TCM	4T65EV	●	●	●	●	●	●	10, 11	
S80	2003	TCM	4T65EV-GT	●	●	●	●	●	●	10, 11	
S80	2003	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
S80	2003	TCM	AW55-50/51SN	●	●	●	●	●	●	10, 11	
S80	2003	ABS/BCM	ABS/BCM	●	●	●	●	●	●	62, 63	
S80	2003	SAS	SAS	●	●	●	○	●	○		
S80	2003	CCM	CCM	●	●	●	●	●	○	41, 56, 56, 58	
S80	2003	DDM	DDM	●	●	●	●	●	●	47, 59	
S80	2003	PDM	PDM	●	●	●	●	●	●	59	
S80	2003	PSM	PSM	●	●	●	●	●	●	48, 60	
S80	2003	SRS	SRS	●	●	●	●	●	○		
S80	2002	CEM	CEM	●	●	●	●	●	●	27, 51, 40, 30, 32	
S80	2002	Petrol	B5204T5	●	●	●	●	●	●	1, 2, 3, 50	
S80	2002	Petrol	B5234T7	●	●	●	●	●	●	1, 2, 3, 50	
S80	2002	Petrol	B5244S	●	●	●	●	●	●	6, 89	Extend DTC; Elec. Ident. ; Block DTC

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80	2002	Petrol	B5244S2	●	●	●	●	●	●	6, 89	Extend DTC; Elec. Ident. ; Block DTC
S80	2002	Petrol	B5244SG	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC
S80	2002	Petrol	B5244SG2	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC
S80	2002	Petrol	B5244T3	●	●	●	●	●	●	1, 2, 3, 50	
S80	2002	Petrol	B6294S2	●	●	●	●	●	●	1, 2, 4, 50	
S80	2002	Petrol	B6294T	●	●	●	●	●	●	1, 2, 4, 50	
S80	2002	Diesel	D5244T	●	●	●	○	●	●	90, 7	
S80	2002	Diesel	D5244T2	●	●	●	○	●	●	90, 7	
S80	2002	AEM	AEM	●	●	●	●	●	●		
S80	2002	AUM	AUM	●	●	●	●	●	○		
S80	2002	DIM	DIM	●	●	●	●	●	●	33, 35, 53, 37	
S80	2002	PHM	PHM	●	●	●	●	●	○		
S80	2002	REM	REM	●	●	●	●	●	●	55	
S80	2002	RTI	RTI	●	●	●	●	○	○		
S80	2002	SWM	SWM	●	●	●	●	●	○		
S80	2002	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24	
S80	2002	TCM	4T65EV	●	●	●	●	●	●	10, 11	
S80	2002	TCM	4T65EV-GT	●	●	●	●	●	●	10, 11	
S80	2002	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
S80	2002	TCM	AW55-50/51SN	●	●	●	●	●	●	10, 11	
S80	2002	ABS/BCM	ABS/BCM	●	●	●	●	●	●	62, 63	
S80	2002	SAS	SAS	●	●	●	○	●	○		
S80	2002	CCM	CCM	●	●	●	●	●	○	41, 56, 56, 58	
S80	2002	DDM	DDM	●	●	●	●	●	●	59	
S80	2002	PDM	PDM	●	●	●	●	●	●	59	
S80	2002	PSM	PSM	●	●	●	●	●	●	48, 60	
S80	2002	SRS	SRS	●	●	●	●	●	○		
S80	2001	CEM	CEM	●	●	●	●	●	●	27, 51, 40, 30, 32	
S80	2001	Petrol	B5204T5	●	●	●	●	●	●	1, 50	Elec. Ident.
S80	2001	Petrol	B5234T7	●	●	●	●	●	●	1, 50	Elec. Ident.
S80	2001	Petrol	B5244S	●	●	●	●	●	●	6, 89	Extend DTC; Elec. Ident. ; Block DTC

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80	2001	Petrol	B5244S2	●	●	●	●	●	●	6, 89	Extend DTC; Elec. Ident. ; Block DTC
S80	2001	Petrol	B5244SG	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC
S80	2001	Petrol	B5244T3	●	●	●	●	●	●	1, 50	Elec. Ident.
S80	2001	Petrol	B6284T	●	●	●	●	●	●	1, 50	Elec. Ident.
S80	2001	Petrol	B6294S	●	●	●	●	●	●	1, 50	Elec. Ident.
S80	2001	Diesel	D5244T	●	●	●	○	●	●	90, 7	
S80	2001	Diesel	D5252T MSA 15.8	●	○	○	●	●	●	91, 92	
S80	2001	AEM	AEM	●	●	●	●	●	●		
S80	2001	AUM	AUM	●	●	●	●	●	○		
S80	2001	DIM	DIM	●	●	●	●	●	●	33, 35, 53, 37	
S80	2001	PHM	PHM	●	●	●	●	●	○		
S80	2001	REM	REM	●	●	●	●	●	●		
S80	2001	RTI	RTI	●	●	●	●	○	○		
S80	2001	SWM	SWM	●	●	●	●	●	○		
S80	2001	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24	
S80	2001	TCM	4T65EV	●	●	●	●	●	●	10, 11	
S80	2001	TCM	4T65EV-GT	●	●	●	●	●	●	10, 11	
S80	2001	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
S80	2001	TCM	AW50-42	●	●	●	●	●	●	10, 11	
S80	2001	TCM	AW55-50/51SN	●	●	●	●	●	●	10, 11	
S80	2001	ABS/BCM	ABS/BCM	●	●	●	●	●	●		DSTC(Live Data); DSTC(Active Test)
S80	2001	SAS	SAS	●	●	●	○	●	○		
S80	2001	CCM	CCM	●	●	●	●	●	○	41, 56, 56, 58	
S80	2001	DDM	DDM	●	●	●	●	●	●	59	
S80	2001	PDM	PDM	●	●	●	●	●	●	59	
S80	2001	PSM	PSM	●	●	●	●	●	●	48, 60	
S80	2001	SRS	SRS	●	●	●	●	●	○		
S80	2000	CEM	CEM	●	●	●	●	●	●	27, 21, 32	
S80	2000	Petrol	B5204T3	●	●	●	●	●	●	1, 50	Elec. Ident.
S80	2000	Petrol	B5204T4	●	●	●	●	●	●	1, 50	Elec. Ident.
S80	2000	Petrol	B5204T5	●	●	●	●	●	●	1, 50	Elec. Ident.
S80	2000	Petrol	B5234T7	●	●	●	●	●	●	1, 50	Elec. Ident.
S80	2000	Petrol	B5244S	●	●	●	●	●	●	6, 89	Extend DTC; Elec. Ident.

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80	2000	Petrol	B5244S2	●	●	●	●	●	●	6, 89	Extend DTC; Elec. Ident.
S80	2000	Petrol	B6284T	●	●	●	●	●	●	1, 50	Elec. Ident.
S80	2000	Petrol	B6294S	●	●	●	●	●	●	1, 50	Elec. Ident.
S80	2000	Diesel	D5252T MSA 15.8	●	○	○	●	●	●	91, 92	
S80	2000	AUM	AUM	●	●	●	●	●	○		
S80	2000	DIM	DIM	●	●	●	●	●	●	33, 35, 53, 37	
S80	2000	PHM	PHM	●	●	●	●	○	○		
S80	2000	REM	REM	●	●	●	●	●	●		
S80	2000	RTI	RTI	●	●	●	●	○	○		
S80	2000	SWM	SWM	●	●	●	●	●	○		
S80	2000	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24	
S80	2000	TCM	4T65EV	●	●	●	●	●	●	10, 11	
S80	2000	TCM	4T65EV-GT	●	●	●	●	●	●	10, 11	
S80	2000	TCM	AW50-42	●	●	●	●	●	●	10, 11	
S80	2000	TCM	AW55-50/51SN	●	●	●	●	●	●	10, 11	
S80	2000	ABS/BCM	ABS/BCM	●	●	●	●	●	●		DSTC(Live Data); DSTC(Active Test)
S80	2000	SAS	SAS	●	●	●	○	●	○		
S80	2000	CCM	CCM	●	●	●	●	●	○	41, 56, 56, 58	
S80	2000	DDM	DDM	●	●	●	●	●	●	59	
S80	2000	PDM	PDM	●	●	●	●	●	●	59	
S80	2000	PSM	PSM	●	●	●	●	●	●	48, 60	
S80	2000	SRS	SRS	●	●	●	●	●	○		
S80	1999	CEM	CEM	●	●	●	●	●	●	27, 21, 32	
S80	1999	Petrol	B5204T3	●	●	●	●	●	●	1, 50	Elec. Ident.
S80	1999	Petrol	B5204T4	●	●	●	●	●	●	1, 93	Elec. Ident.
S80	1999	Petrol	B5244S	●	●	●	●	●	●	6, 89	Extend DTC; Elec. Ident.
S80	1999	Petrol	B5244S2	●	●	●	●	●	●	6, 89	Extend DTC; Elec. Ident.
S80	1999	Petrol	B6284T	●	●	●	●	●	●	1, 50	
S80	1999	Petrol	B6304S3	●	●	●	●	●	●	1, 93	
S80	1999	Diesel	D5252T MSA 15.8	●	○	○	●	●	●	91, 92	
S80	1999	AUM	AUM	●	●	●	●	○	○		
S80	1999	DIM	DIM	●	●	●	●	●	●	33, 35, 53, 37	
S80	1999	PHM	PHM	●	●	●	●	○	○		
S80	1999	REM	REM	●	●	●	●	●	●		
S80	1999	RTI	RTI	●	●	●	●	○	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80	1999	SWM	SWM	●	●	●	●	●	○		
S80	1999	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24	
S80	1999	TCM	4T65EV	●	●	●	●	●	●	10, 11	
S80	1999	TCM	4T65EV-GT	●	●	●	●	●	●	10, 11	
S80	1999	TCM	AW50-42	●	●	●	○	●	●	10, 11	
S80	1999	TCM	AW55-50/51SN	●	●	●	●	●	●	10, 11	
S80	1999	ABS/BCM	ABS/BCM	●	●	●	○	●	●		DSTC(Live Data); DSTC(Active Test)
S80	1999	SAS	SAS	●	●	●	○	●	○		
S80	1999	CCM	CCM	●	●	●	●	●	○	41, 56, 56, 58	
S80	1999	DDM	DDM	●	●	●	●	●	●	59	
S80	1999	PDM	PDM	●	●	●	●	●	●	59	
S80	1999	PSM	PSM	●	●	●	●	●	●		
S80	1999	SRS	SRS	●	●	●	●	○	○		
S80(-06)	2006	ECM	D5244T2	●	●	●	●	●	●		
S80(-06)	2006	ECM	D5244T	●	●	●	●	●	●		
S80(-06)	2006	ECM	B6294T	●	●	●	●	●	●	74	
S80(-06)	2006	ECM	B6294S2	●	●	●	●	●	●	74	
S80(-06)	2006	ECM	B5254T2	●	●	●	●	●	●	74	
S80(-06)	2006	ECM	B5244T4	●	●	●	●	●	●	74	
S80(-06)	2006	ETM	B5244SG	●	○	○	○	●	○		
S80(-06)	2006	ECM	B5244SG	●	●	●	●	●	●		
S80(-06)	2006	ECM	B5244S2	●	●	●	●	●	●		
S80(-06)	2006	ECM	B5244S	●	●	●	●	●	●		
S80(-06)	2006	ECM	B5204T5	●	●	●	●	●	●	74	
S80(-06)	2006	TCM	AW55-50/51SN	●	●	●	●	●	●	100, 101, 102, 103, 125	
S80(-06)	2006	TCM	AW50/51 AWD	●	●	●	●	●	●	100, 101, 102, 103, 125	
S80(-06)	2006	DEM	AW50/51 AWD	●	●	●	●	●	○		
S80(-06)	2006	TCM	4T65EV-GT	●	●	●	●	●	●	125, 102, 100, 103	
S80(-06)	2006	TCM	4T65EV	●	●	●	●	●	●	125, 102, 100, 103	
S80(-06)	2006	REM		●	●	●	●	●	●		
S80(-06)	2006	AUM		●	●	●	●	●	○		
S80(-06)	2006	BCM		●	●	●	●	●	●	86, 87	
S80(-06)	2006	SRS		●	●	●	●	●	○	95	
S80(-06)	2006	PSM		●	●	●	●	●	●	107	
S80(-06)	2006	DDM		●	●	●	●	●	●	107, 108	
S80(-06)	2006	PDM		●	●	●	●	●	●	108	
S80(-06)	2006	SUM		●	●	●	●	●	●		
S80(-06)	2006	AEM		●	●	●	●	●	●		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80(-06)	2006	PHM		●	●	●	●	●	○		
S80(-06)	2006	DIM		●	●	●	●	●	●	116, 117, 28, 46, 47	
S80(-06)	2006	CPM		●	○	○	○	●	○	111, 112	
S80(-06)	2006	UEM		●	●	●	●	●	●	119, 120, 128, 122, 123, 12	
S80(-06)	2006	CEM		●	●	●	●	●	●	91, 92, 94, 95	
S80(-06)	2006	CCM		●	●	●	●	●	○	30, 113, 114, 29, 32, 115	
S80(-06)	2006	RTI		●	●	●	●	○	○		
S80(-06)	2006	SAS		●	●	●	●	●	○		
S80(07-)	2009	DEM	TF-80SC AWD	●	●	●	●	●	●		
S80(07-)	2009	DEM	M66 AWD	●	●	●	●	●	●		
S80(07-)	2009	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80(07-)	2009	ECM	D5244T5	●	●	●	●	●	●	58, 59, 60, 61, 62, 63, 90, 6	
S80(07-)	2009	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80(07-)	2009	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80(07-)	2009	ECM	D5244T4	●	●	●	●	●	●	58, 59, 60, 61, 62, 63, 90, 6	
S80(07-)	2009	ECM	D4204T	●	●	●	●	●	●	69, 70, 71	
S80(07-)	2009	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80(07-)	2009	ECM	B8444S	●	●	●	●	●	●	9	
S80(07-)	2009	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80(07-)	2009	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80(07-)	2009	ECM	B6324S	●	●	●	●	●	●	9	
S80(07-)	2009	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80(07-)	2009	ECM	B6304T2	●	●	●	●	●	●	9	
S80(07-)	2009	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80(07-)	2009	ECM	B5254T8	●	●	●	●	●	●	74, 79	
S80(07-)	2009	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80(07-)	2009	ECM	B5254T6	●	●	●	●	●	●	74, 79	
S80(07-)	2009	ECM	B4204S4	●	●	●	●	●	●	79	
S80(07-)	2009	ECM	B4204S3	●	●	●	●	●	●	79	
S80(07-)	2009	SUM		●	●	●	●	●	●	10	
S80(07-)	2009	IAM		●	●	●	●	○	○		
S80(07-)	2009	PSM		●	●	●	●	●	●		
S80(07-)	2009	HLDF		●	●	●	●	●	○		
S80(07-)	2009	AUU		●	●	●	●	●	○		
S80(07-)	2009	DDM		●	●	●	●	●	●	12, 13	
S80(07-)	2009	PDM		●	●	●	●	●	●	12, 13	
S80(07-)	2009	PAM		●	●	●	●	●	○	14	
S80(07-)	2009	KVM		●	●	●	●	●	○	16, 17	
S80(07-)	2009	AUD		●	●	●	●	○	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80 (07-)	2009	CPM		●	●	●	●	●	●		
S80 (07-)	2009	HCM		●	●	●	●	●	○	23	
S80 (07-)	2009	BCM		●	●	●	●	●	●	10	
S80 (07-)	2009	SAS		●	●	●	●	●	○		
S80 (07-)	2009	SRS		●	●	●	●	●	○	25, 26, 27	
S80 (07-)	2009	CCM		●	●	●	●	●	●	28, 29, 30, 31, 32	
S80 (07-)	2009	CEM		●	●	●	●	●	●	35, 39	
S80 (07-)	2009	TRM		●	●	●	●	●	○		
S80 (07-)	2009	PBM		●	●	●	●	●	○	43	
S80 (07-)	2009	FSM		●	●	●	●	●	○		
S80 (07-)	2009	DIM		●	●	●	●	●	○	47, 48, 49, 50, 51, 52	
S80 (07-)	2009	PAC		●	●	●	●	●	○		
S80 (07-)	2009	RDAR		●	●	●	●	○	○		
S80 (07-)	2009	MMM		●	●	●	●	○	○		
S80 (07-)	2009	ICM		●	●	●	●	●	●		
S80 (07-)	2009	BPM		●	●	●	●	●	○		
S80 (07-)	2009	PHM		●	●	●	●	●	○		
S80 (07-)	2008	DEM	TF-80SC AWD	●	●	●	●	●	●		
S80 (07-)	2008	DEM	M66 AWD	●	●	●	●	●	●		
S80 (07-)	2008	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80 (07-)	2008	ECM	D5244T5	●	●	●	●	●	●	58, 59, 60, 61, 62, 63, 90, 6	
S80 (07-)	2008	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80 (07-)	2008	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80 (07-)	2008	ECM	D5244T4	●	●	●	●	●	●	58, 59, 60, 61, 62, 63, 90, 6	
S80 (07-)	2008	ECM	D4204T	●	●	●	●	●	●	69, 70, 71	
S80 (07-)	2008	TCM	B8444S	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80 (07-)	2008	ECM	B8444S	●	●	●	●	●	●	9	
S80 (07-)	2008	TCM	B6324S	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80 (07-)	2008	TCM	B6324S	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80 (07-)	2008	ECM	B6324S	●	●	●	●	●	●	9	
S80 (07-)	2008	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80 (07-)	2008	ECM	B6304T2	●	●	●	●	●	●	9	
S80 (07-)	2008	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80 (07-)	2008	ECM	B5254T6	●	●	●	●	●	●	74, 79	
S80 (07-)	2008	ECM	B4204S4	●	●	●	●	●	●	79	
S80 (07-)	2008	ECM	B4204S3	●	●	●	●	●	●	79	
S80 (07-)	2008	SUM		●	●	●	●	●	●	10	
S80 (07-)	2008	IAM		●	●	●	●	○	○		
S80 (07-)	2008	PSM		●	●	●	●	●	●		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80 (07-)	2008	RDAR		●	●	●	●	○	○		
S80 (07-)	2008	HLDF		●	●	●	●	●	○		
S80 (07-)	2008	AUU		●	●	●	●	●	○		
S80 (07-)	2008	DDM		●	●	●	●	●	●	12, 13	
S80 (07-)	2008	PDM		●	●	●	●	●	●	12, 13	
S80 (07-)	2008	PAM		●	●	●	●	●	○	14	
S80 (07-)	2008	KVM		●	●	●	●	●	○	16, 17	
S80 (07-)	2008	AUD		●	●	●	●	○	○		
S80 (07-)	2008	PHM		●	●	●	●	●	○		
S80 (07-)	2008	CPM		●	●	●	●	●	●		
S80 (07-)	2008	HCM		●	●	●	●	●	○	23	
S80 (07-)	2008	BCM		●	●	●	●	●	●	80	
S80 (07-)	2008	SAS		●	●	●	●	●	○		
S80 (07-)	2008	SRS		●	●	●	●	●	○	25, 26, 27	
S80 (07-)	2008	CEM		●	●	●	●	●	●	35, 39	
S80 (07-)	2008	DIM		●	●	●	●	●	○	47, 48, 49, 50, 51, 52	
S80 (07-)	2008	CCM		●	●	●	●	●	●	28, 29, 30, 31, 32	
S80 (07-)	2008	TRM		●	●	●	●	●	○		
S80 (07-)	2008	PBM		●	●	●	●	●	○	43	
S80 (07-)	2008	BPM		●	●	●	●	●	○		
S80 (07-)	2008	MMM		●	●	●	●	○	○		
S80 (07-)	2008	FSM		●	●	●	●	●	○		
S80 (07-)	2008	ICM		●	●	●	●	●	●		
S80 (07-)	2008	PAC		●	●	●	●	●	○		
S80 (07-)	2007	DEM	TF-80SC AWD	●	●	●	●	●	●		
S80 (07-)	2007	ECM	B5254T6	●	●	●	●	●	●	74, 79	
S80 (07-)	2007	SUM		●	●	●	●	●	●	10	
S80 (07-)	2007	PSM		●	●	●	●	●	●		
S80 (07-)	2007	HLDF		●	●	●	●	●	○		
S80 (07-)	2007	AUU		●	●	●	●	●	○		
S80 (07-)	2007	DDM		●	●	●	●	●	●	12, 13	
S80 (07-)	2007	PDM		●	●	●	●	●	●	12, 13	
S80 (07-)	2007	PAM		●	●	●	●	●	○	14	
S80 (07-)	2007	KVM		●	●	●	●	●	○	16, 17	
S80 (07-)	2007	AUD		●	●	●	●	○	○		
S80 (07-)	2007	PHM		●	●	●	●	●	○		
S80 (07-)	2007	CPM		●	●	●	●	●	●		
S80 (07-)	2007	HCM		●	●	●	●	●	○	23	
S80 (07-)	2007	SAS		●	●	●	●	●	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
 - This function is not supported.
 - ▲ This function is the new feature in this version.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
- As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S80 (07-)	2007	CCM		●	●	●	●	●	●	28, 29, 30, 31, 32	
S80 (07-)	2007	TRM		●	●	●	●	●	○		
S80 (07-)	2007	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80 (07-)	2007	ECM	D5244T5	●	●	●	●	●	●	58, 59, 60, 61, 62, 63, 90, 6	
S80 (07-)	2007	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80 (07-)	2007	ECM	D5244T4	●	●	●	●	●	●	58, 59, 60, 61, 62, 63, 90, 6	
S80 (07-)	2007	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80 (07-)	2007	ECM	B8444S	●	●	●	●	●	●	9	
S80 (07-)	2007	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80 (07-)	2007	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80 (07-)	2007	ECM	B6324S	●	●	●	●	●	●	9	
S80 (07-)	2007	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 5	
S80 (07-)	2007	BCM		●	●	●	●	●	●	10	
S80 (07-)	2007	FSM		●	●	●	●	●	○		
S80 (07-)	2007	IAM		●	●	●	●	○	○		
S80 (07-)	2007	PAC		●	●	●	●	●	○		
S80 (07-)	2007	RDAR		●	●	●	●	○	○		
S80 (07-)	2007	ICM		●	●	●	●	●	●		
S80 (07-)	2007	SRS		●	●	●	●	●	○	25, 26, 27	
S80 (07-)	2007	PBM		●	●	●	●	●	○	43	
S80 (07-)	2007	CEM		●	●	●	●	●	●	35, 39	
S80 (07-)	2007	BPM		●	●	●	●	●	○		
S80 (07-)	2007	DIM		●	●	●	●	●	○	47, 48, 49, 50, 51, 52	
S80 (07-)	2007	MMM		●	●	●	●	○	○		
V40	2004	Petrol	B4164S2	●	●	●	○	●	●	113, 1	
V40	2004	Petrol	B4184S10	●	●	●	○	●	●	113, 1	
V40	2004	Petrol	B4184S2	●	●	●	○	●	●	113, 1	
V40	2004	Petrol	B4184S3	●	●	●	○	●	●	113, 1	
V40	2004	Petrol	B4184S9	●	●	●	○	●	●	113, 1	
V40	2004	Petrol	B4184SJ	●	●	●	○	●	●	117	
V40	2004	Petrol	B4204S2	●	●	●	○	●	●	113, 1	
V40	2004	Petrol	B4204T3	●	●	●	○	●	●	118, 1	
V40	2004	Diesel	D4192T3 (Anti-spin	●	●	●	○	●	●		
V40	2004	Diesel	D4192T4 (Anti-spin	●	●	●	○	●	●		
V40	2004	Anti-spin system	Anti-spin system	●	●	●	○	●	○		
V40	2004	DIM	DIM	●	●	●	○	●	●	121, 122, 81, 125, 126	
V40	2004	Gas discharge light	Gas discharge light	●	●	●	○	●	●		
V40	2004	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
V40	2004	TCM	AW55-50/51SN	●	●	●	○	●	●	130, 131	

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
 - This function is not supported.
 - ▲ This function is the new feature in this version.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
- As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V40	2004	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
V40	2004	CCM	CCM	●	●	●	○	●	●	132, 133, 81	
V40	2004	CPM	CPM	●	●	●	○	●	○	21	
V40	2004	SRS	SRS	●	●	●	○	●	○		
V40	2003	Petrol	B4164S2	●	●	●	○	●	●	113, 1	
V40	2003	Petrol	B4184S10	●	●	●	○	●	●	113, 1	
V40	2003	Petrol	B4184S2	●	●	●	○	●	●	113, 1	
V40	2003	Petrol	B4184S3	●	●	●	○	●	●	113, 1	
V40	2003	Petrol	B4184S9	●	●	●	○	●	●	113, 1	
V40	2003	Petrol	B4184SJ	●	●	●	○	●	●	117	
V40	2003	Petrol	B4204S2	●	●	●	○	●	●	113, 1	
V40	2003	Petrol	B4204T3	●	●	●	○	●	●	118, 1	
V40	2003	Petrol	B4204T5	●	●	●	○	●	●	118, 1	
V40	2003	Diesel	D4192T3 (Anti-spin	●	●	●	○	●	○		
V40	2003	Diesel	D4192T4 (Anti-spin	●	●	●	○	●	○		
V40	2003	Anti-spin system	Anti-spin system	●	●	●	○	●	○		
V40	2003	DIM	DIM	●	●	●	○	●	●	121, 122, 81, 125, 126	
V40	2003	Gas discharge light	Gas discharge light	●	●	●	○	●	●		
V40	2003	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
V40	2003	TCM	AW55-50/51SN	●	●	●	○	●	●	130, 131	
V40	2003	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
V40	2003	CCM	CCM	●	●	●	○	●	●	132, 133, 81	
V40	2003	CPM	CPM	●	●	●	○	●	○	21	
V40	2003	SRS	SRS	●	●	●	○	●	○		
V40	2002	Petrol	B4164S2	●	●	●	○	●	●	113, 1	
V40	2002	Petrol	B4184S10	●	●	●	○	●	●	113, 1	
V40	2002	Petrol	B4184S2	●	●	●	○	●	●	113, 1	
V40	2002	Petrol	B4184S3	●	●	●	○	●	●	113, 1	
V40	2002	Petrol	B4184S9	●	●	●	○	●	●	113, 1	
V40	2002	Petrol	B4184SJ	●	●	●	○	●	●	117	
V40	2002	Petrol	B4204S2	●	●	●	○	●	●	113, 1	
V40	2002	Petrol	B4204T3	●	●	●	○	●	●	118, 1	
V40	2002	Petrol	B4204T5	●	●	●	○	●	●	118, 1	
V40	2002	Diesel	D4192T3 (Anti-spin	●	●	●	○	●	○		
V40	2002	Diesel	D4192T4 (Anti-spin	●	●	●	○	●	○		
V40	2002	Anti-spin system	Anti-spin system	●	●	●	○	●	○		
V40	2002	DIM	DIM	●	●	●	○	●	●	121, 122, 81, 125, 126	
V40	2002	Gas discharge light	Gas discharge light	●	●	●	○	●	●		
V40	2002	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ▲ This function is the new feature in this version.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V40	2002	TCM	AW55-50/51SN	●	●	●	○	●	●	130, 131	
V40	2002	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
V40	2002	CCM	CCM	●	●	●	○	●	●	132, 133, 81	
V40	2002	CPM	CPM	●	●	●	○	●	○	21	
V40	2002	SRS	SRS	●	●	●	○	●	○		
V40	2001	Petrol	B4164S2	●	●	●	○	●	●	113, 1	
V40	2001	Petrol	B4184S10	●	●	●	○	●	●	113, 1	
V40	2001	Petrol	B4184S2	●	●	●	○	●	●	113, 1	
V40	2001	Petrol	B4184S3	●	●	●	○	●	●	113, 1	
V40	2001	Petrol	B4184S9	●	●	●	○	●	●	113, 1	
V40	2001	Petrol	B4184SJ	●	●	●	○	●	●	117	
V40	2001	Petrol	B4184SM	●	●	●	○	●	●	134, 135	
V40	2001	Petrol	B4204S2	●	●	●	○	●	●	113, 1	
V40	2001	Petrol	B4204T3	●	●	●	○	●	●	118, 1	
V40	2001	Petrol	B4204T5	●	●	●	○	●	●	118, 1	
V40	2001	Diesel	D4192T3(Anti-spin	●	●	●	○	●	○		
V40	2001	Diesel	D4192T4(Anti-spin	●	●	●	○	●	○		
V40	2001	Anti-spin system	Anti-spin system	●	●	●	○	●	○		
V40	2001	DIM	DIM	●	●	●	○	●	●	121, 122, 81, 125, 126	
V40	2001	Gas discharge light	Gas discharge light	●	●	●	○	●	●		
V40	2001	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
V40	2001	TCM	AW55-50/51SN	●	●	●	○	●	●	130, 131	
V40	2001	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
V40	2001	CCM	CCM	●	●	●	○	●	●	132, 133, 81	
V40	2001	CPM	CPM	●	●	●	○	●	○	21	
V40	2001	SRS	SRS	●	●	●	○	●	○		
V40	2000	Petrol	B4164S2	●	●	●	○	●	●		
V40	2000	Petrol	B4184S2	●	●	●	○	●	●		
V40	2000	Petrol	B4184S3	●	●	●	○	●	●		
V40	2000	Petrol	B4184SM	●	●	●	○	●	●	134, 135	
V40	2000	Petrol	B4194T2	●	●	●	○	●	●		
V40	2000	Petrol	B4204S2	●	●	●	○	●	●		
V40	2000	Petrol	B4204T2	●	●	●	○	●	●		
V40	2000	Diesel	D4192T2(Anti-spin	●	●	●	○	●	○		
V40	2000	Anti-spin system	Anti-spin system	●	●	●	○	●	○		
V40	2000	DIM	DIM	●	●	●	○	●	●	121, 122, 81, 125, 126	
V40	2000	Lock and alarm	Lock and alarm	●	●	●	○	●	○	80, 81, 40	
V40	2000	TCM	AW50-42	●	●	●	○	●	●		
V40	2000	ABS/BCM	ABS/BCM	●	●	●	○	●	●		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V40	2000	CCM	CCM	●	●	●	○	●	○		
V40	2000	CPM	CPM	●	●	●	○	●	○	21	
V40	2000	SRS	SRS	●	●	●	○	○	○		
V40	1999	Petrol	B4164S(Anti-spin	●	●	●	○	●	○		
V40	1999	Petrol	B4184S(Anti-spin	●	●	●	○	●	○		
V40	1999	Petrol	B4184SM	●	●	●	○	●	●	134, 135	
V40	1999	Petrol	B4194T	●	●	●	○	●	●	113	
V40	1999	Petrol	B4204S(Anti-spin	●	●	●	○	●	○		
V40	1999	Petrol	B4204T	●	●	●	○	●	●	113	
V40	1999	Diesel	D4192T(Anti-spin	●	●	●	○	●	○		
V40	1999	Diesel	D4192T2(Anti-spin	●	●	●	○	●	○		
V40	1999	DIM	DIM	●	●	●	○	●	●	125, 126	
V40	1999	Lock and alarm	Lock and alarm	●	●	●	○	●	●	139	
V40	1999	TCM	AW50-42	●	●	●	○	●	●		
V40	1999	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
V40	1999	CCM	CCM	●	●	●	○	●	○		
V40	1999	CPM	CPM	●	●	●	○	●	○	21	
V40	1999	SRS	SRS	●	●	●	○	○	○		
V50	2005	Petrol	B4164S3	●	●	●	●	●	●		
V50	2005	Petrol	B4184S11	●	●	●	●	●	●		
V50	2005	Petrol	B5244S4	●	●	●	●	●	●	88, 6, 95	
V50	2005	Petrol	B5244S5	●	●	●	●	●	●	88, 6, 95	
V50	2005	Petrol	B5254T3	●	●	●	●	●	●	1, 2, 3, 4, 5, 6	
V50	2005	Diesel	D4164T	●	●	●	○	●	●	96, 97, 98, 99	
V50	2005	Diesel	D4204T	●	●	●	●	●	●	96, 100, 99, 97	
V50	2005	Diesel	D4204T2	●	●	●	●	●	●	96, 100, 99, 97	
V50	2005	AFM	AFM	●	●	●	●	●	○		
V50	2005	AEM	AEM	●	●	●	●	●	●		
V50	2005	AUD	AUD	●	●	●	●	○	○		
V50	2005	CEM	CEM	●	●	●	●	●	●	110, 27, 29, 31	
V50	2005	DIM	DIM	●	●	●	●	●	●	103, 35, 37, 104	
V50	2005	ICM	ICM	●	●	●	●	●	●		
V50	2005	IAM	IAM	●	●	●	●	●	●		
V50	2005	KVM	KVM	●	●	●	●	●	●		
V50	2005	MPM	MPM	●	●	●	●	●	●		
V50	2005	MMM	MMM	●	●	●	●	●	●		
V50	2005	PAM	PAM	●	●	●	●	●	○		
V50	2005	PHM	PHM	●	●	●	●	●	○		
V50	2005	SWM	SWM	●	●	●	○	●	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V50	2005	SUB	SUB	●	●	●	●	○	○		
V50	2005	TMC	TMC	●	●	●	●	●	○		
V50	2005	TCM	AW50/51AWD	●	●	●	●	●	●		
V50	2005	TCM	AW55-50/51SN	●	●	●	●	●	●		
V50	2005	ABS/BCM	ABS/BCM	●	●	●	●	●	●		
V50	2005	EPS	EPS	●	●	●	○	●	○		
V50	2005	CCM	CCM	●	●	●	●	●	○	44	
V50	2005	DDM	DDM	●	●	●	○	●	●	46	
V50	2005	PDM	PDM	●	●	●	○	●	●	46	
V50	2005	PSM	PSM	●	●	●	●	●	●	109	
V50	2005	SRS	SRS	●	●	●	●	●	○		
V50	2005	TRM	TRM	●	●	●	●	●	○		
V50	2005	DEM	DEM	●	●	●	●	●	○		
V50	2005	GPS	GPS	●	●	●	●	●	○		
V50	2004	Petrol	B5244S4	●	●	●	●	●	●	88, 6, 95	
V50	2004	Petrol	B5244S5	●	●	●	●	●	●	88, 6, 95	
V50	2004	Petrol	B5254T3	●	●	●	●	●	●	1, 2, 3, 4, 5, 6	
V50	2004	Diesel	D4204T	●	●	●	●	●	●	96, 100, 97	
V50	2004	Diesel	D4204T2	●	●	●	●	●	●	96, 100, 97	
V50	2004	AFM	AFM	●	●	●	●	●	○		
V50	2004	AEM	AEM	●	●	●	●	●	●		
V50	2004	AUD	AUD	●	●	●	●	○	○		
V50	2004	CEM	CEM	●	●	●	○	●	●	110, 27	
V50	2004	DIM	DIM	●	●	●	●	●	●	103, 35, 37, 104	
V50	2004	ICM	ICM	●	●	●	●	●	●		
V50	2004	MPM	MPM	●	●	●	●	●	●		
V50	2004	MMM	MMM	●	●	●	●	●	●		
V50	2004	PHM	PHM	●	●	●	●	●	○		
V50	2004	SWM	SWM	●	●	●	○	●	○		
V50	2004	SUB	SUB	●	●	●	●	○	○		
V50	2004	TMC	TMC	●	●	●	●	●	○		
V50	2004	TCM	AW55-50/51SN	●	●	●	●	●	●		
V50	2004	ABS/BCM	ABS/BCM	●	●	●	●	●	●		
V50	2004	CCM	CCM	●	●	●	●	●	○	44	
V50	2004	DDM	DDM	●	●	●	○	●	●	46, 109	
V50	2004	PDM	PDM	●	●	●	○	●	●	46	
V50	2004	PSM	PSM	●	●	●	●	●	●	109	
V50	2004	SRS	SRS	●	●	●	●	●	○		
V50	2004	TRM	TRM	●	●	●	●	●	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V50	2004	EPS	EPS	●	●	●	○	●	○		
V50	2004	GPS	GPS	●	●	●	●	●	○		
V50	2009	TCM	MPS6	●	●	●	●	●	○		
V50	2009	DEM	M66 AWD	●	●	●	●	●	○		
V50	2009	ECM	D5244T9	●	●	●	●	●	●		
V50	2009	ECM	D5244T8	●	●	●	●	●	●		
V50	2009	ECM	D5244T13	●	●	●	●	●	●		
V50	2009	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
V50	2009	ADM	D4204T	●	●	●	●	●	○		
V50	2009	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
V50	2009	ADM	D4164T	●	●	●	●	●	○		
V50	2009	ECM	D4164T	●	●	●	●	●	●	69, 141	
V50	2009	ECM	B5254T7	●	●	●	●	●	●	74	
V50	2009	ECM	B5244S7	●	●	●	●	●	●	9	
V50	2009	ECM	B5244S5	●	●	●	●	●	●	9	
V50	2009	ECM	B5244S4	●	●	●	●	●	●	9	
V50	2009	ECM	B4204S3	●	●	●	●	●	●	9	
V50	2009	ECM	B4184S8	●	●	●	●	●	●	9	
V50	2009	ECM	B4184S11	●	●	●	●	●	●	9	
V50	2009	ECM	B4164S3	●	●	●	●	●	●	9	
V50	2009	TCM	AW55-50/51SN	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
V50	2009	DEM	AW50/51 AWD	●	●	●	●	●	○		
V50	2009	TCM	AW50/51 AWD	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
V50	2009	PSM		●	●	●	●	●	●	145	
V50	2009	AEM		●	●	●	●	●	●	146	
V50	2009	KVM		●	●	●	●	●	●	147	
V50	2009	RDAR		●	●	●	●	●	○		
V50	2009	PHM		●	●	●	●	●	○		
V50	2009	CPM		●	●	●	●	●	●		
V50	2009	AUD		●	●	●	●	○	○		
V50	2009	BPM		●	●	●	●	●	○		
V50	2009	PAM		●	●	●	●	●	○		
V50	2009	SRS		●	●	●	●	●	○	95	
V50	2009	DDM		●	●	●	●	●	●	149, 150	
V50	2009	PDM		●	●	●	●	●	●	149, 150	
V50	2009	AUU		●	●	●	●	●	○		
V50	2009	HCM		●	●	●	●	●	○	23	
V50	2009	BCM		●	●	●	●	●	○	146, 111	
V50	2009	CCM		●	●	●	●	○	○	30, 113, 152, 32, 153	

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V50	2009	SWM		●	●	●	●	●	○		
V50	2009	TRM		●	●	●	●	●	○		
V50	2009	EPS		●	●	●	●	●	○		
V50	2009	IAM		●	●	●	●	●	●		
V50	2009	CEM		●	●	●	●	●	●	154, 156, 94, 158, 159, 160, 162, 95, 35	
V50	2009	DIM		●	●	●	●	●	●	48, 161, 118, 46, 165, 51	
V50	2009	ICM		●	●	●	●	●	●	166, 167, 168	
V50	2009	MMM		●	●	●	●	○	○		
V50	2008	TCM	MPS6	●	●	●	●	●	○		
V50	2008	DEM	M66 AWD	●	●	●	●	●	○		
V50	2008	ECM	D5244T9	●	●	●	●	●	●		
V50	2008	ECM	D5244T8	●	●	●	●	●	●		
V50	2008	ECM	D5244T13	●	●	●	●	●	●		
V50	2008	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
V50	2008	ADM	D4204T	●	●	●	●	●	○		
V50	2008	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
V50	2008	ADM	D4164T	●	●	●	●	●	○		
V50	2008	ECM	D4164T	●	●	●	●	●	●	69, 141	
V50	2008	ECM	B5254T7	●	●	●	●	●	●	74	
V50	2008	ECM	B5244S7	●	●	●	●	●	●	9	
V50	2008	ECM	B5244S5	●	●	●	●	●	●	9	
V50	2008	ECM	B5244S4	●	●	●	●	●	●	9	
V50	2008	ECM	B4204S3	●	●	●	●	●	●	9	
V50	2008	ECM	B4184S8	●	●	●	●	●	●	9	
V50	2008	ECM	B4184S11	●	●	●	●	●	●	9	
V50	2008	ECM	B4164S3	●	●	●	●	●	●	9	
V50	2008	TCM	AW55-50/51SN	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
V50	2008	DEM	AW50/51 AWD	●	●	●	●	●	○		
V50	2008	TCM	AW50/51 AWD	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
V50	2008	BCM		●	●	●	●	●	○	146, 111	
V50	2008	PSM		●	●	●	●	●	●	145	
V50	2008	AEM		●	●	●	●	●	●	146	
V50	2008	KVM		●	●	●	●	●	●	147	
V50	2008	RDAR		●	●	●	●	●	○		
V50	2008	CPM		●	●	●	●	●	●		
V50	2008	AUD		●	●	●	●	○	○		
V50	2008	PAM		●	●	●	●	●	○		
V50	2008	SRS		●	●	●	●	●	○	95	

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V50	2008	DDM		●	●	●	●	●	●	149, 150	
V50	2008	PDM		●	●	●	●	●	●	149, 150	
V50	2008	AUU		●	●	●	●	●	○		
V50	2008	HCM		●	●	●	●	●	○	23	
V50	2008	CCM		●	●	●	●	●	○	30, 113, 152, 32, 153	
V50	2008	PHM		●	●	●	●	●	○		
V50	2008	CEM		●	●	●	●	●	●	154, 156, 94, 158, 159, 160, 162, 95, 35	
V50	2008	DIM		●	●	●	●	●	●	48, 161, 118, 46, 165, 51	
V50	2008	SWM		●	●	●	●	●	○		
V50	2008	TRM		●	●	●	●	●	○		
V50	2008	EPS		●	●	●	●	●	○		
V50	2008	IAM		●	●	●	●	●	●		
V50	2008	ICM		●	●	●	●	●	●	166, 167, 168	
V50	2008	MMM		●	●	●	●	○	○		
V50	2007	DEM	M66 AWD	●	●	●	●	●	○		
V50	2007	ECM	D5244T9	●	●	●	●	●	●		
V50	2007	ECM	D5244T8	●	●	●	●	●	●		
V50	2007	ADM	D4204T	●	●	●	●	●	○		
V50	2007	ECM	D4204T	●	●	●	●	●	●	71, 9, 141, 69	
V50	2007	ADM	D4164T	●	●	●	●	●	○		
V50	2007	ECM	D4164T	●	●	●	●	●	●	69, 141, 169	
V50	2007	ECM	B5254T3	●	●	●	●	●	●	74	
V50	2007	ECM	B5244S7	●	●	●	●	●	●	9	
V50	2007	ECM	B5244S5	●	●	●	●	●	●	9	
V50	2007	ECM	B5244S4	●	●	●	●	●	●	9	
V50	2007	ECM	B4204S3	●	●	●	●	●	●	9	
V50	2007	ECM	B4184S8	●	●	●	●	●	●	9	
V50	2007	ECM	B4184S11	●	●	●	●	●	●	9	
V50	2007	ECM	B4164S3	●	●	●	●	●	●	9	
V50	2007	TCM	AW55-50/51SN	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
V50	2007	DEM	AW50/51 AWD	●	●	●	●	●	○		
V50	2007	TCM	AW50/51 AWD	●	●	●	●	●	●	83, 111, 1, 140, 4, 100, 101	
V50	2007	GPS		●	●	●	●	●	○		
V50	2007	BCM		●	●	●	●	●	○	146, 111	
V50	2007	PSM		●	●	●	●	●	●	145	
V50	2007	TMC		●	●	●	●	●	○		
V50	2007	SWM		●	●	●	●	●	○		
V50	2007	KVM		●	●	●	●	●	●	147	

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V50	2006	PDM		●	●	●	●	●	●	149, 150	
V50	2006	BCM		●	●	●	●	●	○	146, 111	
V50	2006	PSM		●	●	●	●	●	●	145	
V50	2006	TMC		●	●	●	●	●	○		
V50	2006	SWM		●	●	●	●	●	○		
V50	2006	KVM		●	●	●	●	●	●	147	
V50	2006	AEM		●	●	●	●	●	●	146	
V50	2006	ICM		●	●	●	●	●	●	166	
V50	2006	IAM		●	●	●	●	●	●		
V50	2006	PHM		●	●	●	●	●	○		
V50	2006	TRM		●	●	●	●	●	○		
V50	2006	PAM		●	●	●	●	●	○		
V50	2006	CEM		●	●	●	●	●	●	154, 156, 94, 158, 159, 160, 162, 95	
V50	2006	MMM		●	●	●	●	○	○		
V50	2006	CPM		●	●	●	●	●	●		
V50	2006	CCM		●	●	●	●	●	○	30, 113, 152, 32, 153	
V50	2006	AUD		●	●	●	●	○	○		
V50	2006	SRS		●	●	●	●	●	○	95	
V50	2006	EPS		●	●	●	●	●	○		
V70 (00-08)	2008	DEM	TF-80SC AWD	●	●	●	●	●	○		
V70 (00-08)	2008	TCM	TF-80SC	●	●	●	●	●	●	81, 82, 83, 84, 85	
V70 (00-08)	2008	DEM	M66 AWD	●	●	●	●	●	○		
V70 (00-08)	2008	ECM	D5244T7	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
V70 (00-08)	2008	ECM	D5244T5	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
V70 (00-08)	2008	ECM	B5254T2	●	●	●	●	●	●	74	
V70 (00-08)	2008	ETM	B5244SG	●	○	○	○	●	○		
V70 (00-08)	2008	ECM	B5244SG	●	●	●	●	●	●		
V70 (00-08)	2008	ECM	B5244S2	●	●	●	●	●	●		
V70 (00-08)	2008	ECM	B5244S	●	●	●	●	●	●		
V70 (00-08)	2008	DEM	AW55-50/51SN	●	●	●	●	●	○		
V70 (00-08)	2008	TCM	AW55-50/51SN	●	●	●	●	●	●	100, 101, 102, 103, 125	
V70 (00-08)	2008	DEM	AW50/51 AWD	●	●	●	●	●	○		
V70 (00-08)	2008	TCM	AW50/51 AWD	●	●	●	●	●	●	100, 101, 102, 103, 125	
V70 (00-08)	2008	PHM		●	●	●	●	●	○		
V70 (00-08)	2008	AUM		●	●	●	●	●	○		
V70 (00-08)	2008	BCM		●	●	●	●	●	●	86, 87	
V70 (00-08)	2008	SRS		●	●	●	●	●	○	95	
V70 (00-08)	2008	PSM		●	●	●	●	●	●	107	

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
 - This function is not supported.
 - ▲ This function is the new feature in this version.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
- As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70(00-08)	2008	DDM		●	●	●	●	●	●	107, 108	
V70(00-08)	2008	PDM		●	●	●	●	●	●	108	
V70(00-08)	2008	SUM		●	●	●	●	●	●		
V70(00-08)	2008	AEM		●	●	●	●	●	●		
V70(00-08)	2008	REM		●	●	●	●	●	●		
V70(00-08)	2008	CPM		●	○	○	○	●	○	111, 112	
V70(00-08)	2008	CEM		●	●	●	●	●	●	91, 92, 94, 95, 96	
V70(00-08)	2008	HCM		●	●	●	●	●	○		
V70(00-08)	2008	RTI		●	●	●	●	○	○		
V70(00-08)	2008	SAS		●	●	●	●	●	○		
V70(00-08)	2008	AUU		●	●	●	●	●	○		
V70(00-08)	2008	CCM		●	●	●	●	●	○	30, 113, 114, 29, 32, 115	
V70(00-08)	2008	DIM		●	●	●	●	●	●	116, 117, 28, 46, 47, 118	
V70(00-08)	2008	UEM		●	●	●	●	●	●		
V70(00-08)	2007	DEM	TF-80SC AWD	●	●	●	●	●	○		
V70(00-08)	2007	DEM	M66 AWD	●	●	●	●	●	○		
V70(00-08)	2007	DEM	M58	●	●	●	●	●	○		
V70(00-08)	2007	ECM	D5244T7	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
V70(00-08)	2007	TCM	TF-80SC	●	●	●	●	●	●	81, 82, 83, 84, 85	
V70(00-08)	2007	ECM	D5244T5	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
V70(00-08)	2007	TCM	TF-80SC AWD	●	●	●	●	●	●	81, 82, 83, 84, 85	
V70(00-08)	2007	TCM	TF-80SC	●	●	●	●	●	●	81, 82, 83, 84, 85	
V70(00-08)	2007	ECM	D5244T4	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
V70(00-08)	2007	TCM	TF-80SC AWD	●	●	●	●	●	●	81, 82, 83, 84, 85	
V70(00-08)	2007	ECM	B5254T4	●	●	●	●	●	●	74	
V70(00-08)	2007	ECM	B5254T2	●	●	●	●	●	●	74	
V70(00-08)	2007	ECM	B5244T5	●	●	●	●	●	●	74	
V70(00-08)	2007	ETM	B5244SG	●	○	○	○	●	○		
V70(00-08)	2007	ECM	B5244SG	●	●	●	●	●	●		
V70(00-08)	2007	ECM	B5244S2	●	●	●	●	●	●		
V70(00-08)	2007	ECM	B5244S	●	●	●	●	●	●		
V70(00-08)	2007	ECM	B5204T5	●	●	●	●	●	●	74	
V70(00-08)	2007	TCM	AW55-50/51SN	●	●	●	●	●	●	100, 101, 102, 103, 125	
V70(00-08)	2007	TCM	AW50/51 AWD	●	●	●	●	●	●	100, 101, 102, 103, 125	
V70(00-08)	2007	DEM	AW50/51 AWD	●	●	●	●	●	○		
V70(00-08)	2007	PHM		●	●	●	●	●	○		
V70(00-08)	2007	AUM		●	●	●	●	●	○		
V70(00-08)	2007	BCM		●	●	●	●	●	●	86, 87	
V70(00-08)	2007	SRS		●	●	●	●	●	○	95	

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70(00-08)	2007	PSM		●	●	●	●	●	●	107	
V70(00-08)	2007	DDM		●	●	●	●	●	●	107, 108	
V70(00-08)	2007	PDM		●	●	●	●	●	●	108	
V70(00-08)	2007	SUM		●	●	●	●	●	●		
V70(00-08)	2007	AEM		●	●	●	●	●	●		
V70(00-08)	2007	REM		●	●	●	●	●	●		
V70(00-08)	2007	CPM		●	○	○	○	●	○	111, 112	
V70(00-08)	2007	CEM		●	●	●	●	●	●	91, 92, 94, 95, 96	
V70(00-08)	2007	HCM		●	●	●	●	●	○		
V70(00-08)	2007	CCM		●	●	●	●	●	○	30, 113, 114, 29, 32, 115	
V70(00-08)	2007	RTI		●	●	●	●	○	○		
V70(00-08)	2007	SAS		●	●	●	●	●	○		
V70(00-08)	2007	DIM		●	●	●	●	●	●	116, 117, 28, 46, 47, 118	
V70(00-08)	2007	UEM		●	●	●	●	●	●		
V70(00-08)	2006	DEM	TF-80SC AWD	●	●	●	●	●	○		
V70(00-08)	2006	TCM	TF-80SC	●	●	●	●	●	●	81, 82, 83, 84, 85	
V70(00-08)	2006	DEM	M66 AWD	●	●	●	●	●	○		
V70(00-08)	2006	DEM	M58	●	●	●	●	●	○		
V70(00-08)	2006	ECM	D5244T7	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
V70(00-08)	2006	ECM	D5244T6	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
V70(00-08)	2006	ECM	D5244T5	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
V70(00-08)	2006	TCM	TF-80SC AWD	●	●	●	●	●	●	81, 82, 83, 84, 85	
V70(00-08)	2006	ECM	D5244T4	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
V70(00-08)	2006	ECM	D5244T2	●	●	●	●	●	●		
V70(00-08)	2006	ECM	D5244T	●	●	●	●	●	●		
V70(00-08)	2006	TCM	TF-80SC AWD	●	●	●	●	●	●	81, 82, 83, 84, 85	
V70(00-08)	2006	ECM	B5254T4	●	●	●	●	●	●	74	
V70(00-08)	2006	ECM	B5254T2	●	●	●	●	●	●	74	
V70(00-08)	2006	ECM	B5244T5	●	●	●	●	●	●	74	
V70(00-08)	2006	ETM	B5244SG	●	○	○	○	●	○		
V70(00-08)	2006	ECM	B5244SG	●	●	●	●	●	●		
V70(00-08)	2006	ECM	B5244S6	●	●	●	●	●	●		
V70(00-08)	2006	ECM	B5244S2	●	●	●	●	●	●		
V70(00-08)	2006	ECM	B5244S	●	●	●	●	●	●	74	
V70(00-08)	2006	ECM	B5204T5	●	●	●	●	●	●	74	
V70(00-08)	2006	TCM	AW55-50/51SN	●	●	●	●	●	●	100, 101, 102, 103, 125	
V70(00-08)	2006	TCM	AW50/51 AWD	●	●	●	●	●	●	100, 101, 102, 103, 125	
V70(00-08)	2006	DEM	AW50/51 AWD	●	●	●	●	●	○		
V70(00-08)	2006	REM		●	●	●	●	●	●		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70(00-08)	2006	AUM		●	●	●	●	●	○		
V70(00-08)	2006	BCM		●	●	●	●	●	●	86, 87	
V70(00-08)	2006	SRS		●	●	●	●	●	○	95	
V70(00-08)	2006	PSM		●	●	●	●	●	●	107	
V70(00-08)	2006	DDM		●	●	●	●	●	●	107, 108	
V70(00-08)	2006	PDM		●	●	●	●	●	●	108	
V70(00-08)	2006	SUM		●	●	●	●	●	●		
V70(00-08)	2006	AEM		●	●	●	●	●	●		
V70(00-08)	2006	PHM		●	●	●	●	●	○		
V70(00-08)	2006	DIM		●	●	●	●	●	●	116, 117, 28, 46, 47	
V70(00-08)	2006	CPM		●	○	○	○	●	○	111, 112	
V70(00-08)	2006	UEM		●	●	●	●	●	●	119, 120, 128, 122, 123, 12	
V70(00-08)	2006	CEM		●	●	●	●	●	●	91, 92, 94, 95	
V70(00-08)	2006	CCM		●	●	●	●	●	○	30, 113, 114, 29, 32, 115	
V70(00-08)	2006	RTI		●	●	●	●	○	○		
V70(00-08)	2006	SAS		●	●	●	●	●	○		
V70(08-)	2009	DEM	TF-80SC AWD	●	●	●	●	●	●		
V70(08-)	2009	DEM	M66 AWD	●	●	●	●	●	●		
V70(08-)	2009	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 5	
V70(08-)	2009	ECM	D5244T5	●	●	●	●	●	●	58, 59, 60, 61, 62, 63, 90, 6	
V70(08-)	2009	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
V70(08-)	2009	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 5	
V70(08-)	2009	ECM	D5244T4	●	●	●	●	●	●	58, 59, 60, 61, 62, 63, 90, 6	
V70(08-)	2009	ECM	D4204T	●	●	●	●	●	●	69, 70, 71	
V70(08-)	2009	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
V70(08-)	2009	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 5	
V70(08-)	2009	ECM	B6324S	●	●	●	●	●	●	9	
V70(08-)	2009	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
V70(08-)	2009	ECM	B6304T2	●	●	●	●	●	●	9	
V70(08-)	2009	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 5	
V70(08-)	2009	ECM	B5254T8	●	●	●	●	●	●	74, 79	
V70(08-)	2009	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 5	
V70(08-)	2009	ECM	B5254T6	●	●	●	●	●	●	74, 79	
V70(08-)	2009	ECM	B4204S4	●	●	●	●	●	●	79	
V70(08-)	2009	ECM	B4204S3	●	●	●	●	●	●	79	
V70(08-)	2009	POT		●	●	●	●	○	○		
V70(08-)	2009	SUM		●	●	●	●	●	●	10	
V70(08-)	2009	IAM		●	●	●	●	○	○		
V70(08-)	2009	PSM		●	●	●	●	●	●		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 (08-)	2008	ECM	B5254T6	●	●	●	●	●	●	74, 79	
V70 (08-)	2008	ECM	B4204S4	●	●	●	●	●	●	79	
V70 (08-)	2008	ECM	B4204S3	●	●	●	●	●	●	79	
V70 (08-)	2008	POT		●	●	●	●	○	○		
V70 (08-)	2008	SUM		●	●	●	●	●	●	10	
V70 (08-)	2008	IAM		●	●	●	●	○	○		
V70 (08-)	2008	PSM		●	●	●	●	●	●		
V70 (08-)	2008	RDAR		●	●	●	●	○	○		
V70 (08-)	2008	HLDF		●	●	●	●	●	○		
V70 (08-)	2008	AUU		●	●	●	●	●	○		
V70 (08-)	2008	DDM		●	●	●	●	●	●	12, 13	
V70 (08-)	2008	PDM		●	●	●	●	●	●	12, 13	
V70 (08-)	2008	PAM		●	●	●	●	●	○	14	
V70 (08-)	2008	KVM		●	●	●	●	●	○	16, 17	
V70 (08-)	2008	AUD		●	●	●	●	○	○		
V70 (08-)	2008	PHM		●	●	●	●	●	○		
V70 (08-)	2008	CPM		●	●	●	●	●	●		
V70 (08-)	2008	SUB		●	●	●	●	○	○		
V70 (08-)	2008	HCM		●	●	●	●	●	○	23	
V70 (08-)	2008	SRS		●	●	●	●	●	○	25, 26, 27	
V70 (08-)	2008	BCM		●	●	●	●	●	●	80	
V70 (08-)	2008	SAS		●	●	●	●	●	○		
V70 (08-)	2008	CEM		●	●	●	●	●	●	35, 39	
V70 (08-)	2008	DIM		●	●	●	●	●	○	47, 48, 49, 50, 51, 52	
V70 (08-)	2008	CCM		●	●	●	●	●	●	28, 29, 30, 31, 32	
V70 (08-)	2008	TRM		●	●	●	●	●	○		
V70 (08-)	2008	PBM		●	●	●	●	●	○	43	
V70 (08-)	2008	BPM		●	●	●	●	●	○		
V70 (08-)	2008	MMM		●	●	●	●	○	○		
V70 (08-)	2008	FSM		●	●	●	●	●	○		
V70 (08-)	2008	ICM		●	●	●	●	●	●		
V70 (08-)	2008	PAC		●	●	●	●	●	○		
V70 XC (01-)/XC70 (-07)	2007	DEM	TF-80SC AWD	●	●	●	●	●	○		
V70 XC (01-)/XC70 (-07)	2007	DEM	M66 AWD	●	●	●	●	●	○		
V70 XC (01-)/XC70 (-07)	2007	DEM	M58	●	●	●	●	●	○		
V70 XC (01-)/XC70 (-07)	2007	TCM	TF-80SC AWD	●	●	●	●	●	●	81, 82, 83, 84, 85	
V70 XC (01-)/XC70 (-07)	2007	ECM	D5244T4	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
V70 XC (01-)/XC70 (-07)	2007	ECM	B5254T2	●	●	●	●	●	●	74	
V70 XC (01-)/XC70 (-07)	2007	DEM	AW50/51 AWD	●	●	●	●	●	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 XC(01-)/XC70(-07)	2007	TCM	AW50/51 AWD	●	●	●	●	●	●	100, 101, 102, 103, 125	
V70 XC(01-)/XC70(-07)	2007	PHM		●	●	●	●	●	○		
V70 XC(01-)/XC70(-07)	2007	AUM		●	●	●	●	●	○		
V70 XC(01-)/XC70(-07)	2007	BCM		●	●	●	●	●	●	86, 87	
V70 XC(01-)/XC70(-07)	2007	SRS		●	●	●	●	●	○	95	
V70 XC(01-)/XC70(-07)	2007	PSM		●	●	●	●	●	●	107	
V70 XC(01-)/XC70(-07)	2007	DDM		●	●	●	●	●	●	107, 108	
V70 XC(01-)/XC70(-07)	2007	PDM		●	●	●	●	●	●	108	
V70 XC(01-)/XC70(-07)	2007	SUM		●	●	●	●	●	●		
V70 XC(01-)/XC70(-07)	2007	AEM		●	●	●	●	●	●		
V70 XC(01-)/XC70(-07)	2007	REM		●	●	●	●	●	●		
V70 XC(01-)/XC70(-07)	2007	CPM		●	○	○	○	●	○	111, 112	
V70 XC(01-)/XC70(-07)	2007	CEM		●	●	●	●	●	●	91, 92, 94, 95, 96	
V70 XC(01-)/XC70(-07)	2007	HCM		●	●	●	●	●	○		
V70 XC(01-)/XC70(-07)	2007	CCM		●	●	●	●	●	○	30, 113, 114, 29, 32, 115	
V70 XC(01-)/XC70(-07)	2007	RTI		●	●	●	●	○	○		
V70 XC(01-)/XC70(-07)	2007	SAS		●	●	●	●	●	○		
V70 XC(01-)/XC70(-07)	2007	DIM		●	●	●	●	●	●	116, 117, 28, 46, 47, 118	
V70 XC(01-)/XC70(-07)	2007	UEM		●	●	●	●	●	●		
V70 XC(01-)/XC70(-07)	2006	TCM	TF-80SC AWD	●	●	●	●	●	●	81, 82, 83, 84, 85	
V70 XC(01-)/XC70(-07)	2006	DEM	TF-80SC AWD	●	●	●	●	●	○		
V70 XC(01-)/XC70(-07)	2006	DEM	M66 AWD	●	●	●	●	●	○		
V70 XC(01-)/XC70(-07)	2006	DEM	M58	●	●	●	●	●	○		
V70 XC(01-)/XC70(-07)	2006	ECM	D5244T4	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
V70 XC(01-)/XC70(-07)	2006	ECM	D5244T	●	●	●	●	●	●		
V70 XC(01-)/XC70(-07)	2006	ECM	B5254T2	●	●	●	●	●	●	74	
V70 XC(01-)/XC70(-07)	2006	ECM	B5244T4	●	●	●	●	●	●	74	
V70 XC(01-)/XC70(-07)	2006	TCM	AW55-50/51SN	●	●	●	●	●	●	100, 101, 102, 103, 125	
V70 XC(01-)/XC70(-07)	2006	TCM	AW50/51 AWD	●	●	●	●	●	●	100, 101, 102, 103, 125	
V70 XC(01-)/XC70(-07)	2006	DEM	AW50/51 AWD	●	●	●	●	●	○		
V70 XC(01-)/XC70(-07)	2006	REM		●	●	●	●	●	●		
V70 XC(01-)/XC70(-07)	2006	AUM		●	●	●	●	●	○		
V70 XC(01-)/XC70(-07)	2006	BCM		●	●	●	●	●	●	86, 87	
V70 XC(01-)/XC70(-07)	2006	SRS		●	●	●	●	●	○	95	
V70 XC(01-)/XC70(-07)	2006	PSM		●	●	●	●	●	●	107	
V70 XC(01-)/XC70(-07)	2006	DDM		●	●	●	●	●	●	107, 108	
V70 XC(01-)/XC70(-07)	2006	PDM		●	●	●	●	●	●	108	
V70 XC(01-)/XC70(-07)	2006	SUM		●	●	●	●	●	●		
V70 XC(01-)/XC70(-07)	2006	AEM		●	●	●	●	●	●		

● This function is supported. ▲ This function is the new feature in this version.
 ○ This function is not supported. ✖ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

[illegible]

● This function is supported. ▲ This function is the new feature in this version.
 ○ This function is not supported. ✖ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

[illegible]

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
 - This function is not supported.
 - ▲ This function is the new feature in this version.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
- As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 XC(01-)/XC70	2003	Petrol	B5254T2	●	●	●	●	●	●	1, 2, 3, 4, 50	
V70 XC(01-)/XC70	2003	Diesel	D5244T	●	●	●	○	●	●	7	
V70 XC(01-)/XC70	2003	AEM	AEM	●	●	●	●	●	●		
V70 XC(01-)/XC70	2003	AUM	AUM	●	●	●	●	●	○		
V70 XC(01-)/XC70	2003	CEM	CEM	●	●	●	●	●	●	27, 51, 40, 30, 32	Immobiliser (Live Data)
V70 XC(01-)/XC70	2003	DIM	DIM	●	●	●	●	●	●	33, 35, 53, 37	
V70 XC(01-)/XC70	2003	PHM	PHM	●	●	●	●	●	○		
V70 XC(01-)/XC70	2003	REM	REM	●	●	●	●	●	●	55	
V70 XC(01-)/XC70	2003	RTI	RTI	●	●	●	●	○	○		
V70 XC(01-)/XC70	2003	SWM	SWM	●	●	●	●	●	○		
V70 XC(01-)/XC70	2003	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24	
V70 XC(01-)/XC70	2003	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
V70 XC(01-)/XC70	2003	DEM	DEM	●	●	●	○	●	○		
V70 XC(01-)/XC70	2003	ABS/BCM	ABS/BCM	●	●	●	●	●	●	62, 63	
V70 XC(01-)/XC70	2003	SAS	SAS	●	●	●	○	●	○		
V70 XC(01-)/XC70	2003	CCM	CCM	●	●	●	●	●	○	41, 56, 56, 58	
V70 XC(01-)/XC70	2003	DDM	DDM	●	●	●	●	●	●	46, 47, 48	
V70 XC(01-)/XC70	2003	PDM	PDM	●	●	●	●	●	●	47, 59	
V70 XC(01-)/XC70	2003	PSM	PSM	●	●	●	●	●	●	48, 60	
V70 XC(01-)/XC70	2003	SRS	SRS	●	●	●	●	●	○		
V70 XC(01-)/XC70	2002	Petrol	B5234T7	●	●	●	●	●	●	1, 2, 3, 50	
V70 XC(01-)/XC70	2002	Petrol	B5244T3	●	●	●	●	●	●	1, 2, 3, 50	
V70 XC(01-)/XC70	2002	AEM	AEM	●	●	●	●	●	●		
V70 XC(01-)/XC70	2002	AUM	AUM	●	●	●	●	●	○		
V70 XC(01-)/XC70	2002	CEM	CEM	●	●	●	●	●	●	27, 51, 40, 30, 32	Immobiliser (Live Data)
V70 XC(01-)/XC70	2002	DIM	DIM	●	●	●	●	●	●	33, 35, 53, 37	
V70 XC(01-)/XC70	2002	PHM	PHM	●	●	●	●	●	○		
V70 XC(01-)/XC70	2002	REM	REM	●	●	●	●	●	●	55	
V70 XC(01-)/XC70	2002	RTI	RTI	●	●	●	●	○	○		
V70 XC(01-)/XC70	2002	SWM	SWM	●	●	●	●	●	○		
V70 XC(01-)/XC70	2002	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24	
V70 XC(01-)/XC70	2002	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
V70 XC(01-)/XC70	2002	ABS/BCM	ABS/BCM	●	●	●	●	●	●	62, 63	
V70 XC(01-)/XC70	2002	SAS	SAS	●	●	●	○	●	○		
V70 XC(01-)/XC70	2002	CCM	CCM	●	●	●	●	●	○	41, 56, 56, 58	
V70 XC(01-)/XC70	2002	DDM	DDM	●	●	●	●	●	●	59	
V70 XC(01-)/XC70	2002	PDM	PDM	●	●	●	●	●	●	59	

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 XC(01-)/XC70	2002	PSM	PSM	●	●	●	●	●	●	48, 60	
V70 XC(01-)/XC70	2002	SRS	SRS	●	●	●	●	●	○		
V70 XC(01-)/XC70	2001	Petrol	B5234T7	●	●	●	●	●	●	1, 50	Elec. Ident.
V70 XC(01-)/XC70	2001	Petrol	B5244T3	●	●	●	●	●	●	1, 50	Elec. Ident.
V70 XC(01-)/XC70	2001	AEM	AEM	●	●	●	●	●	●		
V70 XC(01-)/XC70	2001	AUM	AUM	●	●	●	●	○	○		
V70 XC(01-)/XC70	2001	CEM	CEM	●	●	●	●	●	●	27, 51, 40, 30, 32	Immobiliser(Live Data)
V70 XC(01-)/XC70	2001	DIM	DIM	●	●	●	●	●	●	33, 35, 53, 37	
V70 XC(01-)/XC70	2001	PHM	PHM	●	●	●	●	●	○		
V70 XC(01-)/XC70	2001	REM	REM	●	●	●	●	●	●		
V70 XC(01-)/XC70	2001	RTI	RTI	●	●	●	●	○	○		
V70 XC(01-)/XC70	2001	SWM	SWM	●	●	●	●	●	○		
V70 XC(01-)/XC70	2001	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24	
V70 XC(01-)/XC70	2001	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
V70 XC(01-)/XC70	2001	ABS/BCM	ABS/BCM	●	●	●	●	●	●		DSTC(Live Data); DSTC(Active Test)
V70 XC(01-)/XC70	2001	SAS	SAS	●	●	●	○	●	○		
V70 XC(01-)/XC70	2001	CCM	CCM	●	●	●	●	●	○	41, 56, 56, 58	
V70 XC(01-)/XC70	2001	DDM	DDM	●	●	●	●	●	●	47, 59	
V70 XC(01-)/XC70	2001	PDM	PDM	●	●	●	●	●	●	47, 59	
V70 XC(01-)/XC70	2001	PSM	PSM	●	●	●	●	●	●	48, 60	
V70 XC(01-)/XC70	2001	SRS	SRS	●	●	●	●	●	○		
V70(-00)	2000	Petrol	B5204T3	●	●	●	●	●	●	1, 50	Elec. Ident.
V70(-00)	2000	Petrol	B5204T4	●	●	●	●	●	●	1, 50	Elec. Ident.
V70(-00)	2000	Petrol	B5234T3	●	●	●	●	●	●	1, 50	Elec. Ident.
V70(-00)	2000	Petrol	B5234T7	●	●	●	●	●	●	1, 50	Elec. Ident.
V70(-00)	2000	Petrol	B5244S	●	●	●	○	●	●	88, 6, 89	Extend DTC; Elec. Ident.
V70(-00)	2000	Petrol	B5244S2	●	●	●	○	●	●	88, 6, 89	Extend DTC; Elec. Ident.
V70(-00)	2000	Petrol	B5244SG	●	●	●	○	●	○		Elec. Ident.
V70(-00)	2000	Petrol	B5244SG2	●	●	●	○	●	○		Elec. Ident.
V70(-00)	2000	Petrol	B5244T	●	●	●	●	●	●	1, 50	Elec. Ident.
V70(-00)	2000	Petrol	B5244T2	●	●	●	●	●	●	1, 50	Elec. Ident.
V70(-00)	2000	Diesel	D5252T MSA 15.8	●	○	○	○	●	●	91, 92	
V70(-00)	2000	Combined instrument	Combined instrument	●	●	●	○	●	●	72, 73, 37, 32	
V70(-00)	2000	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
V70(-00)	2000	RTI	RTI	●	●	●	○	●	●		

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
- This function is not supported.
- ▲ This function is the new feature in this version.
- ※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70(-00)	2000	TCM	AW42AWD	●	●	●	○	●	●	10, 11	
V70(-00)	2000	TCM	AW50/51AWD	●	●	●	○	●	●	10, 11	
V70(-00)	2000	TCM	AW50-42	●	●	●	○	●	●	10, 11	
V70(-00)	2000	TCM	AW55-50/51SN	●	●	●	○	●	●	10, 11	
V70(-00)	2000	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
V70(-00)	2000	CCM	CCM	●	●	●	○	●	○		
V70(-00)	2000	CPM	CPM	●	●	●	○	●	○		
V70(-00)	2000	Power seat module, left	Power seat module, left	●	●	●	○	●	●		
V70(-00)	2000	Power seat module, right	Power seat module,	●	●	●	○	●	●		
V70(-00)	2000	SRS	SRS	●	●	●	○	●	○		
V70(-00)	1999	Petrol	B5204T3	●	●	●	●	●	●	1, 50	Elec. Ident.
V70(-00)	1999	Petrol	B5204T4	●	●	●	●	●	●	1, 93	Elec. Ident.
V70(-00)	1999	Petrol	B5234T3	●	●	●	●	●	●	1, 93	Elec. Ident.
V70(-00)	1999	Petrol	B5234T7	●	●	●	●	●	●	1, 93	Elec. Ident.
V70(-00)	1999	Petrol	B5234T8	●	●	●	○	●	●	1, 93	Elec. Ident.
V70(-00)	1999	Petrol	B5254S DENSO	●	●	●	○	●	●	88, 6, 89	Extend DTC; Elec. Ident.
V70(-00)	1999	Petrol	B5254T	●	●	●	●	●	●	1, 93	Elec. Ident.
V70(-00)	1999	Diesel	D5252T MSA 15.7	●	●	●	○	●	●		
V70(-00)	1999	Diesel	D5252T MSA 15.8	●	○	○	○	●	●	91, 92	
V70(-00)	1999	Combined instrument	Combined instrument	●	●	●	○	●	●	72, 73, 37, 32	
V70(-00)	1999	Lock and alarm	Lock and alarm	●	●	●	○	●	●	80, 81, 40	
V70(-00)	1999	RTI	RTI	●	●	●	○	●	●		
V70(-00)	1999	TCM	AW42AWD	●	●	●	○	●	●		
V70(-00)	1999	TCM	AW50-42	●	●	●	○	●	●		
V70(-00)	1999	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
V70(-00)	1999	CCM	CCM	●	●	●	○	●	○		
V70(-00)	1999	CPM	CPM	●	●	●	○	●	○		
V70(-00)	1999	Power seat module, left	Power seat module, left	●	●	●	○	●	●		
V70(-00)	1999	Power seat module, right	Power seat module,	●	●	●	○	●	●		
V70(-00)	1999	SRS	SRS	●	●	●	○	●	○		
V70(00-)	2005	Petrol	B5204T5	●	●	●	●	●	●	2, 3, 4, 5	
V70(00-)	2005	Petrol	B5244S	●	●	●	●	●	●	88, 6	
V70(00-)	2005	Petrol	B5244S2	●	●	●	●	●	●		
V70(00-)	2005	Petrol	B5244SG	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70(00-)	2005	Petrol	B5244SG2	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC
V70(00-)	2005	Petrol	B5244T4	●	●	●	●	●	●	1, 2, 3, 4, 5	
V70(00-)	2005	Petrol	B5244T5	●	●	●	●	●	●	1, 2, 3, 4, 5, 6	
V70(00-)	2005	Petrol	B5254T2	●	●	●	●	●	●	1, 2, 3, 4, 5, 6	
V70(00-)	2005	Petrol	B5254T4	●	●	●	●	●	●	1, 2, 3, 4, 5, 6	
V70(00-)	2005	Diesel	D5244T	●	●	●	○	●	●	7	
V70(00-)	2005	Diesel	D5244T2	●	●	●	○	●	●	7	
V70(00-)	2005	Diesel	D5244T3	●	●	●	○	●	●	7	
V70(00-)	2005	AEM	AEM	●	●	●	●	●	●		
V70(00-)	2005	AUM	AUM	●	●	●	●	●	○		
V70(00-)	2005	CEM	CEM	●	●	●	●	●	●	27, 28, 150, 151, 29, 30, 31, 32	
V70(00-)	2005	DIM	DIM	●	●	●	●	●	●	33, 35, 36, 37	
V70(00-)	2005	PHM	PHM	●	●	●	●	●	○		
V70(00-)	2005	REM	REM	●	●	●	●	●	●	39, 40	
V70(00-)	2005	RTI	RTI	●	●	●	●	○	○		
V70(00-)	2005	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24, 25	
V70(00-)	2005	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
V70(00-)	2005	TCM	AW55-50/51SN	●	●	●	●	●	●	10, 11	
V70(00-)	2005	DEM	DEM	●	●	●	●	●	○		
V70(00-)	2005	DEM	DEM	●	●	●	●	●	○		
V70(00-)	2005	ABS/BCM	ABS/BCM	●	●	●	●	●	●	62, 63	
V70(00-)	2005	SAS	SAS	●	●	●	●	●	○		
V70(00-)	2005	SUM	SUM	●	●	●	●	●	○		
V70(00-)	2005	CCM	CCM	●	●	●	●	●	○	43, 44	
V70(00-)	2005	DDM	DDM	●	●	●	●	●	●	46, 47, 48	
V70(00-)	2005	PDM	PDM	●	●	●	●	●	●	46	
V70(00-)	2005	PSM	PSM	●	●	●	●	●	●	48	
V70(00-)	2005	SRS	SRS	●	●	●	●	●	○		
V70(00-)	2004	Petrol	B5204T5	●	●	●	●	●	●	1, 2, 3, 4, 50	
V70(00-)	2004	Petrol	B5234T3	●	●	●	●	●	●	1, 2, 3, 4, 50	
V70(00-)	2004	Petrol	B5234T7	●	●	●	●	●	●	1, 2, 3, 4, 50	
V70(00-)	2004	Petrol	B5244S	●	●	●	●	●	●	88, 6	
V70(00-)	2004	Petrol	B5244S2	●	●	●	●	●	●		
V70(00-)	2004	Petrol	B5244SG	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70(00-)	2004	Petrol	B5244SG2	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC
V70(00-)	2004	Petrol	B5254T2	●	●	●	●	●	●	1, 2, 3, 4, 50	
V70(00-)	2004	Petrol	B5254T4	●	●	●	●	●	●	1, 2, 3, 4, 5, 50	
V70(00-)	2004	Diesel	D5244T	●	●	●	○	●	●	7	
V70(00-)	2004	Diesel	D5244T2	●	●	●	○	●	●	7	
V70(00-)	2004	AEM	AEM	●	●	●	●	●	●		
V70(00-)	2004	AUM	AUM	●	●	●	●	●	○		
V70(00-)	2004	CEM	CEM	●	●	●	●	●	●	27, 51, 40, 30, 32	Immobiliser (Live Data)
V70(00-)	2004	DIM	DIM	●	●	●	●	●	●	33, 35, 53, 37	
V70(00-)	2004	PHM	PHM	●	●	●	●	●	○		
V70(00-)	2004	REM	REM	●	●	●	●	●	●	55	
V70(00-)	2004	RTI	RTI	●	●	●	●	○	○		
V70(00-)	2004	SWM	SWM	●	●	●	●	●	○		
V70(00-)	2004	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24	
V70(00-)	2004	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
V70(00-)	2004	TCM	AW55-50/51SN	●	●	●	●	●	●	10, 11	
V70(00-)	2004	ABS/BCM	ABS/BCM	●	●	●	●	●	●	62, 63	
V70(00-)	2004	SAS	SAS	●	●	●	○	●	○		
V70(00-)	2004	SUM	SUM	●	●	●	●	●	○		
V70(00-)	2004	CCM	CCM	●	●	●	●	●	○	41, 56, 56, 58	
V70(00-)	2004	DDM	DDM	●	●	●	●	●	●	46, 47, 48	
V70(00-)	2004	PDM	PDM	●	●	●	●	●	●	47, 59	
V70(00-)	2004	PSM	PSM	●	●	●	●	●	●	48, 60	
V70(00-)	2004	SRS	SRS	●	●	●	●	●	○		
V70(00-)	2004	DEM	DEM	●	●	●	○	●	○		
V70(00-)	2004	DEM	DEM	●	●	●	○	●	○		
V70(00-)	2003	Petrol	B5204T5	●	●	●	●	●	●	1, 2, 3, 4, 50	
V70(00-)	2003	Petrol	B5234T3	●	●	●	●	●	●	1, 2, 3, 4, 50	
V70(00-)	2003	Petrol	B5234T7	●	●	●	●	●	●	1, 2, 3, 4, 50	
V70(00-)	2003	Petrol	B5244S	●	●	●	●	●	●	88, 6	
V70(00-)	2003	Petrol	B5244S2	●	●	●	●	●	●		
V70(00-)	2003	Petrol	B5244SG	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70(00-)	2003	Petrol	B5244SG2	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC
V70(00-)	2003	Petrol	B5244T3	●	●	●	●	●	●	1, 2, 3, 4, 50	
V70(00-)	2003	Petrol	B5254T2	●	●	●	●	●	●	1, 2, 3, 4, 50	
V70(00-)	2003	Diesel	D5244T	●	●	●	○	●	●	7	
V70(00-)	2003	Diesel	D5244T2	●	●	●	○	●	●	7	
V70(00-)	2003	AEM	AEM	●	●	●	●	●	●		
V70(00-)	2003	AUM	AUM	●	●	●	●	●	○		
V70(00-)	2003	CEM	CEM	●	●	●	●	●	●	27, 51, 40, 30, 32	Immobiliser (Live Data)
V70(00-)	2003	DIM	DIM	●	●	●	●	●	●	33, 35, 53, 37	
V70(00-)	2003	PHM	PHM	●	●	●	●	●	○		
V70(00-)	2003	REM	REM	●	●	●	●	●	●	55	
V70(00-)	2003	RTI	RTI	●	●	●	●	○	○		
V70(00-)	2003	SWM	SWM	●	●	●	●	●	○		
V70(00-)	2003	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24	
V70(00-)	2003	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
V70(00-)	2003	TCM	AW55-50/51SN	●	●	●	●	●	●	10, 11	
V70(00-)	2003	ABS/BCM	ABS/BCM	●	●	●	●	●	●	62, 63	
V70(00-)	2003	SAS	SAS	●	●	●	○	●	○		
V70(00-)	2003	CCM	CCM	●	●	●	●	●	○	41, 56, 56, 58	
V70(00-)	2003	DDM	DDM	●	●	●	●	●	●	46, 47, 48	
V70(00-)	2003	PDM	PDM	●	●	●	●	●	●	47, 59	
V70(00-)	2003	PSM	PSM	●	●	●	●	●	●	48, 60	
V70(00-)	2003	SRS	SRS	●	●	●	●	●	○		
V70(00-)	2003	DEM	DEM	●	●	●	○	●	○		
V70(00-)	2002	Petrol	B5204T5	●	●	●	●	●	●	1, 2, 3, 50	
V70(00-)	2002	Petrol	B5234T3	●	●	●	●	●	●	1, 2, 3, 50	
V70(00-)	2002	Petrol	B5234T7	●	●	●	●	●	●	1, 2, 3, 4, 50	
V70(00-)	2002	Petrol	B5244S	●	●	●	●	●	●	88, 6, 89	Extend DTC; Elec. Ident. ; Block DTC
V70(00-)	2002	Petrol	B5244S2	●	●	●	●	●	●	6, 89	Extend DTC; Elec. Ident. ; Block DTC
V70(00-)	2002	Petrol	B5244SG	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70(00-)	2002	Petrol	B5244SG2	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC
V70(00-)	2002	Petrol	B5244T3	●	●	●	●	●	●	1, 2, 3, 50	
V70(00-)	2002	Diesel	D5244T	●	●	●	○	●	●	90, 7	
V70(00-)	2002	Diesel	D5244T2	●	●	●	○	●	●	90, 7	
V70(00-)	2002	AEM	AEM	●	●	●	●	●	●		
V70(00-)	2002	AUM	AUM	●	●	●	●	●	○		
V70(00-)	2002	CEM	CEM	●	●	●	●	●	●	27, 51, 40, 30, 32	Immobiliser (Live Data)
V70(00-)	2002	DIM	DIM	●	●	●	●	●	●	33, 35, 53, 37	
V70(00-)	2002	PHM	PHM	●	●	●	●	●	○		
V70(00-)	2002	REM	REM	●	●	●	●	●	●	55	
V70(00-)	2002	RTI	RTI	●	●	●	●	○	○		
V70(00-)	2002	SWM	SWM	●	●	●	●	●	○		
V70(00-)	2002	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24	
V70(00-)	2002	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
V70(00-)	2002	TCM	AW55-50/51SN	●	●	●	●	●	●	10, 11	
V70(00-)	2002	ABS/BCM	ABS/BCM	●	●	●	●	●	●	62, 63	
V70(00-)	2002	SAS	SAS	●	●	●	○	●	○		
V70(00-)	2002	CCM	CCM	●	●	●	●	●	○	41, 56, 56, 58	
V70(00-)	2002	DDM	DDM	●	●	●	●	●	●	59	
V70(00-)	2002	PDM	PDM	●	●	●	●	●	●	59	
V70(00-)	2002	PSM	PSM	●	●	●	●	●	●	48, 60	
V70(00-)	2002	SRS	SRS	●	●	●	●	●	○		
V70(00-)	2001	Petrol	B5204T5	●	●	●	●	●	●	1, 50	Elec. Ident.
V70(00-)	2001	Petrol	B5234T3	●	●	●	●	●	●	1, 50	Elec. Ident.
V70(00-)	2001	Petrol	B5234T7	●	●	●	●	●	●	1, 50	Elec. Ident.
V70(00-)	2001	Petrol	B5244S	●	●	●	●	●	●	88, 6, 89	Extend DTC; Elec. Ident. ; Block DTC
V70(00-)	2001	Petrol	B5244S2	●	●	●	●	●	●	6, 89	Extend DTC; Elec. Ident. ; Block DTC
V70(00-)	2001	Petrol	B5244SG	●	●	●	●	●	●	89	Extend DTC; Elec. Ident. ; Block DTC
V70(00-)	2001	Petrol	B5244T3	●	●	●	●	●	●	1, 50	Elec. Ident.
V70(00-)	2001	Diesel	D5244T	●	●	●	○	●	●	90, 7	

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
 - This function is not supported.
 - ▲ This function is the new feature in this version.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
- As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70(00-)	2001	Diesel	D5252T MSA 15.8	●	○	○	●	●	●	91, 92	
V70(00-)	2001	AEM	AEM	●	●	●	●	●	●		
V70(00-)	2001	AUM	AUM	●	●	●	●	●	○		
V70(00-)	2001	CEM	CEM	●	●	●	●	●	●	27, 51, 40, 30, 32	Immobiliser(Live Data)
V70(00-)	2001	DIM	DIM	●	●	●	●	●	●	33, 35, 53, 37	
V70(00-)	2001	PHM	PHM	●	●	●	●	●	○		
V70(00-)	2001	REM	REM	●	●	●	●	●	●		
V70(00-)	2001	RTI	RTI	●	●	●	●	○	○		
V70(00-)	2001	SWM	SWM	●	●	●	●	●	○		
V70(00-)	2001	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24	
V70(00-)	2001	TCM	AW50/51AWD	●	●	●	○	●	●	10, 11	
V70(00-)	2001	TCM	AW55-50/51SN	●	●	●	●	●	●	10, 11	
V70(00-)	2001	ABS/BCM	ABS/BCM	●	●	●	●	●	●		
V70(00-)	2001	SAS	SAS	●	●	●	○	●	○		
V70(00-)	2001	CCM	CCM	●	●	●	●	●	○	41, 56, 56, 58	
V70(00-)	2001	DDM	DDM	●	●	●	●	●	●	47, 59	
V70(00-)	2001	PDM	PDM	●	●	●	●	●	●	47, 59	
V70(00-)	2001	PSM	PSM	●	●	●	●	●	●	48, 60	
V70(00-)	2001	SRS	SRS	●	●	●	●	●	○		
V70(00-)	2000	Petrol	B5204T5	●	●	●	●	●	●	1, 50	Elec. Ident.
V70(00-)	2000	Petrol	B5234T3	●	●	●	●	●	●	1, 50	Elec. Ident.
V70(00-)	2000	Petrol	B5244T3	●	●	●	●	●	●	1, 50	Elec. Ident.
V70(00-)	2000	Diesel	D5252T MSA 15.8	●	○	○	●	●	●	91, 92	
V70(00-)	2000	AUM	AUM	●	●	●	●	●	○		
V70(00-)	2000	CEM	CEM	●	●	●	●	●	●	27, 21, 32	Immobiliser(Live Data)
V70(00-)	2000	DIM	DIM	●	●	●	●	●	●	33, 35, 53, 37	
V70(00-)	2000	PHM	PHM	●	●	●	●	○	○		
V70(00-)	2000	REM	REM	●	●	●	●	●	●		
V70(00-)	2000	RTI	RTI	●	●	●	●	○	○		
V70(00-)	2000	SWM	SWM	●	●	●	●	●	○		
V70(00-)	2000	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24	
V70(00-)	2000	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
V70(00-)	2000	TCM	AW55-50/51SN	●	●	●	●	●	●	10, 11	
V70(00-)	2000	ABS/BCM	ABS/BCM	●	●	●	●	●	●		DSTC(Live Data); DSTC(Active Test)
V70(00-)	2000	SAS	SAS	●	●	●	○	●	○		
V70(00-)	2000	CCM	CCM	●	●	●	●	●	○	41, 56, 56, 58	

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70(00-)	2000	DDM	DDM	●	●	●	●	●	●	47, 59	
V70(00-)	2000	PDM	PDM	●	●	●	●	●	●	47, 59	
V70(00-)	2000	PSM	PSM	●	●	●	●	●	●	48, 60	
V70(00-)	2000	SRS	SRS	●	●	●	●	●	○		
XC60	2009	DEM	TF-80SC AWD	●	●	●	●	●	●		
XC60	2009	DEM	M66 AWD	●	●	●	●	●	●		
XC60	2009	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
XC60	2009	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
XC60	2009	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
XC60	2009	SUM		●	●	●	●	●	●	10	
XC60	2009	PSM		●	●	●	●	●	●		
XC60	2009	AUU		●	●	●	●	●	○		
XC60	2009	DDM		●	●	●	●	●	●	12, 13	
XC60	2009	PDM		●	●	●	●	●	●	12, 13	
XC60	2009	PAM		●	●	●	●	●	○	14	
XC60	2009	KVM		●	●	●	●	●	○	16, 17	
XC60	2009	AUD		●	●	●	●	○	○		
XC60	2009	CPM		●	●	●	●	●	●		
XC60	2009	SUB		●	●	●	●	○	○		
XC60	2009	BCM		●	●	●	●	●	●	10	
XC60	2009	SAS		●	●	●	●	●	○		
XC60	2009	TRM		●	●	●	●	●	○		
XC60	2009	PBM		●	●	●	●	●	○	43	
XC60	2009	MMM		●	●	●	●	○	○		
XC60	2009	PHM		●	●	●	●	●	○		
XC60	2009	ECM	D5244T5	●	●	●	●	●	●		
XC60	2009	ECM	D5244T4	●	●	●	●	●	●		
XC60	2009	ECM	B6304T2	●	●	●	●	●	●	9	
XC60	2009	CVM		●	●	●	●	○	○		
XC60	2009	HCM		●	●	●	●	●	○	83	
XC60	2009	BPM		●	●	●	●	●	○		
XC60	2009	CEM		●	●	●	●	●	●	35, 39	
XC60	2009	CCM		●	●	●	●	●	●	28, 29, 30, 31, 32	
XC60	2009	ICM		●	●	●	●	●	●		
XC60	2009	POT		●	●	●	●	●	○		
XC60	2009	HLDF		●	●	●	●	●	○		
XC60	2009	IAM		●	●	●	●	○	○		
XC60	2009	DIM		●	●	●	●	●	○	47, 48, 49, 50, 51, 52	
XC60	2009	DABM		●	●	●	●	○	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC60	2009	RDAR		●	●	●	●	●	○		
XC60	2009	SRS		●	●	●	●	●	○	25, 26, 27	
XC60	2009	FSM		●	●	●	●	●	○		
XC60	2009	PAC		●	●	●	●	●	○		
XC70 (08-)	2009	DEM	TF-80SC AWD	●	●	●	●	●	●		
XC70 (08-)	2009	DEM	M66 AWD	●	●	●	●	●	●		
XC70 (08-)	2009	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
XC70 (08-)	2009	ECM	D5244T5	●	●	●	●	●	●	58, 59, 60, 61, 62, 63, 90, 6	
XC70 (08-)	2009	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
XC70 (08-)	2009	ECM	D5244T4	●	●	●	●	●	●	58, 59, 60, 61, 62, 63, 90, 6	
XC70 (08-)	2009	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
XC70 (08-)	2009	ECM	B6324S	●	●	●	●	●	●	9	
XC70 (08-)	2009	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
XC70 (08-)	2009	ECM	B6304T2	●	●	●	●	●	●	9	
XC70 (08-)	2009	POT		●	●	●	●	○	○		
XC70 (08-)	2009	SUM		●	●	●	●	●	●	10	
XC70 (08-)	2009	IAM		●	●	●	●	○	○		
XC70 (08-)	2009	PSM		●	●	●	●	●	●		
XC70 (08-)	2009	HLDF		●	●	●	●	●	○		
XC70 (08-)	2009	AUU		●	●	●	●	●	○		
XC70 (08-)	2009	DDM		●	●	●	●	●	●	12, 13	
XC70 (08-)	2009	PDM		●	●	●	●	●	●	12, 13	
XC70 (08-)	2009	PAM		●	●	●	●	●	○	14	
XC70 (08-)	2009	KVM		●	●	●	●	●	○	16, 17	
XC70 (08-)	2009	AUD		●	●	●	●	○	○		
XC70 (08-)	2009	CPM		●	●	●	●	●	●		
XC70 (08-)	2009	SUB		●	●	●	●	○	○		
XC70 (08-)	2009	HCM		●	●	●	●	●	○	23	
XC70 (08-)	2009	SRS		●	●	●	●	●	○	25, 26, 27	
XC70 (08-)	2009	BCM		●	●	●	●	●	●	10	
XC70 (08-)	2009	SAS		●	●	●	●	●	○		
XC70 (08-)	2009	CCM		●	●	●	●	●	●	28, 29, 30, 31, 32	
XC70 (08-)	2009	CEM		●	●	●	●	●	●	35, 39	
XC70 (08-)	2009	TRM		●	●	●	●	●	○		
XC70 (08-)	2009	PBM		●	●	●	●	●	○	43	
XC70 (08-)	2009	FSM		●	●	●	●	●	○		
XC70 (08-)	2009	DIM		●	●	●	●	●	○	47, 48, 49, 50, 51, 52	
XC70 (08-)	2009	PAC		●	●	●	●	●	○		
XC70 (08-)	2009	RDAR		●	●	●	●	○	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC70 (08-)	2009	MMM		●	●	●	●	○	○		
XC70 (08-)	2009	ICM		●	●	●	●	●	●		
XC70 (08-)	2009	BPM		●	●	●	●	●	○		
XC70 (08-)	2009	PHM		●	●	●	●	●	○		
XC70 (08-)	2008	DEM	TF-80SC AWD	●	●	●	●	●	●		
XC70 (08-)	2008	DEM	M66 AWD	●	●	●	●	●	●		
XC70 (08-)	2008	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
XC70 (08-)	2008	ECM	D5244T5	●	●	●	●	●	●	58, 59, 60, 61, 62, 63, 90, 6	
XC70 (08-)	2008	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
XC70 (08-)	2008	ECM	D5244T4	●	●	●	●	●	●	58, 59, 60, 61, 62, 63, 90, 6	
XC70 (08-)	2008	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 2, 3, 4, 5	
XC70 (08-)	2008	ECM	B6324S	●	●	●	●	●	●	9	
XC70 (08-)	2008	POT		●	●	●	●	○	○		
XC70 (08-)	2008	SUM		●	●	●	●	●	●	10	
XC70 (08-)	2008	IAM		●	●	●	●	○	○		
XC70 (08-)	2008	PSM		●	●	●	●	●	●		
XC70 (08-)	2008	RDAR		●	●	●	●	○	○		
XC70 (08-)	2008	HLDF		●	●	●	●	●	○		
XC70 (08-)	2008	AUU		●	●	●	●	●	○		
XC70 (08-)	2008	DDM		●	●	●	●	●	●	12, 13	
XC70 (08-)	2008	PDM		●	●	●	●	●	●	12, 13	
XC70 (08-)	2008	PAM		●	●	●	●	●	○	14	
XC70 (08-)	2008	KVM		●	●	●	●	●	○	16, 17	
XC70 (08-)	2008	AUD		●	●	●	●	○	○		
XC70 (08-)	2008	PHM		●	●	●	●	●	○		
XC70 (08-)	2008	CPM		●	●	●	●	●	●		
XC70 (08-)	2008	SUB		●	●	●	●	○	○		
XC70 (08-)	2008	HCM		●	●	●	●	●	○	23	
XC70 (08-)	2008	SRS		●	●	●	●	●	○	25, 26, 27	
XC70 (08-)	2008	BCM		●	●	●	●	●	●	80	
XC70 (08-)	2008	SAS		●	●	●	●	●	○		
XC70 (08-)	2008	CEM		●	●	●	●	●	●	35, 39	
XC70 (08-)	2008	DIM		●	●	●	●	●	○	47, 48, 49, 50, 51, 52	
XC70 (08-)	2008	CCM		●	●	●	●	●	●	28, 29, 30, 31, 32	
XC70 (08-)	2008	TRM		●	●	●	●	●	○		
XC70 (08-)	2008	PBM		●	●	●	●	●	○	43	
XC70 (08-)	2008	BPM		●	●	●	●	●	○		
XC70 (08-)	2008	MMM		●	●	●	●	○	○		
XC70 (08-)	2008	FSM		●	●	●	●	●	○		

● This function is supported. ▲ This function is the new feature in this version.
 ○ This function is not supported. ✖ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC70 (08-)	2008	ICM		●	●	●	●	●	●		
XC70 (08-)	2008	PAC		●	●	●	●	●	○		
XC90	2005	AEM	AEM	●	●	●	●	●	●		
XC90	2005	ATM	ATM	●	●	●	○	●	○		
XC90	2005	AUD	AUD	●	●	●	●	○	○		
XC90	2005	MP2	MP2	●	●	●	●	●	●		
XC90	2005	CEM	CEM	●	●	●	●	●	●	27, 28, 150, 151, 29, 30, 31, 32	Immobiliser (Live Data)
XC90	2005	DIM	DIM	●	●	●	●	●	●	33, 34, 35, 36, 37	
XC90	2005	ICM	ICM	●	●	●	●	●	●		
XC90	2005	MP1	MP1	●	●	●	●	●	●		
XC90	2005	MMM	MMM	●	●	●	●	○	○		
XC90	2005	PHM	PHM	●	●	●	●	●	○		
XC90	2005	REM	REM	●	●	●	●	●	●	39, 40	
XC90	2005	SAS	SAS	●	●	●	●	●	○		
XC90	2005	SAS	SAS	●	●	●	●	●	○		
XC90	2005	CCM	CCM	●	●	●	●	●	○	43, 44	
XC90	2005	DDM	DDM	●	●	●	●	●	●	46, 47, 48	
XC90	2005	PDM	PDM	●	●	●	●	●	●	46, 47	
XC90	2005	PSM	PSM	●	●	●	●	●	●	48	
XC90	2004	Petrol	B5254T2	●	●	●	●	●	●	1, 2, 3, 4, 50	
XC90	2004	Petrol	B6294T	●	●	●	●	●	●	1, 2, 3, 4, 50	
XC90	2004	Diesel	D5244T	●	●	●	○	●	●	7	
XC90	2004	AEM	AEM	●	●	●	●	●	●		
XC90	2004	ATM	ATM	●	●	●	○	●	○		
XC90	2004	AUD	AUD	●	●	●	●	○	○		
XC90	2004	MP2	MP2	●	●	●	●	●	●		
XC90	2004	CEM	CEM	●	●	●	●	●	●	27, 51, 40, 30, 32	Immobiliser (Live Data)
XC90	2004	DIM	DIM	●	●	●	●	●	●	33, 34, 35, 36, 37	
XC90	2004	ICM	ICM	●	●	●	●	●	●		
XC90	2004	MP1	MP1	●	●	●	●	●	●		
XC90	2004	MMM	MMM	●	●	●	●	○	○		
XC90	2004	PHM	PHM	●	●	●	●	○	○		
XC90	2004	REM	REM	●	●	●	●	●	●	55	
XC90	2004	SWM	SWM	●	●	●	●	●	○		
XC90	2004	SUB	SUB	●	●	●	●	○	○		
XC90	2004	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24	
XC90	2004	TCM	4T65AWD	●	●	●	●	●	●	10, 11	

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2004	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
XC90	2004	DEM	DEM	●	●	●	○	●	○		
XC90	2004	ABS/BCM	ABS/BCM	●	●	●	●	●	●	62, 63	
XC90	2004	SAS	SAS	●	●	●	○	●	○		
XC90	2004	CCM	CCM	●	●	●	●	●	○	41, 56, 56, 58	
XC90	2004	DDM	DDM	●	●	●	●	●	●	46, 47, 48	
XC90	2004	PDM	PDM	●	●	●	●	●	●	47, 59	
XC90	2004	PSM	PSM	●	●	●	●	●	●	48, 60	
XC90	2004	SRS	SRS	●	●	●	●	●	○		
XC90	2003	Petrol	B5254T2	●	●	●	●	●	●	1, 2, 3, 4, 50	
XC90	2003	Petrol	B6294T	●	●	●	●	●	●	1, 2, 3, 4, 50	
XC90	2003	Diesel	D5244T	●	●	●	○	●	●	7	
XC90	2003	AEM	AEM	●	●	●	●	●	●		
XC90	2003	ATM	ATM	●	●	●	○	●	○		
XC90	2003	AUD	AUD	●	●	●	●	○	○		
XC90	2003	MP2	MP2	●	●	●	●	●	●		
XC90	2003	CEM	CEM	●	●	●	●	●	●	27, 51, 40, 30, 32	Immobiliser (Live Data)
XC90	2003	DIM	DIM	●	●	●	●	●	●	33, 34, 35, 36, 37	
XC90	2003	ICM	ICM	●	●	●	●	●	●		
XC90	2003	MP1	MP1	●	●	●	●	●	●		
XC90	2003	MMM	MMM	●	●	●	●	○	○		
XC90	2003	PHM	PHM	●	●	●	●	●	○		
XC90	2003	REM	REM	●	●	●	●	●	●	55	
XC90	2003	SWM	SWM	●	●	●	●	●	○		
XC90	2003	SUB	SUB	●	●	●	●	○	○		
XC90	2003	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24	
XC90	2003	TCM	4T65AWD	●	●	●	●	●	●	10, 11	
XC90	2003	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
XC90	2003	ABS/BCM	ABS/BCM	●	●	●	●	●	●	62, 63	
XC90	2003	SAS	SAS	●	●	●	○	●	○		
XC90	2003	CCM	CCM	●	●	●	●	●	○	41, 56, 56, 58	
XC90	2003	DDM	DDM	●	●	●	●	●	●	46, 47, 48	
XC90	2003	PDM	PDM	●	●	●	●	●	●	47, 59	
XC90	2003	PSM	PSM	●	●	●	●	●	●	48, 60	
XC90	2003	SRS	SRS	●	●	●	●	●	○		
XC90	2003	DEM	DEM	●	●	●	○	●	○		
XC90	2009	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 3, 81, 84, 85	
XC90	2009	DEM	TF-80SC AWD	●	●	●	●	●	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2009	PDM		●	●	●	●	●	●	108	
XC90	2009	AEM		●	●	●	●	●	●		
XC90	2009	REM		●	●	●	●	●	●		
XC90	2009	CPM		●	○	○	○	●	○	111, 112	
XC90	2009	RDAR		●	●	●	●	●	○		
XC90	2009	AUD		●	●	●	●	○	○		
XC90	2009	PAC		●	○	○	○	○	○		
XC90	2009	AUU		●	●	●	●	●	○		
XC90	2009	CCM		●	●	●	●	●	○	30, 113, 114, 29, 32, 115	
XC90	2009	DIM		●	●	●	●	●	●	116, 117, 28, 46, 47, 118	
XC90	2009	UEM		●	●	●	●	●	●	119, 120, 128, 122, 123, 12	
XC90	2009	IAM		●	●	●	●	●	●		
XC90	2009	ICM		●	●	●	●	●	●		
XC90	2009	MMM		●	●	●	●	○	○		
XC90	2009	PHM		●	●	●	●	●	○		
XC90	2009	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 85	
XC90	2008	TCM	TF-80SC AWD	●	●	●	●	●	●	81, 82, 83, 84, 85	
XC90	2008	DEM	TF-80SC AWD	●	●	●	●	●	○		
XC90	2008	DEM	M66 AWD	●	●	●	●	●	○		
XC90	2008	BCM	D5244T5	●	●	●	●	●	●	86, 87	
XC90	2008	CEM	D5244T5	●	●	●	●	●	●	91, 92, 94, 95, 96	
XC90	2008	HCM	D5244T5	●	●	●	●	●	○		
XC90	2008	SAS	D5244T5	●	●	●	●	●	○		
XC90	2008	ECM	D5244T5	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
XC90	2008	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 3, 81, 84, 85	
XC90	2008	DEM	TF-80SC AWD	●	●	●	●	●	○		
XC90	2008	DEM	M66 AWD	●	●	●	●	●	○		
XC90	2008	BCM	D5244T4	●	●	●	●	●	●	86, 87	
XC90	2008	CEM	D5244T4	●	●	●	●	●	●	91, 92, 94, 95, 96	
XC90	2008	HCM	D5244T4	●	●	●	●	●	○		
XC90	2008	SAS	D5244T4	●	●	●	●	●	○		
XC90	2008	ECM	D5244T4	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
XC90	2008	TCM	TF-80SC AWD	●	●	●	●	●	●	81, 82, 83, 84, 85	
XC90	2008	DEM	TF-80SC AWD	●	●	●	●	●	●		
XC90	2008	BCM	B8444S	●	●	●	●	●	●	86, 87	
XC90	2008	ECM	B8444S	●	●	●	●	●	●		
XC90	2008	SAS	B8444S	●	●	●	●	●	○		
XC90	2008	CEM	B8444S	●	●	●	●	●	●	91, 92, 94, 95, 96	
XC90	2008	HCM	B8444S	●	●	●	●	●	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2008	DEM	TF-80SC AWD	●	●	●	●	●	●		
XC90	2008	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 3, 81, 84, 85	
XC90	2008	BCM	B6324S	●	●	●	●	●	●	86, 87	
XC90	2008	SAS	B6324S	●	●	●	●	●	○		
XC90	2008	CEM	B6324S	●	●	●	●	●	●	91, 92, 94, 95, 96	
XC90	2008	HCM	B6324S	●	●	●	●	●	○		
XC90	2008	ECM	B6324S	●	●	●	●	●	●	9	
XC90	2008	DEM	TF-80SC AWD	●	●	●	●	●	○		
XC90	2008	TCM	TF-80SC AWD	●	●	●	●	●	●	81, 82, 83, 84, 85	
XC90	2008	BCM	B5254T2	●	●	●	●	●	●	86, 87	
XC90	2008	CEM	B5254T2	●	●	●	●	●	●	91, 92, 94, 95, 96	
XC90	2008	HCM	B5254T2	●	●	●	●	●	○		
XC90	2008	SAS	B5254T2	●	●	●	●	●	○		
XC90	2008	ECM	B5254T2	●	●	●	●	●	●	74	
XC90	2008	GPS		●	●	●	●	●	○		
XC90	2008	SRS		●	●	●	●	●	○	95	
XC90	2008	PSM		●	●	●	●	●	●	107	
XC90	2008	DDM		●	●	●	●	●	●	107, 108	
XC90	2008	PDM		●	●	●	●	●	●	108	
XC90	2008	AEM		●	●	●	●	●	●		
XC90	2008	REM		●	●	●	●	●	●		
XC90	2008	CPM		●	○	○	○	●	○	111, 112	
XC90	2008	RDAR		●	●	●	●	●	○		
XC90	2008	IAM		●	●	●	●	●	●		
XC90	2008	AUD		●	●	●	●	○	○		
XC90	2008	PAC		●	○	○	○	○	○		
XC90	2008	AUU		●	●	●	●	●	○		
XC90	2008	PHM		●	●	●	●	●	○		
XC90	2008	CCM		●	●	●	●	●	○	30, 113, 114, 29, 32, 115	
XC90	2008	DIM		●	●	●	●	●	●	116, 117, 28, 46, 47, 118	
XC90	2008	UEM		●	●	●	●	●	●	119, 120, 128, 122, 123, 12	
XC90	2008	ICM		●	●	●	●	●	●		
XC90	2008	MMM		●	●	●	●	○	○		
XC90	2008	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 85	
XC90	2007	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 3, 81, 84, 85	
XC90	2007	DEM	TF-80SC AWD	●	●	●	●	●	○		
XC90	2007	DEM	M66 AWD	●	●	●	●	●	○		
XC90	2007	BCM	D5244T4	●	●	●	●	●	●	86, 87	
XC90	2007	CEM	D5244T4	●	●	●	●	●	●	91, 92, 94, 95, 96	

MaxiDas_Volvo_V5.60 Function List

NOTES:

- This function is supported.
 - This function is not supported.
 - ▲ This function is the new feature in this version.
 - ※ This function may be supported, which depends on the actual condition of the vehicle.
- As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2007	HCM	D5244T4	●	●	●	●	●	○		
XC90	2007	SAS	D5244T4	●	●	●	●	●	○		
XC90	2007	ECM	D5244T4	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
XC90	2007	TCM	TF-80SC AWD	●	●	●	●	●	●	81, 82, 83, 84, 85	
XC90	2007	DEM	TF-80SC AWD	●	●	●	●	●	●		
XC90	2007	BCM	B8444S	●	●	●	●	●	●	86, 87	
XC90	2007	SAS	B8444S	●	●	●	●	●	○		
XC90	2007	CEM	B8444S	●	●	●	●	●	●	91, 92, 94, 95, 96	
XC90	2007	HCM	B8444S	●	●	●	●	●	○		
XC90	2007	ECM	B8444S	●	●	●	●	●	●		
XC90	2007	DEM	TF-80SC AWD	●	●	●	●	●	●		
XC90	2007	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 3, 81, 84, 85	
XC90	2007	BCM	B6324S	●	●	●	●	●	●	86, 87	
XC90	2007	SAS	B6324S	●	●	●	●	●	○		
XC90	2007	CEM	B6324S	●	●	●	●	●	●	91, 92, 94, 95, 96	
XC90	2007	HCM	B6324S	●	●	●	●	●	○		
XC90	2007	ECM	B6324S	●	●	●	●	●	●	9	
XC90	2007	DEM	M66 AWD	●	●	●	●	●	○		
XC90	2007	TCM	AW55-50/51SN	●	●	●	●	●	●	100, 101, 102, 103, 125	
XC90	2007	DEM	AW50/51 AWD	●	●	●	●	●	○		
XC90	2007	TCM	TF-80SC AWD	●	●	●	●	●	●	81, 82, 83, 84, 85	
XC90	2007	BCM	B5254T2	●	●	●	●	●	●	86, 87	
XC90	2007	CEM	B5254T2	●	●	●	●	●	●	91, 92, 94, 95, 96	
XC90	2007	HCM	B5254T2	●	●	●	●	●	○		
XC90	2007	SAS	B5254T2	●	●	●	●	●	○		
XC90	2007	ECM	B5254T2	●	●	●	●	●	●	74	
XC90	2007	GPS		●	●	●	●	●	○		
XC90	2007	SRS		●	●	●	●	●	○	95	
XC90	2007	PSM		●	●	●	●	●	●	107	
XC90	2007	DDM		●	●	●	●	●	●	107, 108	
XC90	2007	PDM		●	●	●	●	●	●	108	
XC90	2007	AEM		●	●	●	●	●	●		
XC90	2007	PHM		●	●	●	●	●	○		
XC90	2007	REM		●	●	●	●	●	●		
XC90	2007	CPM		●	○	○	○	●	○	111, 112	
XC90	2007	RDAR		●	●	●	●	●	○		
XC90	2007	CCM		●	●	●	●	●	○	30, 113, 114, 29, 32, 115	
XC90	2007	IAM		●	●	●	●	●	●		
XC90	2007	AUD		●	●	●	●	○	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2007	PAC		●	○	○	○	○	○		
XC90	2007	MMM		●	●	●	●	○	○		
XC90	2007	AUU		●	●	●	●	●	○		
XC90	2007	DIM		●	●	●	●	●	●	116, 117, 28, 46, 47, 118	
XC90	2007	UEM		●	●	●	●	●	●	119, 120, 128, 122, 123, 12	
XC90	2007	ICM		●	●	●	●	●	●		
XC90	2007	TCM	TF-80SC	●	●	●	●	●	●	1, 2, 3, 4, 85	
XC90	2006	TCM	TF-80SC AWD	●	●	●	●	●	●	1, 3, 81, 84, 85	
XC90	2006	DEM	TF-80SC AWD	●	●	●	●	●	○		
XC90	2006	DEM	M66 AWD	●	●	●	●	●	○		
XC90	2006	BCM	D5244T4	●	●	●	●	●	●	86, 87	
XC90	2006	CEM	D5244T4	●	●	●	●	●	●	91, 92, 94, 95	
XC90	2006	SAS	D5244T4	●	●	●	●	●	○		
XC90	2006	ECM	D5244T4	●	●	●	●	●	●	58, 59, 89, 60, 61, 62, 63, 6	
XC90	2006	TCM	AW50/51 AWD	●	●	●	●	●	●	100, 101, 102, 103, 125	
XC90	2006	DEM	AW50/51 AWD	●	●	●	●	●	○		
XC90	2006	ECM	D5244T	●	●	●	●	●	●		
XC90	2006	BCM	D5244T	●	●	●	●	●	●	86, 87	
XC90	2006	CEM	D5244T	●	●	●	●	●	●	91, 92, 94, 95	
XC90	2006	SAS	D5244T	●	●	●	●	●	○		
XC90	2006	TCM	TF-80SC AWD	●	●	●	●	●	●	81, 82, 83, 84, 85	
XC90	2006	DEM	TF-80SC AWD	●	●	●	●	●	●		
XC90	2006	BCM	B8444S	●	●	●	●	●	●	86, 87	
XC90	2006	SAS	B8444S	●	●	●	●	●	○		
XC90	2006	CEM	B8444S	●	●	●	●	●	●	91, 92, 94, 95	
XC90	2006	ECM	B8444S	●	●	●	●	●	●		
XC90	2006	TCM	4T65 AWD	●	●	●	●	●	●	125, 102, 100, 103	
XC90	2006	DEM	4T65 AWD	●	●	●	●	●	○		
XC90	2006	BCM	B6294T	●	●	●	●	●	●	86, 87	
XC90	2006	ECM	B6294T	●	●	●	●	●	●	74	
XC90	2006	CEM	B6294T	●	●	●	●	●	●	91, 92, 94, 95	
XC90	2006	SAS	B6294T	●	●	●	●	●	○		
XC90	2006	DEM	M66 AWD	●	●	●	●	●	○		
XC90	2006	TCM	AW50/51 AWD	●	●	●	●	●	●	100, 101, 102, 103, 125	
XC90	2006	DEM	AW50/51 AWD	●	●	●	●	●	○		
XC90	2006	BCM	B5254T2	●	●	●	●	●	●	86, 87	
XC90	2006	CEM	B5254T2	●	●	●	●	●	●	91, 92, 94, 95	
XC90	2006	ECM	B5254T2	●	●	●	●	●	●	74	
XC90	2006	SAS	B5254T2	●	●	●	●	●	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
XC90	2006	MP1		●	●	●	●	●	●		
XC90	2006	MP2		●	●	●	●	●	●		
XC90	2006	ATM		●	●	●	●	●	●		
XC90	2006	REM		●	●	●	●	●	●		
XC90	2006	SRS		●	●	●	●	●	○	95	
XC90	2006	PSM		●	●	●	●	●	●	107	
XC90	2006	DDM		●	●	●	●	●	●	107, 108	
XC90	2006	PDM		●	●	●	●	●	●	108	
XC90	2006	AEM		●	●	●	●	●	●		
XC90	2006	AUD		●	●	●	●	○	○		
XC90	2006	ICM		●	●	●	●	●	●		
XC90	2006	PHM		●	●	●	●	●	○		
XC90	2006	DIM		●	●	●	●	●	●	116, 117, 28, 46, 47	
XC90	2006	CPM		●	○	○	○	●	○	111, 112	
XC90	2006	UEM		●	●	●	●	●	●	119, 120, 128, 122, 123, 12	
XC90	2006	CCM		●	●	●	●	●	○	30, 113, 114, 29, 32, 115	
XC90	2006	MMM		●	●	●	●	○	○		
XC90	2005	Petrol	B5254T2	●	●	●	●	●	●	1, 2, 3, 4, 5, 6	
XC90	2005	Petrol	B6294T	●	●	●	●	●	●	1, 2, 3, 4, 5, 6	
XC90	2005	Petrol	B8444S	●	●	●	○	●	●		
XC90	2005	Diesel	D5244T	●	●	●	○	●	●	7	
XC90	2005	TCM	4T65AWD	●	●	●	●	●	●	10, 11	
XC90	2005	TCM	AW50/51AWD	●	●	●	●	●	●	10, 11	
XC90	2005	DEM	DEM	●	●	●	●	●	○		
XC90	2005	TCM	TF-80SC AWD	●	●	●	●	●	●		
XC90	2005	ABS/BCM	ABS/BCM	●	●	●	●	●	●		
XC90	2005	SUB	SUB	●	●	●	●	○	○		
XC90	2005	SRS	SRS	●	●	●	●	●	○		
XC90	2005	UEM	UEM	●	●	●	●	●	●	21, 22, 23, 24, 25	
V90	1998	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
V90	1998	Immobilizer	IMM	●	●	●	○	●	○		
V90	1998	Petrol	ECM	●	●	●	○	●	○		
V90	1998	CI	CI	●	○	○	○	○	○	0 0001	
V90	1998	PSL	PSL	●	●	●	○	●	○		
V90	1998	PSR	PSR	●	●	●	○	●	●		
V90	1998	RTI	RTI	●	●	●	○	●	●		
V90	1998	SRS	SRS	●	●	●	○	●	○		
V90	1998	TCM	AW30-40	●	●	●	○	●	○		
V90	1997	ABS/BCM	ABS/BCM	●	●	●	○	●	●		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V90	1997	Immobilizer	IMM	●	●	●	○	●	○		
V90	1997	Petrol	ECM	●	●	●	○	●	○		
V90	1997	CI	CI	●	○	○	○	○	○	0 0001	
V90	1997	PSL	PSL	●	●	●	○	●	○		
V90	1997	PSR	PSR	●	●	●	○	●	●		
V90	1997	RTI	RTI	●	●	●	○	●	●		
V90	1997	SRS	SRS	●	●	●	○	●	○		
V90	1997	TCM	AW30-40	●	●	●	○	●	○		
V70(-00)	1998	ABS/BCM	ABS/BCM	●	●	●	○	●	○		
V70(-00)	1998	ECM	D5252T MSA 15.7	●	●	●	○	●	○		
V70(-00)	1998	Motronic 4.4	ECM	●	●	●	○	●	○		
V70(-00)	1998	Immobilizer	IMM	●	●	●	○	●	○		
V70(-00)	1998	CI	CI	●	●	●	○	●	○	0 0001	
V70(-00)	1998	VGLA	VGLA	●	●	●	○	○	○		
V70(-00)	1998	PSL	PSL	●	●	●	○	●	○		
V70(-00)	1998	PSR	PSR	●	●	●	○	●	●		
V70(-00)	1998	CPM	CPM	●	●	●	○	●	●		
V70(-00)	1998	RTI	RTI	●	●	●	○	●	●		
V70(-00)	1998	SRS	SRS	●	●	●	○	●	○		
V70(-00)	1998	TCM	AW42AWD	●	●	●	○	●	○		
V70(-00)	1997	ABS/BCM	ABS/BCM	●	●	●	○	●	○		
V70(-00)	1997	ECM	D5252T MSA 15.7	●	●	●	○	●	○		
V70(-00)	1997	Motronic 4.4	ECM	●	●	●	○	●	○		
V70(-00)	1997	Immobilizer	IMM	●	●	●	○	●	○		
V70(-00)	1997	CI	CI	●	●	●	○	●	○	0 0001	
V70(-00)	1997	VGLA	VGLA	●	●	●	○	○	○		
V70(-00)	1997	PSL	PSL	●	●	●	○	●	○		
V70(-00)	1997	PSR	PSR	●	●	●	○	●	●		
V70(-00)	1997	CPM	CPM	●	●	●	○	●	●		
V70(-00)	1997	RTI	RTI	●	●	●	○	●	●		
V70(-00)	1997	SRS	SRS	●	●	●	○	●	○		
V70(-00)	1997	TCM	AW42AWD	●	●	●	○	●	○		
V70 XC(-00)	1998	ABS/BCM	ABS/BCM	●	●	●	○	●	○		
V70 XC(-00)	1998	CI	CI	●	●	●	○	●	○	0 0001	
V70 XC(-00)	1998	VGLA	VGLA	●	●	●	○	○	○		
V70 XC(-00)	1998	PSL	PSL	●	●	●	○	●	○		
V70 XC(-00)	1998	PSR	PSR	●	●	●	○	●	●		
V70 XC(-00)	1998	Immobilizer	IMM	●	●	●	○	●	○		
V70 XC(-00)	1998	ECM	D5252T MSA 15.7	●	●	●	○	●	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
V70 XC(-00)	1998	RTI	RTI	●	●	●	○	●	●		
V70 XC(-00)	1998	SRS	SRS	●	●	●	○	●	○		
V70 XC(-00)	1998	TCM	AW42AWD	●	●	●	○	●	○		
V40	1998	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
V40	1998	CI	CI	●	●	●	○	●	●	0 0001	
V40	1998	Immobilizer	IMM	●	●	●	○	●	●		
V40	1998	VGLA	VGLA	●	●	●	○	●	●		
V40	1998	CPM	CPM	●	●	●	○	●	●		
V40	1998	DSA	DSA	●	●	●	○	●	●		
V40	1998	SRS	SRS	●	●	●	○	●	○		
V40	1998	TCM	AW50-42	●	●	●	○	●	○		
V40	1998	CCM	CCM	●	●	●	○	●	●		
V40	1998	RTI	RTI	●	●	●	○	●	●		
V40	1997	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
V40	1997	CI	CI	●	●	●	○	●	●	0 0001	
V40	1997	Immobilizer	IMM	●	●	●	○	●	●		
V40	1997	VGLA	VGLA	●	●	●	○	●	●		
V40	1997	CPM	CPM	●	●	●	○	●	●		
V40	1997	DSA	DSA	●	●	●	○	●	●		
V40	1997	SRS	SRS	●	●	●	○	●	○		
V40	1997	TCM	AW50-42	●	●	●	○	●	○		
V40	1997	CCM	CCM	●	●	●	○	●	●		
V40	1997	RTI	RTI	●	●	●	○	●	●		
V40	1996	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
V40	1996	CI	CI	●	●	●	○	●	●	0 0001	
V40	1996	Immobilizer	IMM	●	●	●	○	●	●		
V40	1996	VGLA	VGLA	●	●	●	○	●	●		
V40	1996	CPM	CPM	●	●	●	○	●	●		
V40	1996	DSA	DSA	●	●	●	○	●	●		
V40	1996	SRS	SRS	●	●	●	○	●	○		
V40	1996	TCM	AW50-42	●	●	●	○	●	○		
V40	1996	CCM	CCM	●	●	●	○	●	●		
V40	1996	RTI	RTI	●	●	●	○	●	●		
S90	1998	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
S90	1998	Immobilizer	IMM	●	●	●	○	●	○		
S90	1998	CI	CI	●	○	○	○	○	○	0 0001	
S90	1998	PSL	PSL	●	●	●	○	●	○		
S90	1998	PSR	PSR	●	●	●	○	●	●		
S90	1998	Engine 1	ECM	●	●	●	○	●	○		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S90	1998	SRS	SRS	●	●	●	○	●	○		
S90	1998	RTI	RTI	●	●	●	○	●	●		
S90	1998	TCM	AW30-43	●	●	●	○	●	○		
S90	1997	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
S90	1997	Immobilizer	IMM	●	●	●	○	●	○		
S90	1997	CI	CI	●	○	○	○	○	○	0 0001	
S90	1997	PSL	PSL	●	●	●	○	●	○		
S90	1997	PSR	PSR	●	●	●	○	●	○		
S90	1997	Engine 1	ECM	●	●	●	○	●	○		
S90	1997	SRS	SRS	●	●	●	○	●	○		
S90	1997	RTI	RTI	●	●	●	○	●	●		
S90	1997	TCM	AW30-43	●	●	●	○	●	○		
S70	1998	ABS/BCM	ABS/BCM	●	●	●	○	●	○		
S70	1998	Motronic 4.4	ECM	●	●	●	○	●	○		
S70	1998	ECM	D5252T MSA 15.7	●	●	●	○	●	○		
S70	1998	Engine 1	ECM	●	●	●	○	●	○		
S70	1998	Immobilizer	IMM	●	●	●	○	●	○		
S70	1998	CI	CI	●	○	○	○	○	○	0 0001	
S70	1998	VGLA	VGLA	●	●	●	○	○	○		
S70	1998	PSL	PSL	●	●	●	○	●	○		
S70	1998	PSR	PSR	●	●	●	○	●	○		
S70	1998	CPM	CPM	●	●	●	○	●	●		
S70	1998	RTI	RTI	●	●	●	○	●	●		
S70	1998	SRS	SRS	●	●	●	○	●	○		
S70	1998	TCM	AW50-42	●	●	●	○	●	○		
S70	1997	ABS/BCM	ABS/BCM	●	●	●	○	●	○		
S70	1997	Petrol	ECM	●	●	●	○	●	○		
S70	1997	Motronic 4.4	ECM	●	●	●	○	●	○		
S70	1997	ECM	D5252T MSA 15.7	●	●	●	○	●	○		
S70	1997	Immobilizer	IMM	●	●	●	○	●	○		
S70	1997	CI	CI	●	○	○	○	○	○	0 0001	
S70	1997	VGLA	VGLA	●	●	●	○	○	○		
S70	1997	PSL	PSL	●	●	●	○	●	○		
S70	1997	PSR	PSR	●	●	●	○	●	○		
S70	1997	CPM	CPM	●	●	●	○	●	●		
S70	1997	RTI	RTI	●	●	●	○	●	●		
S70	1997	SRS	SRS	●	●	●	○	●	○		
S70	1997	TCM	AW50-42	●	●	●	○	●	○		
S40(-04)	1998	ABS/BCM	ABS/BCM	●	●	●	○	●	●		

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
S40(-04)	1998	CI	CI	●	●	●	○	●	●	0 0001	
S40(-04)	1998	immobilizer	IMM	●	●	●	○	●	●		
S40(-04)	1998	VGLA	VGLA	●	●	●	○	●	●		
S40(-04)	1998	CPM	CPM	●	●	●	○	●	●		
S40(-04)	1998	DSA	DSA	●	●	●	○	●	●		
S40(-04)	1998	CCM	CCM	●	●	●	○	●	●		
S40(-04)	1998	RTI	RTI	●	●	●	○	●	●		
S40(-04)	1998	SRS	SRS	●	●	●	○	●	○		
S40(-04)	1998	TCM	AW50-42	●	●	●	○	●	○		
S40(-04)	1997	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
S40(-04)	1997	CI	CI	●	●	●	○	●	●	0 0001	
S40(-04)	1997	immobilizer	IMM	●	●	●	○	●	●		
S40(-04)	1997	VGLA	VGLA	●	●	●	○	●	●		
S40(-04)	1997	CPM	CPM	●	●	●	○	●	●		
S40(-04)	1997	DSA	DSA	●	●	●	○	●	●		
S40(-04)	1997	CCM	CCM	●	●	●	○	●	●		
S40(-04)	1997	RTI	RTI	●	●	●	○	●	●		
S40(-04)	1997	SRS	SRS	●	●	●	○	●	○		
S40(-04)	1997	TCM	AW50-42	●	●	●	○	●	○		
S40(-04)	1996	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
S40(-04)	1996	CI	CI	●	●	●	○	●	●	0 0001	
S40(-04)	1996	immobilizer	IMM	●	●	●	○	●	●		
S40(-04)	1996	VGLA	VGLA	●	●	●	○	●	●		
S40(-04)	1996	CPM	CPM	●	●	●	○	●	●		
S40(-04)	1996	DSA	DSA	●	●	●	○	●	●		
S40(-04)	1996	CCM	CCM	●	●	●	○	●	●		
S40(-04)	1996	RTI	RTI	●	●	●	○	●	●		
S40(-04)	1996	SRS	SRS	●	●	●	○	●	○		
S40(-04)	1996	TCM	AW50-42	●	●	●	○	●	○		
960	1997	Petrol	ECM	●	●	●	○	●	○		
960	1997	CI	CI	●	●	●	○	●	●	0 0001	
960	1997	immobilizer	IMM	●	●	●	○	●	○		
960	1997	PSL	PSL	●	●	●	○	●	○		
960	1997	PSR	PSR	●	●	●	○	●	○		
960	1997	TCM	AW30-43	●	●	●	○	●	○		
960	1997	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
960	1997	SRS	SRS	●	●	●	○	●	○		
960	1996	Petrol	ECM	●	●	●	○	●	○		
960	1996	CI	CI	●	●	●	○	●	●	0 0001	

MaxiDas_Volvo_V5.60 Function List

NOTES:

● This function is supported.

▲ This function is the new feature in this version.

○ This function is not supported.

※ This function may be supported, which depends on the actual condition of the vehicle.

As for special function please refer to the special function table.

Vehicle	Year	System	Type	ECU Info.	Read DTC	Clear DTC	Freeze Frame	Live Data	Active Test	Special Function	Other
960	1996	immobilizer	IMM	●	●	●	○	●	○		
960	1996	PSL	PSL	●	●	●	○	●	○		
960	1996	PSR	PSR	●	●	●	○	●	○		
960	1996	TCM	AW30-43	●	●	●	○	●	○		
960	1996	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
960	1996	SRS	SRS	●	●	●	○	●	○		
960	1995	Petrol	ECM	●	●	●	○	●	○		
960	1995	CI	CI	●	●	●	○	●	●	0 0001	
960	1995	immobilizer	IMM	●	●	●	○	●	○		
960	1995	PSL	PSL	●	●	●	○	●	○		
960	1995	PSR	PSR	●	●	●	○	●	○		
960	1995	TCM	AW30-43	●	●	●	○	●	○		
960	1995	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
960	1995	SRS	SRS	●	●	●	○	●	○		
850	1997	Motronic 4.4	ECM	●	●	●	○	●	●		
850	1997	CI	CI	●	●	●	○	●	●	0 0001	
850	1997	immobilizer	IMM	●	●	●	○	●	○		
850	1997	PSL	PSL	●	●	●	○	●	○		
850	1997	PSR	PSR	●	●	●	○	●	○		
850	1997	TCM	AW50-42	●	●	●	○	●	●		
850	1997	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
850	1997	SRS	SRS	●	●	●	○	●	○		
850	1996	CI	CI	●	●	●	○	●	●	0 0001	
850	1996	Immobilizer	IMM	●	●	●	○	●	○		
850	1996	PSL	PSL	●	●	●	○	●	○		
850	1996	PSR	PSR	●	●	●	○	●	○		
850	1996	Motronic 4.4	ECM	●	●	●	○	●	●		
850	1996	TCM	AW50-42	●	●	●	○	●	●		
850	1996	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
850	1996	SRS	SRS	●	●	●	○	●	○		
850	1995	CI	CI	●	●	●	○	●	●	0 0001	
850	1995	Immobilizer	IMM	●	●	●	○	●	○		
850	1995	PSL	PSL	●	●	●	○	●	○		
850	1995	PSR	PSR	●	●	●	○	●	○		
850	1995	Petrol	ECM	●	●	●	○	●	●		
850	1995	TCM	AW50-42	●	●	●	○	●	●		
850	1995	ABS/BCM	ABS/BCM	●	●	●	○	●	●		
850	1995	SRS	SRS	●	●	●	○	●	○		

Special Function

ID	year range	Description	ID	year range	Description
0_0001	<-2005	Resetting the service reminder lamp(SRL)	0_0007	2006->	Reading off IUMPR(USA/CDN)
1	<-2005	Readiness Code	8	2006->	Quick test of fuel tank system(USA/CDM)
2	<-2005	Adaptation of the throttle unit	9	2006->	Resetting the adaptation values
3	<-2005	Quick test of exhaust camshaft control	10	2006->	Calibration
4	<-2005	Quick test of intake camshaft control	11	2006->	Activation
5	<-2005	Quick test of the fuel pump (FP)	12	2006->	Initializing the window in the front door
6	<-2005	Quick test of the fuel tank system (USA/CDN)	13	2006->	Initializing the window in the rear door
7	<-2005	Programming optimizing parameters	14	2006->	Programming of Parking Assistance Module (PAM)
8	<-2005	Activating TEST MODE	15	2006->	Checking all antennas
9	<-2005	Control module adaption	16	2006->	Check the communication with the remote control receiver
10	<-2005	Reset adaptation to zero	17	2006->	Remote control
11	<-2005	Resetting the counter for-Gearbox oil change	18	2006->	Test of internal memory
12	<-2005	Resetting adaptation	19	2006->	Activation of quick-lock motors
13	<-2005	Calibration of gear position sensor	20	2006->	Quick test of function of the additional/parking heater
14	<-2005	Resetting the oil counter	21	2006->	Cooling of the cooling system
15	<-2005	Calibration the system	22	2006->	Activating components
16	<-2005	Calibrating the occupant weight sensor(OWS)	23	2006->	Calibration of position sensor
17	<-2005	Configuring the number of seats	24	2006->	Activation
18	<-2005	Storing the ID number for the occupant weight sensor (OWS)	25	2006->	Powering the SRS system
19	<-2005	Activating and reading off sun roof parameters	26	2006->	Calibrating the occupant weight sensor (OWS)
20	<-2005	Add or Remove remote controls	27	2006->	Checking the PAD-light
21	<-2005	Programming the control unit	28	2006->	Reading off programmed values
22	<-2005	Configuration of the siren	29	2006->	Programming the calimate control module (CCM)
23	<-2005	Replacing the control module	30	2006->	Calibrating the Climate Control Module (CCM)
24	<-2005	Reading the programmed values	31	2006->	Identifying components on the LIN network that belong to climate control
25	<-2005	Quick test of the tire pressure sensor	32	2006->	Reading out electronic damper motor, actual/preset range and tolerance limit
26	<-2005	Logging detailed diagnostic data	33	2006->	Programming the evaporator, climate control module (CCM)
27	<-2005	Reading data for vehicle configuration	34	2006->	Pre-delivery service for new car
28	<-2005	Programming the control module, central electronic module(CEM)	35	2006->	Workshop test (TPMS)
29	<-2005	Quick test of alternator fuction	36	2006->	Quick test of alternator funtion
30	<-2005	Resetting factory settings	37	2006->	Read-out and resetting alco-lock
31	<-2005	Resetting low voltage counters	38	2006->	Checking the control module before replacement
32	<-2005	Resetting car	39	2006->	Reading off alarm cause
33	<-2005	Testing all displays and lamps in instrument	40	2006->	Reading off power supply positon

Special Function

ID	year range	Description	ID	year range	Description
0_0001	<-2005	Resetting the service reminder lamp(SRL)	0_0007	2006->	Reading off IUMPR(USA/CDN)
34	<-2005	Programming the audible acknowledgement signal, seat belt	41	2006->	Check the brake light switch and brake pedal control switch adjustment
35	<-2005	Programming the driver information module(DIM)	42	2006->	Calibration angle sensor
36	<-2005	Reading off programmed values	43	2006->	Activation snd service
37	<-2005	Resetting the service reminder indicator(SRI)	44	2006->	Activating the internal test procedures
38	<-2005	Resetting the carphone code	45	2006->	Calibration of radar and camera
39	<-2005	Caibrating the position sensor for Bi-Xenon lamps	46	2006->	Programming the driver information module(DIM)
40	<-2005	Reading off the alarm cause	47	2006->	Resetting the service reminder indicator(SRI)
41	<-2005	Programming the climate control module (CCM)	48	2006->	Testing all indicator and lamp in the driver information module (DIM)
42	<-2005	Checking LIN bus	49	2006->	Read-out of fuel volume
43	<-2005	Reading off programmed parameters	50	2006->	Programming loudest audible signal, seat belt reminder
44	<-2005	Identifying the Damper Motor Module (DMM)	51	2006->	Programming seatbelt reminder in backseat
45	<-2005	Programming the additional and parking heater	52	2006->	Programming text message, seatbelt reminder
46	<-2005	Initializing the window position	53	2006->	Activation of installation image
47	<-2005	Programming soft stop	54	2006->	Programming control module
48	<-2005	Programming the remote control setting	55	2006->	Communication on MOST
49	<-2005	Checking current values	56	2006->	Open-circuit in the MOST cable
50	<-2005	Quick test of the fuel tank system	57	2006->	Reinstalling the reserve battery
51	<-2005	Programming the control module	58	2006->	Resetting counter particle filter
52	<-2005	Installing/removing key	59	2006->	Adaptation of differential pressure sensor particle filter
53	<-2005	Read-out of programmed values in driver information module	60	2006->	Adaptation of throttle module
54	<-2005	Reading off static data	61	2006->	Adaptation of swivel channel throttle
55	<-2005	Calibrating the Bi-Xenon lamp position sensor	62	2006->	Adaptation of mass airflow sensor
56	<-2005	Self-adjustment of damper motor end stops	63	2006->	Adaptation of turbo control motor
57	<-2005	Adjusting parameter, ECC	64	2006->	Adaptation of mass airflow sensor
58	<-2005	Read-out of programmed values in driver information module	65	2006->	Combustion of soot particles
59	<-2005	Window position set-up	66	2006->	Checking injectors
60	<-2005	programming the seat temperature	67	2006->	Quick-test injectors
61	<-2005	Calibration(DSTC)	68	2006->	Combustion of soot particles,particle trap
62	<-2005	Checking brake light switch adjustment	69	2006->	Adaptation of the exhaust gas recirculation (EGR) valve
63	<-2005	Calibration	70	2006->	Resetting the adaptation values
64	<-2005	Reading the user information	71	2006->	Programming the optimizing parameters
65	<-2005	Activating/deactivating Volvo on Call	72	2006->	Quick test of fuel tank system
66	<-2005	Volvo On Call service check	73	2006->	Readiness Code

Special Function

ID	year range	Description	ID	year range	Description
0_0001	<-2005	Resetting the service reminder lamp (SRL)	0_0007	2006->	Reading off IUMPR (USA/CDN)
67	<-2005	Reinstalling the spare battery	74	2006->	Adaptation of the throttle unit
68	<-2005	Calibrating the system	75	2006->	Quick test of exhaust camshaft control
69	<-2005	Add or Remove key	76	2006->	Quick test of intake camshaft control
70	<-2005	Resetting the SRL (Service Reminder Lamp) to zero	77	2006->	Quick test of the fuel pump (FP)
71	<-2005	Program functionality	78	2006->	Checking/adjusting ethanol content
72	<-2005	Programming combined instrument panel	79	2006->	Resetting the adaptation values
73	<-2005	Reading off programmed values in the combined instrument panel	80	2006->	Calibration
74	<-2005	Add/Erase keys	81	2006->	Resetting the counter for Transmission oil, change
75	<-2005	Erase the VIN code	82	2006->	Resetting adaptation
76	<-2005	Initiate immobilizer control module	83	2006->	Calibration of position sensor
77	<-2005	Programming lock type	84	2006->	Activation gear indication
78	<-2005	Programming new control module	85	2006->	Activation of adaption
79	<-2005	Programming remote control	86	2006->	Calibration (only vehicles with DSTC)
80	<-2005	Checking the number of remote controls	87	2006->	Checking brake light switch adjustment
81	<-2005	Reading off the programmed values	88	2006->	Quick-test of HCM
82	<-2005	Reading the static data	89	2006->	Resetting counter oil
83	<-2005	System test	90	2006->	Adaptation of fuel pressure control valve
84	<-2005	Programming the ECC control module	91	2006->	Programming control module
85	<-2005	Self-adjusting of shutter motor end position	92	2006->	Quick test of alternator function
86	<-2005	Updating the electronic climate control module (ECC)	93	2006->	Resetting factory settings
87	<-2005	Resetting "Transmission oil replacement" counter	94	2006->	Resetting low voltage counters
88	<-2005	Readiness Code (USA/CDN)	95	2006->	Resetting crash mode
89	<-2005	Reading off the diagnostic operating cycle	96	2006->	Programming of short flash sequence
90	<-2005	Programming fuel pump (FP) start diesel	97	2006->	Pre-delivery service for new car
91	<-2005	Programming the idle speed	98	2006->	Reading off the alarm cause
92	<-2005	Check and adjust dynamic pump setting	99	2006->	Testing the fuel pump (FP)
93	<-2005	Quick fuel tank system test	100	2006->	Activating TEST MODE
94	<-2005	IUMPR read out (USA/CDN)	101	2006->	Control module adaptation
95	<-2005	Testing the fuel pump (FP)	102	2006->	Resetting the adaptation
96	<-2005	Programming the optimizing parameters	103	2006->	Activating gear indication
97	<-2005	Adaptation of the exhaust gas recirculation (EGR) valve	104	2006->	Configuring the number of seats
98	<-2005	Combustion of soot particles	105	2006->	Storing the ID number for the occupant weight sensor (OWS)
99	<-2005	Resetting the odometer particle trap	106	2006->	Checking current values

Special Function

ID	year range	Description	ID	year range	Description
0_0001	<-2005	Resetting the service reminder lamp(SRL)	0_0007	2006->	Reading off IUMPR(USA/CDN)
100	<-2005	Resetting the adaptation values	107	2006->	Programming the remote control setting
101	<-2005	Reading off the configuration	108	2006->	Initiazing the window position
102	<-2005	Programming of global opening/closing of windows	109	2006->	Programming soft stop
103	<-2005	Testing all displays and lamps in the driver information module	110	2006->	Calibrating the position for Bi-Xenon lamps
104	<-2005	Indicates programmed values	111	2006->	Activating components and functions
105	<-2005	Programming the infotainment control module(ICM)	112	2006->	Programming the additional and parking heater
106	<-2005	Programming customer parameters	113	2006->	Identifying the Damper Motor Module (DMM)
107	<-2005	Calibration (cars with DSTC)	114	2006->	Reading off the programmed parameters in the climate control module (CCM)
108	<-2005	Calibration of the climate control module(CCM)	115	2006->	Compartment fan afterblow, status
109	<-2005	Programming remote control setting	116	2006->	Testing all needles and lamps in the dashboard
110	<-2005	Calibration of position sensor, GDL lamps	117	2006->	Programming the audible acknowledgement signal, seat belt reminder
111	<-2005	Calibration of position sensor	118	2006->	Display of DSTC message
112	<-2005	Resetting counter oil	119	2006->	Activating and reading off sun roof parameter
113	<-2005	Reading off VIN LEARNED	120	2006->	Programming the control module
114	<-2005	Programming a new control module	121	2006->	Configuring the number of siren
115	<-2005	Programming the cruise control	122	2006->	Replacing the control module
116	<-2005	Programming a new control unit	123	2006->	Reading the programmed values
117	<-2005	Positioning of accelerator pedal sensor	124	2006->	Read out the stored ID numbers for the tyre pressure sensors
118	<-2005	Continuous variable valve timing (CVVT) test	125	2006->	Resetting Gearbox fluid change counter
119	<-2005	Activating the DSA warning lamp	126	2006->	Programming optimising parameters
120	<-2005	Activating torque reduction	127	2006->	Activating/reading out components/functions
121	<-2005	Modify the settings in the combined instrument panel	128	2006->	Configuration of the siren
122	<-2005	Programming the outside temperature display	129	2006->	Activating/deactivating Volvo On Call
123	<-2005	Programming the trip computer function	130	2006->	Service check forVolvo On Call
124	<-2005	Programming a new combined instrument panel	131	2006->	Resetting the carphone code
125	<-2005	Resetting the mileage, new car	132	2006->	Reading the user information
126	<-2005	Resetting the service reminder lamp(SRL)	133	2006->	Calibrating the system
127	<-2005	Calibrating the control module	134	2006->	Checking the Four-C(Continuouslyly Controlled Chassis Concept)keypad unit
128	<-2005	Programming the alarm function	135	2006->	ETM test
129	<-2005	Programming the remote control function	136	2006->	Extended diagnostic trouble code (DTC)reading
130	<-2005	Resetting the Transmission fluid change counter	137	2006->	Reading off blocks of diagnostic trouble codes(DTCS)
131	<-2005	Resetting the adaptation	138	2006->	Reading off the diagnostic operating cycle
132	<-2005	Programming the climate control module	139	2006->	Extended fault-tracing for the diagnostic trouble code(DTC),Engine control module (ECM)

Special Function

ID	year range	Description	ID	year range	Description
0_0001	<-2005	Resetting the service reminder lamp(SRL)	0_0007	2006->	Reading off IUMPR(USA/CDN)
133	<-2005	Self-adjustment of damper motor end positions	140	2006->	Resetting the Transmission fluid change counter
134	<-2005	Idling speed adjustment	141	2006->	Resetting the odometer particle trap
135	<-2005	Positioning the throttle position sensor	142	2006->	Checking the additive level
136	<-2005	Activating self-adjustment	143	2006->	Refilling the feed hose with additive
137	<-2005	Updating the climate control module	144	2006->	Resetting the tank level gauge
138	<-2005	Updating the combined instrument panel for diesel engines	145	2006->	Programming remote control setting
139	<-2005	Reading cause of alarms	146	2006->	Reading off the configuration
140	<-2005	Programming and calibration	147	2006->	Read out of the number of programmed remote keys
150	<-2005	Installing low beam reduction US/CDN	148	2006->	Utlasning artikel/serienr RFR
151	<-2005	Programming the control module, central electronic module(CEM)	149	2006->	Initializing the window position
152	<-2005	Programming the combined instrument panel	150	2006->	Checking the window in the rear door
1	2006->	Resetting adaptation	151	2006->	Calibration (cars with DSTC)
2	2006->	resetting the "Transmission fluid change" counter	152	2006->	Programming the seat temperature
3	2006->	Calibration of gear position sensor	153	2006->	Reading out detected/expected control modules/sensors
4	2006->	Activating gear indication	154	2006->	Calibration of position sensor, GDL lamps
5	2006->	Control module adaptation	155	2006->	Programming of global opening/closing of windows
6	2006->	Readiness Code(USA/CDN)	156	2006->	Programming of rear window wiper when reversing
166	2006->	Programming the infotainment control module (ICM)	157	2006->	Setting clock deviation
167	2006->	Programming other settings	158	2006->	Ignition switch key position
168	2006->	Programming the clock	159	2006->	Read-out of part number remotes receiver and siren
169	2006->	Adaption reset,control valve inlet(throttle)	160	2006->	Position sensor xenon lamp
170	2006->	Calibration of position sensor	161	2006->	Resetting the service reminder indicator (SRI)
171	2006->	Calibrating the position sensor for Bi-Xenon lamps	162	2006->	Reading off and programming vehicle mode
172	2006->	Finding the predefined service position	164	2006->	Resetting counter by-passing alcolock
173	2006->	Unlocking catches	165	2006->	Indicates programmed values
174	2006->	Calibration of position sensor	176	2006->	Restart the Convertible Roof Module (CRM)
175	2006->	Loading assistance adjustment	177	2006->	Reading off diagnostic data
178	2006->	Initializing the front seat position			